Pioneer sound.vision.soul

Service Manual

ORDER NO.
RRV3119

EFFECTOR
EFX-500-R

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	EFX-500-R		
KUC	○	AC120V	——
RL	○	AC110–120V/AC220– 240V	With the voltage selector
WY	○	AC220– 240V	——

● This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
EFX-500/KUC	RRV2082	

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2005

T – ZZR MAR. 2005 Printed in Japan

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES:
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)*
- *Reference Nos. indicate the pages and Nos. in the service manual for the base model.*

■ CONTRAST TABLE

EFX-500-R/KUC and EFX-500/KUC are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			EFX-500 /KUC	EFX-500-R /KUC	
		PACKING			
P3- 10		Packing Case (KUC)	DHG1873	DHG2544	
		EXTERIOR (1/2) SECTION			
P5- 22	NSP	Chassis (KUC)	DNK3603	DNK4483	
P5- 32		65 Label	ARW7050	Not used	
		EXTERIOR (2/2) SECTION			
P7- 21		TAP Plate	DNK3608	DNK4482	
P7- 26		Control Panel	DNK3650	DNK4481	
P7- 40		Tap Knob	DAC1899	DAC2268	

EFX-500-R/RL and EFX-500/RL are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			EFX-500 /RL	EFX-500-R /RL	
		PACKING			
P3- 10		Packing Case (RL)	DHG1872	DHG2546	
		IEC65-6 CAUTION	Not used	ARM7067	For Packing
		EXTERIOR (1/2) SECTION			
P5- 22	NSP	Chassis (RL)	DNK3605	DNK4485	
		EXTERIOR (2/2) SECTION			
P7- 21		TAP Plate	DNK3608	DNK4482	
P7- 26		Control Panel	DNK3650	DNK4481	
P7- 40		Tap Knob	DAC1899	DAC2268	

■ CONTRAST TABLE

EFX-500-R/WY and EFX-500/WY are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			EFX-500 /WY	EFX-500-R /WY	
		PACKING			
P3- 10		Packing Case (WY)	DHG1870	DHG2545	
		EXTERIOR (1/2) SECTION			
P5- 22	NSP	Chassis (WY)	DNK3599	DNK4484	
		EXTERIOR (2/2) SECTION			
P7- 21		TAP Plate	DNK3608	DNK4482	
P7- 26		Control Panel	DNK3650	DNK4481	
P7- 40		Tap Knob	DAC1899	DAC2268	

■ EXPLODED VIEWS

● EXTERIOR (2/2) SECTION

