1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
● *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
● *When ordering resistors, first convert resistance values into code form as shown in the following examples.*

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47 k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω → 56 × 10^1 → 561 ····· RD1/4PU 5 6 1 J
47 kΩ → 47 × 10^3 → 473 ····· RD1/4PU 4 7 3 J
0.5 Ω → R50 ····· RN2H R 5 0 K
1 Ω → 1R0 ····· RS1P 1 R 0 K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 kΩ → 562 × 10^1 → 5621 ····· RN1/4PC 5 6 2 1 F

CONTRAST TABLE

CDJ-2000NXS2/SYXJ, CDJ-2000NXS2-W/UXJ and YXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-2000NXS2 /SYXJ	CDJ-2000NXS2-W /UXJ	CDJ-2000NXS2-W /YXJ	Remarks
		PACKING SECTION				
⚠	P72-1	Power Cord	ADG1244	DDG1108	ADG1244	
	P72-6	Operating Instructions (Quick Start Guide) (En, Fr, De, It, Nl, Es, Pt, Ru)	DRH1322	Not used	DRH1322	
	P72-7	Operating Instructions (Quick Start Guide)(En)	Not used	DRH1321	Not used	
	P72-14	Packing Case	DHG3438	DHG3587	DHG3586	
NSP	P72-16	Warranty	DRY1270	Not used	DRY1270	
		Leaflet	DRM1426	Not used	DRM1426	
NSP		Other Card	Not used	DRM1413	Not used	
NSP		Label	Not used	DRW2737	Not used	No.1
		Label/IM1	Not used	Not used	DRW2534	No.2
		EXTERIOR SECTION				
⚠	P74-31	Chassis	DNK6500	DNK6742	DNK6742	
	P74-47	Panel	DAH3052	DAH3175	DAH3175	
NSP		Plate	Not used	DAM1094	DAM1093	No.3
		CONTROL PANEL SECTION				
	P76-12	Panel	DAH3051	DAH3176	DAH3176	
	P76-33	Slide Sheet 1C (Sheet)	DAH2404	DAH3193	DAH3193	
	P76-54	Knob/SLD	DNK5981	DNK6188	DNK6188	
⚠	P76-60	Control Panel	DNK6494	DNK6736	DNK6736	
		JOG DIAL SECTION				
	P78-5	Jog Plate (Plate/JOG)	DAH2679	DAH2898	DAH2898	
	P78-12	Jog B (JOG Dial/B)	DNK4068	DNK6135	DNK6135	
		DISPLAY SECTION				
	P80-4	Dial Knob (Knob)	DAA1246	DAA1365	DAA1365	
	P80-6	Button	DAC3113	DAC3353	DAC3353	
	P80-10	Button	DAC3117	DAC3354	DAC3354	
	P80-11	Button	DAC3118	DAC3355	DAC3355	
	P80-13	Panel	DAH3043	DAH3187	DAH3187	
	P80-14	Panel	DAH3044	DAH3188	DAH3188	
⚠	P80-23	Control Panel	DNK6465	DNK6735	DNK6735	