A : N09-6108-15
B : N09-6426-15+
C : N09-6735-05
D : N09-6737-15
E : N09-6738-15
F : N19-2335-14
G : N35-2003-48
H : N39-1720-48





Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

* New parts
Parts without **Parts No**. are not supplied.
Les articles non mentionnes dans le **Parts No**. ne sont pas fournis.
Teile ohne **Parts No**. werden nicht geliefert.

Ref.No.	Add	New	Parts No.	Description	Destination
KDC-MP642U/X693/X993/ X7013U/X7013UL/XBT8013U/XBT8013UL					
202	1C		A02-2757-13	PLASTIC CABINET ASSY	M1M2M3
202	1C		A02-2757-13	PLASTIC CABINET ASSY	M4
203	2C	*	A22-3218-02	SUB PANEL ASSY	
205	3D	*	A40-1365-02	BOTTOM PLATE	
206	2C	*	A46-1890-01	REAR COVER	
207	1D	*	A52-1111-01	TOP COVER	
PA1	3C	*	A64-4776-01	PANEL ASSY	K
PA1	3C	*	A64-4778-01	PANEL ASSY	K2
PA1	3C	*	A64-4779-01	PANEL ASSY	K3
PA1	3C	*	A64-4780-01	PANEL ASSY	M1M3
PA1	3C	*	A64-4781-01	PANEL ASSY	M2M4
RC1	1C		A70-2085-15	REMOTE CONTROLLER ASSY (RC-547)	
-		*	B64-4416-00	INST. MANUAL (ENGLISH)	KK2K3
-		*	B64-4417-00	INST. MANUAL (FRE.SPA.)	KK2K3
-		*	B64-4418-00	INST. MANUAL (ENGLISH)	M1M2M3
-		*	B64-4418-00	INST. MANUAL (ENGLISH)	M4
-		*	B64-4419-00	INST. MANUAL (T-CHI.)	M1M2
-		*	B64-4471-00	INST. MANUAL (ARABIC)	M3M4
211	1C		B07-3235-03	ESCUTCHEON (POLISH)	KK2M1
211	1C		B07-3235-03	ESCUTCHEON (POLISH)	M2M3M4
211	1C	*	B07-3304-03	ESCUTCHEON	K3
214	3C	*	B07-3287-03	ESCUTCHEON (KNOB)	
216	2D	*	B11-2027-04	REFLECTION SHEET (LCD)	
217	3C	*	B11-2028-04	OPTICAL DIFFUSER (LCD)	
218	3C	*	B19-2532-02	LIGHTING BOARD	
220	2C	*	B19-2535-03	LIGHTING BOARD (LCD)	
222	3C		B43-1518-04	BADGE	
ED1	3C	*	B38-1213-05	LCD (240*64DOTS)	
224	2C		D10-4730-03	LEVER (LOCK)	
225	2C		D10-4731-03	LEVER (PUSH)	
226	1C		D10-7049-04	LEVER (ACCESSORY)	
227	2C		D39-0255-05	DAMPER	
228	2D	*	E29-2136-04	LEAD PLATE	
230	2D	*	E30-6905-05	CORD WITH CONNECTOR (USB)	
232	2D	*	E30-6907-05	CORD WITH CONNECTOR (MIC)	KM1M3
⚠ DC1	1C		E30-6428-05	DC CORD	
FC1	2D		E39-1055-05	FLAT CABLE (MECHA)	
239	2D	*	F11-1870-23	SHIELDING COVER (MECHA)	
241	1C		F19-1475-04	COVER (USB KIT)	KK2
245	2D		F29-0637-04	INSULATING COVER (USB CAP)	
⚠ F1	3D		F52-0023-05	FUSE (MINI BLADE TYPE) (10A)	
247	2C		G01-3171-04	TORSION COIL SPRING (LOCK)	
248	2C		G01-3172-04	TORSION COIL SPRING (PUSH)	
249	2C		G01-3173-04	COMPRESSION SPRING (REAR COVER)	
250	3C		G01-3203-04	COMPRESSION SPRING (REL)	
-		*	H54-4584-03	ITEM CARTON CASE	K
-		*	H54-4586-03	ITEM CARTON CASE	K2
-		*	H54-4587-03	ITEM CARTON CASE	K3
-		*	H54-4588-03	ITEM CARTON CASE	M1
-		*	H54-4589-03	ITEM CARTON CASE	M2
-		*	H54-4644-03	ITEM CARTON CASE	M3
-		*	H54-4645-03	ITEM CARTON CASE	M4
258	2C		J19-5203-03	HOLDER (LEFT)	
259	2D		J19-5204-03	HOLDER (RIGHT)	
260	2C		J19-5205-03	HOLDER (REAR COVER)	
261	2C	*	J19-7252-03	HOLDER (LCD)	
262	2D		J21-9977-03	MOUNTING HARDWARE (DUMPER)	
264	1C		J22-0789-03	MOUNTING HARDWARE ASSY	
266	3C	*	K24-4991-03	PUSH KNOB (SEARCH)	KK2M
266	3C	*	K24-4991-03	PUSH KNOB (SEARCH)	M2M3
266	3C	*	K24-4992-03	PUSH KNOB (SEARCH)	K3
268	2C	*	K24-4995-03	PUSH KNOB (EJECT)	
269	3C	*	K24-4996-03	PUSH KNOB (RELEASE)	
273	3C	*	K28-0363-04	KNOB ASSY (VOL)	K3
273	3C	*	K28-0381-04	KNOB ASSY (VOL)	KK2M
273	3C	*	K28-0381-04	KNOB ASSY (VOL)	M2M3
276	3C	*	K28-0371-04	KNOB ASSY (FM/AM)	K3
276	3C	*	K28-0383-04	KNOB ASSY (FM/AM)	KK2M
276	3C	*	K28-0383-04	KNOB ASSY (FM/AM)	M2M3
280	1C		N99-1730-35	SCREW SET (DISPLAY)	
281	1C		N99-1757-15	SCREW SET	
282	1C		N99-1790-05	SCREW SET	KK2
A	3D		N09-6358-05	TAPTITE SCREW (BT)	KM1M
B	3D		N09-6758-05	TAPTITE SCREW (X34)	
C	3C		N80-2006-48	PAN HEAD TAPTITE SCREW	
D	2C		N80-2008-43	PAN HEAD TAPTITE SCREW	
E	2C		N84-2005-43	PAN HEAD TAPTITE SCREW	
F	2D		N84-2005-48	PAN HEAD TAPTITE SCREW	
G	2C		N84-2606-43	PAN HEAD TAPTITE SCREW	
H	1D		N86-2604-43	BINDING HEAD TAPTITE SCREW	
J	1D		N86-2606-48	BINDING HEAD TAPTITE SCREW	
283	1C		W01-1664-05	CARRYING CASE (EXCELON)	KK2
283	1C		W01-1710-05	CARRYING CASE	K3
284	1C		W01-1718-05	MICROPHONE (3m)	KM1M
285	1C		W01-1723-15	COMPACT DISC	
286	3D	*	W02-5339-15	ELECTRIC CIRCUIT MODULE (BT)	KM1M
DME1	1D	*	X92-6360-02	MECHANISM ASSY (DXM-9B32W)	

DISPLAY UNIT (X15-1220-10)

D1			B30-1779-05	LED (1608,SR)	
CN1			E41-2984-05	PIN ASSY	
J1			E58-1008-05	RECTANGULAR RECEPTACLE	
R1			RK73EB2E432J	CHIP R 4.3K J 1/4W	
R2			RK73EB2E000J	CHIP R 0.0 J 1/4W	
R3 ,4			RK73EB2E432J	CHIP R 4.3K J 1/4W	
R5 -8			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R9 ,10			RK73EB2E432J	CHIP R 4.3K J 1/4W	
R11			RK73FB2B331J	CHIP R 330 J 1/8W	
S1			S70-0901-05	TACT SWITCH	
S2			S70-0948-05	TACT SWITCH	

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

Ref.No.	Add	New	Parts No.	Description	Destination
SWITCH UNIT (X16-65xx-xx)					
D1			B30-1566-05	LED (1608,RED)	
D2			B30-1780-05	LED (1608,PG)	KK2
D3 -10			B30-1781-05	LED (1608,BLUE)	K3
D21 -24			B30-1798-05	LED (RGB MPX A,B,C,D)	KK2M1
D21 -24			B30-1798-05	LED (RGB MPX A,B,C,D)	M2M3M4
D93 ,94		*	B30-3211-05	LED	K3
D107			B30-1784-05	LED (RGB SIDE)	KK2M1
D107			B30-1784-05	LED (RGB SIDE)	M2M3M4
D110			B30-1784-05	LED (RGB SIDE)	KK2M1
D110			B30-1784-05	LED (RGB SIDE)	M2M3M4
C66			CK73FB1C105K	CHIP C 1.0UF K	
C76 ,77			CK73GB1H103K	CHIP C 0.010UF K	
C85			CK73GB1H104K	CHIP C 0.10UF K	
C86 ,87			CK73GB1H103K	CHIP C 0.010UF K	
C92 -95			CK73GB1C225K	CHIP C 2.2UF K	
C96			CK73GB1A105K	CHIP C 1.0UF K	
C97			CK73GB1H104K	CHIP C 0.10UF K	
C98			CK73GB1A105K	CHIP C 1.0UF K	
CN1		*	E41-3094-05	FLAT CABLE CONNECTOR	
J1			E59-0850-05	RECTANGULAR PLUG	
X1			L78-0872-05	RESONATOR (12MHZ)	
CP1 ,2			RK74HB1J472J	CHIP-COM 4.7K J 1/16W	
CP12			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP15			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
CP16			RK74HB1J392J	CHIP-COM 3.9K J 1/16W	
CP17			RK74HB1J331J	CHIP-COM 330 J 1/16W	
CP18			RK74HB1J473J	CHIP-COM 47K J 1/16W	
R1			RK73GB2A331J	CHIP R 330 J 1/10W	
R3 ,4			RK73GB2A471J	CHIP R 470 J 1/10W	K3
R7 ,8			RK73GB2A471J	CHIP R 470 J 1/10W	K3
R21			RK73EB2E151J	CHIP R 150 J 1/4W	KK2M1
R21			RK73EB2E151J	CHIP R 150 J 1/4W	M2M3M4
R22			RK73EB2E301J	CHIP R 300 J 1/4W	KK2M1
R22			RK73EB2E301J	CHIP R 300 J 1/4W	M2M3M4
R23			RK73EB2E161J	CHIP R 160 J 1/4W	KK2M1
R23			RK73EB2E161J	CHIP R 160 J 1/4W	M2M3M4
R24			RK73EB2E151J	CHIP R 150 J 1/4W	KK2M1
R24			RK73EB2E151J	CHIP R 150 J 1/4W	M2M3M4
R25			RK73EB2E301J	CHIP R 300 J 1/4W	KK2M1
R25			RK73EB2E301J	CHIP R 300 J 1/4W	M2M3M4
R26			RK73EB2E161J	CHIP R 160 J 1/4W	KK2M1
R26			RK73EB2E161J	CHIP R 160 J 1/4W	M2M3M4
R67			RK73GB2A101J	CHIP R 100 J 1/10W	
R68			RK73GB2A473J	CHIP R 47K J 1/10W	
R69			RK73GB2A101J	CHIP R 100 J 1/10W	
R70			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R71			RK73GB2A473J	CHIP R 47K J 1/10W	
R74			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R76			RK73GB2A103J	CHIP R 10K J 1/10W	
R79 ,80			RK73GB2A473J	CHIP R 47K J 1/10W	
R83			RK73GB2A106J	CHIP R 10M J 1/10W	
R86			RK73GB2A473J	CHIP R 47K J 1/10W	KK2M
R86			RK73GB2A473J	CHIP R 47K J 1/10W	M2M3
R87			RK73GB2A473J	CHIP R 47K J 1/10W	K3
R90 -94			RK73GB2A202J	CHIP R 2.0K J 1/10W	
R95 -99			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R115			RK73EB2E181J	CHIP R 180 J 1/4W	KK2M
R115			RK73EB2E181J	CHIP R 180 J 1/4W	M2M3
R116			RK73EB2E361J	CHIP R 360 J 1/4W	KK2M
R116			RK73EB2E361J	CHIP R 360 J 1/4W	M2M3
R117			RK73EB2E181J	CHIP R 180 J 1/4W	K3
R117			RK73EB2E561J	CHIP R 560 J 1/4W	KK2M
R117			RK73EB2E561J	CHIP R 560 J 1/4W	M2M3
R139			RK73GB2A473J	CHIP R 47K J 1/10W	
R140			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	
S1			T99-0456-15	ROTARY ENCODER	
S2 -4			S70-0901-05	TACT SWITCH	
S6			S70-0901-05	TACT SWITCH	
S8			S70-0951-05	TACT SWITCH	
D40		*	LVS10C270S030	VARISTOR	
D92		*	LVS10C270S030	VARISTOR	
IC1		*	30626MHPB97GP	MICROCONTROLLER IC	K3KK2
IC1		*	30626MJPA26GP	MICROCONTROLLER IC	M3M4
IC1		*	30626MJPA28GP	MICROCONTROLLER IC	M1M2
IC3			PIC95603	ANALOGUE IC	
IC7			S-1112B32MCG	ANALOGUE IC	
Q1			KRC406-P	DIGITAL TRANSISTOR	K3M1
Q1			KRC406-P	DIGITAL TRANSISTOR	M3M4
Q1 -8			KRC406-P	DIGITAL TRANSISTOR	KK2
Q3 -8			KRC406-P	DIGITAL TRANSISTOR	M1M2
Q3 -8			KRC406-P	DIGITAL TRANSISTOR	M4
Q8 ,9			KRC406-P	DIGITAL TRANSISTOR	K3
Q27 -29			KRC406-P	DIGITAL TRANSISTOR	KK2M
Q27 -29			KRC406-P	DIGITAL TRANSISTOR	M2M3
Q41			KRC406-P	DIGITAL TRANSISTOR	K3
CD PLAYER UNIT (X32-6260-00) IN CD MECHA					
C1 ,2			CK73GB1A105K	CHIP C 1.0UF K	
C3			CK73GB1A474K	CHIP C 0.47UF K	
C4 -7			CK73GB1A105K	CHIP C 1.0UF K	
C9			CK73GB1C104K	CHIP C 0.10UF K	
C11			CK73GB1H153K	CHIP C 0.015UF K	
C12			CK73GB1H103K	CHIP C 0.010UF K	
C21			CK73GB1H103K	CHIP C 0.010UF K	
C22			CC73GCH1H220J	CHIP C 22PF J	
C23			CC73GCH1H180J	CHIP C 18PF J	
C24 ,25			CK73GB1H103K	CHIP C 0.010UF K	
C26			CK73FB0J106K	CHIP C 10UF K	
C27			CK73GB1A105K	CHIP C 1.0UF K	
C28			CK73GB1H103K	CHIP C 0.010UF K	
C29			CK73FB0J106K	CHIP C 10UF K	
C30 -33			CK73GB1H103K	CHIP C 0.010UF K	
C34 ,35			CC73GCH1H150J	CHIP C 15PF J	
C36			CK73GB1H103K	CHIP C 0.010UF K	
C37			CK73GB1A105K	CHIP C 1.0UF K	
C38			CK73GB1H103K	CHIP C 0.010UF K	

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

CD PLAYER UNIT (X32-6260-00) IN CD MECHA

Ref.No.	Add	New	Parts No.	Description	Destination
C51			CK73GB1C104K	CHIP C 0.10UF K	
C52			CK73GB1H222K	CHIP C 2200PF K	
C53			CK73FB1C105K	CHIP C 1.0UF K	
C54			CK73GB1H103K	CHIP C 0.010UF K	
C55			CK73GB1H332K	CHIP C 3300PF K	
C56			CK73GB1C104K	CHIP C 0.10UF K	
C57			CK73GB1H153K	CHIP C 0.015UF K	
C58			CK73GB1C104K	CHIP C 0.10UF K	
C59			CC73GCH1H680J	CHIP C 68PF J	
C61			CK73GB1C104K	CHIP C 0.10UF K	
C62			CK73FB0J106K	CHIP C 10UF K	
C63			CK73GB1H333K	CHIP C 0.033UF K	
C64			CK73GB1H472K	CHIP C 4700PF K	
C65			CK73GB1C104K	CHIP C 0.10UF K	
C66			CK73GB1H153K	CHIP C 0.015UF K	
C67			CK73GB1H103K	CHIP C 0.010UF K	
C68			CK73GB1C104K	CHIP C 0.10UF K	
C69			CK73FB0J106K	CHIP C 10UF K	
C71			CK73FB0J106K	CHIP C 10UF K	
C73 ,74			CK73GB1H102K	CHIP C 1000PF K	
C75 -77			CK73GB1C104K	CHIP C 0.10UF K	
C78			CK73GB1A105K	CHIP C 1.0UF K	
C79 -81			CK73GB1C104K	CHIP C 0.10UF K	
C83			CC73GCH1H470J	CHIP C 47PF J	
C84			CK73GB1H153K	CHIP C 0.015UF K	
C85			CK73GB1A105K	CHIP C 1.0UF K	
C86			CK73GB1H103K	CHIP C 0.010UF K	
C92			CK73FB1A225K	CHIP C 2.2UF K	
C93			CC73GCH1H101J	CHIP C 100PF J	
C94			CC73GCH1H560J	CHIP C 56PF J	
C101,102			CK73GB1H103K	CHIP C 0.010UF K	
C113			CK73GB1C104K	CHIP C 0.10UF K	
C114			CK73GB1H103K	CHIP C 0.010UF K	
CN1			E41-2954-05	FLAT CABLE CONNECTOR	
CN2			E41-2083-15	FLAT CABLE CONNECTOR	
X1			L77-2964-05	CRYSTAL RESONATOR (9.00MHZ)	
X2			L77-2921-15	CRYSTAL RESONATOR (32.768KHZ)	
X3			L78-1221-05	RESONATOR (16.93MHZ)	
CP10			RK74GA1J101J	CHIP-COM 100 J 1/16W	
CP11,12			RK74GB1J101J	CHIP-COM 100 J 1/16W	
CP15			RK74GB1J103J	CHIP-COM 10K J 1/16W	
CP22			RK74GB1J103J	CHIP-COM 10K J 1/16W	
CP32			RK74GA1J101J	CHIP-COM 100 J 1/16W	
R1 ,2			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R3			RK73GB2A202J	CHIP R 2.0K J 1/10W	
R4			RK73GB2A103J	CHIP R 10K J 1/10W	
R10			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R19			RK73GB2A223J	CHIP R 22K J 1/10W	
R21			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R23			RK73GB2A223J	CHIP R 22K J 1/10W	
R24			RK73GB2A101J	CHIP R 100 J 1/10W	
R25			RK73GB2A104J	CHIP R 100K J 1/10W	
R26			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	

Ref.No.	Add	New	Parts No.	Description	Destination
R27			RK73GB2A101J	CHIP R 100 J 1/10W	
R28 ,29			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R30			RK73GB2A223J	CHIP R 22K J 1/10W	
R31			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R33			RK73GB2A223J	CHIP R 22K J 1/10W	
R36			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R38			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R41			RK73GB2A223J	CHIP R 22K J 1/10W	
R44			RK73GB2A223J	CHIP R 22K J 1/10W	
R45			RK73GB2A101J	CHIP R 100 J 1/10W	
R47			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R48			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R49			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R50			RK73GB2A223J	CHIP R 22K J 1/10W	
R51			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R52			RK73GB2A100J	CHIP R 10 J 1/10W	
R53			RK73GB2A153J	CHIP R 15K J 1/10W	
R54			RK73GB2A100J	CHIP R 10 J 1/10W	
R55			RK73GB2A153J	CHIP R 15K J 1/10W	
R57			RK73GB2A223J	CHIP R 22K J 1/10W	
R58 ,59			RK73GB2A101J	CHIP R 100 J 1/10W	
R63			RK73GB2A223J	CHIP R 22K J 1/10W	
R65 ,66			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R67 -69			RK73GB2A101J	CHIP R 100 J 1/10W	
R70			RK73GB2A223J	CHIP R 22K J 1/10W	
R81 ,82			RK73GB2A101J	CHIP R 100 J 1/10W	
R84			RK73GB2A101J	CHIP R 100 J 1/10W	
R86			RK73GB2A101J	CHIP R 100 J 1/10W	
R88			RK73GB2A101J	CHIP R 100 J 1/10W	
R90 -94			RK73GB2A101J	CHIP R 100 J 1/10W	
R95 -98			RK73GB2A223J	CHIP R 22K J 1/10W	
R101			RK73GB2A221J	CHIP R 220 J 1/10W	
R102			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R103			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R104			RK73GB2A225J	CHIP R 2.2M J 1/10W	
R105			RK73GB2A104J	CHIP R 100K J 1/10W	
R106			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R107			RK73GB2A560J	CHIP R 56 J 1/10W	
R108			RK73GB2A333J	CHIP R 33K J 1/10W	
R109			RK73GB2A622J	CHIP R 6.2K J 1/10W	
R110			RK73GB2A913J	CHIP R 91K J 1/10W	
R112,113			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R115			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R116			RK73GB2A681J	CHIP R 680 J 1/10W	
R117-121			RK73GB2A103J	CHIP R 10K J 1/10W	
R123			RK73GB2A104J	CHIP R 100K J 1/10W	
R127			RK73GB2A153J	CHIP R 15K J 1/10W	
R128			RK73GB2A334J	CHIP R 330K J 1/10W	
R131			RK73GB2A204J	CHIP R 200K J 1/10W	
R132			RK73GB2A101J	CHIP R 100 J 1/10W	
R136			RK73GB2A363J	CHIP R 36K J 1/10W	
R137			RK73GB2A223J	CHIP R 22K J 1/10W	
R139			RK73GB2A393J	CHIP R 39K J 1/10W	
R151			RK73GB2A333J	CHIP R 33K J 1/10W	
R152			RK73GB2A223J	CHIP R 22K J 1/10W	

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

CD PLAYER UNIT (X32-6260-00) IN CD MECHA

Ref.No.	Add	New	Parts No.	Description	Destination
R173-178			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	
R180			RK73GB2A102J	CHIP R 1.0K J 1/10W	
S1 ,2			S68-0924-05	PUSH SWITCH	
D1			DAP202U	DIODE	
D2 ,3			DA204U	DIODE	
IC1			92CD28AFG7C32	MICROCONTROLLER IC	
IC2			TC94A92FG-301	MOS-IC	
IC3			BD8222EFV	ANALOGUE IC	
IC4			MFI341S2162	MICROPROCESSOR IC	
IC5			74AHCT08PW	MOS-IC	
IC6			74LVC08APW	MOS-IC	
IC7			XC6415S001P1	MOS-IC	
IC8			BR24L04FV-W	ROM IC	
IC9			XC6219B332MR	ANALOGUE IC	
Q3			RUE003N02	FET	
Q5			2SA1577	TRANSISTOR	
Q6			DTC114YUA	DIGITAL TRANSISTOR	
Q7			2SB0970	TRANSISTOR	
Q9			DTC114YUA	DIGITAL TRANSISTOR	

ELECTRIC UNIT (X34-631x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C1			CD04AZ1C332M2	ELECTRO 3300UF 16WV	K3M1M2
C1			CD04AZ1C332M2	ELECTRO 3300UF 16WV	M3M4
C1			C90-6784-05	ELECTRO 3900UF 16WV	KK2
C10 ,11			CK73GB1A105K	CHIP C 1.0UF K	
C13			CD04AY1A221M	ELECTRO 220UF 10WV	
C14			CK73GB1A105K	CHIP C 1.0UF K	
C21			C90-6851-05	ELECTRO 220UF 25WV	
C23			CD04BA1C100M	ELECTRO 10UF 16WV	
C24			CD04AJ1C101M	ELECTRO 100UF 16WV	
C31			CK73GB1H104K	CHIP C 0.10UF K	
C32			CD04AY1C220M	ELECTRO 22UF 16WV	KK2
C43			CD04AT1C100M	ELECTRO 10UF 16WV	
C55			CK73EB1H475K	CHIP C 4.7UF K	
C57			CK73GB1H104K	CHIP C 0.10UF K	
C61			CK73GB1H104K	CHIP C 0.10UF K	
C62			CC73GCH1H471J	CHIP C 470PF J	
C63			CK73GB1A474K	CHIP C 0.47UF K	
C64			CK73FB0J106K	CHIP C 10UF K	
C65			CK73GB1H102K	CHIP C 1000PF K	
C121			CK73GB1H103K	CHIP C 0.010UF K	
C141			CD04AS1H3R3M	ELECTRO 3.3UF 50WV	
C142			CK73GB1A105K	CHIP C 1.0UF K	
C143			CK73GB1H104K	CHIP C 0.10UF K	
C151			CK73GB1H103K	CHIP C 0.010UF K	
C152			CK73GB1H223K	CHIP C 0.022UF K	
C153			CK73GB1A105K	CHIP C 1.0UF K	
C201			CK73GB1A105K	CHIP C 1.0UF K	
C211,212			CK73GB1H104K	CHIP C 0.10UF K	
C213			CD04BF1C221M	ELECTRO 220UF 16WV	
C301,302			CC73GCH1H180J	CHIP C 18PF J	KK2
C303			CK73GB1H103K	CHIP C 0.010UF K	KK2
C307			CK73FB1A225K	CHIP C 2.2UF K	KK2
C308			CC73GCH1H271J	CHIP C 270PF J	KK2
C321-324			CK73GB1H103K	CHIP C 0.010UF K	
C351			CD04AS1C220M	ELECTRO 22UF 16WV	KK2M
C351			CD04AS1C220M	ELECTRO 22UF 16WV	M2M3
C352,353			CK73GB1H102K	CHIP C 1000PF K	KK2M
C352,353			CK73GB1H102K	CHIP C 1000PF K	M2M3
C354			CD04AS1V100M	ELECTRO 10UF 35WV	KK2M
C354			CD04AS1V100M	ELECTRO 10UF 35WV	M2M3
C370			CC73GCH1H120J	CHIP C 12PF J	
C372			CC73GCH1H120J	CHIP C 12PF J	
C373			CK73GB1H103K	CHIP C 0.010UF K	
C375-377			CK73GB1H103K	CHIP C 0.010UF K	
C378			CD04AS1V100M	ELECTRO 10UF 35WV	
C379			CK73GB0J225K	CHIP C 2.2UF K	
C381			CD04AS0J470M	ELECTRO 47UF 6.3WV	
C383-388			CK73GB1H222K	CHIP C 2200PF K	
C401,402			CD04AS1V100M	ELECTRO 10UF 35WV	
C405,406			CD04AS1V100M	ELECTRO 10UF 35WV	
C409,410			CD04AS1V100M	ELECTRO 10UF 35WV	
C421,422			CK73GB1A105K	CHIP C 1.0UF K	
C423			CD04AS0J470M	ELECTRO 47UF 6.3WV	
C431			CK73GB1A105K	CHIP C 1.0UF K	
C432			CD04AS0J470M	ELECTRO 47UF 6.3WV	
C433			CK73GB1A105K	CHIP C 1.0UF K	
C451-460			CK73GB1A105K	CHIP C 1.0UF K	
C461			CK73GB1H103K	CHIP C 0.010UF K	
C462			CD04AS1H2R2M	ELECTRO 2.2UF 50WV	
C463			CK73GB1A474K	CHIP C 0.47UF K	
C464			CK73GB1A105K	CHIP C 1.0UF K	
C465			CK73GB1A474K	CHIP C 0.47UF K	
C466			CK73GB1A105K	CHIP C 1.0UF K	
C467,468			CC73GCH1H100D	CHIP C 10PF D	
C469-471			CK73GB1A105K	CHIP C 1.0UF K	KK2
C469-472			CK73GB1A105K	CHIP C 1.0UF K	K3M1
C469-472			CK73GB1A105K	CHIP C 1.0UF K	M3M4
C473			CD04AS1H2R2M	ELECTRO 2.2UF 50WV	KK2
C474			CK73GB1A105K	CHIP C 1.0UF K	K3M1
C474			CK73GB1A105K	CHIP C 1.0UF K	M3M4
C475			CD04AS1H2R2M	ELECTRO 2.2UF 50WV	KK2
C476			CD04AS1C470M	ELECTRO 47UF 16WV	
C483			CC73GCH1H470J	CHIP C 47PF J	
C505			CK73GB1A105K	CHIP C 1.0UF K	
C506			C90-6765-05	ELECTRO 1UF 16WV	KK2
C508			CD04BA1C100M	ELECTRO 10UF 16WV	
C511-514			C90-6768-05	ELECTRO 0.22UF 16WV	KK2
C516			CK73GB1A105K	CHIP C 1.0UF K	
C517-520			CK73GB1C224K	CHIP C 0.22UF K	K3M1
C517-520			CK73GB1C224K	CHIP C 0.22UF K	M3M4
C521			CK73FB1C105K	CHIP C 1.0UF K	K3M1
C521			CK73FB1C105K	CHIP C 1.0UF K	M3M4
C601			CK73GB1H104K	CHIP C 0.10UF K	
C602			CK73GB1H103K	CHIP C 0.010UF K	
C603,604			CC73GCH1H180J	CHIP C 18PF J	
C605,606			CK73GB1H103K	CHIP C 0.010UF K	
C608-610			CK73GB1H103K	CHIP C 0.010UF K	
C611			CK73GB1H102K	CHIP C 1000PF K	

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-631x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C612-614			CK73GB1H103K	CHIP C 0.010UF K	
C615			CK73GB1H104K	CHIP C 0.10UF K	
C680,681			CK73GB1H104K	CHIP C 0.10UF K	KM1M3
C682			CK73GB1H103K	CHIP C 0.010UF K	
C902,903			CC73GCH1H100D	CHIP C 10PF D	KM1M3
C963			CK73GB1H104K	CHIP C 0.10UF K	KM1M3
C968			CK73GB1H104K	CHIP C 0.10UF K	KM1M3
C969-972			CK73GB1A105K	CHIP C 1.0UF K	KM1M3
C973,974			CC73GCH1H100D	CHIP C 10PF D	KM1M3
C975			CK73FB0J226M	CHIP C 22UF M	KM1M3
C976			CD04AS0J470M	ELECTRO 47UF 6.3WV	KM1M3
C981			CK73FB0J106K	CHIP C 10UF K	KM1M3
CN201			E41-1701-05	PIN ASSY	
CN680			E40-9747-05	PIN ASSY	
CN701			E41-2352-05	FLAT CABLE CONNECTOR	
CN901			E41-2956-05	SOCKET FOR PIN ASSY	KM1M3
CN902			E41-2957-05	SOCKET FOR PIN ASSY	KM1M3
CN962			E41-1699-05	PIN ASSY	KM1M3
⚠ J1			E58-0991-05	RECTANGULAR RECEPTACLE	
J401			E63-0960-05	PIN JACK (3-PRE)	
J421			E11-0625-05	PHONE JACK (LGY6502-0900)	
J431			E56-0855-05	CYLINDRICAL RECEPTACLE	
W321	2D		E30-6438-05	CORD WITH PLUG (ANT)	
WH151	2D		E30-6822-15	WIRING HARNESS (REMOTE)	
⚠ L1			L33-2365-05	CHOKE COIL ASSY	
L60			L92-0639-05	CHIP FERRITE (100MHZ)	
L61			L33-2453-05	SMALL FIXED INDUCTOR	
L600			L92-0378-05	CHIP FERRITE	
X301			L77-2002-05	CRYSTAL RESONATOR	KK2
X370			L77-3810-05	CRYSTAL RESONATOR (11.2896MHZ)	
X600			L78-0872-05	RESONATOR (12MHZ)	
X601			L77-2921-15	CRYSTAL RESONATOR (32.768KHZ)	
K	2D		N80-3008-48	PAN HEAD TAPTITE SCREW	
L	2D		N83-3005-48	PAN HEAD TAPTITE SCREW	
M	2D		N83-3008-48	PAN HEAD TAPTITE SCREW	
N	2D		N83-3016-48	PAN HEAD TAPTITE SCREW	
P	3D		N86-2604-43	BINDING HEAD TAPTITE SCREW	
CP300			RK74HB1J222J	CHIP-COM 2.2K J 1/16W	KK2
CP603			RK74GA1J101J	CHIP-COM 100 J 1/16W	
CP604			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP605			RK74GA1J101J	CHIP-COM 100 J 1/16W	KM1M3
CP607			RK74GA1J101J	CHIP-COM 100 J 1/16W	
CP609			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP613			RK74GA1J472J	CHIP-COM 4.7K J 1/16W	
R1 ,2			RK73EB2E103J	CHIP R 10K J 1/4W	
R11			RK73FB2B221J	CHIP R 220 J 1/8W	
R12			RK73GH2A243D	CHIP R 24K D 1/10W	
R13			RK73GH2A432D	CHIP R 4.3K D 1/10W	
R21			RK73FB2B123J	CHIP R 12K J 1/8W	
R31			RK73FB2B152J	CHIP R 1.5K J 1/8W	
R41			RK73FB2B102J	CHIP R 1.0K J 1/8W	
R61			RK73GH2A123D	CHIP R 12K D 1/10W	
R62			RK73GB2A153J	CHIP R 15K J 1/10W	

Ref.No.	Add	New	Parts No.	Description	Destination
R63			RK73GH2A153D	CHIP R 15K D 1/10W	
R64			RK73GH2A823D	CHIP R 82K D 1/10W	
R67			RK73GB2A473J	CHIP R 47K J 1/10W	
R68			RK73GB2A333J	CHIP R 33K J 1/10W	
R121			RK73FB2B203J	CHIP R 20K J 1/8W	
R122,123			RK73GB2A103J	CHIP R 10K J 1/10W	
R124			RK73FB2B683J	CHIP R 68K J 1/8W	
R125			RK73GB2A473J	CHIP R 47K J 1/10W	
R126			RK73GB2A104J	CHIP R 100K J 1/10W	
R127			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R128			RK73EB2E473J	CHIP R 47K J 1/4W	
R129			RK73GB2A183J	CHIP R 18K J 1/10W	
R134,135			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R141			RK73FB2B472J	CHIP R 4.7K J 1/8W	
R142			RK73PB2H561J	CHIP R 560 J 1/2W	
R143			RK73GB2A223J	CHIP R 22K J 1/10W	
R144			RK73PB2H561J	CHIP R 560 J 1/2W	
R145			RK73FB2B472J	CHIP R 4.7K J 1/8W	
R146,147			RK73PB2H221J	CHIP R 220 J 1/2W	
R148			RK73GB2A223J	CHIP R 22K J 1/10W	
R149,150			RK73PB2H561J	CHIP R 560 J 1/2W	
R151			RK73GB2A104J	CHIP R 100K J 1/10W	
R152			RK73GB2A473J	CHIP R 47K J 1/10W	
R153			RK73GB2A104J	CHIP R 100K J 1/10W	
R161			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R211			RK73GB2A101J	CHIP R 100 J 1/10W	
R213			RK73GB2A223J	CHIP R 22K J 1/10W	
R304			RK73GB2A102J	CHIP R 1.0K J 1/10W	KK2
R321			RK73GB2A223J	CHIP R 22K J 1/10W	
R322			RK73FB2B821J	CHIP R 820 J 1/8W	
R323,324			RK73GB2A471J	CHIP R 470 J 1/10W	
R353			RK73GB2A362J	CHIP R 3.6K J 1/10W	KK2M
R353			RK73GB2A362J	CHIP R 3.6K J 1/10W	M2M3
R354			RK73GB2A432J	CHIP R 4.3K J 1/10W	KK2M
R354			RK73GB2A432J	CHIP R 4.3K J 1/10W	M2M3
R355			RK73GB2A562J	CHIP R 5.6K J 1/10W	KK2M
R355			RK73GB2A562J	CHIP R 5.6K J 1/10W	M2M3
R356			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	KK2M
R356			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	M2M3
R357			RK73FB2B102J	CHIP R 1.0K J 1/8W	KK2M
R357			RK73FB2B102J	CHIP R 1.0K J 1/8W	M2M3
R370			RK73EB2E2R2J	CHIP R 2.2 J 1/4W	
R371			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R373-378			RK73GB2A471J	CHIP R 470 J 1/10W	
R401,402			RK73GB2A331J	CHIP R 330 J 1/10W	
R403,404			RK73GB2A223J	CHIP R 22K J 1/10W	
R405,406			RK73FB2B181J	CHIP R 180 J 1/8W	
R407,408			RK73GB2A331J	CHIP R 330 J 1/10W	
R409,410			RK73GB2A223J	CHIP R 22K J 1/10W	
R411,412			RK73FB2B181J	CHIP R 180 J 1/8W	
R413,414			RK73GB2A331J	CHIP R 330 J 1/10W	
R415,416			RK73GB2A223J	CHIP R 22K J 1/10W	
R417,418			RK73FB2B181J	CHIP R 180 J 1/8W	
R421,422			RK73EB2E101J	CHIP R 100 J 1/4W	
R423,424			RK73GB2A123J	CHIP R 12K J 1/10W	

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-631x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R425			RK73EB2E470J	CHIP R 47 J 1/4W	
R426			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R431-435			RK73EB2E432J	CHIP R 4.3K J 1/4W	
R436,437			RK73EB2E101J	CHIP R 100 J 1/4W	
R438			RK73EB2E470J	CHIP R 47 J 1/4W	
R439			RK73EB2E101J	CHIP R 100 J 1/4W	
R440			RK73EB2E432J	CHIP R 4.3K J 1/4W	
R441			RK73EB2E101J	CHIP R 100 J 1/4W	
R442			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R451			RK73GB2A000J	CHIP R 0.0 J 1/10W	K3
R452,453			RK73GB2A220J	CHIP R 22 J 1/10W	
R454			RK73GB2A103J	CHIP R 10K J 1/10W	
R455			RK73EB2E2R2J	CHIP R 2.2 J 1/4W	
R456			RK73GB2A100J	CHIP R 10 J 1/10W	
R462,463			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R464,465			RK73GB2A182J	CHIP R 1.8K J 1/10W	
R466			RK73GB2A683J	CHIP R 68K J 1/10W	
R467			RK73GB2A223J	CHIP R 22K J 1/10W	
R468			RK73GB2A103J	CHIP R 10K J 1/10W	
R469			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R501,502			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R505			RK73GB2A133J	CHIP R 13K J 1/10W	
R506			RK73GB2A473J	CHIP R 47K J 1/10W	
R507			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R508			RK73GB2A100J	CHIP R 10 J 1/10W	
R512			RK73GB2A473J	CHIP R 47K J 1/10W	
R514			RK73GB2A331J	CHIP R 330 J 1/10W	
R603,604			RK73GB2A473J	CHIP R 47K J 1/10W	
R606			RK73GB2A473J	CHIP R 47K J 1/10W	
R607			RK73GB2A103J	CHIP R 10K J 1/10W	
R608,609			RK73GB2A104J	CHIP R 100K J 1/10W	
R610,611			RK73GB2A473J	CHIP R 47K J 1/10W	
R613			RK73GB2A473J	CHIP R 47K J 1/10W	
R614			RK73GB2A101J	CHIP R 100 J 1/10W	
R615			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R616			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R617			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R618			RK73GB2A223J	CHIP R 22K J 1/10W	
R619			RK73GB2A103J	CHIP R 10K J 1/10W	
R620			RK73GB2A473J	CHIP R 47K J 1/10W	
R621			RK73GB2A101J	CHIP R 100 J 1/10W	
R622			RK73GB2A473J	CHIP R 47K J 1/10W	
R623			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R624			RK73GB2A104J	CHIP R 100K J 1/10W	
R625			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R626,627			RK73GB2A104J	CHIP R 100K J 1/10W	
R628			RK73GB2A473J	CHIP R 47K J 1/10W	M1M2M3
R628			RK73GB2A473J	CHIP R 47K J 1/10W	M4
R629			RK73GB2A223J	CHIP R 22K J 1/10W	KK2M1
R629			RK73GB2A223J	CHIP R 22K J 1/10W	M2
R629,630			RK73GB2A223J	CHIP R 22K J 1/10W	K3M3M4
R631			RK73GB2A223J	CHIP R 22K J 1/10W	KK2M1
R631			RK73GB2A223J	CHIP R 22K J 1/10W	M2
R632			RK73GB2A104J	CHIP R 100K J 1/10W	
R633,634			RK73GB2A471J	CHIP R 470 J 1/10W	

Ref.No.	Add	New	Parts No.	Description	Destination
R635,636			RK73GB2A104J	CHIP R 100K J 1/10W	
R638			RK73GB2A471J	CHIP R 470 J 1/10W	
R641			RK73GB2A473J	CHIP R 47K J 1/10W	
R642			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R643			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R645			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R646			RK73GB2A101J	CHIP R 100 J 1/10W	
R647			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R649			RK73GB2A104J	CHIP R 100K J 1/10W	
R650			RK73GB2A473J	CHIP R 47K J 1/10W	
R654			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R655			RK73GB2A101J	CHIP R 100 J 1/10W	
R657,658			RK73GB2A104J	CHIP R 100K J 1/10W	
R680			RK73GB2A471J	CHIP R 470 J 1/10W	
R681			RK73GB2A104J	CHIP R 100K J 1/10W	
R682			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R683			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R684			RK73GB2A223J	CHIP R 22K J 1/10W	
R686			RK73EB2E432J	CHIP R 4.3K J 1/4W	
R960			RK73GB2A472J	CHIP R 4.7K J 1/10W	KM1M
R961			RK73GB2A473J	CHIP R 47K J 1/10W	KM1M
R963,964			RK73GB2A331J	CHIP R 330 J 1/10W	KM1M
R965			RK73GB2A473J	CHIP R 47K J 1/10W	KM1M
R966,967			RK73GB2A101J	CHIP R 100 J 1/10W	KM1M
R969-972			RK73GB2A223J	CHIP R 22K J 1/10W	KM1M
R973-976			RK73GB2A104J	CHIP R 100K J 1/10W	KM1M
R979,980			RK73EB2E101J	CHIP R 100 J 1/4W	KM1M
R982			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	KM1M
R984,985			RK73GB2A183J	CHIP R 18K J 1/10W	KM1M
W304			R92-2053-05	CHIP R 0 OHM J 1/8W	
W350			R92-2053-05	CHIP R 0 OHM J 1/8W	K3
S680			S74-0809-05	MICRO SWITCH	
D1			S2V60-5009F46	DIODE	
D21			D1FJ4	DIODE	
D22			UDZW5.6(B)	ZENER DIODE	
D31			UDZW8.2(B)	ZENER DIODE	
D41			UDZW10(B)	ZENER DIODE	KK2M
D41			UDZW10(B)	ZENER DIODE	M2M3
D42			1SS355	DIODE	KK2M
D42			1SS355	DIODE	M2M3
D43			UDZW11(B)	ZENER DIODE	K3
D61			CMS14	DIODE	
D121			UDZW6.8(B)	ZENER DIODE	
D123			UDZW6.8(B)	ZENER DIODE	
D124			UDZW6.2(B)	ZENER DIODE	
D141,142			1SR154-400	DIODE	
D143			1SS355	DIODE	
D144,145			1SR154-400	DIODE	
D151			UDZW4.7(B)	ZENER DIODE	
D161			UDZW6.2(B)	ZENER DIODE	
D201,202		*	LVS10C270S030	VARISTOR	
D350			1SR154-400	DIODE	KK2M
D350			1SR154-400	DIODE	M2M3

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-631x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
D352			UDZW5.6(B)	ZENER DIODE	KK2M1
D352			UDZW5.6(B)	ZENER DIODE	M2M3M4
D401,402			DAP202U	DIODE	
D421-423			UDZW6.8(B)	ZENER DIODE	
D431-433			UDZW6.8(B)	ZENER DIODE	
D434			UDZW6.2(B)	ZENER DIODE	
D439			UDZW6.2(B)	ZENER DIODE	
D451-453			DAP202U	DIODE	
D456,457			DAP202U	DIODE	
D458			DA204U	DIODE	
D459			1SS355	DIODE	
D460-465			UDZW6.8(B)	ZENER DIODE	
D501			DAP202U	DIODE	
D504			1SR154-400	DIODE	
D508			1SR154-400	DIODE	
D682			UDZW6.2(B)	ZENER DIODE	
D684			UDZW6.2(B)	ZENER DIODE	
D691			DA204U	DIODE	
IC10			XC6201P502PR	ANALOGUE IC	
IC11			M5237ML-CF0J	ANALOGUE IC	
IC60			LT3685EMSE	ANALOGUE IC	
IC211			BD6538G	MOS-IC	
IC301			E-TDA7478AD	ANALOGUE IC	KK2
IC371			AK7600VF	MOS-IC	
IC451		*	E-TDA7716	ANALOGUE IC	
IC500			TB2923HQ	ANALOGUE IC	
IC600			XC6120N362N1	MOS-IC	
IC602		*	30626MHPC00GP	MICROCONTROLLER IC	KM1M3
IC602		*	30626MHPC02GP	MICROCONTROLLER IC	K2K3M2
IC602		*	30626MHPC02GP	MICROCONTROLLER IC	M4
IC603			M24C08-RDW6TP	ROM IC	K2K3M2
IC603			M24C08-RDW6TP	ROM IC	M4
IC603			M24C16-RDW6P	ROM IC	KM1M3
IC604			74HC2G02DP	MOS-IC	
IC680			74AHCT1G08GW	MOS-IC	KM1M3
IC681			74AHC1G08GW	MOS-IC	KM1M3
IC964			NJM4565V-ZB	ANALOGUE IC	KM1M3
IC965			SI-3033KMS	ANALOGUE IC	KM1M3
Q11			2SB1565	TRANSISTOR	
Q12			DTA124EUA	DIGITAL TRANSISTOR	
Q13			DTC124EUA	DIGITAL TRANSISTOR	
Q21			2SB1565	TRANSISTOR	
Q22			2SC4081	TRANSISTOR	
Q31			2SB1565	TRANSISTOR	
Q32			2SC4081	TRANSISTOR	
Q33			DTA124EUA	DIGITAL TRANSISTOR	
Q34			DTC124EUA	DIGITAL TRANSISTOR	
Q41			2SB1565	TRANSISTOR	
Q42			2SC4081	TRANSISTOR	
Q43			DTA124EUA	DIGITAL TRANSISTOR	
Q44			DTC124EUA	DIGITAL TRANSISTOR	
Q121-123			2SC4081	TRANSISTOR	
Q141			2SB1188(Q,R)	TRANSISTOR	
Q142			2SA1576A	TRANSISTOR	
Q143			DTA114EUA	DIGITAL TRANSISTOR	
Q144			DTC114YUA	DIGITAL TRANSISTOR	
Q145			2SB1188(Q,R)	TRANSISTOR	
Q146			DTC114YUA	DIGITAL TRANSISTOR	
Q151			DTC144EUA	DIGITAL TRANSISTOR	
Q321			2SA1577	TRANSISTOR	
Q322			KRC403-P	DIGITAL TRANSISTOR	
Q350			2SC4081	TRANSISTOR	KK2M
Q350			2SC4081	TRANSISTOR	M2M3
Q351			2SC5053	TRANSISTOR	KK2M
Q351			2SC5053	TRANSISTOR	M2M3
Q352			DTA124EUA	DIGITAL TRANSISTOR	KK2M
Q352			DTA124EUA	DIGITAL TRANSISTOR	M2M3
Q353			DTC124EUA	DIGITAL TRANSISTOR	KK2M
Q353			DTC124EUA	DIGITAL TRANSISTOR	M2M3
Q401-406			DTC143TUA	DIGITAL TRANSISTOR	
Q407,408			KRA303-P	DIGITAL TRANSISTOR	
Q451			2SC4081	TRANSISTOR	
Q680			KRC403-P	DIGITAL TRANSISTOR	KM1M
Q681			KRA307-P	DIGITAL TRANSISTOR	
Q682			KRC403-P	DIGITAL TRANSISTOR	
Q683			2SA1576A	TRANSISTOR	
TH500			PRF18BE471QS2	POSITIVE RESISTOR	
A1	2D		X86-4160-11	FRONT-END UNIT	

MECHANISM ASSY (X92-6360-02) DXM-9B32W

1	2B		A10-5450-53	CHASSIS ASSY
3	3B		A10-5452-41	CHASSIS
4	1B		A10-5453-32	CHASSIS
12	3A		D10-4993-52	LEVER
13	1B		D10-4991-22	ARM
14	1B		D10-4992-13	ARM
15	2A		D10-4994-02	SLIDER
16	2A		D10-4995-03	SLIDER
17	2B		D10-4996-02	SLIDER
18	2A		D10-4997-03	LEVER
19	1A		D10-4998-03	ARM
20	2A		D10-4999-03	ARM
21	2A		D10-7001-03	ARM
22	2A		D10-7002-03	ARM
23	2A		D10-7003-03	ARM
24	2A		D13-2445-04	GEAR
25	2A		D13-2446-04	GEAR
27	2A		D13-2448-04	GEAR
28	2A		D13-2449-04	GEAR
29	2A		D13-2450-04	GEAR
30	2A		D13-2451-04	GEAR
31	2A		D13-2452-04	GEAR
32	2A		D13-2453-04	GEAR
33	2A		D13-2454-04	GEAR
34	2A		D13-2455-04	GEAR
35	2B		D13-2456-03	RACK (GEAR)
36	2A		D14-1028-04	ROLLER
37	3A		D21-2507-04	SHAFT
38	2B		D21-2508-04	SHAFT

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.

PARTS LIST

MECHANISM ASSY (X92-6360-02) DXM-9B32W

Ref.No.	Add	New	Parts No.	Description	Destination
39	3A		D23-0963-04	RETAINER	
40	3B		D39-0277-15	DAMPER	
41	3B		D39-0278-15	DAMPER	
46	1B		G01-4682-34	TORSION COIL SPRING	
47	3A		G01-4683-24	EXTENSION SPRING	
48	2A		G01-4684-04	EXTENSION SPRING	
49	2B		G01-4685-04	EXTENSION SPRING	
50	1B		G01-4686-14	EXTENSION SPRING	
51	3A		G01-4688-14	EXTENSION SPRING	
52	3A		G01-4692-24	TORSION COIL SPRING	
53	2B		G02-1587-04	FLAT SPRING	
54	3A		G02-1588-04	FLAT SPRING	
55	1B		G13-1297-04	CUSHION	
56	1B		G13-1299-14	CUSHION	
57	1A		G16-1715-04	SHEET	
61	1B		J11-0675-03	CLAMPER	
64	2A		J19-7210-21	HOLDER	
65	2B		J19-7225-04	HOLDER	
66	1B		J22-0706-03	MOUNTING HARDWARE	
67	1A		J22-0707-12	MOUNTING HARDWARE	
68	1B		J90-1166-11	GUIDE	
69	2B		J90-1168-03	RAIL	
A	1A		N09-6108-15	TAPTITE SCREW (M2X3.5)	
B	2B		N09-6426-15+	MACHINE SCREW	
C	2B		N09-6735-05	TAPTITE SCREW	
D	2B		N09-6737-15	MACHINE SCREW	
E	2B		N09-6738-15	TAPTITE SCREW	
F	2A		N19-2335-14	FLAT WASHER	
G	2B		N35-2003-48	BINDING HEAD MACHINE SCREW	
H	2B		N39-1720-48	PAN HEAD MACHINE SCREW	
76	2A		S68-0921-05	PUSH SWITCH	
DM1	2B		X94-2090-00	SPINDLE MOTOR ASSY	
DM2	2B		X94-2100-00	FEED MOTOR ASSY (LOAD/SLED)	
DPU1	2B		X93-2260-01	OPTICAL PICKUP ASSY	

Ref.No.	Add	New	Parts No.	Description	Destination

K: KDC-X993 **K2**: KDC-X693 **K3**: KDC-MP642U
M1: KDC-XBT8013U **M2**: KDC-X7013U **M3**: KDC-XBT8013UL **M4**: KDC-X7013UL

⚠ indicates safety critical components.