

Service Manual

ORDER NO.
CRT3410

7 INCH WIDE FULLY MOTORIZED LCD COLOR DISPLAY WITH 5 CHANNEL HIGH-POWER DVD/VCD/CD RECEIVER

AVH-P7600DVD /UC

AVH-P7500DVD II /EW



DVD is a trademark of DVD Format/Logo Licensing Corporation.

**This service manual should be used together with the manual(s) listed below.
For the parts numbers, adjustments, etc. which are not shown in this manual,
refer to the following manual(s).**

Model No.	Order No.	Mech.Module	Remarks
AVH-P7500DVD /UC,EW	CRT3039		
AVH-P7500DVD /UC,EW	CRT3112		
CX-3016	CRT3056	MS3	DVD Mech. Module:Circuit Description, Mech.Description, Disassembly

PACKING(Page 10)**PACKING SECTION PARTS LIST**

*:Non spare part

Mark	No.	Description	AVH-P7500DVD/UC	AVH-P7600DVD/UC
A	1-2	Owner's Manual	CRB1863	CRB2068
	1-3	Owner's Manual	CRB1864	CRB2069
	1-4	Installation Manual	CRD3795	CRD3979
	2	Carton	CHG5110	CHG5504
	3	Contain Box	CHL5110	CHL5504
B	23	Screw Assy	CEA3686	CEA5144
	24	Screw(M4x6)	CBA1468	CBA1870
	* 26	Polyethylene Bag	CEG1101	Not used
	38	Screw	BNC40P120FZK	Not used
	* 39	Polyethylene Bag	CEG1158	Not used
	40	Screw	HMF40P080FZK	Not used
	42	Angle	CNB2351	Not used
	45	DC Antenna Assy	CXB9183	Not used
	* 46	Caution Card	CZR3093	Not used
	47	Antenna Unit	CZX5019	Not used
C	*	Caution Card	CRN1071	Not used
		Fastener	Not used	CNM3729 (This is in the sub carton)


PACKING SECTION PARTS LIST

Mark	No.	Description	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
D	1-2	Owner's Manual	CRB1857	CRB2062
	1-3	Owner's Manual	CRB1858	CRB2063
	1-4	Installation Manual	CRD3794	CRD3978
	2	Carton	CHG5109	CHG5503
	3	Contain Box	CHL5109	CHL5503
E	23	Screw Assy	CEA3686	CEA5144
	24	Screw(M4x6)	CBA1468	CBA1870
	* 26	Polyethylene Bag	CEG1101	Not used
	35-2	Owner's Manual	CRB1859	CRB2064
	35-3	Owner's Manual	CRB1860	CRB2065
	35-4	Owner's Manual	CRB1861	CRB2066
	35-5	Owner's Manual	CRB1862	CRB2067
	38	Screw	BNC40P120FZK	Not used
	* 39	Polyethylene Bag	CEG1158	Not used
	40	Screw	HMF40P080FZK	Not used
F	42	Angle	CNB2351	Not used
		Fastener	Not used	CNM3729 (This is in the sub carton)

EXTERIOR(1)(Page 14)


EXTERIOR(1) SECTION PARTS LIST

Mark	No.	Description	AVH-P7500DVD/UC	AVH-P7600DVD/UC
	2	Case	CNB2967	CNB3142
	17	Panel	CNS7480	CNS8179
	19	DVD Amp Unit	CWM8813	CWN1055
	53	Screw	BMZ20P025FTC	BMZ20P030FTB
	54	Screw	BMZ20P030FZK	BMZ20P030FTB
	55	Screw	BMZ26P030FZK	BMZ26P030FTC
	56	Screw	BMZ26P040FTC	BMZ26P030FTC
	62	Screw	CBA1633	CBA1871
	79	Panel Unit	CXC1895	CXC4551
	80	Screw(M2 x 4)	CBA1734	CBA1873
	81	Screw	BPZ20P080FZK	BPZ20P080FTB
	82	Button(DETACH)	CAC7944	CAC9124
	83	Button(EJECT)	CAC7945	CAC9125
	86	Button	CAC8149	CAC9127
	87	Button(RESET)	CAC8053	CAC9128
	91	Cover	CNS7441	CNS8246
	92	Keyboard Unit	CWM8823	*CWN1067
	99	Screw	BMZ20P025FTC	IMS20P025FTC
	103	Screw	CBA1777	CBA1874
	106	Spacer	CNM8575	CNM9272
		Grille Assy	CXC1203	CXC4524
		Grille Unit(Service)	CXX1793	CXX1882



EXTERIOR(1) SECTION PARTS LIST

Mark	No.	Description	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
A	2	Case	CNB2967	CNB3142
	17	Panel	CNS7480	CNS8179
	19	DVD Amp Unit	CWM8817	CWN1058
	53	Screw	BMZ20P025FTC	BMZ20P030FTB
	54	Screw	BMZ20P030FZK	BMZ20P030FTB
B	55	Screw	BMZ26P030FZK	BMZ26P030FTC
	56	Screw	BMZ26P040FTC	BMZ26P030FTC
	62	Screw	CBA1633	CBA1871
	79	Panel Unit	CXC1895	CXC4551
	80	Screw(M2 x 4)	CBA1734	CBA1873
	81	Screw	BPZ20P080FZK	BPZ20P080FTB
	82	Button(DETACH)	CAC7944	CAC9124
	83	Button(EJECT)	CAC7945	CAC9125
	86	Button	CAC7948	CAC9126
	87	Button(RESET)	CAC8053	CAC9128
C	91	Cover	CNS7441	CNS8246
	92	Keyboard Unit	CWM8827	*CWN1070
	99	Screw	BMZ20P025FTC	IMS20P025FTC
	103	Screw	CBA1777	CBA1874
	106	Spacer	CNM8575	CNM9272
		Grille Assy	CXC1207	CXC4527
		Grille Unit(Service)	CXX1796	CXX1885


**EXTERIOR(2)(Page 12)****EXTERIOR(2) SECTION PARTS LIST**

Mark	No.	Description	AVH-P7500DVD/UC AVH-P7500DVD/EW	AVH-P7600DVD/UC AVH-P7500DVDII/EW
E	177	Screw	CBA1753	CBA1872
	180	Cover	CNS7438	CNS8248

EXTERIOR(3)(Page 18)

EXTERIOR(3) SECTION PARTS LIST

Mark	No.	Description	AVH-P7500DVD/UC	AVH-P7600DVD/UC
	238	Grille Unit	CXC1320	CXC4557
	240	Button(ENT,WIDE,MENU)	CAC7935	CAC9129
	241	Button	CAC7936	CAC9130
	242	Screw	CBA1753	CBA1872
	244	LCD	CAW1805	CAW1871
	257	Monitor Unit	CWM8818	CWN1061
	274	Ferrite	Not used	CTX1094



EXTERIOR(3) SECTION PARTS LIST

Mark	No.	Description	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
	238	Grille Unit	CXC1319	CXC4556
	240	Button(ENT,WIDE,MENU)	CAC7935	CAC9129
	241	Button	CAC7936	Not used
	242	Screw	CBA1753	CBA1872
	244	LCD	CAW1805	Not used
	257	Monitor Unit	CWM8822	CWN1064

TUNER SELECTOR ASSY(EW MODEL)(Page 22)

TUNER SELECTOR ASSY(EW MODEL) SECTION PARTS LIST

Mark	No.	Description	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
	1	Screw	BSZ30P060FZK	BSZ30P060FTB
	6	Chassis	CNA2644	CNA2819
	7	Case	CNB2857	CNB3157
	9	Insulator	CNM9548	CNM9495
	10	Tuner Selector Unit	CWM8837	CWN1082


ELECTRICAL PARTS LIST(Page 149)

DVD AMP UNIT(UC MODEL)

Circuit Symbol and No.	AVH-P7500DVD/UC	AVH-P7600DVD/UC
IC 103 IC	TC7SH08FU	TC7SH08FUS1
IC 104 IC	PE5365C	PE5495A
IC 301 IC	HA12187FP	HA12240FP
IC 501 IC	TC7SH08FU	TC7SH08FUS1
IC 502 IC	TC74VHC08FT	TC74VHC08FUS1
IC 503 IC	TC74VHCT08AFT	TC74VHCT08AFTS1
IC 552 IC	TC74VHC08FT	TC74VHC08FUS1
IC 1604 IC	TC74VHC08FT	TC74VHC08FUS1
IC 1951 IC	TC74VHC08FT	TC74VHC08FUS1
IC 1952 IC	TC74VHC541FT	TC74VHC541FUS1
IC 1953 IC	TC74LCX541FT	TC74LCX541FUS1
IC 7001 IC	PD8113A	PD8145A
IC 7002 IC	PE5366C	PE5496A
IC 7003 IC	PD8114A	PD8146A
IC 7006 IC	TC7SET08FU	TC7SET08FUS1
IC 7007 IC	TC7SH08FU	TC7SH08FUS1
L102 Inductor	LCTA2R2J2520	LCTAW2R2J2520
L1001 Chip-Inductor	LCTA2R2J3225	LCTAW2R2J3225
L1622 Inductor	LCTA3R3J2520	LCTAW3R3J2520
R307	Not used	RS1/16S472J

DVD AMP UNIT(EW MODEL)

Circuit Symbol and No.	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
IC 103 IC	TC7SH08FU	TC7SH08FUS1
IC 301 IC	HA12187FP	HA12240FP
IC 501 IC	TC7SH08FU	TC7SH08FUS1
IC 502 IC	TC74VHC08FT	TC74VHC08FUS1
IC 503 IC	TC74VHCT08AFT	TC74VHCT08AFTS1
IC 552 IC	TC74VHC08FT	TC74VHC08FUS1
IC 1604 IC	TC74VHC08FT	TC74VHC08FUS1
IC 1951 IC	TC74VHC08FT	TC74VHC08FUS1
IC 1952 IC	TC74VHC541FT	TC74VHC541FUS1
IC 1953 IC	TC74LCX541FT	TC74LCX541FUS1
IC 7001 IC	PD8113A	PD8145A
IC 7003 IC	PD8114A	PD8146A
IC 7006 IC	TC7SET08FU	TC7SET08FUS1
IC 7007 IC	TC7SH08FU	TC7SH08FUS1
L102 Inductor	LCTA2R2J2520	LCTAW2R2J2520
L1001 Chip-Inductor	LCTA2R2J3225	LCTAW2R2J3225
L1622 Inductor	LCTA3R3J2520	LCTAW3R3J2520
R307	Not used	RS1/16S472J



TUNER SELECTOR UNIT(EW MODEL)

Circuit Symbol and No.	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
IC3002 IC	TC74VHC126FT	TC74VHC126FTS1
L3001 Inductor	LCTA4R7J2520	LCTAW4R7J2520
L3002 Inductor	LCTA1R0J3225	LCTAW1R0J3225
L3004 Inductor	LCTA4R7J2520	LCTAW4R7J2520
L3702 Inductor	LCKA2R2J2520	LCKAW2R2J2520
C1346	CEV100M16	CEVW100M16
C1347	CEV220M16	CEVW220M16
C3002	CEV101M1	CEVW101M1
C3101	CEV221M4	CEVW221M4
C3102	CEV221M4	CEVW221M4
C3113	CEV100M10	CEVW100M10
C3114	CEV100M10	CEVW100M10
C3120	CEV100M10	CEVW100M10
C3121	CEV100M10	CEVW100M10
C3123	CEV221M4	CEVW221M4
C3124	CEV221M4	CEVW221M4
C3132	CEV220M16	CEVW220M16
C3170	CEV100M10	CEVW100M10
C3175	CEV221M4	CEVW221M4
C3176	CEV221M4	CEVW221M4
C3183	CEV221M4	CEVW221M4
C3184	CEV221M4	CEVW221M4
C3185	CEV221M4	CEVW221M4
C3186	CEV221M4	CEVW221M4
C3510	CEV101M16	CEVW101M16
C3513	CEV330M10	CEVW330M10
C3518	CEV100M16	CEVW100M16
C3521	CEV101M16	CEVW101M16
C3704	CEV100M16	CEVW100M16
C3714	CEV330M10	CEVW330M10
C3725	CEV100M10	CEVW100M10
C3728	CEV221M4	CEVW221M4
C3729	CEV221M4	CEVW221M4
C3739	CEV100M10	CEVW100M10
C3740	CEV100M10	CEVW100M10
C3742	CEV330M10	CEVW330M10
C3745	CEV101M10	CEVW101M10
C3746	CEV221M4	CEVW221M4
C3756	CEV101M16	CEVW101M16

MONITOR UNIT(UC MODEL)

Circuit Symbol and No.	AVH-P7500DVD/UC	AVH-P7600DVD/UC
A	IC4141 IC	TC7SH08FU
	IC4142 IC	TK15404MI
	IC4451 IC	TC7SET08FU
	IC4731 IC	TC7SET08FU
	IC4732 IC	TC7SH08FU
B	IC5002 IC	TC7SET08FU
	L4061 Inductor	LCKA101J2520
	L4071 Inductor	LCKB100K2520
	L4074 Inductor	LCKB100K2520
	L4075 Inductor	LCKB100K2520
C	L4078 Inductor	LCKB100K2520
	L4101 Inductor	LCKB100K2520
	L4141 Inductor	LCKB100K2520
	L4151 Inductor	LCKB100K2520
	L4152 Inductor	LCKB100K2520
D	L4181 Inductor	LCKA101J2520
	L4182 Inductor	LCKA101J2520
	L4311 Inductor	LCKB100K2520
	L4701 Inductor	LCKB100K2520
	L4801	LCKB100K2520
E	L4802 Inductor	LCKB100K2520
	L4803 Inductor	LCKB100K2520
	L4804 Inductor	LCKB100K2520
	L4863 Inductor	LCKB100K2520
	L4864 Inductor	LCKB100K2520
F	L4865 Inductor	LCKB100K2520

MONITOR UNIT(EW MODEL)

Circuit Symbol and No.	AVH-P7500DVD/EW	AVH-P7500DVDII/EW
IC4141 IC	CTC7SH08FU	TC7SH08FUS1
IC4142 IC	TK15404MI	TK15404AMI
IC4451 IC	TC7SET08FU	TC7SET08FUS1
IC4731 IC	TC7SET08FU	TC7SET08FUS1
IC4732 IC	TC7SH08FU	TC7SH08FUS1
IC5002 IC	TC7SET08FU	TC7SET08FUS1
L4061 Inductor	LCKA101J2520	LCKAW101J2520S1
L4071 Inductor	LCKB100K2520	LCKBW100K2520
L4071 Inductor	LCKB100K2520	LCKBW100K2520
L4074 Inductor	LCKB100K2520	LCKBW100K2520
L4075 Inductor	LCKB100K2520	LCKBW100K2520
L4078 Inductor	LCKB100K2520	LCKBW100K2520
L4101 Inductor	LCKB100K2520	LCKBW100K2520
L4141 Inductor	LCKB100K2520	LCKBW100K2520
L4152 Inductor	LCKB100K2520	LCKBW100K2520
L4181 Inductor	LCKA101J2520	LCKAW101J2520
L4182 Inductor	LCKA101J2520	LCKAW101J2520
L4311 Inductor	LCKB100K2520	LCKBW100K2520
L4701 Inductor	LCKB100K2520	LCKBW100K2520
L4801 Inductor	LCKB100K2520	LCKBW100K2520
L4802 Inductor	LCKB100K2520	LCKBW100K2520
L4803 Inductor	LCKB100K2520	LCKBW100K2520
L4804 Inductor	LCKB100K2520	LCKBW100K2520
L4863 Inductor	LCKB100K2520	LCKBW100K2520
L4864 Inductor	LCKB100K2520	LCKBW100K2520
L4865 Inductor	LCKB100K2520	LCKBW100K2520

EXPLODED VIEWS AND PARTS LIST

NOTES : • Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.

• The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.


Therefore, when replacing, be sure to use parts of identical designation.

• Screw adjacent to ▽ mark on the product are used for disassembly.

• For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

TUNER SELECTOR ASSY(UC MODEL)



TUNER SELECTOR ASSY(UC MODEL) SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.	
1	Screw	BSZ30P060FTB	31	Connector(CN3101)	CKS4701	A
2	Screw	CBA1620	32	Antenna Jack(CN3003)	CKX1056	
3	Cord Assy	CDE7255	33	Holder	CNC6746	
4	Cord Assy	CDE7258	34	Holder	CNC7205	
5			35			
6	Chassis	CNA2819	36	Holder	CND1557	
7	Case	CNB3157	37	Holder	CND1558	
8	Holder	CND1773	38	Holder	CND1559	
9	Insulator	CNM9495	39	Holder	CND1774	
10	Tuner Selector Unit	CWN1079	40	Heat Sink	CNR1693	B
11	Screw	BMZ26P060FTC	41-53			
12	Screw	BMZ26P120FTC	54	Transistor(Q3510,Q3515)	2SD2375	
13						
14	Clamper	CEF1038				
15	FM/AM Tuner Unit	CWE1651				
16	Connector(CN101,CN102)	CKS4653				
17	Screw	ISS26P060FTC				
18	Holder	CND1432				
19	Terminal(CN1368,CN3002)	CKF1064				
20	Fan Motor(M1003)	CXM1186				
21	Plug(CN3701)	CKS-462				C
22	Pin Jack(CN3705)	CKS4790				
23	Pin Jack(CN3703,CN3704)	CKS1829				
24	IC(IC3701)	PAL007A				
25	Connector(CN3501)	CKS3124				
26	Connector(CN3702)	CKS3125				
27	Connector(CN1362)	CKS3131				
28	Connector(CN1360)	CKS3410				
29						
30	Connector(CN3001)	CKS4663				D

ELECTRICAL PARTS LIST

NOTE:

- Parts whose parts numbers are omitted are subject to being not supplied.
- The part numbers shown below indicate chip components.

Chip Resistor

RS1/○S○○○○J, RS1/○○S○○○○J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

- The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

Circuit Symbol and No.

Part No.

Circuit Symbol and No.

Part No.

GF

Unit Number: CWN1079(UC model)

Unit Name: Tuner Selector Unit

MISCELLANEOUS

IC 1340	IC	TA2050F	Q 3512	Transistor	2SD1767
IC 3001	IC	TC7W34FU	Q 3513	Transistor	DTA114EU
IC 3051	IC	NJM4558MD	Q 3514	Transistor	DTC124EU
IC 3101	IC	NJM2137V	Q 3515	Transistor	2SD2375
IC 3102	IC	TA2050F	Q 3516	Transistor	2SD1767
IC 3103	IC	TA2050F	Q 3701	Transistor	2SC4081
IC 3104	IC	NJM2137V	Q 3702	Transistor	2SC4081
IC 3105	IC	CXA2069Q	Q 3703	Transistor	2SC4081
IC 3106	IC	NJM2137V	Q 3704	Transistor	DTC124EU
IC 3107	IC	NJM2137V	Q 3705	Transistor	DTC323TU
IC 3501	IC	BA033FP	Q 3706	Transistor	2SA1576
IC 3502	IC	BA00BC0WFP	Q 3707	Transistor	FMG12
IC 3503	IC	S-812C50AUA-C3E	Q 3709	Transistor	2SA1576
IC 3504	IC	BA00BC0WFP	Q 3710	Transistor	DTC144EU
IC 3701	IC	PAL007A	Q 3711	Transistor	DTA114EU
IC 3702	IC	OPA2134UA	D 1340	Diode	UDZS5R6(B)
IC 3703	IC	NJM4558MD	D 1341	Diode	UDZS5R6(B)
IC 3704	IC	BA7623F	D 1342	Diode	UDZS5R6(B)
IC 3705	IC	TA2050F	D 1343	Diode	UDZS5R6(B)
Q 3010	Transistor	DTA144EU	D 1360	Diode	HZU2R0(B)
Q 3011	Transistor	2SC4081	D 1361	Diode	HZU2R0(B)
Q 3104	Transistor	2SC4081	D 1362	Diode	UDZS12(B)
Q 3105	Transistor	2SC4081	D 1365	Diode	UDZS12(B)
Q 3107	Transistor	FMG12	D 3010	Diode	UDZS4R7(B)
Q 3501	Transistor	DTC124EU	D 3101	Diode	DAP202K
Q 3502	Transistor	2SA1576	D 3102	Diode	1SR154-400
Q 3503	Transistor	IMD2A	D 3501	Diode	UDZS16(B)
Q 3504	Transistor	2SC4081	D 3502	Diode	1SR154-400
Q 3505	Transistor	IMD2A	D 3503	Diode	1SR154-400
Q 3506	Transistor	DTC124EU	D 3504	Diode	1SR154-400
Q 3507	Transistor	2SB1189	D 3505	Diode	UDZS8R2(B)
Q 3508	Transistor	DTC124EU	D 3506	Diode	UDZ5R6(B)
Q 3509	Transistor	2SA1797	D 3507	Diode	UDZ11(B)
Q 3510	Transistor	2SD2375	D 3508	Diode	UDZS12(B)
Q 3511	Transistor	2SD1767	D 3509	Diode	UDZS16(B)
			D 3701	Diode	1SR154-400
			D 3702	Diode	1SR154-400
			D 3703	Diode	UDZ8R2(B)
			D 3704	Diode	DAN202U
			D 3705	Diode	DAN202U
			D 3706	Diode	UDZS3R9(B)
			D 3707	Diode	DAP202K
			D 3708	Diode	1SS355
			D 3709	Diode	MA153
			D 3710	Diode	DAN202U

<u>Circuit Symbol and No.</u>		<u>Part No.</u>	<u>Circuit Symbol and No.</u>	<u>Part No.</u>	
D 3711	Diode	UDZS20(B)	R 3033	RS1/16S0R0J	A
D 3712	Diode	DAN202U	R 3034	RS1/16S0R0J	
ZNR3001	Surge Protector	RCCA-201Q31UA-PI	R 3035	RS1/16S0R0J	
L 1364	Inductor	CTF1379	R 3036	RS1/16S104J	
L 1390	Choke Coil 2.4mH	CTH1101	R 3037	RS1/16S104J	
L 3001	Inductor	LCTAW4R7J2520	R 3039	RS1/16S0R0J	
L 3002	Inductor	LCTAW1R0J3225	R 3040	RS1/16S0R0J	
L 3004	Inductor	LCKAW1R0J2520	R 3051	RS1/16S823J	
L 3005	Inductor-Array	CTF1421	R 3052	RS1/16S823J	
L 3006	Inductor-Array	CTF1421	R 3053	RS1/16S123J	
L 3007	Inductor-Array	CTF1421	R 3054	RS1/16S123J	B
L 3008	Inductor-Array	CTF1421	R 3055	RS1/16S823J	
L 3009	Inductor-Array	CTF1421	R 3056	RS1/16S823J	
L 3101	Inductor-Array	CTF1421	R 3057	RS1/16S104J	
L 3102	Inductor-Array	CTF1421	R 3058	RS1/16S104J	
L 3103	Inductor	CTF1379	R 3059	RS1/16S0R0J	
L 3104	Inductor	CTF1379	R 3060	RS1/16S0R0J	
L 3105	Inductor	CTF1379	R 3063	RS1/16S123J	
L 3106	Inductor	CTF1379	R 3064	RS1/16S123J	
L 3702	Inductor	LCKAW2R2J2520	R 3101	RS1/16S101J	
L 3703	Inductor	CTF1379	R 3103	RS1/16S152J	C
L 3704	Inductor	LCYC100K2125	R 3104	RS1/16S152J	
⚠FU1360	Fuse 2A	CEK1257	R 3105	RS1/16S152J	
⚠FU1361	Fuse 2A	CEK1257	R 3106	RS1/16S152J	
⚠FU3004	Fuse 4A	CEK1288	R 3107	RS1/16S101J	
⚠FU3501	Fuse 630mA	CEK1252	R 3109	RS1/16S473J	
⚠FU3502	Fuse 630mA	CEK1252	R 3110	RS1/16S473J	
⚠FU3701	Fuse 4A	CEK1288	R 3111	RS1/16S102J	
⚠FU3702	Fuse 4A	CEK1288	R 3112	RS1/16S102J	
EF3701	Filter	CTF1580	R 3113	RS1/16S223J	
FM/AM Tuner Unit		CWE1651	R 3114	RS1/16S223J	D
			R 3115	RS1/16S102J	
			R 3116	RS1/16S102J	
			R 3117	RS1/16S102J	
			R 3118	RS1/16S102J	
<u>RESISTORS</u>					
R 1340		RS1/16S101J			
R 1341		RS1/16S101J			
R 1342		RS1/16S223J	R 3119	RS1/16S473J	
R 1343		RS1/16S223J	R 3120	RS1/16S473J	
R 1344		RS1/16S102J	R 3121	RS1/16S102J	
			R 3122	RS1/16S102J	
			R 3123	RS1/16S750J	
R 1345		RS1/16S102J			
R 1361		RS1/10S750J			
R 3001		RS1/16S102J	R 3124	RS1/16S0R0J	
R 3002		RS1/16S102J	R 3125	RS1/16S332J	
R 3003		RS1/16S102J	R 3126	RS1/16S332J	
			R 3127	RS1/16S332J	
			R 3128	RS1/16S332J	
R 3007		RS1/16S0R0J			E
R 3008		RS1/16S681J			
R 3009		RS1/16S681J	R 3129	RS1/16S101J	
R 3010		RS1/16S681J	R 3130	RS1/16S473J	
R 3011		RS1/16S681J	R 3131	RS1/16S473J	
			R 3133	RS1/16S820J	
			R 3135	RS1/16S101J	
R 3013		RS1/16S681J			
R 3014		RS1/16S470J			
R 3020		RS1/16S0R0J	R 3136	RS1/16S102J	
R 3025		RAB4C0R0J	R 3137	RS1/16S474J	
R 3026		RAB4C0R0J	R 3138	RS1/16S0R0J	
			R 3139	RS1/16S0R0J	
			R 3140	RS1/16S474J	
R 3027		RAB4C0R0J			
R 3028		RS1/16S820J			F
R 3029		RS1/16S0R0J	R 3141	RS1/16S622J	
R 3030		RS1/16S0R0J	R 3143	RS1/16S474J	
R 3031		RS1/16S0R0J	R 3144	RS1/16S622J	

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

R 3145 RS1/16S622J
R 3146 RS1/16S474J
R 3147 RS1/16S622J
R 3148 RS1/16S474J
R 3149 RS1/16S474J
R 3150 RS1/16S474J
R 3151 RS1/16S474J

R 3519 RAB4C221J
R 3520 RS1/16S391J
R 3521 RS1/16S223J
R 3523 RS1/16S102J
R 3524 RS1/16S0R0J
R 3525 RS1/16S473J
R 3526 RS1/16S102J
R 3527 RS1/16S223J
R 3528 RS1/16S274J

R 3152 RS1/16S474J
R 3153 RS1/16S622J
R 3154 RS1/16S622J
R 3155 RS1/16S474J
R 3156 RS1/16S474J

R 3529 RS1/16S0R0J
R 3530 RS1/16S102J
R 3531 RS1/16S1R0J
R 3532 RAB4C121J
R 3533 RS1/16S333J

R 3157 RS1/16S622J
R 3159 RS1/16S622J
R 3160 RS1/16S474J
R 3161 RS1/16S474J
R 3162 RS1/16S470J

R 3534 RS1/16S472J
R 3535 RS1/16S224J
R 3701 RS1/16S224J
R 3702 RS1/16S224J
R 3703 RS1/16S103J

R 3163 RS1/16S470J
R 3164 RS1/16S392J
R 3165 RS1/16S682J
R 3166 RS1/16S101J
R 3167 RS1/16S102J

R 3704 RS1/16S472J
R 3705 RS1/16S103J
R 3706 RS1/16S103J
R 3708 RS1/16S224J
R 3709 RS1/16S223J

R 3168 RS1/16S152J
R 3169 RS1/16S152J
R 3170 RS1/16S152J
R 3171 RS1/16S152J
R 3172 RS1/16S151J

R 3710 RS1/16S473J
R 3711 RS1/16S103J
R 3712 RS1/16S103J
R 3713 RS1/16S331J
R 3714 RS1/16S0R0J

R 3173 RS1/16S151J
R 3174 RS1/16S682J
R 3175 RS1/16S392J
R 3176 RS1/16S101J
R 3177 RS1/16S102J

R 3716 RS1/16S223J
R 3717 RS1/16S223J
R 3718 RS1/16S223J
R 3719 RS1/16S223J
R 3720 RS1/16S223J

R 3178 RS1/16S152J
R 3179 RS1/16S152J
R 3180 RS1/16S152J
R 3181 RS1/16S152J
R 3182 RS1/16S151J

R 3721 RS1/16S223J
R 3722 RS1/16S223J
R 3723 RS1/16S104J
R 3724 RS1/16S104J
R 3725 RS1/16S473J

R 3183 RS1/16S151J
R 3184 RS1/16S102J
R 3185 RS1/16S622J
R 3186 RS1/16S622J
R 3187 RS1/16S622J

R 3726 RS1/16S471J
R 3727 RS1/16S104J
R 3728 RS1/16S561J
R 3729 RS1/16S222J
R 3730 RS1/16S104J

R 3189 RS1/16S622J
R 3190 RS1/16S622J
R 3191 RS1/16S0R0J
R 3195 RS1/16S821J
R 3196 RS1/16S821J

R 3731 RS1/16S471J
R 3732 RS1/16S102J
R 3733 RS1/16S151J
R 3735 RS1/16S151J
R 3736 RS1/16S151J

R 3501 RS1/16S102J
R 3503 RS1/16S562J
R 3504 RS1/16S332J
R 3510 RS1/16S102J
R 3511 RS1/16S471J

R 3737 RS1/16S103J
R 3738 RS1/16S103J
R 3739 RS1/16S821J
R 3740 RS1/16S821J
R 3741 RS1/16S223J

R 3512 RS1/16S102J
R 3513 RS1/16S681J
R 3514 RS1/16S223J
R 3515 RS1/16S1R0J
R 3516 RS1/16S681J

R 3742 RS1/16S223J
R 3743 RS1/16S103J
R 3744 RS1/16S103J
R 3745 RS1/16S103J
R 3746 RS1/16S103J

R 3518 RAB4C331J

<u>Circuit Symbol and No.</u>	<u>Part No.</u>	<u>Circuit Symbol and No.</u>	<u>Part No.</u>
R 3747	RS1/16S103J	C 3111	CKSQYB225K10
R 3748	RS1/16S103J	C 3112	CKSQYB225K10
R 3749	RS1/16S224J	C 3113	CEVW100M10
R 3751	RS1/16S104J	C 3114	CEVW100M10
R 3752	RS1/16S683J	C 3115	CKSRYB104K25
R 3753	RS1/16S683J	C 3116	CKSQYB225K10
R 3754	RS1/16S473J	C 3117	CKSQYB225K10
R 3755	RS1/16S473J	C 3118	CKSQYB225K10
R 3756	RS1/16S0R0J	C 3119	CKSQYB225K10
R 3757	RS1/16S0R0J	C 3120	CEVW100M10
R 3758	RS1/16S103J	C 3121	CEVW100M10
R 3759	RS1/16S103J	C 3122	CKSRYB104K25
R 3760	RS1/16S103J	C 3123	CEVW221M4
R 3761	RS1/16S104J	C 3124	CEVW221M4
R 3762	RS1/16S101J	C 3126	CCSRCH4R0D50
R 3951	RS1/16S0R0J	C 3129	CKSRYB104K25
R 3954	RS1/16S0R0J	C 3130	CKSRYB102K50
R 3956	RS1/16S0R0J	C 3131	CKSRYB104K25
R 3957	RS1/16S0R0J	C 3132	CEVW220M16
R 3958	RS1/16S0R0J	C 3133	CKSYB106K6R3
CAPACITORS		C 3134	CKSYB106K6R3
C 1340	CCSRCH471J50	C 3135	CKSYB106K6R3
C 1341	CCSRCH471J50	C 3136	CKSRYB104K25
C 1342	CKSRYB105K10	C 3137	CKSRYB104K25
C 1343	CKSRYB105K10	C 3138	CKSRYB105K10
C 1344	CKSRYB105K10	C 3139	CKSRYB105K10
C 1345	CKSRYB105K10	C 3140	CKSRYB105K10
C 1346	CEVW100M16	C 3141	CKSRYB105K10
C 1347	CEVW220M16	C 3142	CKSRYB105K10
C 1360	CKSRYB103K50	C 3143	CKSRYB105K10
C 1390	CCH1583	C 3144	CKSYB474K16
C 3001	CKSRYB103K50	C 3145	CKSRYB105K10
C 3002	CEVW101M10	C 3146	CKSRYB104K25
C 3004	CKSRYB103K50	C 3147	CKSRYB105K10
C 3005	CKSRYB103K50	C 3148	CKSRYB104K25
C 3006	CCH1497	C 3149	CKSRYB105K10
C 3007	CKSRYB104K25	C 3150	CKSRYB105K10
C 3008	CKSRYB104K25	C 3151	CKSRYB104K25
C 3051	CKSRYB105K10	C 3152	CKSRYB105K10
C 3052	CKSRYB105K10	C 3153	CKSRYB104K25
C 3053	CCSRCH6R0D50	C 3154	CKSRYB105K10
C 3054	CCSRCH6R0D50	C 3155	CKSRYB105K10
C 3055	CKSYF226Z10	C 3156	CKSRYB104K25
C 3056	CKSRYB104K25	C 3157	CKSRYB105K10
C 3057	CKSYF106Z10	C 3158	CKSRYB104K25
C 3058	CKSQYB475K6R3	C 3159	CKSYB106K6R3
C 3059	CKSRYB105K6R3	C 3160	CKSRYB105K10
C 3060	CKSRYB105K6R3	C 3161	CKSRYB104K16
C 3101	CEVW221M4	C 3162	CKSRYB105K10
C 3102	CEVW221M4	C 3163	CKSRYB104K25
C 3104	CCSRCH6R0D50	C 3164	CKSRYB104K25
C 3106	CKSRYB102K50	C 3165	CKSRYB104K25
C 3107	CKSYB106K6R3	C 3166	CKSRYB105K10
C 3108	CKSRYB102K50	C 3167	CKSRYB105K10
C 3109	CKSQYB225K10	C 3168	CKSRYB105K10
C 3110	CKSQYB225K10	C 3169	CKSRYB102K50
		C 3170	CEVW100M10
		C 3171	CKSRYB102K50
		C 3172	CKSRYB105K6R3

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

C 3173	CCSRCH6R0D50
C 3175	CEVW221M4
C 3176	CEVW221M4
C 3177	CKSRYB102K50
C 3178	CKSYB106K6R3
C 3179	CKSRYB102K50
C 3180	CKSRYB105K6R3
C 3181	CCSRCH6R0D50
C 3183	CEVW221M4
C 3184	CEVW221M4
C 3185	CEVW221M4
C 3186	CEVW221M4
C 3187	CKSYB106K6R3
C 3501	CKSRYB103K50
C 3502	CKSYB106K6R3
C 3503	CKSRYB103K50
C 3504	CKSYB475K16
C 3505	CCH1496
C 3506	CCH1356
C 3508	CKSRYB104K25
C 3509	CKSYB106K6R3
C 3510	CEVW101M16
C 3511	CKSRYB103K50
C 3512	CKSRYB104K25
C 3513	CEVW330M10
C 3514	CKSRYB104K25
C 3515	CKSRYB104K25
C 3516	CKSRYB104K25
C 3517	CKSRYB103K50
C 3518	CEVW100M16
C 3519	CKSYB475K10
C 3521	CEVW101M16
C 3522	CKSRYB104K25
C 3523	CKSRYB104K25
C 3524	CKSRYB105K10
C 3525	CKSRYB105K10
C 3701	CKSRYB105K10
C 3702	CKSQYB225K10
C 3703	CKSQYB225K10
C 3704	CEVW100M16
C 3705	CCSRCH471J50
C 3707	CKSYB106K6R3
C 3708	CKSYB106K6R3
C 3709	CCSRCH470J50
C 3710	CCSRCH470J50
C 3711	CKSRYB474K10
C 3712	CKSQYB474K16
C 3713	CKSRYB104K25
C 3714	CEVW330M10
C 3715	CKSRYB104K25
C 3719	CKSYF106Z10
C 3720	CKSRYB104K25
C 3721	CCSRCH100D50
C 3722	CKSRYB104K25
C 3723	CKSRYB105K10
C 3724	CCSRCH471J50
C 3725	CEVW100M10
C 3726	CKSRYB104K25

C 3727	22 μ F/6.3V	CCG1178
C 3728		CEVW221M4
C 3729		CEVW221M4
C 3730		CKSRYB473K50
C 3731		CKSYB475K10
C 3732		CKSYB475K10
C 3733		CKSRYB102K50
C 3734		CKSRYB102K50
C 3735		CKSRYB105K10
C 3736		CKSRYB105K10
C 3737		CKSRYB105K10
C 3738		CKSRYB105K10
C 3739		CEVW100M10
C 3740		CEVW100M10
C 3741		CKSRYB104K25
C 3742		CEVW330M10
C 3743		CKSYB106K6R3
C 3744		CKSYB106K6R3
C 3745		CEVW101M10
C 3746		CEVW221M4
C 3750		CKSRYB474K10
C 3751		CKSQYB474K16
C 3752		CKSRYB474K10
C 3753		CKSQYB474K16
C 3754		CKSRYB474K10
C 3755		CKSQYB474K16
C 3756		CEVW101M16
C 3757		CKSRYB471K50
C 3758		CKSRYB471K50
C 3759		CKSRYB471K50
C 3760		CKSRYB471K50