


9. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 - The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to ∇ mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual.
(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST


<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
	1 USB Cable	DDE1128
A	⚠ 2 Power Cord	See Contrast table (2)
NSP	3 CD ROM Assy/DVS	DXX2734
	4 Operating Instructions (Quick Start Guide)	See Contrast table (2)
	5 Operating Instructions (Quick Start Guide)	See Contrast table (2)
	6 Operating Instructions (Quick Start Guide)	See Contrast table (2)
NSP	7 Polyethylene Bag	AHG7117
B	8 Packing Pad	DHA1929
	9 Packing Pad	DHA1930
	10 Packing Board	DHB1002
	11 Sheet	RHX1006
	12 Packing Case	See Contrast table (2)
NSP	13 Leaflet/FPC	DRM1393
NSP	14 Warranty Card	See Contrast table (2)

C

(2) CONTRAST TABLE

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	DJM-S9 /LSYXJ	DJM-S9 /UXJCB	DJM-S9-N /LSYXJ	DJM-S9-N /UXJCB
	2	Power Cord	ADG1244	DDG1108	ADG1244	DDG1108
	4	Operating Instructions (Quick Start Guide) (En, Fr, De, It)	DRH1334	Not used	DRH1334	Not used
	5	Operating Instructions (Quick Start Guide) (NI, Es, Pt, Rs)	DRH1335	Not used	DRH1335	Not used
	6	Operating Instructions (Quick Start Guide) (En)	Not used	DRH1336	Not used	DRH1336
D	12	Packing Case	DHG3420	DHG3421	DHG3435	DHG3436
NSP	14	Warranty Card	ARY7158	Not used	ARY7158	Not used



(1) EXTERIOR and CH FADER SECTION PARTS LIST


Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	1 CH1FD Assy	DWX3689	26	Holder	DNK6425
	2 CH2FD Assy	DWX3690	27	Slider	DNK6426
	3 Connector Assy	PF03PP2B07	28	Brake	DNK6427
	4 Connector Assy	PF03PP-B17	29	Stopper	DNK6440
	5 Connector Assy	PF04PP-B12	30	Knob	See Contrast table (2)
	6 Plug/Pin	DKM1024	31	Slider Knob 2	See Contrast table (2)
	7 Rotary SW Knob (MA)	DAA1198	32	Panel	See Contrast table (2)
	8 Rotary SW Knob S (C)	DAA1204	33	Guide Bar	VLL1514
	9 Knob/RSW	DAA1305	34	Fader Bumper A	GNK1010
	10 Knob	DAA1344	35	Fader Bumper B	DEC3596
B	11 Knob	DAA1345	36	Fader Bumper C	DEC3605
	12 Knob/CL	See Contrast table (2)	37		
	13 Knob	DAA1346	38	Screw	BBZ30P060FTC
	14 Knob	DAC3088	39	Screw	BPZ20P050FTC
	15 Plate	DAH3033	40	Screw	BPZ30P080FNI
	16 Window	DAH3034	41	Screw	BSZ30P060FTB
	17 Damper	DEB2032	42	Screw	CPZ26P080FTC
	18 Fader Packing (B)	DEC2572	43	Screw	IBZ30P080FTB
	NSP 19 Cushion	DEC3356	44	Screw	See Contrast table (2)
	C 20 Felt	DEC3603			
	21				
	22 Cushion	DEC3639			
	23 Packing	DEC3642			
	24 Stay	DNF1942			
	25 Lever	DNH3211			

(2) CONTRAST TABLE

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	DJM-S9 /LSYXJ	DJM-S9 /UXJCB	DJM-S9-N /LSYXJ	DJM-S9-N /UXJCB
	12	Knob/CL	DAA1320	DAA1320	Not used	Not used
	12	Knob	Not used	Not used	DAA1350	DAA1350
	30	Knob	DAC3089	DAC3089	DAC3100	DAC3100
	31	Slider Knob 2	DAC2685	DAC2685	Not used	Not used
	31	Knob	Not used	Not used	DAC3164	DAC3164
E	32	Panel	DNB1241	DNB1241	DEA1038	DEA1038
	44	Screw	DBA1446	DBA1446	DBA1447	DBA1447

* This acetate tape is for protecting cables.
If it is peeled away, be sure to adhere new acetate tape.



(1) CHASSIS SECTION (1/2) SECTION PARTS LIST

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
A	1	HPJK Assy	DWX3686		21	Shield Case	DNF1946
	2	INPUT Assy	DWX3683	⚠	22	Holder	DNK6429
	3	ATT Assy	DWX3682		23	Guard	DNK6441
	4	FRVR Assy	DWX3687	⚠	24	Panel	See Contrast table (2)
	5	MCSW Assy	DWX3688		25	Guide Bar	VLL1514
	6	FFC	DDD1701		26		
	7	FFC	DDD1702		27		
	8	Connector Assy	PF06PP-D05		28	Nut M12	DBN1018
	9	Shielded Conn-Cable	DDA1059		29	Nut	NK90FTC
	10	Knob	DAA1348		30	Screw	AMZ26P040FTC
B	11	Cap/MIC	DAC2773		31	Screw	BBZ30P060FTB
	12	Spring	DBH1810		32	Screw	BBZ30P060FTC
	13	Damper/SI	DEB2008		33	Screw	BPZ30P080FNI
	14	Slide SW Packing (B)	DEC2590		34	Screw	BPZ30P080FTB
	⚠ 15	Insulating Sheet	DEC3629		35	Screw	BSZ30P060FTB
	16	Cushion	DEC3640		36	Screw	CPZ26P080FTC
	17	SW Packing	DED1177				
	18	Shield Case	DNF1943				
	19	Stay	DNF1944				
	20	Stay	DNF1945				
C							

(2) CONTRAST TABLE

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	DJM-S9 /LSYXJ	DJM-S9 /UXJCB	DJM-S9-N /LSYXJ	DJM-S9-N /UXJCB
⚠	24	Panel	DXA2291	DXA2291	DXA2298	DXA2298

A

B

C

D

E

F



CHASSIS SECTION (2/2) SECTION PARTS LIST


Mark No.	Description	Part No.
A	1 MAIN Assy	DWX3673
	2 HPAMP Assy	DWX3684
	3 ACSW Assy	DWR1547
	⚠ 4 POWER SUPPLY Assy	DWR1463
	⚠ 5 AC Inlet	DKP3973
NSP	6 FFC	DDD1701
	7 Crimp Connector	DDC1023
	8 Connector Assy	PF06PP-D05
	9 PCB Spacer	AEC1446
	10 Cushion 11x7	AED7092
NSP	11 Power Knob	DAC2306
	12 Heat Cond Sheet	DEB2026
	13 Cushion	DEC3177
	14 Chassis	DNA1456
	15 Rear Panel	DNC2118
C	16 Power Knob Guard	DNK4534
	17 Holder	VEC1355
	18 Binder	ZCA-SKB90BK
	19 Earth Terminal	DKE1019
	20 Bracket PSW	DNF1759
⚠	21 Chassis	DNK6442
	22	
	23	
	24 Screw	BBZ30P060FTB
	25 Screw	BPZ30P080FNI
D	26 Screw	BPZ30P080FTB
	27 Screw	BPZ30P100FTB
	28 Screw	IBZ30P080FTB
	29 Screw	IMZ30P040FTC
	30 Screw	PMH40P080FTC
F	31 Screw	PPZ30P080FTB
	32 Screw (M3*5)	DBA1340
	33 Flange Nut M9	DBN1008
	34 Washer	DEC2920
	35 Nut (M12)	NKX2FNI

E

F

5 6 7 8


9.5 CROSSFADER SECTION



CROSSFADER SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	CRFD Assy	DWX3678	16	Brake	DNK6445
2	Spring/TRQ	DBH1792	17	Plate	DNK6446
3	Spring	DBH1809	18	Guide Bar	VLL1514
4	Damper	DEB2032	19		
5	Felt	DEC3597	20		
6	Shaft	DLA2240	21	Washer	YC60FAC
7			22	Screw	BPZ20P050FTC
8	Bush (MA)	DNK5086	23	Screw	BPZ26P080FTC
9	Brake	DNK6427	24	Screw	BPZ30P080FNI
10	Brake	DNK6428	25	Screw	CPZ26P080FTC
11	Gear	DNK6430			
12	Gear	DNK6431			
13	Holder	DNK6432			
14	Holder	DNK6433			
15	Slider	DEA1037			

9.6 PANEL SECTION (1/2)



PANEL SECTION (1/2) SECTION PARTS LIST

Mark No.	Description	Part No.	
1	PADB Assy	DWX3675	
2	LVMT Assy	DWX3679	A
3	PNL1B Assy	DWX3685	
4	HPFD Assy	DWX3680	
5	SPVR Assy	DWX3681	
6	FFC/21P	DDD1655	
7	FFC	DDD1698	
8	FFC	DDD1699	
9	FFC	DDD1700	
10	FFC	DDD1701	
11	FFC	DDD1724	B
12	Lever	DAC3081	
13	Lever Spring	DBH1702	
14	Button	DEB2014	
15	Sheet	DEC3593	
16	Sheet	DEC3600	
17	Spacer	DEC3601	
18	Sheet	DEC3635	
19	I-Shield Sheet	DEC3644	
20	Stay	DNH3212	C
21	Stay	DNH3213	
22	Stay	DNH3214	
23	Lever Cap	DNK5344	
24	Holder	DNK6435	
25			
26			
27	Screw	BPZ26P080FTC	
28	Screw	BPZ30P080FNI	D

1 2 3 4

9.7 PANEL SECTION (2/2)

A

B


C

D

E

F

• Bottom view



PANEL SECTION (2/2) SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Matrix OEL	MXS4057	16	Button	DXA2289
2	Button	DAC3082	17	Button	See Contrast table (2)
3	Button	DAC3084	18	Button	See Contrast table (2)
4	Button	DAC3090	19	Button	See Contrast table (2)
5	Button	DAC3093	20	Button	See Contrast table (2)
6	Button	DAC3094	21	Button	See Contrast table (2)
7	Button	DAC3095	22	Panel	See Contrast table (2)
8	Button	DAC3096	23	Panel	See Contrast table (2)
9	Button	DEB2015			
10	Sheet	DEC3604			
11	Spacer	DEC3641			
12	Shield Plate	DNF1969			
⚠ 13	Panel	DNK6438			
14	Holder	DNK6439			
15	Holder	DNK6443			

(2) CONTRAST TABLE

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	DJM-S9 /LSYXJ	DJM-S9 /UXJCB	DJM-S9-N /LSYXJ	DJM-S9-N /UXJCB
	17	Button	DAC3085	DAC3085	DAC3101	DAC3101
	18	Button	DXA2288	DXA2288	DXA2290	DXA2290
	19	Button	DAC3087	DAC3087	DAC3102	DAC3102
	20	Button	DAC3091	DAC3091	DAC3103	DAC3103
	21	Button	DAC3092	DAC3092	DAC3104	DAC3104
	22	Panel	DNK6436	DNK6436	DNK6457	DNK6457
	23	Panel	DNK6437	DNK6437	DNK6459*	DNK6459*

*The serial number is not printed on this part for service.

12. PCB PARTS LIST

- NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.
 ● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47 k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ 56 $\times 10^1$ $\rightarrow$ 561 RD1/APU $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 1 \\ 0 \end{bmatrix} J$
 47 k Ω $\rightarrow$ 47 $\times 10^3$ $\rightarrow$ 473 RD1/APU $\begin{bmatrix} 4 \\ 7 \end{bmatrix} \begin{bmatrix} 3 \\ 0 \end{bmatrix} J$
 0.5 Ω $\rightarrow$ R50 RN2H $\begin{bmatrix} R \\ 5 \end{bmatrix} \begin{bmatrix} 0 \\ 0 \end{bmatrix} K$
 1 Ω $\rightarrow$ 1R0 RS1P $\begin{bmatrix} 1 \\ R \end{bmatrix} \begin{bmatrix} 0 \\ 0 \end{bmatrix} K$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 k Ω $\rightarrow$ 562 $\times 10^1$ $\rightarrow$ 5621 RN1/4PC $\begin{bmatrix} 5 \\ 6 \end{bmatrix} \begin{bmatrix} 2 \\ 1 \end{bmatrix} F$

Mark No. Description Part No.

LIST OF ASSEMBLIES

1..MAIN ASSY DWX3673

NSP 1..PAD ASSY DWM2565
 2..PADB ASSY DWX3675
 2..CH1FD ASSY DWX3689
 2..CH2FD ASSY DWX3690
 2..CRFD ASSY DWX3678
 2..LVMT ASSY DWX3679

NSP 1..PNL ASSY DWM2566
 2..PNL1B ASSY DWX3685
 2..SPVR ASSY DWX3681
 2..HPJK ASSY DWX3686
 2..ACSW ASSY DWR1547

NSP 1..JACK ASSY DWM2567
 2..INPUT ASSY DWX3683
 2..HPAMP ASSY DWX3684
 2..FRVR ASSY DWX3687
 2..HPFD ASSY DWX3680
 2..ATT ASSY DWX3682
 2..MCSW ASSY DWX3688

$\triangle$ 1..POWER SUPPLY ASSY DWR1463

Mark No. Description Part No.

A INPUT ASSY SEMICONDUCTORS

IC 6101,6103,6104,6301 NJM4580MD
 IC 6102,6302 NJM4580D
 IC 6105,6106,6305,6306 NJM2121MD
 IC 6303,6304,6501,6701 NJM4580MD
 Q 6101-6104,6301-6304 2SK209

Q 6105,6305,6503 LTA124EUB
 Q 6106,6306,6508 LTC124EUB
 Q 6107,6108,6307,6308 INC2002AC1
 Q 6109,6309 LTC114EUB
 Q 6501,6502,6506,6507 2SK209

Q 6505 INC2002AC1
 D 6501,6502,6504,6505 DZ2J270MO
 D 6507,6508 DZ2J270MO
 D 6509,6510,6511,6512 DZ2J130MO

MISCELLANEOUS

JA 6101,6301 RCA JACK/4P DKB1112

Mark No. Description Part No.

JA 6501 CANON CONNECTOR DKB1108
 JA 6701 RCA JACK DKB1122
 S 6501 SLIDE SWITCH DSH1025
 CN 6001,6002 L-PLUG(6P) KM200NA6L

CN 6003 3P JUMPER CONNECTOR 52147-0310
 CN 6004,6005 31P CONNECTOR VKN1291
 VA 6105,6501,6703 VARISTORS EZJZ1V270RM

RESISTORS

R 6001,6002 RS1/4SA0R0J
 R 6105,6106,6301,6302 RS1/10SR1000D
 R 6107,6108,6303,6304 RN1/16SE1000D
 R 6109,6110,6305,6306 RS1/10SR2200D
 R 6111,6112,6147,6149,6187,6189, 6307,6308 RN1/16SE2200D

R 6113,6114,6309,6310 RS1/10SR1003D
 R 6115,6116,6311,6312 RN1/16SE4702D
 R 6117,6118,6314,6315 RS1/10SR9102D
 R 6127,6130,6133,6134,6153,6154,6185,6186 RN1/16SE1501D
 R 6191,6192,6327,6330,6333,6334,6343,6344 RN1/16SE1501D

R 6128,6129,6131,6132,6328,6329,6331,6332 RN1/16SE1201D
 R 6135-6138,6179-6182,6323-6326,6367-6370 RN1/16SE1002D
 R 6141-6144,6341,6342,6345,6346 RS1/10SR1201D
 R 6145,6146,6347,6348 RN1/16SE2202D
 R 6148,6150,6188,6190,6336,6338,6380,6382 RN1/16SE3300D

R 6151,6152,6353,6354 RN1/16SE2703D
 R 6155,6355 RS1/8SQ0R0J
 R 6156-6159,6193-6196,6349-6352,6389-6392 RN1/16SE2201D
 R 6160,6161,6356,6357 RS1/10SR3002D
 R 6162,6163,6358,6359 RS1/10SR2002D

R 6164,6165,6360,6361 RS1/10SR1503D
 R 6169,6170,6373,6374 RS1/10SR8201D
 R 6175 RS1/10SR1002D
 R 6183,6184,6385,6386 RS1/10SR1601D
 R 6335,6337,6379,6381 RN1/16SE2200D

R 6383,6384,6387,6388,6512,6514 RN1/16SE1501D
 R 6504,6505 RN1/16SE1000D
 R 6506,6507 RN1/16SE2200D
 R 6508,6509,6539,6540 RN1/16SE5601D
 R 6510,6511,6515,6519 RN1/16SE4701D

R 6513 RS1/10SR2000D
 R 6516 RS1/10SR1500D
 R 6521,6705,6706 RS1/10SR1003D
 R 6530 RS1/10SR3301D
 R 6532,6533 RN1/16SE1003D

R 6543 RS1/10SR8200D
 R 6701,6702 RS1/10SR1000D

Mark No. Description

R 6177,6178,6377,6378,6703,6704
R 6707,6708
Other Resistors

Part No.

RS1/10SR1501D
RS1/10SR9102D
RS1/10SR###J

Mark No. Description

IC 603,609,1202
IC 605,610,1206
IC 607

Part No.

TC7SHU04FUS1
TC7SH08FUS1
TC7SH04FUS1

CAPACITORS

C 6001,6002,6119,6311
C 6003,6004,6120,6121
C 6101-6104,6301-6304
C 6105-6108,6126,6127
C 6109,6110,6309,6310

CEHAZL101M25
CKSRYB104K25
CCSRCH102J50
CCSRCH101J50
CEAL101M16

IC 1001
IC 1002
IC 1201,1203-1205,1207
IC 1208-1210,2002,2003
IC 1211

D810K013DZKB400
M12L128168A-5TG2N
TC74VHC08FK
TC7SH08FUS1
TC7SG08FU

C 6111,6112,6314,6315,6511,6514
C 6113,6114,6320,6321
C 6115,6117,6322,6324
C 6116,6118,6323,6325
C 6122,6123,6328,6331

CCSRCH471J50
CKSRYB223K50
CCSRCH331J50
CEHAT471M6R3
DCE1018

IC 2001
IC 2012,2013
IC 2014,2015
IC 2201,2301
IC 2401

TC74VHC74FK
CS5381-KZ
NJM4565MD
AK5358AET
WM8740SEDS

C 6124,6125,6131,6133,6329,6330,6333,6335
C 6130,6132,6332,6334,6502,6503
C 6138-6143,6338-6343
C 6160,6161,6312,6313
C 6167,6367

ACE7099
DCE1020
ACE7128
CKSRYB104K25
CKSRYB104K16

IC 2402,2403,2406,2602
IC 2404,2405,2603,2604
IC 2601,3001
IC 3003
Q 101,2401,2402

NJM4580MD
NJM4580D
AK4387ET
NJM4580MD
LTA024EEB

C 6305-6308,6316,6317
C 6344,6345,6703,6704
C 6346,6347,6501,6708
C 6506,6507,6701,6702
C 6508,6509

CCSRCH101J50
CCSRCH101J50
CKSRYB104K25
CCSRCH102J50
CEAT220M50

Q 102,203,208,601
Q 201,202,204,206
Q 205
Q 207,210,212-214
Q 209

LTC024EEB
LSAR523UB
LTC114YUB
LSCR523UB
2SAR502UB

C 6510
C 6512
C 6513
C 6515,6518
C 6519,6520,6705,6706,6711

CKSRYB471K50
CKSRYB103K50
CKSRYB331K50
CEAT101M25
CEAT101M16

Q 211
Q 401
Q 402
Q 403,404
Q 603-606,3005

2SC4097
RSR020P05
RTQ045N03
RSQ030P03
LTC024EEB

C 6148,6522,6707
C 6149,6521,6710
C 6709
C 6712

CKSRYB104K50
CKSRYB102K50
CKSRYB104K25
CEAT101M16

Q 2403-2416,2601-2604
Q 2605-2608
Q 2609-2612
Q 3003,3004
Q 3006,3007

INC2002AC1
2SK209
INC2002AC1
LSCR523UB
LSAR523UB

D 201,202,204,2601
D 209,210
D 403,406,407,410
D 404,405,408
D 411

DA2J101
DAN202UM
DB2J41100
RB501VM-40
DB2J41100

D 2202,2301,2302
D 2401-2406,2602-2605
D 3001
D 3003

DAN217UM
DZ2S180C
RB160M-30
DA2J101

**B ATT ASSY
MISCELLANEOUS**

KN 7701,7702 SCREW PLATE
S 7701 SLIDE SWITCH
JH 7701 3P CABLE HOLDER
JP 7701 JUMPER WIRE

VNE1948
DSH1063
51048-0300
D20PDY0305E

RESISTORS

All Resistors

RS1/10SR###J

MISCELLANEOUS

L 201 INDUCTOR
L 202 COIL
L 204 POWER INDUCTOR
L 205 CHIP BEEDS FILTER
L 401,402,405 POWER INDUCTOR

CTH1255
CTH1475
ATH7053
BTX1042
ATH7011

L 406 POWER INDUCTOR
L 601 INDUCTOR
L 602,604,605 INDUCTOR
L 603,805 COIL
L 802-804 INDUCTOR

ATH7011
CTF1545
CTF1793
ATH7015
CTF1793

L 1001 SMD FERRITE BEADS
F 1001 EMI FILTER
JA 601,801 USB CONNECTOR
JA 2401,2402 CANON CONNECTOR
JA 2403 RCA JACK

CTF1823
DTL1106
DKN1237
DKB1093
DKB1120

JA 2601,2602 HEADPHONE JACK

DKN1622

**C MAIN ASSY
SEMICONDUCTORS**

IC 201
IC 202,208,209,406
IC 203,210
IC 204-206
IC 207

S-80930CNMC-G80
NJM2872BF33
NJM2831F05
BD9328EFJ
NJM2886DL3-33

IC 212
IC 401,407
IC 402
IC 403,405
IC 404

BD2226G
NJM78M15DL1A
NJM79M15DL1A
BD9851EFV
NJM7805DL1A

IC 601,801
IC 602

R5S72690RW266FP
DYW1907*

*Part number of the initial firmware equipped

5		6		7		8	
Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
	KN 101-109	WRAPPING TERMINAL	CKF1089	R	802,803,846,905		RS1/10SR0R0J
	X 601	RESONATOR	CSS1760	R	1213,1222-1224,1267		RS1/10SR0R0J
	X 602	CRYSTAL RESONATOR	CSS1840	R	1269,2428-2435,3064		RS1/10SR0R0J
	X 1201	CRYSTAL(24.576MHZ)	DSS1204	R	2103,2105		RS1/10SR5R1J
	CN 101,103,106	31P CONNECTOR	VKN1435	R	2204,2312,2314		RS1/10SR1801D
	CN 102,105	CONNECTOR	AKM1277	R	2205,2313,2315		RS1/10SR4700D
	CN 104	23P CONNECTOR	VKN1427	R	2408-2411		RS1/10SR513J
	CN 107	31P CONNECTOR	VKN1435	R	2436-2443		RS1/10SR1302D
	CN 201	CONNECTOR	B6B-XH-A	R	2444-2451		RS1/10SR3901D
	1001	CANON SHIELD	DNF1789	R	2457-2464		RS1/8SQ8200F
	1002,1003	PHONE SHIELD	DNF1875	R	2465-2468,2477-2480		RS1/10SR223J
⚠	P 2401,2402	PROTECTOR(1A)	AEK1073	R	2469-2472		RS1/8SQ3300F
RESISTORS				R	2481-2484,2545-2548		RS1/8SQ2200F
	R 101		RS1/10SR102J	R	2489-2496,2609,2610		RS1/10SR5601D
	R 102		RS1/4SA561J	R	2497,2498,2541,2542		RS1/10SR1802D
	R 103-119,223,226		RS1/10SR0R0J	R	2499-2506		RN1/16SE1202D
	R 201,204,216		RS1/16SS1202D	R	2507,2508,2543,2544		RN1/16SE2202D
	R 203,210,220		RS1/16SS1802D	R	2509,2512-2516		DCN1200
	R 208,218,235,236		RS1/16SS2202D	R	2517-2520,2645-2648		RS1/10SR2201D
	R 209,211,215,219		RS1/16SS1002D	R	2521-2526,2651-2654		RS1/10SR183J
	R 212,424		RS1/10SR2002D	R	2527-2530,2533-2536		RS1/4SA220J
	R 217		RS1/16SS4701D	R	2531,2532,2649,2650		RS1/10SR474J
	R 224		RS1/16SS1201D	R	2611,2612,2615,2616		RS1/10SR5602D
	R 225		RS1/16SS4702D	R	2613,2614,2617,2618		RS1/10SR4701D
	R 229,232,269		RS1/16SS3902D	R	2620-2627		RS1/10SR3301D
	R 230,245,293,602		RS1/10SR0R0J	R	2628-2632		RS1/10SR473J
	R 234,248,442		RS1/10SR103J	R	2633-2640		RS1/10SR1502D
	R 244,246		RS1/4SA151J	R	2641-2644		DCN1200
	R 265		RS1/16SS6800D	R	3017,3018		RS1/10SR5601D
	R 266		RS1/16SS3301D	R	3019,3020,3023,3024		RN1/16SE6802D
	R 267,270,271,273		RS1/16SS1002D	R	3025,3026		RS1/10SR4701D
	R 268		RS1/16SS7501D	R	3065		RS1/10SR0R0J
	R 272		RS1/16SS6802D	Other Resistors			RS1/16SS###J
	R 401,410,427		RS1/10SR1502D	CAPACITORS			
	R 402,406,420,428		RS1/10SR1002D	C	101,464,616,2086		ACG7115
	R 403,416,429,440		RS1/10SR3002D	C	201,211,217,219		CKSSYB103K16
	R 404,419,430,443		RS1/10SR6802D	C	202,204,208,215		CKSSYB104K10
	R 405		RS1/10SR1803D	C	205,230,283,286		CCG1218
	R 407,423,3021,3022		RS1/10SR5101D	C	206,233,234		CCH1680
	R 411,415		RS1/10SR220J	C	207,310,311,492		ACE7114
	R 412,413,425,426		RS1/4SA0R0J	C	209,214,418,425		DCH1263
	R 414,438		RS1/10SR472J	C	218,222,278,405		CKSRYB104K25
	R 417,441,614,673		RS1/10SR105J	C	220,221,307,403		CKSRYB103K50
	R 418		RS1/10SR6201D	C	223-226,228		CKSSYB104K10
	R 422		RS1/10SR1503D	C	227,236-238		CKSSYB104K16
	R 431		RS1/10SR5102D	C	229,313,602		CKSSYB103K16
	R 432,2412-2419		RS1/10SR5601D	C	235,434,438		CGG1236
	R 435		RS1/10SR123J	C	239-241,263-265		CCSSCH102J50
	R 436,445,2485-2488		RS1/10SR1002D	C	245-247,251		CKSSYB104K10
	R 437,439,2619,3013		RS1/10SR100J	C	248-250,268,295		CKSSYB104K16
	R 446		RS1/10SR6202D	C	252		CKSSYB223K16
	R 448,450,451,453		RS1/4SA0R0J	C	253		CKSSYB473K16
	R 449		RS1/10SR3001D	C	257-259,266,267		CKSSYB104K10
	R 452		RS1/4SA3R9J	C	269,270,272,273		CCG1192
	R 454		RS1/4SA0R0J	C	275-277,1005,2111		CCH1565
	R 607,636,637,747		RS1/10SR0R0J	C	279,285,290,459		CKSSYB104K10
	R 638,684		RS1/16SS2402F	C	280,401,445,485		CKSRYB334K25
	R 744,902		RS1/16SS5601D	C	284,423,427,428		CKSRYB105K16
	R 773,926		RS1/8SQ0R0J	C	288		DCH1201

Mark	No.	Description	Part No.
A	C 292,297,312,466		CCG1218
	C 402		CKSYB225K25
	C 406,433,436,487		CKSRYB104K25
	C 407,435		CCSSCH271J50
	C 409,410,437,441		CKSQYB105K25
■	C 411		CKSSYB332K50
	C 413,414,484,488		CKSRYB103K50
	C 416,417,489,603		CKSSYB102K50
	C 420		CCSSCH221J50
	C 421,422,440,443		CEHVAW101M25
B	C 426,463		CKSYB105K16
	C 431,471		CKSSYB682K25
	C 439,442,469,479		CCSSCH102J50
	C 444,460,465,477		CKSRYB105K16
	C 446		CKSRYB563K16
■	C 449		CKSSYB472K50
	C 452,2090,2099		CFHXSQ103J16
	C 454,491,614,615		CCH1961
	C 456,462,474,478		DCH1263
	C 458		CCSSCH561J50
C	C 467		CCG1218
	C 472,601,607,610		CKSSYB104K10
	C 473,476,622,2001		CKSSYB104K16
	C 480,483,2470,2471		CEVW101M25
	C 481,1042		CKSRYB105K16
■	C 482		CCSSCH102J50
	C 486		CKSQYB105K25
	C 490		CCG1223
	C 493		ACE7114
	C 604,657,705,839		CCSSCH101J50
D	C 605,638,641,643		CCSSCH470J50
	C 606,706,707,1201		CCSSCH120J50
	C 608		CCSSCH100D50
	C 609,628,645,646		CKSSYB102K50
	C 612,613,618,619		CKSSYB104K10
■	C 620,621,809,810		CKSSYB471K50
	C 623,662,673-675		CKSSYB104K10
	C 624-627,630-634		CKSSYB103K16
	C 636,637,639,640		CKSSYB103K16
	C 642,644,648-652		CKSSYB103K16
E	C 656,659-661,663		CKSSYB103K16
	C 658,664,665		CKSSYB102K50
	C 666,677,678		CCG1192
	C 667-672,676,679		CKSSYB103K16
	C 680-682,695,703		CKSSYB102K50
■	C 683-685,710-720		CKSSYB103K16
	C 687-689,694,709		CKSSYB104K10
	C 691-693,848,861		CCG1192
	C 700,843,853,884		CCSSCH470J50
	C 708,840,846,847		CKSSYB102K50
F	C 801,802,807,808		CKSSYB104K10
	C 803,804,1003		CCH1961
	C 811-837,842,845		CKSSYB103K16
	C 844,855-857		CKSSYB104K10
	C 849-851,854		CKSSYB103K16
■	C 858-860,863		CKSSYB103K16
	C 862,873-875,1044		CCG1192
	C 864-866,879,883		CKSSYB102K50
	C 867-869,889-893		CKSSYB103K16
	C 870-872,878,1001		CKSSYB104K10

Mark	No.	Description	Part No.
C	C 887,1014,1016,1018		CKSSYB102K50
	C 1002,1004,1007,1203		CKSSYB104K10
	C 1006,1009		CKSSYB471K50
	C 1008,1010-1013,1015		CKSSYB103K16
	C 1017,1019,1021,1023		CKSSYB103K16
C	C 1020,1022,1024,1026		CKSSYB102K50
	C 1025,1027,1029,1031		CKSSYB103K16
	C 1028,1030,1032,1034		CKSSYB102K50
	C 1033,1035,1037,1039		CKSSYB103K16
	C 1036,1038,1209,1210		CKSSYB102K50
C	C 1040,1204,1207,1208		CCSSCH101J50
	C 1041,1045-1051,1221		CKSSYB103K16
	C 1202		CCSSCH120J50
	C 1205,1206,1214		CKSSYB104K10
	C 1211-1213,1227,2005		CCSSCH101J50
C	C 1215-1217,1228,1229		CKSSYB102K50
	C 1218-1220,1222-1226		CKSSYB104K10
	C 1233		CCSRCH470J50
	C 2002,2003,2007,2008		CKSSYB102K50
	C 2004,2009,2204,2208		CKSSYB104K10
C	C 2006		CCSSCH101J50
	C 2010,2011,2403,2407		CKSSYB102K50
	C 2012,2013,2087,2092		CKSSYB103K16
	C 2091		ACG7115
	C 2093,2098,2100,2103		CKSSYB104K16
C	C 2106,2107,2112,2113		CKSSYB103K16
	C 2108,2109,2114,2115		CCSRCH222J50
	C 2110,2116		CEVW331M6R3
	C 2117,2119,2121,2401		CCH1565
	C 2118,2120		CKSSYB104K16
C	C 2122,2123,2213,2313		CKSSYB103K16
	C 2124,2125,2212,2312		CKSRYB103K50
	C 2202,2207,2209,2302		CCG1192
	C 2205,2305,2306		CEVW220M16
	C 2210,2304,2308,2310		CKSSYB104K10
C	C 2211,2311,2414,2416		CCSRCH102J50
	C 2307,2309		CCG1192
	C 2402,2405,2409,2413		CKSSYB104K10
	C 2404,2406,2448,2457		CEVW221M25
	C 2408,2419,2431		CCH1565
C	C 2412,2420		CKSSYB102K50
	C 2415,2417,2611,2613		CKSRYB103K50
	C 2418,2425,2609,2614		CKSSYB104K10
	C 2426,2603,3001,3027		CKSSYB103K16
	C 2427-2430		CCSRCH271J50
C	C 2432-2439		CCSRCH121J50
	C 2440-2443,2449,2452		CKSRYB104K25
	C 2450,2451,2454,2455		CCSRCH101J50
	C 2453,2456,2459,2460		CKSRYB104K25
	C 2458,2465		CEVW221M25
C	C 2461-2464,2627-2630		CCSRCH101J50
	C 2466-2469		CCH1680
	C 2472-2477,2649-2652		CFHXSQ472J16
	C 2601,2602,2653,2654		CEVW470M25
	C 2604,2605,3014,3015		CCSRCH272J50
C	C 2606,3002		CEVW220M6R3
	C 2607,2608,2623-2626		CCSRCH471J50
	C 2610,2612,3004,3006		CCSRCH102J50
	C 2615,2616,3018,3019		CCSRCH220J50

5			6			7			8		
Mark	No.	Description	Part No.	Mark	No.	Description	Part No.				
	C	2617,2639-2642	CEVW101M16		C	8130,8134,8135	CKSRYB104K25				
	C	2620,2621,2631-2634	CKSRYB104K25	E	MCSW ASSY						
	C	2635-2638	CCSRCH101J50								
	C	3003,3008	CKSSYB104K10								
	C	3005,3007	CKSRYB103K50								
	C	3010-3012	CEVW101M16								
	C	3016,3017	CCSRCH471J50	MISCELLANEOUS							
	C	3020,3021	CKSRYB104K25								
	C	3022,3023	CEVW100M50								
	C	3024	CEVW331M35								
				RESISTORS							
				All Resistors							
				RS1/10SR###J							
D HPAMP ASSY				F FRVR ASSY							
SEMICONDUCTORS											
	IC	8001,8103	NJM4565MD								
	IC	8101,8102	NJM4580MD								
	Q	8101,8103,8104,8113	2SK209								
	Q	8102,8105,8106,8114	INC2002AC1	MISCELLANEOUS							
	Q	8107,8109,8111,8115	KTC3209								
	Q	8108,8110,8112,8116	KTA1281								
	Q	8117,8119,8121,8123	LSCR523UB								
	Q	8118,8120,8122,8124	LSAR523UB	RESISTORS							
	D	8101-8108	DA2J101								
MISCELLANEOUS				All Resistors							
	CN	8001 PLUG(6P)	KM200NA6								
	CN	8003 31P CONNECTOR	VKN1262								
	CN	8004,8007 3P JUMPER CONNECTOR	52147-0310								
	CN	8005 9P JUMPER CONNECTOR	52147-0910								
	CN	8006 11P CONNECTOR	VKN1242	RS1/10SR###J							
	CN	8009 3P JUMPER CONNECTOR	52147-0310								
	CN	8010 9P CONNECTOR	VKN1824								
RESISTORS				CAPACITORS							
	R	8001	RS1/10SR2200D								
	R	8002,8017,8137	RS1/4SA0R0J								
	R	8003	RN1/16SE1501D								
	R	8009,8012	RS1/10SR6800D								
	R	8011,8014,8175	RS1/10SR1003D	RS1/10SR###J							
	R	8101-8103,8128	RS1/10SR1002D								
	R	8104,8106,8107,8129	RN1/16SE1002D								
	R	8112,8116,8118,8133	RS1/8SQ680J								
	R	8119-8121,8134,8178,8181,8184,8187	RS1/10SR1001D	RS1/10SR###J							
	R	8122-8127,8135,8136	RS1/4SA220J								
	R	8139-8146	RN1/16SE3301D								
	R	8163,8164	RN1/16SE2700D								
	R	8169,8170	RS1/10SR3900D	RS1/4SA0R0J							
	R	8147,8149,8151,8153,8155,8157,8159,8161	RS1/4SA220J								
	R	8176,8177,8179,8180,8182,8183,8185,8186	RS1/10SR1801D								
	Other Resistors		RS1/10SR###J								
CAPACITORS				CAPACITORS							
	C	8001,8002	CEAT470M25								
	C	8003,8004,8006	CKSRYB104K25								
	C	8005,8007	CEAT221M10								
	C	8008-8010,8104,8108	CKSRYB104K25								
	C	8014,8136,8137	CEAL101M16	CKSRYB102K50							
	C	8101,8105,8106,8122	CCSRCH391J50								
	C	8110,8114,8115	CKSRYB104K25								
	C	8116,8121,8128,8131	DCH1201								
	C	8117-8120,8124,8129	CKSRYB104K25	DYW1908*							
	C	8125,8126,8132,8133	CEAT471M10								

Mark No. Description**Part No.****Mark No. Description****Part No.**

IC 5301 TC74HC151AF
 IC 5501,5502 TC74HC4051AF
 Q 5101 LTA124EUB

Q 5301-5303,5306,5703 LSAR523UB
 Q 5501 UMT1N
 Q 5502 UMX1N
 Q 5503 LSCR523UB
 Q 5504 LTA143EUB

Q 4611,4633,4655,4677,4704,4706 LTC014EEB
 Q 4617,4639,4661,4683 2SB1689
 Q 4634-4638,4640-4653 LSAR523UB
 Q 4656-4659,4662-4676,4678-4682 LSAR523UB
 Q 4684-4688,4736,4738,4742,4744 LSAR523UB

Q 4689-4703,4705,4707,4709,4711 LTC023JEB
 Q 4708,4710,4712-4721 LTC014EEB
 Q 4709 LTC023JEB
 Q 4722-4735 HN1A01FU(YGR)
 D 4601-4605,4608-4611,4613-4617,4620-4623 SMLVN6RGB2UK(B)

D 4680,4682 SMLVN6RGB2UK(B)
 D 4629-4632,4647-4650,4665-4668,4675,4676 SMLE12BC7T(NP)
 D 4639,4640,4657,4658 SML-D12V8W(PQ)

Q 5701,5705,5706,5712,5716,5717 LTC123JUB
 Q 5702,5711 LTC114YUB
 Q 5704,5713,5714 LSAR523UB
 D 5701,5702,5705,5706 LTL17KRH5D
 D 5708,5709,5710,5713,5714 LTL17KRH5D
 D 5716,5717 SLR343BD2T(NP)

MISCELLANEOUS

L 5101 CHIP COIL LCTAW330J2520
 L 5102 INDUCTOR CTF1793
 VR 5501,5506,5507,5513 ROTARY VR DCS1104
 VR 5502,5513 ROTARY VR DCS1126
 VR 5503-5505,5508-5511 ROTARY VR DCS1078

MISCELLANEOUS

S 4501,4502,4504 TACTILE SWITCH DSG1143
 S 4503,4506,4520,4525 TACT SWITCH DSG1134
 S 4505, 4507-4519 TACTILE SWITCH DSG1143
 S 4521-4524 TACTILE SWITCH DSG1143
 X 4301 CRYSTAL RESONATOR BSS1146

S 5301,5304,5307 TACT SWITCH DSG1117
 S 5302,5303 ENCODER SW DSX1080
 S 5305,5306,5308-5311 TACT SWITCH DSG1079
 S 5312-5314 TACT SWITCH DSG1117
 S 5502,5503 ROTARY SWITCH DSG1131

CN 4201 21P CONNECTOR VKN1425
 CN 4202,4203 31P CONNECTOR VKN1435
 CN 4204,4205 FFC/FPC CONNECTOR CKS6476

X 5101 CRYSTAL RESONATOR DSS1149
 CN 5001,5006 11P CONNECTOR VKN1271
 CN 5002 23P CONNECTOR VKN1283
 CN 5003-5005 31P CONNECTOR VKN1291
 PC 5301-5304 PHOTO INTERRUPTER GP1S094HCZ0F

RESISTORS

R 4201-4216,4503-4505 RS1/10SR101J
 R 4220,4304,4392,4528,4609,4620,4621,4625 RS1/10SR0R0J
 R 4217,4542,4576,4577,4610,4644,4653,4749 RS1/4SA0R0J
 R 4354 RS1/10SR105J
 R 4501,4502,4506,4507,4543-4563 RS1/10SR223J

R 4508-4518,4521,4526 RS1/10SR101J
 R 4527,4530,4531,4534-4536,4539-4541 RS1/10SR101J
 R 4612,4645,4668,4756 RS1/10SR470J
 R 4613,4651,4677,4771 RS1/10SR221J
 R 4616-4619,4684-4687,4752-4755,4820-4823 RS1/10SR390J

RESISTORS

R 5509 RS1/10SR2202D
 R 5510 RS1/10SR1001D
 R 5220,5222,5234,5351,5726,5727 RS1/4SA0R0J
 Other Resistors RS1/10SR###J

CAPACITORS

C 5101,5105,5160,5522 DCH1201
 C 5102,5106-5121 CKSRYB471K50
 C 5103,5122,5124-5126,5132-5135,5139-5141 CKSRYB104K16
 C 5127-5129,5136 CKSRYB103K16
 C 5137 CCSRCH100D50

R 4631-4634,4699-4702,4767-4770,4835-4838 RS1/10SR151J
 R 4647-4650,4715-4718,4783-4786,4851-4854 RS1/10SR120J
 R 4750,4757,4758,4761,4766,4772,4774,4777 RS1/4SA0R0J
 R 4652,4680-4682,4696-4698,4703-4711 RS1/10SR0R0J
 R 4751,4759,4760,4762-4765,4773,4776 RS1/10SR0R0J

C 5138 CCSRCH120J50
 C 5144,5155,5542,5543 CCSRCH470J50
 C 5146 CKSRYB473K16
 C 5301,5311,5323,5324,5326,5504,5505 CKSRYB104K16
 C 5142,5143,5147,5148,5162,5501-5503,5506,5513-5516 CKSRYB102K50

R 4778,4978,4979,4980 RS1/10SR0R0J
 R 4779,4976,4977,4981,4986,4988,4992,4995 RS1/4SA0R0J
 R 4614,4654,4678,4787 RS1/10SR150J
 R 4886,4888,4971,4975 RS1/10SR181J
 R 4906,4909,4928,4931,4934,4937,4940,4943 RS1/10SR270J

C 5508,5509,5511,5517,5519,5520,5521 CKSRYB104K16
 C 5523,5531-5533,5538-5540 CKSRYB104K16
 C 5524-5526,5534-5537 CKSRYB102K50
 C 5553,5561 CKSQYB105K25

R 4945,4948,4951,4954 RS1/10SR270J
 R 4957,4960 RS1/10SR560J
 R 4982-4985,4987,4989,4990,4993,4994,4996 RS1/10SR0R0J
 Other Resistors RS1/16SS###J

CAPACITORS

C 4201-4204,4207,4208 CKSRYB104K50
 C 4205,4206,4214 CCG1222
 C 4211 CEVW331M6R3
 C 4301,4322,4340,4341,4526,4529,4541 CKSSYB104K10
 C 4304 CKSRYB104K50
 C 4305,4530-4533,4537-4540,4542,4543 CCSSCH471J50

C 4307,4313,4317 CCSSCH470J50
 C 4309,4310 DCH1263
 C 4336,4350,4527,4528,4560-4573 CKSSYB103K16
 C 4337 CCSSCH120J50
 C 4338 CCSSCH100D50

I PADB ASSY**SEMICONDUCTORS**

NSP IC 4301 DYW1909*
 *Part number of the initial firmware equipped
 IC 4302 S-80930CNMC-G80
 IC 4501-4503 TC74HC151AF
 Q 4302 RT1N431M
 Q 4601-4610,4612-4616,4618-4626,4628-4631 LSAR523UB

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.	
	C	4346	CKSSYB473K16					
	C	4545,4549-4553,4557-4559,4577	CCSSCH471J50					
	C	4574	CKSRYB105K10					
J		LVMT ASSY		M		CRFD ASSY		
		SEMICONDUCTORS				SEMICONDUCTORS		
	Q	7301,7303,7304,7307,7314,7318,7320,7321	LTC014EEB		IC	7201,7202	EQ-730L	A
	Q	7302,7305,7311,7316,7317,7319,7329,7331	2SAR502UB		IC	7203	NJM12904V	
	Q	7306,7308,7309,7310,7312,7313,7315	LTC024EEB					
	Q	7322,7324,7325	LTC024EEB					
	Q	7323,7326-7328,7330,7332-7336	LSAR523UB					
	D	7302,7306,7321-7324,7329,7338,7347,7364	SML-D12V8W(PQ)					
	D	7304,7305,7325-7328,7330,7331,7339	SML-D12Y8W(QR)					
	D	7340,7348,7356	SML-D12Y8W(QR)					
	D	7308-7311,7318,7319,7332-7334,7341-7343	SML-D12M8W(NP)					
	D	7350,7351,7358,7359	SML-D12M8W(NP)					
		MISCELLANEOUS				MISCELLANEOUS		
	KN	7301,7302 WRAPPING TERMINAL	CKF1089					
	CN	7301 21P CONNECTOR	VKN1425					
		RESISTORS				RESISTORS		
		All Resistors	RS1/10SR###J					
		CAPACITORS				CAPACITORS		
	C	7301	CEHVAW101M6R3					
K		HPFD ASSY		N		CH1FD ASSY		
		MISCELLANEOUS				MISCELLANEOUS		
	VR	7501 VARIABLE RESISTOR	DCV1014		VR	7001 VARIABLE RESISTOR	CCW1024	
	VR	7502 ROTARY VR	DCS1117		CN	7002 CONNECTOR	AKM1274	
	VR	7503 ROTARY VR	DCS1116					
	CN	7501 11P CONNECTOR	VKN1271					
	VA	7501,7507,7508 VARISTORS	EZJZ1V270RM					
		RESISTORS				RESISTORS		
		All Resistors	RS1/10SR###J					
		CAPACITORS				CAPACITORS		
	C	7503-7505	CKSRYB104K16					
L		SPVR ASSY		O		CH2FD ASSY		
		MISCELLANEOUS				MISCELLANEOUS		
	VR	7602 ROTARY VR	DCS1117		VR	7101 VARIABLE RESISTOR	CCW1024	
	CN	7601 PLUG(4P)	KM200NA4		CN	7102 CONNECTOR	AKM1274	
	CN	7602 PLUG(3P)	KM200NA3R					
	CN	7603 PLUG(3P)	KM200NA3					
	CN	7604,7605 11P CONNECTOR	VKN1271					
	VA	7601-7606 VARISTORS	EZJZ1V270RM					
		RESISTORS				RESISTORS		
	R	7601,7602,7604,7607	RS1/10SR0R0J					
	R	7608,7614,7620,7621	RS1/10SR0R0J					
		Other Resistors	RS1/4SA###J					
		CAPACITORS				CAPACITORS		
	C	7601,7603	CKSRYB104K16					
	C	7604	DCH1201					
				P		ACSW ASSY		
						MISCELLANEOUS		
						⚠ S 7801 SWITCH	DSA1036	
						⚠ CN 7801 2P-SIDE VA-CONNECTOR	S2P3-VH	E
						⚠ JP 7801 BOARD IN JUMPER	DDX1289	
						CAPACITORS		
						⚠ C 7801	ACG7030	
				Q		POWER SUPPLY ASSY		
						* When replacement of the POWER SUPPLY Assy is required, be sure to order the POWER SUPPLY Assy (DWR1463) which is a parent Assy.		F