Pioneer sound.vision.soul

Service Manual

ORDER NO.
CRT3060

MULTI-CD CONTROL HIGH POWER CD/MP3/WMA PLAYER WITH FM/AM TUNER

DEH-P850MP XN/UC

DEH-P8500MP XN/UC





● **This service manual should be used together with the following manual(s):**
For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
DEH-P840MP/XN/UC	CRT2845		
CX-3007	CRT2820	S9MP3	CD Mech. Module:Circuit Description, Mech.Description, Disassembly

PIONEER CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS (USA) INC. P.O.Box 1760, Long Beach, CA 90801-1760 U.S.A.
PIONEER EUROPE NV Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE.LTD. 253 Alexandra Road, #04-01, Singapore 159936

© PIONEER CORPORATION 2003

K-ZZY. MAR. 2003 Printed in Japan

EXPLODED VIEWS AND PARTS LIST

PACKING (Page 4)

● PACKING SECTION PARTS LIST

* : Non spare part

Mark No.	Symbol and Description	Part No. DEH-P840MP/XN/UC	Part No. DEH-P850MP/XN/UC
1-1	Owner's Manual	CRD3569	CRD3774
1-2	Installation Manual	CRD3570	CRD3775
15	Carton	CHG4661	CHG5057
16	Contain Box	CHL4661	CHL5057

Mark No.	Symbol and Description	Part No. DEH-P8400MP/XN/UC	Part No. DEH-P8500MP/XN/UC
1-1	Owner's Manual	CRD3571	CRD3776
1-2	Installation Manual	CRD3572	CRD3777
15	Carton	CHG4662	CHG5056
16	Contain Box	CHL4662	CHL5056

EXTERIOR(1) (Page 10)

● EXTERIOR(1) SECTION PARTS LIST

Mark No.	Symbol and Description	Part No. DEH-P840MP/XN/UC	Part No. DEH-P850MP/XN/UC
20	Tuner Amp Unit	CWM8042	CWM8943

Mark No.	Symbol and Description	Part No. DEH-P8400MP/XN/UC	Part No. DEH-P8500MP/XN/UC
20	Tuner Amp Unit	CWM8043	CWM8944

EXTERIOR(2) (Page 12)

● EXTERIOR(2) SECTION PARTS LIST

Mark No.	Symbol and Description	Part No. DEH-P840MP/XN/UC	Part No. DEH-P850MP/XN/UC
8	Keyboard Unit(OEL)	CWM8051	CWM8945
14	Sub Grille Assy	CXB9363	CXC1805
16	Detach Grille Assy	CXB8092	CXC1747
36	Grille Unit	CXB7942	CXC1632

Mark No.	Symbol and Description	Part No. DEH-P8400MP/XN/UC	Part No. DEH-P8500MP/XN/UC
8	Keyboard Unit(OEL)	CWM8052	CWM8946
14	Sub Grille Assy	CXB9362	CXC1804
16	Detach Grille Assy	CXB8093	CXC1748
36	Grille Unit	CXB7941	CXC1631

ELECTRICAL PARTS LIST(Page 48)

TUNER AMP UNIT

Symbol and Description	Part No.	
	DEH-P840MP/XN/UC DEH-P8400MP/XN/UC	DEH-P850MP/XN/UC DEH-P8500MP/XN/NC
IC 601	PD5741A	PD5867A
L 401	LCTB4R7K2125	LCTC4R7K2125

KEYBOARD UNIT(OEL)

Symbol and Description	Part No.	
	DEH-P840MP/XN/UC DEH-P8400MP/XN/UC	DEH-P850MP/XN/UC DEH-P8500MP/XN/NC
IC 1801	PD5745B	PD5868A