

KTC-HR100

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KTC-HR100					
1	1B	*	A01-2830-02	METALLIC CABINET	
-			B46-0100-50	WARRANTY CARD	
-		*	B64-2644-00	INSTRUCTION MANUAL	
3	1A		E30-4291-05	CORD WITH PLUG	
4	1A		E30-4953-05	CORD WITH PLUG	
7	1A		H30-0051-05	MAGIC TAPE	
-			H11-1546-04	POLYSTYRENE FOAMED BOARD	
-			H25-0333-04	PROTECTION BAG (125X160X0.03)	
-			H25-1130-04	PROTECTION BAG	
-			H25-1158-04	PROTECTION BAG (220X350X0.03)	
-		*	H54-2955-03	ITEM CARTON CASE	
8	1A		J21-3801-04	MOUNTING HARDWARE	
9	2B		N99-1623-05	SCREW SET	
A	1B		N89-3006-45	BINDING HEAD TAPTITE SCREW	
B	2B		N89-3006-46	BINDING HEAD TAPTITE SCREW	
DIGITAL TUNER UNIT (X14-9310-10)					
C1			CD04AY1H100M	ELECTRO 10UF 50WV	
C2			CK73GB1H472K	CHIP C 4700PF K	
C3			CC73GCH1H470J	CHIP C 47PF J	
C4			CD04AZ1E222M	ELECTRO 2200UF 25WV	
C6			CC73GCH1H470J	CHIP C 47PF J	
C7			C90-5577-05	ELECTRO 47UF 16WV	
C8			CK73GB1H471K	CHIP C 470PF K	
C9			C90-5574-05	ELECTRO 10UF 16WV	
C10			CK73GB1C104K	CHIP C 0.10UF K	
C11			C90-5574-05	ELECTRO 10UF 16WV	
C12			CC73GCH1H470J	CHIP C 47PF J	
C13			CK73GB1C104K	CHIP C 0.10UF K	
C14			CC73GCH1H331J	CHIP C 330PF J	
C15			CK73GB1H222K	CHIP C 2200PF K	
C17			CC73GCH1H470J	CHIP C 47PF J	
C18			CK73FB1H104K	CHIP C 0.10UF K	
C19			CK73GB1H103K	CHIP C 0.010UF K	
C20			CC73GCH1H151J	CHIP C 150PF J	
C21-23			CK73GB1H103K	CHIP C 0.010UF K	
C24			CK73GB1H222K	CHIP C 2200PF K	
C25			CC73GCH1H470J	CHIP C 47PF J	
C26			CK73GB1H103K	CHIP C 0.010UF K	
C27			C90-5577-05	ELECTRO 47UF 16WV	
C28			C90-5574-05	ELECTRO 10UF 16WV	
C30			CK73GB1A474K	CHIP C 0.47UF K	
C31,32			CK73GB1C104K	CHIP C 0.10UF K	
C34			C90-5574-05	ELECTRO 10UF 16WV	
C35			CC73GCH1H470J	CHIP C 47PF J	
C36			CK73GB1H103K	CHIP C 0.010UF K	
C37			CK73GB1H471K	CHIP C 470PF K	
C38			CC73GCH1H470J	CHIP C 47PF J	
C39			C90-5577-05	ELECTRO 47UF 16WV	
C40,41			CC73GCH1H470J	CHIP C 47PF J	
C42			CC73GCH1H151J	CHIP C 150PF J	

Ref. No.	Add	New	Parts No.	Description	Destination
C43			CC73GCH1H470J	CHIP C 47PF J	
C44			C92-0628-05	CHIP-TAN 10UF 10WV	
C45			CC73GCH1H470J	CHIP C 47PF J	
C46			C92-0628-05	CHIP-TAN 10UF 10WV	
C47			CC73GCH1H470J	CHIP C 47PF J	
C48			CC73GCH1H331J	CHIP C 330PF J	
C49			CK73GB1H103K	CHIP C 0.010UF K	
C50			CC73GCH1H470J	CHIP C 47PF J	
C51			CK73GB1H103K	CHIP C 0.010UF K	
C52			C90-5574-05	ELECTRO 10UF 16WV	
C53			CK73GB1H103K	CHIP C 0.010UF K	
C55			CD04AY1A101M	ELECTRO 100UF 10WV	
C56			CK73GB1H103K	CHIP C 0.010UF K	
C57			C94-0036-05	ELECTRO 33UF 10WV	
C58			CK73GB1H103K	CHIP C 0.010UF K	
C59			CK73GB1H223K	CHIP C 0.022UF K	
C60,61		*	C90-5514-05	ELECTRO 180UF 16WV	
C62,63			CK73EB1E105K	CHIP C 1.0UF K	
C64,65			CK73GB1H103K	CHIP C 0.010UF K	
C66,67			CK73FB1H104K	CHIP C 0.10UF K	
C68			CK73GB1C104K	CHIP C 0.10UF K	
C69			CK73GB1H103K	CHIP C 0.010UF K	
C70		*	CD04AY0J221M	ELECTRO 220UF 6.3WV	
C72,73			CK73GB1H103K	CHIP C 0.010UF K	
C74			CK73GB1C104K	CHIP C 0.10UF K	
C76			C90-5577-05	ELECTRO 47UF 16WV	
C77			CK73GB1C104K	CHIP C 0.10UF K	
C78			CK73GB0J105K	CHIP C 1.0UF K	
C79			CK73GB1C104K	CHIP C 0.10UF K	
C80			CK73GB1H103K	CHIP C 0.010UF K	
C81		*	CD04AY1E101M	ELECTRO 100UF 25WV	
C82			CK73FB1H104K	CHIP C 0.10UF K	
C83			CK73EB1E105K	CHIP C 1.0UF K	
C84			CK73GB0J105K	CHIP C 1.0UF K	
C85,86			CK73GB1H103K	CHIP C 0.010UF K	
C87			CD04AY1A101M	ELECTRO 100UF 10WV	
C88		*	C90-5647-05	ELECTRO 0.047F 5.5WV	
C89,90			CK73GB1C104K	CHIP C 0.10UF K	
C92,93			CK73GB1C104K	CHIP C 0.10UF K	
C94			CK73GB1H103K	CHIP C 0.010UF K	
C95			CK73GB1C104K	CHIP C 0.10UF K	
C96			CK73GB1H103K	CHIP C 0.010UF K	
C97			CK73GB1C104K	CHIP C 0.10UF K	
C99			CK73GB1H103K	CHIP C 0.010UF K	
C100			CK73GB1C104K	CHIP C 0.10UF K	
C101			CK73GB1H103K	CHIP C 0.010UF K	
C102			CK73GB1C104K	CHIP C 0.10UF K	
C103			CK73GB1H103K	CHIP C 0.010UF K	
C104-108			CK73GB1C104K	CHIP C 0.10UF K	
C109			CK73GB1H103K	CHIP C 0.010UF K	
C110			CK73GB1C104K	CHIP C 0.10UF K	
C111			CK73GB1H103K	CHIP C 0.010UF K	
C112			CK73GB1C104K	CHIP C 0.10UF K	
C113,114			CC73GCH1H561J	CHIP C 560PF J	
C115,116			CK73GB1C104K	CHIP C 0.10UF K	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

DIGITAL TUNER UNIT (X14-9310-10)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C117			CC73GCH1H101J	CHIP C 100PF J		R11			RK73GB2A223J	CHIP R 22K J 1/10W	
C118,119			C90-5601-05	ELECTRO 1UF 50WV		R12			RK73GB2A512J	CHIP R 5.1K J 1/10W	
C120			C90-5574-05	ELECTRO 10UF 16WV		R13			RK73GB2A223J	CHIP R 22K J 1/10W	
C121,122			CK73GB1H472K	CHIP C 4700PF K		R14			RK73GB2A104J	CHIP R 100K J 1/10W	
C123		*	CD04BD1E221M	ELECTRO 220UF 25WV		R15			RK73GB2A223J	CHIP R 22K J 1/10W	
C124			CK73GB1C104K	CHIP C 0.10UF K		R16			RK73GB2A104J	CHIP R 100K J 1/10W	
C125			CK73FB1H104K	CHIP C 0.10UF K		R17			RK73GB2A103J	CHIP R 10K J 1/10W	
C126,127			CK73GB1H103K	CHIP C 0.010UF K		R18			RK73GB2A393J	CHIP R 39K J 1/10W	
C128		*	C90-5575-05	ELECTRO 22UF 16WV		R19			RK73GB2A473J	CHIP R 47K J 1/10W	
C129			CC73GCH1H220J	CHIP C 22PF J		R20			RK73GB2A223J	CHIP R 22K J 1/10W	
C130,131			CK73GB1C104K	CHIP C 0.10UF K		R21			RK73GB2A103J	CHIP R 10K J 1/10W	
C132		*	C90-5581-05	ELECTRO 470UF 16WV		R22			RK73GB2A182J	CHIP R 1.8K J 1/10W	
C133			CK73GB1H104K	CHIP C 0.10UF K		R23			RK73GB2A331J	CHIP R 330 J 1/10W	
C134			CC73GCH1H030C	CHIP C 3.0PF C		R24			RK73GB2A221J	CHIP R 220 J 1/10W	
C135			CK73GB1H103K	CHIP C 0.010UF K		R25			RK73EB2E471J	CHIP R 470 J 1/4W	
C136			CC73GCH1H470J	CHIP C 47PF J		R26			RK73GB2A153J	CHIP R 15K J 1/10W	
C137			CC73GCH1H391J	CHIP C 390PF J		R27			RK73GB2A473J	CHIP R 47K J 1/10W	
C138			CC73GCH1H470J	CHIP C 47PF J		R28			RK73GB2A512J	CHIP R 5.1K J 1/10W	
C139			CK73GB1H152K	CHIP C 1500PF K		R29			RK73GB2A101J	CHIP R 100 J 1/10W	
						R30			RK73EB2E101J	CHIP R 100 J 1/4W	
CN2			E40-3248-05	PIN ASSY (4P)		R31			RK73GB2A622J	CHIP R 6.2K J 1/10W	
CN3,4		*	E41-2029-05	PIN ASSY (10P)		R32			RK73GB2A103J	CHIP R 10K J 1/10W	
CN6			E40-3252-05	PIN ASSY (8P)		R33			RK73EB2E101J	CHIP R 100 J 1/4W	
J1			E63-0893-05	PIN JACK (2P)		R34			RK73GB2A512J	CHIP R 5.1K J 1/10W	
J2,3			E56-0846-05	CYLINDRICAL RECEPTACLE (13P)		R35			RK73EB2E101J	CHIP R 100 J 1/4W	
J4			E56-0811-05	CYLINDRICAL RECEPTACLE (M-D8P)							
J5			E04-0306-05	RF COAXIAL CABLE RECEPTACLE		R36,37			RK73GB2A622J	CHIP R 6.2K J 1/10W	
CF1			L72-0743-05	CERAMIC FILTER		R38			RK73EB2E101J	CHIP R 100 J 1/4W	
CF3			L72-0781-05	CERAMIC FILTER		R39			RK73GB2A103J	CHIP R 10K J 1/10W	
L1			L33-1177-05	CHOKE COIL (22U)		R40			RK73GB2A393J	CHIP R 39K J 1/10W	
L2		*	L33-1975-05	CHOKE COIL (47UH)		R41			RK73GB2A821J	CHIP R 820 J 1/10W	
L3			L33-1187-05	CHOKE COIL (100UH)							
L4			L33-1177-05	CHOKE COIL (22U)		R42,43			RK73EB2E101J	CHIP R 100 J 1/4W	
L5		*	L40-1015-91	SMALL FIXED INDUCTOR (100U)		R44			RK73GB2A223J	CHIP R 22K J 1/10W	
L6-11			L92-0376-05	CHIP FERRITE		R45			RK73EB2E101J	CHIP R 100 J 1/4W	
L12			L33-1123-05	LINE FILTER COIL		R46		*	RK73EB2E150J	CHIP R 15 J 1/4W	
L14-18			L92-0376-05	CHIP FERRITE		R47			RK73GB2A223J	CHIP R 22K J 1/10W	
L19			L33-1177-05	CHOKE COIL (22U)		R48			RK73GB2A822J	CHIP R 8.2K J 1/10W	
L20		*	L40-2785-85	SMALL FIXED INDUCTOR		R49			RK73GB2A333J	CHIP R 33K J 1/10W	
L21			L40-3395-85	SMALL FIXED INDUCTOR		R50			RK73GB2A100J	CHIP R 10 J 1/10W	
L22		*	L40-6895-85	SMALL FIXED INDUCTOR (6.8U)		R51			RK73GB2A102J	CHIP R 1.0K J 1/10W	
X1			L78-0821-05	RESONATOR		R52			RK73GB2A100J	CHIP R 10 J 1/10W	
B	2B		N89-3006-46	BINDING HEAD TAPTITE SCREW		R53			RK73GB2A272J	CHIP R 2.7K J 1/10W	
C	2A		N80-3008-46	PAN HEAD TAPTITE SCREW		R54			RK73GB2A105J	CHIP R 1.0M J 1/10W	
D	2A		N89-3008-45	BINDING HEAD TAPTITE SCREW		R55			RK73EB2E101J	CHIP R 100 J 1/4W	
CP1,2			R90-1058-05	MULTI-COMP 100K X4		R56			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R1			RK73GB2A512J	CHIP R 5.1K J 1/10W		R57			RK73GB2A273J	CHIP R 27K J 1/10W	
R2			RK73GB2A473J	CHIP R 47K J 1/10W		R58			RK73EB2E101J	CHIP R 100 J 1/4W	
R3,4			RK73GB2A221J	CHIP R 220 J 1/10W		R59			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R5			RK73GB2A103J	CHIP R 10K J 1/10W		R60-62			RK73EB2E101J	CHIP R 100 J 1/4W	
R6			RK73GB2A622J	CHIP R 6.2K J 1/10W		R63			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R7			RK73GB2A331J	CHIP R 330 J 1/10W		R64,65			RK73EB2E101J	CHIP R 100 J 1/4W	
R8			RK73GB2A221J	CHIP R 220 J 1/10W		R66			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R9			RK73GB2A101J	CHIP R 100 J 1/10W		R67			RK73GB2A183J	CHIP R 18K J 1/10W	
R10			RK73GB2A473J	CHIP R 47K J 1/10W		R68			RK73GB2A102J	CHIP R 1.0K J 1/10W	
						R69			RK73GB2A514J	CHIP R 510K J 1/10W	
						R70			RK73GH1J683D	CHIP R 68K D 1/16W	

K : North America

△ Indicates safety critical components.

KTC-HR100

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

DIGITAL TUNER UNIT (X14-9310-10)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R71			RK73GH1J303D	CHIP R 30K D 1/16W	
R72			RK73GH1J333D	CHIP R 33K D 1/16W	
R73			RK73GH1J223D	CHIP R 22K D 1/16W	
R75-83			RK73GB2A104J	CHIP R 100K J 1/10W	
R85			RK73GB2A101J	CHIP R 100 J 1/10W	
R87,88			RK73GB2A104J	CHIP R 100K J 1/10W	
R92			RK73GB2A104J	CHIP R 100K J 1/10W	
R93			RK73GB2A223J	CHIP R 22K J 1/10W	
R94-97			RK73GB2A101J	CHIP R 100 J 1/10W	
R99-105			RK73EB2E101J	CHIP R 100 J 1/4W	
R106			RK73GB2A103J	CHIP R 10K J 1/10W	
R107			RK73GB2A104J	CHIP R 100K J 1/10W	
R108			RK73GB2A101J	CHIP R 100 J 1/10W	
R109			RK73GB2A104J	CHIP R 100K J 1/10W	
R110,111			RK73GB2A101J	CHIP R 100 J 1/10W	
R112			RK73GB2A104J	CHIP R 100K J 1/10W	
R115			RK73GB2A103J	CHIP R 10K J 1/10W	
R116			RK73GB2A100J	CHIP R 10 J 1/10W	
R117			RK73GB2A621J	CHIP R 620 J 1/10W	
R118			RK73GB2A101J	CHIP R 100 J 1/10W	
R119			RK73GB2A183J	CHIP R 18K J 1/10W	
R120			RK73GB2A100J	CHIP R 10 J 1/10W	
R121			RK73GB2A621J	CHIP R 620 J 1/10W	
R125			RK73GB2A183J	CHIP R 18K J 1/10W	
R128-131			RK73GB2A100J	CHIP R 10 J 1/10W	
R132			RK73GB2A471J	CHIP R 470 J 1/10W	
R133			RK73GB2A151J	CHIP R 150 J 1/10W	
R134			RK73GB2A471J	CHIP R 470 J 1/10W	
R135			RK73GB2A151J	CHIP R 150 J 1/10W	
R136			RK73GB2A471J	CHIP R 470 J 1/10W	
R137			RK73GB2A750J	CHIP R 75 J 1/10W	
R138			RK73GB2A471J	CHIP R 470 J 1/10W	
R139			RK73GB2A151J	CHIP R 150 J 1/10W	
R141-144			RK73GB2A301J	CHIP R 300 J 1/10W	
R145			RK73GB2A113J	CHIP R 11K J 1/10W	
R146			RK73GB2A512J	CHIP R 5.1K J 1/10W	
R147			RK73GB2A113J	CHIP R 11K J 1/10W	
R148			RK73GB2A512J	CHIP R 5.1K J 1/10W	
R149			RK73GB2A113J	CHIP R 11K J 1/10W	
R150			RK73GB2A512J	CHIP R 5.1K J 1/10W	
R151			RK73GB2A113J	CHIP R 11K J 1/10W	
R152			RK73GB2A512J	CHIP R 5.1K J 1/10W	
R153,154			RK73GB2A101J	CHIP R 100 J 1/10W	
R156			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R157			RK73GB2A391J	CHIP R 390 J 1/10W	
R158			RK73GB2A471J	CHIP R 470 J 1/10W	
R159			RK73GB2A391J	CHIP R 390 J 1/10W	
R160			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R161			RK73GB2A912J	CHIP R 9.1K J 1/10W	
R162,163			RK73GB2A331J	CHIP R 330 J 1/10W	
R164			RK73GB2A202J	CHIP R 2.0K J 1/10W	
R165			RK73GB2A391J	CHIP R 390 J 1/10W	
R166			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R167			RK73GB2A100J	CHIP R 10 J 1/10W	
R168			RK73GB2A621J	CHIP R 620 J 1/10W	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R169			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R170			RK73GB2A183J	CHIP R 18K J 1/10W	
R171			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R172			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R176,177			RK73GB2A473J	CHIP R 47K J 1/10W	
R178			RK73GH1J102D	CHIP R 1K D 1/16W	
R179			RK73GH1J331D	CHIP R 330 D 1/16W	
R180,181			RK73GB2A473J	CHIP R 47K J 1/10W	
R182			RK73GB2A103J	CHIP R 10K J 1/10W	
R185			RK73GH1J133D	CHIP R 13K D 1/16W	
R186			RK73GH1J222D	CHIP R 2.2K D 1/16W	
R187			RK73GB2A101J	CHIP R 100 J 1/10W	
R188			RK73GB2A104J	CHIP R 100K J 1/10W	
R190			RK73GB2A473J	CHIP R 47K J 1/10W	
R193			RK73GB2A821J	CHIP R 820 J 1/10W	
R194,195			RK73GB2A101J	CHIP R 100 J 1/10W	
R196,197			RK73GB2A104J	CHIP R 100K J 1/10W	
R200			RK73GB2A684J	CHIP R 680K J 1/10W	
R203			RK73GB2A101J	CHIP R 100 J 1/10W	
R205			RK73GB2A103J	CHIP R 10K J 1/10W	
R206			RK73GB2A561J	CHIP R 560 J 1/10W	
R207			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R208,209			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R210			RK73GH1J104D	CHIP R 100K D 1/16W	
R211			RK73GH1J472D	CHIP R 4.7K D 1/16W	
R212			RK73GH1J183D	CHIP R 18K D 1/16W	
R213			RK73GH1J202D	CHIP R 2.0K D 1/16W	
R214			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R215,216			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R217			RK73GB2A393J	CHIP R 39K J 1/10W	
R218			RK73GB2A472J	CHIP R 4.7K J 1/10W	
W1			R92-1252-05	CHIP R 0 OHM J 1/16W	
D1			1SR154-400	DIODE	
D2			MA3062WA	ZENER DIODE	
D3			DA204U	DIODE	
D4			MA3062WA	ZENER DIODE	
D5			DA204U	DIODE	
D6			MA3062WA	ZENER DIODE	
D7			DAP202U	DIODE	
D8			SB05-05CP	DIODE	
D9			DAN202U	DIODE	
D10			DAP202U	DIODE	
D11			MA3062WA	ZENER DIODE	
D13			DAP202U	DIODE	
D14			MA3056-M	ZENER DIODE	
D15,16			RB160L-40	DIODE	
D17			MA3062WA	ZENER DIODE	
D18,19			DA204U	DIODE	
D20,21			MA3062WA	ZENER DIODE	
D22,23			MA3056-M	ZENER DIODE	
D25			DAN202U	DIODE	
D26,27			MA3062WA	ZENER DIODE	
D28			1SR154-400	DIODE	
D29,30			MA3062WA	ZENER DIODE	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

DIGITAL TUNER UNIT (X14-9310-10)

Ref. No.	Add	New	Parts No.	Description	Destination	Ref. No.	Add	New	Parts No.	Description	Destination
D31			SBE803	DIODE		C81			CK73FB1C105K	CHIP C 1.0UF K	
D32			IMSA-6801	SURGE ABSORBER		C82			CK73GB1H103K	CHIP C 0.010UF K	
D34,35			DAN202U	DIODE		C83			CK73FB1C105K	CHIP C 1.0UF K	
D37			DAP202U	DIODE		C84			CC73GCH1H181J	CHIP C 180PF J	
D38			SB05-05CP	DIODE		C85			CK73GB1H103K	CHIP C 0.010UF K	
IC1			BA00ASFP	ANALOGUE IC		C86,87			CC73GCH1H120J	CHIP C 12PF J	
IC2			TC4066BF(N)	MOS-IC		C88			C92-1427-05	ELECTRO 100UF 16WV	
IC3-5			NJM4580M1	ANALOGUE IC		C89			CC73GCH1H181J	CHIP C 180PF J	
IC6			FA7703V	ANALOGUE IC		C90			C92-1326-05	CHIP-TAN 47UF 10WV	
IC7,8			NJM4580M1	ANALOGUE IC		C91,92			CC73GCH1H150J	CHIP C 15PF J	
IC9		*	PQ015YZ01ZP	ANALOGUE IC		C93			CK73GB1H103K	CHIP C 0.010UF K	
IC11		*	70F3030BYGC1R9	MICROCONTROLLER IC		C94			C93-1291-05	CERAMIC 10UF 16V	
IC12			TA78L05F	ANALOGUE IC		C95-97			CK73GB1H104K	CHIP C 0.10UF K	
IC13			S-80837CNNB	MOS-IC		C98			CK73FB1C105K	CHIP C 1.0UF K	
IC14			TA48M05F	ANALOGUE IC		C99-111			CK73GB1H104K	CHIP C 0.10UF K	
IC15			BR24C01AF-W	ROM IC		C112			C92-0040-05	CHIP-ELE 47UF 16WV	
IC16			TC7W32FU	MOS-IC		C113,114			CC73GCH1H181J	CHIP C 180PF J	
IC17		*	BA00AST	ANALOGUE IC		C115,116			CK73GB1H104K	CHIP C 0.10UF K	
IC18			NJM2125F	ANALOGUE IC		C117			C92-1326-05	CHIP-TAN 47UF 10WV	
Q1			DTC323TU	TRANSISTOR		C118			C92-1429-05	ELECTRO 220UF 6.3WV	
Q2			2SK3018	FET		C121			CC73GCH1H101J	CHIP C 100PF J	
Q3			2SJ377	FET		C124,125			CC73GCH1H101J	CHIP C 100PF J	
Q4			DTC323TU	TRANSISTOR		C126			CK73FB1C105K	CHIP C 1.0UF K	
Q5			DTA144EUA	TRANSISTOR		C127-130			CK73GB1H332K	CHIP C 3300PF K	
Q6			DTA124EUA	TRANSISTOR		C131			CK73GB1C104K	CHIP C 0.10UF K	
Q7			DTC124EUA	TRANSISTOR		C132			C92-1427-05	ELECTRO 100UF 16WV	
Q8		*	HAT1016R	DUAL FET		C133			CC73GCH1H100D	CHIP C 10PF D	
Q10,11			DTC124EUA	TRANSISTOR		CN1,2	*		E41-2028-05	SOCKET FOR PIN ASSY (10P)	
Q12			2SK3018	FET		CN5			E40-3247-05	PIN ASSY (3P)	
Q14			DTC144EUA	TRANSISTOR		L1-4			L79-0963-05	LC FILTER	
Q16			DTC124EUA	TRANSISTOR		L5			L40-2292-93	SMALL FIXED INDUCTOR (2.2UH)	
Q17			DTA144EUA	TRANSISTOR		L6-9			L92-0316-05	CHIP FERRITE	
Q18,19			2SC4081	TRANSISTOR		L10			L79-0963-05	LC FILTER	
Q20,21			DTA124EUA	TRANSISTOR		X1	*		L77-2865-05	CRYSTAL RESONATOR	
Q22-25			2SC4081	TRANSISTOR		CP2			RK74GB1J103J	CHIP-COM 10K J 1/16W	
Q26			DTC144EUA	TRANSISTOR		CP7			RK74GB1J103J	CHIP-COM 10K J 1/16W	
Q27,28			2SK3018	FET		CP9-13			RK74GB1J103J	CHIP-COM 10K J 1/16W	
Q29			2SC4081	TRANSISTOR		R1,2			RK73GB2A201J	CHIP R 200 J 1/10W	
Q33			DTC144EUA	TRANSISTOR		R3-6			RK73GB2A332J	CHIP R 3.3K J 1/10W	
Q35-39			2SK3018	FET		R11			RK73GB2A102J	CHIP R 1.0K J 1/10W	
A1		*	W02-3428-05	FM/AM FRONT-END		R13,14			RK73GB2A332J	CHIP R 3.3K J 1/10W	
PROCESSOR UNIT (X32-5510-10)											
D1			B30-1533-05	LED (1608,PG)		R16			RK73GB2A332J	CHIP R 3.3K J 1/10W	
D3,4			B30-1533-05	LED (1608,PG)		R18			RK73GB2A332J	CHIP R 3.3K J 1/10W	
C1,2			CK73GB1H103K	CHIP C 0.010UF K		R20,21			RK73GB2A332J	CHIP R 3.3K J 1/10W	
C3-46			CK73GB1C104K	CHIP C 0.10UF K		R22			RK73GB2A103J	CHIP R 10K J 1/10W	
C47			C93-1291-05	CERAMIC 10UF 16V		R23,24			RK73GB2A332J	CHIP R 3.3K J 1/10W	
C48			CK73GB1C104K	CHIP C 0.10UF K		R25,26			RK73GB2A102J	CHIP R 1.0K J 1/10W	
C49			C92-0040-05	CHIP-ELE 47UF 16WV		R27-34			RK73GB2A332J	CHIP R 3.3K J 1/10W	
C51			CK73GB1H104K	CHIP C 0.10UF K		R35,36			RK73GB2A330J	CHIP R 33 J 1/10W	
C53,54			CC73GCH1H181J	CHIP C 180PF J		R40,41			RK73GB2A154J	CHIP R 150K J 1/10W	
C55			C92-1427-05	ELECTRO 100UF 16WV		R42-44			RK73FB2B100J	CHIP R 10 J 1/8W	
C56,57			CK73GB1C104K	CHIP C 0.10UF K		R45			RK73GB2A103J	CHIP R 10K J 1/10W	
C62-80			CK73GB1H104K	CHIP C 0.10UF K		R46			RK73GB2A220J	CHIP R 22 J 1/10W	
						R47,48			RK73GB2A104J	CHIP R 100K J 1/10W	

K : North America

△ Indicates safety critical components.

