





09 Clarion 1DIN AVN Model(NZ409) Accessary List:

No.	Part Name	QTY	Picture	Part No.
1	SMK wiring harness	1		3-WZ1X-0010-18-00
2	Remote Control	1		3-ZREM-1700-27-R2
3	User Manual	1		7-9820-8501-00-00
4	Sleeve	1		1-2810-2002-00-00
5	Sleeve Key	2		1-2923-2037-00-00
6	Back Strap	1		1-2651-2023-00-00


7	4 flush mount bolts 4 cap bolts Rear radio stud and stopper	1		7-2651-8024-00-0A
8	Cleaning cloth	1		7-2651-8015-00-00
9	Warranty Card	1		7-9820-8088-00-00
10	Trim ring	1		1-2810-3028-01-03
11	Navi antenna	1		3-Z800-GPS0-08-02
12	3.5 Jack AV IN cable	1		3-WZAH-1800-09-00




27	1-9810-3504-00-01	Decorate-Block-l	1
26	1-9810-8006-00-00	double_face_P2	1
25	1-9810-8007-00-00	double_face_P3	1
24	1-9810-3506-00-00	Guidelight-Ring-l	1
23	1-9810-8005-00-00	double_face_P1	2
22	1-9810-3525-00-00	Guidelight-Disk-l	1
21	1-9810-3531-00-00	GUIDELIGHT-BKT-L	1
20	1-9810-8001-00-00	dustproof_shade	1
19	1-9810-3504-00-01	EVA	2
18	1-2701-6023-00-01	screw:M2.0X5.0	8
17	P-9810-0652-R3-C4	KEY Board	1
16	P-9810-0660-R1-C3	AUXIN Board asm	1
15	1-9810-3532-00-00	GUIDELIGHT-BKT-R	1
14	1-9810-3520-00-01	Button-Reset	1
13	1-9810-3528-00-00	Button-Panel-Bkt-l	1
12	1-9810-3524-00-00	Guidelight-Disk-r	1
11	1-9810-3502-00-01	Panel	1
10	1-9810-3507-00-00	Guidelight-Ring-r	1
9	1-9810-3503-00-01	Lens-Panel	1
8	1-9810-3505-01-01	Decorate-Block-r	1
7	1-9810-3530-00-01	Knob-Vol	2
6	1-9810-3516-00-01	Button-Eject	1
5	1-9810-3517-00-01	Button-Play	1
4	1-9810-3515-00-01	Button-Source	1
3	1-9810-3519-00-01	Button-Num-r	1
2	1-9810-3518-00-01	Button-Num-l	1
1	1-9810-3521-00-00	Knob-Vol-Cover	2
NO.	PART NO.	DESCRIPTION	QTY




35	1-2810-8011-00-00	EVA SHEET	2
34	1-2701-8004-00-00	double_face_1	1
33	1-2941-2003-01-00	spring plate	2
32	1-2951-8003-00-00	PC SHEET	1
31	1-2941-8014-00-00	insulating plaster	3
30	1-2701-8013-01-00	EVA_sheet_3	2
29	7-2701-1022-00-00	TFT_film	1
28	1-9810-3527-00-00	Button-Screen-Bkt	1
27	1-9810-3528-00-00	Button-Screen-Bkt-l	1
26	1-9810-8009-00-00	EVA	2
25	3-PM00-S070-14-01	LCD	1
24	1-9810-8004-00-00	DOUBLE-FACE-S2	2
23	1-9810-8003-00-00	DOUBLE-FACE-S1	2
22	1-9810-3510-00-01	Button-Open	1
21	1-9810-3508-00-01	Button-BND-Screen	1
20	1-9810-3514-00-01	Lens_LCD	1
19	1-9810-3512-00-01	Button-AS/PS-Screen	1
18	1-9810-3511-00-01	Button-Disp-Screen	1
17	1-2701-8101-00-00	screen-cush-1	1
16	1-2810-2004-00-00	PCB_fix_shaft	1
15	1-2941-8013-00-00	electric adhesive plaster	1
14	P-9810-0650-R3-C4	TFT board	1
13	3-WFXX-7018-12-00	FFC	1
12	3-PATO-707N-07-00	TFT LCD panel	1
11	3-PHLD-0950-TP-00	touch panel	1
10	1-2701-8102-00-00	screen-cush-2	4
9	1-2701-6023-00-01	screw;M2.0X5.0	2
8	P-9810-0667-R2-C3	Led board	1
7	3-WFXX-7015-06-00	FFC	1
6	P-9810-0651-R1-C3	LCD board	1
5	1-9810-3501-00-01	Three-Button-Screen	1
4	1-9810-3522-00-00	Button-Screen-Bkt-r	1
3	1-9810-3523-00-00	Button-Screen-Bkt-r-l	1
2	1-2701-6006-00-01	screw;M2.0X2.0	6
1	1-9810-3508-00-01	screen_panel	1
NO.	PART NO.	DESCRIPTION	QTY



38	B99990028	FAN	1
37	1-2652-6002-02-00	screw;M2.6#13.00	3
36	3-W22X-0117-01-00	USB CABLE	1
35	1-9610-2406-00-00	NAVI FIX BKT	1
34	1-2701-6010-00-01	screw;M2.0X4.0	4
33	1-9850-2214-00-00	guid heat plate	1
32	P-9681-0557-R4-F2	NAVI BOARD	1
31	1-2961-8001-00-00	heat sheet 1	1
30	1-2961-8002-00-00	heat sheet 2	1
29	1-2961-8003-00-00	heat sheet 3	1
28	1-2701-8031-00-00	insulating_plaster_5	1
27	1-2701-8028-00-00	PC sheet_4	1
26	3-W240-1700-37-02	ANTENNA	1
25	1-2701-8009-00-00	PC sheet_3	1
24	3-W22X-0118-01-00	SIRIUS WIRE	1
23	3-W22X-0096-00-00	AUDIO&VIDEO OUT WIRE	1
22	1-2701-8016-00-00	insulating_plaster	1
21	1-2701-8030-00-00	insulating_plaster_5	3
20	1-9810-2001-00-00	bkt_middle	1
19	SLC2067	core	1
18	1-2701-2011-01-00	front_bkt	1
17	1-9850-2213-00-00	FPC shaft	1
16	3-WF07-0004-52-00	FPC	1
15	1-2701-6006-00-01	screw;M2.0X2.0	2
14	1-2701-4005-00-01	screw_pole_1	2
13	1-9810-2004-01-00	rear_bkt	1
12	1-2701-6019-00-01	screw;M2.6X15.0	2
11	1-2941-2005-03-00	fan_cover	1
10	3-M83X-12TL-17-00	fan	1
9	1-2810-2207-00-00	fan-cover2	1
8	1-2701-6018-00-01	screw;M2.6X24.0	2
7	1-2701-6017-00-01	screw;M2.6X12.0	2
6	1-2941-7001-03-00	heat_plate	1
5	1-9810-2005-00-00	PCB_rear_bkt_1	1
4	P-9810-0658-R4-C4	Main PCB	1
3	1-2701-6012-00-03	screw;M2.6X3.5	10
2	1-2701-2015-00-00	IC shaft	1
1	1-2810-2007-01-00	PCB_rear_bkt	1
NO.	PART NO.	DESCRIPTION	QTY



11	1.050.0002.00.00	110.0002	2	1.050.0002.00.00	gear, shaft 1	1
12	1.050.0004.00.00	110.0004	2	1.050.0004.00.00	gear, shaft 2	1
13	1.050.0006.00.00	110.0006	2	1.050.0006.00.00	gear, shaft 3	1
14	1.050.0008.00.00	110.0008	2	1.050.0008.00.00	gear, shaft 4	1
15	1.050.0010.00.00	110.0010	2	1.050.0010.00.00	gear, shaft 5	1
16	1.050.0012.00.00	110.0012	2	1.050.0012.00.00	gear, shaft 6	1
17	1.050.0014.00.00	110.0014	2	1.050.0014.00.00	gear, shaft 7	1
18	1.050.0016.00.00	110.0016	2	1.050.0016.00.00	gear, shaft 8	1
19	1.050.0018.00.00	110.0018	2	1.050.0018.00.00	gear, shaft 9	1
20	1.050.0020.00.00	110.0020	2	1.050.0020.00.00	gear, shaft 10	1
21	1.050.0022.00.00	110.0022	2	1.050.0022.00.00	gear, shaft 11	1
22	1.050.0024.00.00	110.0024	2	1.050.0024.00.00	gear, shaft 12	1
23	1.050.0026.00.00	110.0026	2	1.050.0026.00.00	gear, shaft 13	1
24	1.050.0028.00.00	110.0028	2	1.050.0028.00.00	gear, shaft 14	1
25	1.050.0030.00.00	110.0030	2	1.050.0030.00.00	gear, shaft 15	1
26	1.050.0032.00.00	110.0032	2	1.050.0032.00.00	gear, shaft 16	1
27	1.050.0034.00.00	110.0034	2	1.050.0034.00.00	gear, shaft 17	1
28	1.050.0036.00.00	110.0036	2	1.050.0036.00.00	gear, shaft 18	1
29	1.050.0038.00.00	110.0038	2	1.050.0038.00.00	gear, shaft 19	1
30	1.050.0040.00.00	110.0040	2	1.050.0040.00.00	gear, shaft 20	1
31	1.050.0042.00.00	110.0042	2	1.050.0042.00.00	gear, shaft 21	1
32	1.050.0044.00.00	110.0044	2	1.050.0044.00.00	gear, shaft 22	1
33	1.050.0046.00.00	110.0046	2	1.050.0046.00.00	gear, shaft 23	1
34	1.050.0048.00.00	110.0048	2	1.050.0048.00.00	gear, shaft 24	1
35	1.050.0050.00.00	110.0050	2	1.050.0050.00.00	gear, shaft 25	1
36	1.050.0052.00.00	110.0052	2	1.050.0052.00.00	gear, shaft 26	1
37	1.050.0054.00.00	110.0054	2	1.050.0054.00.00	gear, shaft 27	1
38	1.050.0056.00.00	110.0056	2	1.050.0056.00.00	gear, shaft 28	1
39	1.050.0058.00.00	110.0058	2	1.050.0058.00.00	gear, shaft 29	1
40	1.050.0060.00.00	110.0060	2	1.050.0060.00.00	gear, shaft 30	1
41	1.050.0062.00.00	110.0062	2	1.050.0062.00.00	gear, shaft 31	1
42	1.050.0064.00.00	110.0064	2	1.050.0064.00.00	gear, shaft 32	1
43	1.050.0066.00.00	110.0066	2	1.050.0066.00.00	gear, shaft 33	1
44	1.050.0068.00.00	110.0068	2	1.050.0068.00.00	gear, shaft 34	1
45	1.050.0070.00.00	110.0070	2	1.050.0070.00.00	gear, shaft 35	1
46	1.050.0072.00.00	110.0072	2	1.050.0072.00.00	gear, shaft 36	1
47	1.050.0074.00.00	110.0074	2	1.050.0074.00.00	gear, shaft 37	1
48	1.050.0076.00.00	110.0076	2	1.050.0076.00.00	gear, shaft 38	1
49	1.050.0078.00.00	110.0078	2	1.050.0078.00.00	gear, shaft 39	1
50	1.050.0080.00.00	110.0080	2	1.050.0080.00.00	gear, shaft 40	1
51	1.050.0082.00.00	110.0082	2	1.050.0082.00.00	gear, shaft 41	1
52	1.050.0084.00.00	110.0084	2	1.050.0084.00.00	gear, shaft 42	1
53	1.050.0086.00.00	110.0086	2	1.050.0086.00.00	gear, shaft 43	1
54	1.050.0088.00.00	110.0088	2	1.050.0088.00.00	gear, shaft 44	1
55	1.050.0090.00.00	110.0090	2	1.050.0090.00.00	gear, shaft 45	1
56	1.050.0092.00.00	110.0092	2	1.050.0092.00.00	gear, shaft 46	1
57	1.050.0094.00.00	110.0094	2	1.050.0094.00.00	gear, shaft 47	1
58	1.050.0096.00.00	110.0096	2	1.050.0096.00.00	gear, shaft 48	1
59	1.050.0098.00.00	110.0098	2	1.050.0098.00.00	gear, shaft 49	1
60	1.050.0100.00.00	110.0100	2	1.050.0100.00.00	gear, shaft 50	1
61	1.050.0102.00.00	110.0102	2	1.050.0102.00.00	gear, shaft 51	1
62	1.050.0104.00.00	110.0104	2	1.050.0104.00.00	gear, shaft 52	1
63	1.050.0106.00.00	110.0106	2	1.050.0106.00.00	gear, shaft 53	1
64	1.050.0108.00.00	110.0108	2	1.050.0108.00.00	gear, shaft 54	1
65	1.050.0110.00.00	110.0110	2	1.050.0110.00.00	gear, shaft 55	1
66	1.050.0112.00.00	110.0112	2	1.050.0112.00.00	gear, shaft 56	1
67	1.050.0114.00.00	110.0114	2	1.050.0114.00.00	gear, shaft 57	1
68	1.050.0116.00.00	110.0116	2	1.050.0116.00.00	gear, shaft 58	1
69	1.050.0118.00.00	110.0118	2	1.050.0118.00.00	gear, shaft 59	1
70	1.050.0120.00.00	110.0120	2	1.050.0120.00.00	gear, shaft 60	1
71	1.050.0122.00.00	110.0122	2	1.050.0122.00.00	gear, shaft 61	1
72	1.050.0124.00.00	110.0124	2	1.050.0124.00.00	gear, shaft 62	1



13	1-2701-2016-01-00	switch_shaft	1
12	1-2701-2006-00-00	slote_right	1
11	1-2701-3011-01-00	RACK_RIGHT	1
10	1-2701-6015-00-02	screw;M2. 0X3.0	2
9	1-2701-3012-01-00	RACK_left	1
8	1-2701-2005-00-00	slote_left	1
7	1-2701-4014-00-01	screw_pole_slote	2
6	1-2701-3014-00-00	slote_left_pla	1
5	1-2701-6013-00-01	screw;M3. 0X2.5	4
4	1-9810-2002-00-00	bottom	1
3	1-2701-8010-00-00	EVA_sheet	2
2	1-2701-6006-00-01	screw;M2. 0X2.0	5
1	1-2701-3013-00-00	slote_right_pla	1
NO.	PART NO.	DESCRIPTION	QTY

■ ELECTRICAL PARTS LIST

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
1	3-CC35-0102-4X-0S	CHIP CAP	C505	1
2	3-CC35-0104-6Y-0S	CHIP CAP	C501 C502 C503 C506 C4	5
3	3-CC35-0105-6Y-0S	CHIP CAP	C5 C6	2
4	3-CC5X-0106-6Y-0S	CHIP CAP	C507	1
5	3-CES2-0227-52-0S	SMT E-CAP	C513	1
6	3-DED0-0RED-0S-0S	LED	D1 D2 D3 D9 D10 D518	6
7	3-DED0-BLUE-01-0S	LED	D501 D502 D503 D504 D509 D511 D512 D513 D514 D4 D5 D6 D7 D8 D11 D14	16
8	3-JF30-00R5-08-30	SOCKET	CON1	1
9	3-KEEC-11EC-07-10	ENCODER SW	EN501 EN502	2
10	3-KT11-0150-4W-SS	0	SW501 SW502 SW503 SW505 SW509 SW510	6
11	3-L8SX-0101-K0-0S	WIRE WIND IND.	L501	1
12	3-QMBT-3904-0N-6S	TRAN	Q1 Q3	2
13	3-RS31-0000-J0-0S	CHIP RES	R504 R549 L1 L2	2
14	3-RS31-001K-F0-0S	CHIP RES	R18 R1297	2
15	3-RS31-001K-J0-0S	CHIP RES	R505 R506 R517	3
16	3-RS31-010K-F0-0S	CHIP RES	R502	1
17	3-RS31-010K-J0-0S	CHIP RES	R19	1
18	3-RS31-01K2-F0-0S	CHIP RES	R520	1
19	3-RS31-01K5-F0-0S	CHIP RES	R521	1
20	3-RS31-020K-J0-0S	CHIP RES	R17 R507	2
21	3-RS31-02K2-F0-0S	CHIP RES	R523	1
22	3-RS31-100R-F0-0S	CHIP RES	R20 R22	2
23	3-RS31-180R-F0-0S	CHIP RES	R524	1
24	3-RS31-200R-F0-0S	CHIP RES	R519	1
25	3-RS31-270R-F0-0S	CHIP RES	R12	1
26	3-RS31-470R-J0-0S	CHIP RES	R1-6 R8 R11 R13-16 R509 R530 R531 R532 R533 R538 R540 R541 R542 R543 R1285	23
27	3-RS31-047K-F0-0S	CHIP RES	R21	1
28	3-DJ00-IRMS-38-00	IRM-SVG38A	U501	1
29	3-DKA0-4148-00-0S	SW DIODE	D12 D13 D15	3
30	3-J104-0125-08-30	SOCKET	CON11	1
31	3-DEX0-22SU-RS-BS	LED	D1231	1
33	3-CC23-0010-30-0S	CHIP CAP	C319 C322 C325 C328	4
34	3-CC25-0151-30-0S	CHIP CAP	C318 C321 C327 C430 C320 C323C326 C329	8
35	3-CC33-0474-44-0S	CHIP CAP	C96 C98	2
36	3-CC35-0050-80-0S	CHIP CAP	C298	1
37	3-CC35-0100-30-0S	CHIP CAP	C39 C285 C175	3
38	3-CC35-0101-30-0S	CHIP CAP	C207 C219 C228	3
39	3-CC35-0102-30-0S	CHIP CAP	C188 C227 C249 C282 C287 C289 C388 R423	8
40	3-CC35-0103-4X-0S	CHIP CAP	C38 C52 C87 C89 C112 C114 C115 C119 C121 C123 C124 C125 C126 C127 C128 C129 C137 C138 C139 C140 C141 C142 C154 C155 C156 C157 C160 C161 C162 C165 C167 C174 C186 C192 C193 C194 C213 C239 C240 C252 C300 C308 C311 C432 C434 C172 C185 C220 C290 C291 C293 C294 C295 C302 C409 C226	56

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
41	3-CC35-0104-4X-0S	CHIP CAP	C3 C4 C5 C9 C20 C21 C41 C48 C49 C80 C85 C95 C117 C118 C120 C130 C147 C153 C178 C179 C180 C181 C182 C183 C190 C191 C195 C196 C210 C216 C225 C229 C231 C260 C275 C276 C277 C278 C279 C280 C281 C306 C331 C401 C408 C423 C426 C427 C429 C436 C442 C453 C474 C292 C338 C371 C204 C113 C212	59
42	3-CC35-0105-6Y-0S	CHIP CAP	C1 C2 C22 C23 C24 C25 C26 C27 C30 C31 C32 C42 C45 C51 C55 C56 C57 C59 C63 C92 C93 C100 C109 C110 C111 C132 C133 C134 C143 C145 C146 C148 C158 C159 C168 C173 C198 C203 C86 C91 C214 C254 C258 C259 C264 C286 C309 C310 C312 C355 C356 C402 C404 C415 C454 C33 C104 C71 C136	59
43	3-CC35-0121-30-0S	CHIP CAP	C149 C150 C151 C152	4
44	3-CC35-0150-30-0S	CHIP CAP	C10 C11 C12 C13 C40 C72 C73 C74 C131 C417 C418 C283 C205 C200	14
45	3-CC35-0151-30-0S	CHIP CAP	C217	1
46	3-CC35-0152-4X-0S	CHIP CAP	C187 C189 C197 C199	4
47	3-CC35-0220-30-0S	CHIP CAP	C88 C101 C222 C223 C303 C304 C99 C102	8
48	3-CC35-0222-4X-0S	CHIP CAP	C97	1
49	3-CC35-0223-4X-0S	CHIP CAP	C201 C208 C221	3
50	3-CC35-0273-4X-0S	CHIP CAP	C176 C209	2
51	3-CC35-0333-4X-0S	CHIP CAP	C103 C106	2
52	3-CC35-0330-30-0S	CHIP CAP	C6 C288	2
53	3-CC35-0471-30-0S	CHIP CAP	C230 C233	2
54	3-CC35-0561-30-0S	CHIP CAP	C377	1
55	3-CC35-0681-30-0S	CHIP CAP	C94	1
56	3-CC35-0822-4X-0S	CHIP CAP	C169 C170	2
57	3-CC43-0106-6Y-0S	CHIP CAP	C14 C15 C19 C34 C50 C60 C61 C62 C64 C65 C67 C68 C79 C135 C238 C245 C246 C250 C256 C37 C53 C66 C70 C75 C76 C77 C78 C81 C83 C84 C116 C144 C164 C171 C437 C439 C441 C35 C69 C43 C44 C206	42
58	3-CC5X-0106-6Y-0S	CHIP CAP	C18 C28 C58 C184	4
59	3-CC43-0225-44-0S	CHIP CAP	C299	1
60	3-CC43-0475-44-0S	CHIP CAP	C105 C431	2
61	3-CC35-0680-30-0S	CHIP CAP	C82 C122	2
62	3-CC57-04U7-5X-0S	CHIP CAP	C411 C410	2
63	3-CC65-0226-6Y-0S	CHIP CAP	C29 C36 C46 C47 C54 C163 C202 C336 C166	9
64	3-CE16-0688-52-00	INSERT E-CAP	TC78	1
65	3-CE17-0228-52-00	INSERT E-CAP	TC27	1
66	3-CE32-0107-52-MS	SMDE-CAP	TC2 TC9	2
67	3-CES2-0108-52-0S	SMT E-CAP	TC15 TC17	2
68	3-CES5-0107-52-OH	Smt-Cap	TC45 TC70 TC74 TC132 TC157 TC158	6
69	3-CES5-0108-52-00	SMT E-CAP	TC65	1
70	3-CES5-0476-52-OH	Smt-Cap	TC6 TC7 TC24 TC56 TC57 TC79 TC140	7

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
71	3-CES9-0105-52-0S	SMT E-CAP	TC92	1
72	3-CES9-0335-52-0S	SMT E-CAP	TC91	1
73	3-CES9-0474-52-0S	SMT E-CAP	TC55	1
74	3-CTB2-0107-54-0S	CHIP TAN CAP	TC50 TC81	2
75	3-CTB3-0476-54-0S	CHIP TAN CAP	TC1 TC8 TC13 TC131 TC133 TC156 TC10 TC12 TC14 TC72 TC103	11
76	3-CTB5-0106-54-0S	CHIP TAN CAP	TC99 TC100	2
77	3-CTC3-0107-54-0S	CHIP TAN CAP	TC11 TC16 TC111 TC136 TC101 TC3	6
78	3-DKA0-4148-00-0S	SW DIODE	D7 D10 D11 D30 D32 D46 D54 D55 D66 D67 D68 D69 D1 D2 D4 D5 D6 D8 D9 D12 D13 D17 D20 D25 D27 D33 D35 D37 D3 D19 D21 D22 D26 D60 D28 D49 D15 D16	38
79	3-DRB0-4004-00-0S	REC DIODE	D14 D53 D63 D64 D61	5
80	3-DRX0-5404-00-0S	REC DIODE	D23 D24	2
81	3-DRX0-SK34-00-0S	SOCK. DIODE	D51	1
82	3-DZA3-0010-00-0S	ZENER	ZD1 ZD2 ZD3 ZD13 ZD23 ZD24 ZD25 ZD27 ZD28 ZD29 ZD36 ZD37	12
83	3-DZA3-0012-00-0S	ZENER	ZD6 ZD7	2
84	3-DZA3-0018-00-0S	ZENER	ZD33	1
85	3-DZA3-05V1-00-0S	ZENER	ZD8	1
86	3-DZA3-03V3-00-0S	ZENER	ZD21 ZD22 ZD26	3
87	3-DZA3-05V6-00-0S	ZENER	ZD9	1
88	3-DZA3-06V8-00-0S	ZENER	ZD4 ZD5 ZD10 ZD12 ZD14 ZD15 ZD16 ZD17 ZD18 ZD19 ZD20	11
89	3-F300-01A1-03-0S	fuse	FU1 FU2 FU3 FUS FU9 FU4	6
90	3-J102-MT00-00-30	SOCKET	IC5	1
91	3-J104-0125-07-30	SOCKET	CON12	1
92	3-J104-0125-08-30	SOCKET	CON10	1
93	3-J110-0125-07-30	SOCKET	CON2	1
94	3-J112-0125-08-30	SOCKET	CON5	1
95	3-J114-0125-08-30	SOCKET	CON3	1
96	3-J180-00R8-08-20	SOCKET	CON1	1
97	3-J218-5018-52-00	PLUG	CON27	1
98	3-JF07-00R5-02-30	FFC CON.	J1	1
99	3-JF12-00R5-02-31	FFC CON.	CON7	1
100	3-JF30-00R5-02-30	FFC CON.	CON9	1
101	3-JF52-00R5-02-30	FFC CON.	CON6 CON11	2
102	3-L25X-0100-K0-0S	CHIP INDUCTANCE	L51	1
103	3-L25X-01L1-K0-0S	CHIP INDUCTANCE	L7 L10 L11 L39	4
104	3-L4S0-0101-CD-43	POWER INDUCTANCE	L37	1
105	3-L4S0-0471-CD-43	POWER INDUCTANCE	L2 FB20	2
106	3-L7XX-1420-EE-0S	CMRR COIL	ACCOM1 ACCOM2	2
107	3-L85X-0150-K0-0S	WIRE WIND IND.	L13 L36	2
108	3-L4S0-015U-H1-24	Chip-Inductance	L4	1
109	3-L8SX-0101-K0-0S	WIRE WIND IND.	L25 L30	2
110	3-LA30-182R-00-1S	CHIP BEAD	FB1 FB2 FB3 FB4 FB6 FB7 FB8 FB15 FB28 FB34 FB35 FB39 FB40 FB58 FB64 FB66 FB68 FB69 FB70 FB71 FB72 FB73 FB74 FB86 FB91 FB94 FB95 FB127 FB129 FB5 FB12 FB16 FB17 FB19 R370 R371	36
111	3-LA30-601R-G0-0S	CHIP BEAD	FB18 FB26 FB31 FB32 FB33 FB36 FB37 FB43 FB137 FB138 FB139 FB140 FB141 FB142	14
112	3-LA5X-601R-G0-0S	CHIP BEAD	L31 L5	2
113	3-LA6X-060R-00-0S	CHIP BEAD	L34 FB13 L3 L38 L18 L54 L32 L1	8
114	3-M300-H400-00-10	Buzzer	BUZ1	1
116	3-Q0BT-2907-0P-6S	IRAN	Q18 Q22	2

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
117	3-Q0KR-A304-0P-6S	TRAN	Q51 Q52 Q53 Q65 Q72 Q73	6
118	3-Q0KR-C402-0N-6S	TRAN	Q13 Q28 Q48 Q19 Q31 Q36 Q41 Q42 Q43 Q55 Q56 Q60 Q61 Q66 Q32	15
119	3-QDTC-314T-0N-6S	TRANSISTOR	TC22 TC26 TC36 TC37 TC43 TC44	6
120	3-QIRF-7205-PM-6S	MOSFET	IC31 IC57	2
121	3-QIRL-6402-PM-6S	MOSFET	Q54	1
122	3-QKTA-1718-0P-6S	TRAN	Q16	1
123	3-QKTA-2014-0P-6S	TRAN	Q17	1
124	3-QKTC-2020-0N-6S	TRAN	Q37	1
125	3-QKTD-1624-0N-6S	TRAN	Q24 Q49	2
126	3-QMBT-3904-0N-6S	TRAN	Q14 Q15 Q23 Q2 Q3 Q7 Q9 Q12 Q20 Q25 Q26 Q30 Q35 Q64 Q45 Q46 Q47 Q62 Q63 Q57 Q39 Q38 Q8 Q5	24
127	3-QMBT-3906-0P-6S	TRAN	Q1 Q4 Q10 Q21 Q27 Q29 Q68 Q70 Q71	9
128	3-RS21-075R-F0-0S	CHIP NET RES	R25 R27 R84 R490 R492 R493 R494 R496	8
129	3-RS21-047R-J0-0S	CHIP RES	R138	1
130	3-RS31-0000-J0-0S	CHIP RES	R15 R24 R77 R126 R269 R308 R314 R337 R436 R559 R563 R593 R631 R668 R103 FB11 R437 FB14 R79 R198 R214 R241 R722 R724	24
131	3-RS31-001K-F0-0S	CHIP RES	R444 R448 R153 R154 R155 R156 R157	7
132	3-RS31-01K8-F0-0S	CHIP RES	R65 R66 R67 R69	4
133	3-RS31-01K2-F0-0S	CHIP RES	R68	1
134	3-RS31-001K-J0-0S	CHIP RES	R64 R71 R85 R128 R132 R150 R205 R207 R274 R276 R322 R327 R336 R338 R415 R416 R462 R463 R489 R495 R511 R532 R534 R538 R539 R543 R547 R549 R553 R561 R589 R594 R596 R597 R603 R607 R710 R417	38
135	3-RS31-001M-J0-0S	CHIP RES	R445 R481	2
136	3-RS31-002K-F0-0S	CHIP RES	R517	1
137	3-RS31-010K-F0-0S	CHIP RES	R38 R54 R407 R473	4
138	3-RS31-010K-J0-0S	CHIP RES	R20 R41 R44 R80 R144 R163 R165 R177 R178 R179 R202 R323 R251 R257 R261 R262 R271 R275 R277 R282 R318 R321 R339 R344 R384 R400 R403 R432 R447 R454 R457 R487 R488 R573 R575 R633 R635 R636 R755 R761 R783 R784 R611 R772 R105 R130 R131 R81 R72 R76 R107 R111 R112 R113 R696	55
139	3-RS31-010R-J0-0S	CHIP RES	R558 R48	2
140	3-RS31-011K-F0-0S	CHIP RES	R33 R39 R42	3
141	3-RS31-012K-J0-0S	CHIP RES	R435 R8	2
142	3-RS31-015K-J0-0S	CHIP RES	R6 R312 R376 R377	4
143	3-RS31-018K-J0-0S	CHIP RES	R136	1
144	3-RS31-018R-J0-0S	CHIP RES	R439 R440	2
145	3-RS31-020K-F0-0S	CHIP RES	R443 R525	2
146	3-RS31-020K-J0-0S	CHIP RES	R9 R16 R28 R133 R200 R263 R317 R334 R420 R260	10
147	3-RS31-022K-J0-0S	CHIP RES	R201 R500 R502 R503 R521 R524 R528	7

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
148	3-RS31-024K-J0-0S	CHIP RES	R351	1
149	3-RS31-027K-F0-0S	CHIP RES	R3 R272 R36 R53 R566	5
150	3-RS31-02K2-J0-0S	CHIP RES	R109 R253	2
151	3-RS31-02K7-J0-0S	CHIP RES	R7	1
152	3-RS31-030K-J0-0S	CHIP RES	R2 R21 R86 R106 R174 R637 R768	7
153	3-RS31-033K-J0-0S	CHIP RES	R499 R501 R504 R522 R523 R527	6
154	3-RS31-033R-J0-0S	CHIP RES	R32 R117 R590 R591 R592	5
155	3-RS31-039K-F0-0S	CHIP RES	R311 R330	2
156	3-RS63-039K-J0-0S	CHIP RES	R256	1
157	3-RS95-0000-J0-0S	CHIP RES	R122 R114 R139	3
158	3-RS31-03K3-J0-0S	CHIP RES	R23	1
159	3-RS31-03K9-J0-0S	CHIP RES	R26 R78 R203 R204	4
160	3-RS31-047K-J0-0S	CHIP RES	R37 R110 R192 R233 R252 R273 R279 R281 R347 R632	10
161	3-RS31-04K7-J0-0S	CHIP RES	R17 R18 R22 R97 R98 R116 R121 R190 R191 R238 R248 R305 R319 R383 R472 R486 R526 R540 R560 R787 R101 R102 R45 R46 R74 R75 R62 R399 R357 R434 R245 R247	32
162	3-RS31-04R3-F0-0S	CHIP RES	R83 R87	2
163	3-RS31-04R7-J0-0S	CHIP RES	R469 R129	2
164	3-RS31-051K-J0-0S	CHIP RES	R182 R183 R184 R185	4
165	3-RS31-051K-F0-0S	CHIP RES	R333	1
166	3-RS31-056K-J0-0S	CHIP RES	R10	1
167	3-RS31-056R-J0-0S	CHIP RES	R485	1
168	3-RS31-05K6-J0-0S	CHIP RES	R513 R514 R557 R441	4
169	3-RS31-06K2-J0-0S	CHIP RES	R255 R259	2
170	3-RS31-075R-J0-0S	CHIP RES	R63 R73 R148 R424 R477 R479 R628 R629 R59 R60 R61 R621 R620 R622 R92 R99 R100 R581 FB10	19
171	3-RS31-091R-J0-0S	CHIP RES	R89 R90	2
172	3-RS31-100K-J0-0S	CHIP RES	R14 R34 R134 R186 R187 R188 R189 R254 R270 R315 R328 R782	12
173	3-RS31-100K-F0-0S	CHIP RES	R332	1
174	3-RS31-100R-J0-0S	CHIP RES	R57 R58 R91 R93 R94 R95 R96 R151 R152 R166 R289 R290 R366 R369 R379 R380 R409 R412 R413 R414 R776 R777 R1061 R1062	24
175	3-RS31-150R-J0-0S	CHIP RES	R585	1
176	3-RS31-15K4-F0-0S	CHIP RES	R483	1
177	3-RS31-180K-J0-0S	CHIP RES	R284 R304 R320	3
178	3-RS31-270K-F0-0S	CHIP RES	R349	1
179	3-RS31-200K-J0-0S	CHIP RES	R31	1
180	3-RS31-220K-J0-0S	CHIP RES	R135	1
181	3-RS31-220R-F0-0S	CHIP RES	R82 R88 R47	3
182	3-RS31-220R-J0-0S	CHIP RES	R5 R35 R40 R119 R120 R390 R397 R402 R404 R442 R455	11
183	3-RS31-300R-J0-0S	CHIP RES	R210 R316 R367 R368 R378 R408	6
184	3-RS31-330K-J0-0S	CHIP RES	R309 R115 R118	3
185	3-RS31-392R-F0-0S	CHIP RES	R478	1
186	3-RS31-470R-F0-0S	CHIP RES	R51 R52	2
187	3-RS31-470R-J0-0S	CHIP RES	R1 R4 R19 R108	4
188	3-RS52-0000-J0-0S	CHIP REC	L52 L33 L43	3
189	3-RS52-001R-J0-0S	CHIP RES	R29 R30 R43 R49 R55 R56	6
190	3-RS31-022R-J0-0S	CHIP RES	R660 R661	2
191	3-RS52-010R-J0-0S	CHIP RES	R604	1
192	3-RS52-330R-J0-0S	CHIP RES	R13 R194	2
193	3-RS63-0000-J0-0S	CHIP RES	R137	1

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
194	3-RS63-002R-J0-0S	CHIP RES	R11 R12 R70 R342 R1060	5
195	3-RS63-470R-J0-0S	CHIP RES	R310	1
196	3-RS63-04K7-J0-0S	CHIP RES	R283 R331	2
197	3-RS63-100K-F0-0S	CHIP RES	R506	1
198	3-RS63-100R-J0-0S	CHIP RES	R127 R199	2
199	3-RS95-001K-J0-0S	CHIP RES	R125 R213	2
200	3-U00D-5954-00-XS	DRIVER	IC4	1
201	3-U00D-6849-00-XS	DRIVER	IC3	1
202	3-U0AD-8092-00-9S	AMPLIFIER	U304	1
203	3-U0BA-3121-F0-9S	INSULATE OP	IC1 IC2 IC8 IC37	4
204	3-U0BA-6951-FS-AS	MOTOR DRIVER	IC24	1
205	3-U0BA-7071-00-9S	SYNC SEPARATE	IC15	1
206	3-U0BU-9451-KV-XS	IPOD AUTHENTICATION	IC39	1
207	3-U0CS-4344-CZ-XS	IC	IC11	1
208	3-U0LD-1117-18-0S	REGULATOR	IC38	1
209	3-U0LD-1117-33-0S	REGULATOR	IC59	1
210	3-U0LP-2950-00-9S	IC	IC63	1
211	3-U0MP-4461-00-XS	DC/DC REG	MPS1	1
212	3-U0RT-9193-15-DS	LDO	U14	1
213	3-U0TL-431A-00-0S	BASE SOURCE	ZD11	1
214	3-U0WM-8522-00-AS	IC	IC19	1
215	3-U0XC-6401-37-0S	DUAL LDO	IC60	1
216	3-U4HC-4052-PW-BS	ELEC SW	IC44 IC55	2
217	3-U4HC-4094-PW-BS	SHIFT REG	IC29 IC30 IC46	3
218	3-U57V-6416-20-RS	SDRAM	IC50	1
219	3-UAT2-4C16-00-9S	EEPROM	IC51	1
220	3-UFMS-6501-00-AS	VIDEO SWITCH	IC45	1
221	3-UFSU-SB30-00-XS	USB 2.0 SWITCH	IC13 IC52	2
222	3-UMFI-2162-00-0S	AUTHENTICATION	IC9	1
223	3-UNJM-2505-00-XS	VIDEO ISOLATION	IC35 IC40 IC41	3
224	3-UNJM-2792-00-AS	IC	IC25 IC28	2
225	3-US29-AL01-6D-XS	flash memory	IC42	1
226	3-USST-39VF-16-0S	FLASH	IC21	1
227	3-USTM-8AF5-CY-XS	MCU	IC61	1
228	3-UTDA-7388-00-70	POWER AMP	IC23	1
229	3-UTDA-7419-00-XS	ASP IC	IC305	1
230	3-UZR3-6966-U0-CS	SINGLE CHIP	IC48	1
233	3-XQ06-008M-00-3S	Crystal	Y6	1
234	3-XQ0X-027M-00-2S	CRVSTAL	Y1	1
235	3-XQ0X-24M5-76-6S	CRVSTAL	X2	1
236	3-XQ0X-33M8-68-6S	CRVSTAL	X1	1
237	3-Z2TC-TL26-CR-R0	Tuner	FM/AM TUNER	1
238	3-Z800-0LEA-5S-00	GPS MODEL	IC22	1
239	3-LCCM-2012-2P-0S		U1 U2	2
240	3-M82X-12TS-10-00	FAN		1
241	3-DXX0-6801-00-0S	DIODE	ESD1	1
242	3-J330-SMBA-08-10	FAKRA-CONUECTOR	ANT2	1
243	3-B325-0660-R1-00	PCB		1
244	3-JCKX-3532-07-00	3.5PHONE-JACKS	CON1	1
245	3-B322-0651-R1-00	PCB		1
246	3-DED0-BLUE-01-0S	LED	D401 D402 D403 D404	4
247	3-JF06-00R5-02-30	FFC CON.	CON401	1
248	3-RS31-01K5-F0-0S	CHIP RES	R405	1
249	3-RS31-130R-F0-0S	CHIP RES	R406	1
250	3-RS31-680R-J0-0S	CHIP RES	R401 R402 R403 R404	4
251	3-KT11-0001-00-SS		SW401 SW402 SW403 SW404	4
252	3-RS63-100R-J0-0S	CHIP RES	R411	1
253	3-CC35-0103-4X-0S	CHIP CAP	C401	1
254	3-RS31-01K8-F0-0S	CHIP RES	R407	1
255	3-RS31-02K7-F0-0S	CHIP RES	R409	1
256	3-RS31-470R-F0-0S	CHIP RES	R408	1
257	3-RS31-680R-F0-0S	CHIP RES	R410	1
258	3-PBMS-0409-W1-00	WHITE BACKLIGHT	U401	1
261	3-CC35-0103-4X-0S	CHIP CAP	C19	1
262	3-CC35-0104-6Y-0S	CHIP CAP	C16	1
263	3-CC65-0226-6Y-0S	CHIP CAP	C60-61	2
264	3-DED0-BLUE-01-0S	LED	D101-103	3
265	3-J100-SM02-B0-30	SOCKET	CON102	1
266	3-JF14-00R5-04-30	FFC CON.	CON101	1
267	3-KTTS-1107-GS-SS	TACT SW	SW101-103	3

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
268	3-RS31-0000-J0-0S	CHIP RES	R1	1
269	3-RS52-01R1-P0-0S	CHIP-RES	R24	1
270	3-RS31-001K-J0-0S	CHIP RES	R105-107	3
271	3-RS31-010K-J0-0S	CHIP RES	R104 R21	2
272	3-RS31-027K-J0-0S	CHIP RES	R109	1
273	3-RS31-02K2-J0-0S	CHIP RES	R110	1
274	3-RS31-05K1-J0-0S	CHIP RES	R102	1
275	3-RS31-100K-J0-0S	CHIP RES	R16	1
276	3-RS31-510R-F0-0S	CHIP RES	R103 R108	2
277	3-RS31-010K-F0-0S	CHIP RES	R22	1
278	3-L8S0-0100-NX-00	INDUCTOR	L6	1
279	3-DSX0-SK34-00-0S	SOCK. DIODE	D1	1
280	3-U0MP-2481-DH-XS	LED-DRIVER	IC5	1
281	3-CC35-0105-4X-1S	CHIP CAP	C26	1
282	3-RS31-0432-P0-0S	CHIP-RES	R2	1
283	3-CC67-0225-4X-0S	CHIP CAP	C22	1
285	3-CC35-0080-80-0S	CHIP CAP	C137	1
286	3-CC35-0100-30-0S	CHIP CAP	C72 C138	2
287	3-CC35-0101-30-0S	CHIP CAP	C113-114	2
288	3-CC35-0102-4X-0S	CHIP CAP	C71	1
289	3-CC35-0103-4X-0S	CHIP CAP	C21 C32 C43 C44 C69 C73 C82 C84-85 C93 C95 C97 C111-112	14
290	3-CC35-0104-4X-0S	CHIP CAP	C4 C5 C7 C10 C13 C15 C22 C24 C25 C26 C47 C45 C115 C117-122 C142 C144-145 C201	23
291	3-CC35-0154-4X-0S	CHIP CAP	C135	1
292	3-CC35-0222-4X-0S	CHIP CAP	C140 C102	2
293	3-CC35-0333-4X-0S	CHIP CAP	C12	1
294	3-CC35-0391-30-0S	CHIP CAP	C143	1
295	3-CC35-0473-4X-0S	CHIP CAP	C65	1
296	3-CC35-0474-6Y-0S	CHIP CAP	C70	1
297	3-CC35-0561-30-0S	CHIP CAP	C141	1
298	3-CC37-0105-4X-0S	CHIP CAP	C37 C39 C62-64 C75 C77- 79 C87 C134 C98 C100	13
299	3-CC37-0474-6Y-0S	CHIP-CAP	C103	1
300	3-CC43-0106-6Y-0S	CHIP CAP	C2-3 C23 C29 C34 C35 C36 C38 C40 -41 C50 C139 C149	13
301	3-CC67-0106-6Y-0S	CHIP CAP	C46	1
302	3-CC43-0475-4X-0S	CHIP CAP	C61 C66-68	4
303	3-CC45-0225-6Y-0S	CHIP CAP	C76	1
304	3-CC47-0225-6Y-0S	CHIP CAP	C48 C49	2
305	3-CC59-0105-4X-0S	CHIP CAP	C8	1
306	3-CC65-0226-6Y-0S	CHIP CAP	C42	1
307	3-CC67-0226-6Y-0S	CHIP CAP	C27	1
308	3-CC57-0105-4X-0S	CHIP CAP	C19 C52	2
309	3-CTA2-0476-54-0S	CHIP TAN CAP	C1 C9 C80 C96 TC4 TC10 TC18 TC38	8
310	3-CTA5-0106-54-0S	CHIP TAN CAP	TC9 TC12 TC25-26	4
311	3-CTA8-0224-54-0S	CHIP TAN CAP	C74	1
312	3-CTA5-0474-54-0S	CHIP TAN CAP	TC52 TC58	2
313	3-CTB2-0107-54-0S	CHIP TAN CAP	TC1 TC3	2
314	3-CTB5-0106-54-0S	CHIP TAN CAP	TC21 TC37	2
315	3-DCX0-A335-00-0S	VC DIODE	VD1	1
316	3-DKA0-4148-00-0S	SW DIODE	D1-2 D6 D7 D8	5
317	3-DZA3-05V1-00-0S	ZENER	ZD2-5	4
318	3-JF04-00R5-04-30	FFC CON.	CON20	1
319	3-JF06-00R5-04-30	FFC CON.	CN1	1
320	3-JF14-00R5-04-30	FFC CON.	CON9	1
321	3-JF26-00R5-04-30	FFC CON.	CON10	1
322	3-JF38-00R5-04-30	FFC CON.	CON2 CON4	2
323	3-JF52-00R5-02-30	FFC CON.	CON1	1
324	3-L4S0-0101-CD-32	POWER INDUCTANCE	L2-3 L24	3
325	3-L4S0-0220-3B-16	POWER IND	L4	1
326	3-L84X-0100-K0-0S	WIRE WIND IND.	L33	1
327	3-RS52-0000-J0-0S	CHIP REC	L6 R40 R37	3
328	3-L84X-0101-K0-0S	WIRE WIND IND.	L1 L9 L14 L18	4
329	3-L84X-01U2-K0-0S	WIRE WIND IND.	L34	1
330	3-L84X-0220-K0-0S	WIRE WIND IND.	L20 L23	2
331	3-LA30-182R-00-1S	CHIP BEAD	FB1	1

NO.	PART NO.	DESCRIPTION	REFERENCE	QTY
332	3-LA30-601R-G0-0S	CHIP BEAD	FB2 FB3 FB4 FB9	4
335	3-Q0KR-C402-0N-6S	TRAN	Q2 Q5-6	3
336	3-QIRL-6402-PM-6S	MOSFET	Q4	1
337	3-QMBT-3904-0N-6S	TRAN	Q8 Q10 Q3	3
338	3-QSTA-1663-0P-6S	TRAN	Q1 Q7 Q9	3
339	3-RS31-0000-J0-0S	CHIP RES	R30 R54 R71 R104 R113 C116 R108	7
340	3-RS31-001K-J0-0S	CHIP RES	R17-18 R26-27 R49 R52-53 R86 R134 R203-206 R209- 212	17
341	3-RS31-001M-F0-0S	CHIP RES	R60	1
342	3-RS31-001M-J0-0S	CHIP RES	R200 R237 R239	3
343	3-RS31-002K-J0-0S	CHIP RES	R7	1
344	3-RS31-003K-J0-0S	CHIP RES	R2	1
345	3-RS31-010K-J0-0S	CHIP RES	R42 R56 R58-59 R88 R98 R100 R118 R195-198 R202 R213 R223-226 R236 R4	20
346	3-RS31-018K-J0-0S	CHIP RES	R136	1
347	3-RS31-020K-J0-0S	CHIP RES	R87 R95 R114	3
348	3-RS31-024K-J0-0S	CHIP RES	R242 R22	2
349	3-RS31-02K4-F0-0S	CHIP RES	R25	1
350	3-RS31-02K4-J0-0S	CHIP RES	R234-235	2
351	3-RS31-030K-J0-0S	CHIP RES	R12 R57 R135	3
352	3-RS31-033K-J0-0S	CHIP RES	R82	1
353	3-RS31-047K-J0-0S	CHIP RES	R243	1
354	3-RS31-047R-J0-0S	CHIP RES	R21 R74 R78-81	6
355	3-RS31-04K7-J0-0S	CHIP RES	R8 R41 R46 R220-222 R240 R245 R303	9
356	3-RS31-051K-J0-0S	CHIP RES	R14	1
357	3-RS31-05K6-J0-0S	CHIP RES	R199 R201	2
358	3-RS31-068K-J0-0S	CHIP RES	R241	1
359	3-RS31-075R-J0-0S	CHIP RES	R92 R109	2
360	3-RS31-082K-J0-0S	CHIP RES	R238	1
361	3-RS31-08K2-F0-0S	CHIP RES	R23	1
362	3-RS31-100K-J0-0S	CHIP RES	R1 R105 R97	3
363	3-RS31-100R-J0-0S	CHIP RES	R15 R31 R33 R38 R39 R43 R47 R51 R61-62 R84-85 R207-208	14
364	3-RS31-200R-J0-0S	CHIP RES	R44-45	2
365	3-RS31-220K-J0-0S	CHIP RES	R83 R106	2
366	3-RS31-220R-J0-0S	CHIP RES	R193-194	2
367	3-RS31-560R-J0-0S	CHIP RES	R19 R28-29 R34-36	6
368	3-RS52-001K-J0-0S	CHIP RES	R13	1
369	3-RS63-04R7-J0-0S	CHIP RES	R178-181	4
370	3-RS95-04K7-J0-0S	CHIP RES	R11	1
371	3-U078-L05M-00-XS	REG	IC5	1
372	3-U0BA-7071-00-9S	SYNC SEPARATE	IC15	1
373	3-U0BU-4S81-00-0S	Y-GATE	IC7102	1
374	3-U0LD-1117-33-0S	REGULATOR	IC6	1
375	3-U0TB-1318-00-80	VIDED DSP	U4	1
376	3-U0TL-431A-00-0S	BASE SOURCE	ZR1-2	2
377	3-UAIC-1896-00-X0	DC-DC	U2	1
378	3-UMTV-018N-24-9S	OSD IC	U10	1
379	3-UNJM-2107-00-9S	OP	U12	1
380	3-UNJM-3414-00-9S	DUAL OP	U11	1
381	3-UPCA-2113-00-9S	LCDD DRIVER	U20	1
382	3-UUPS-0170-00-CS	TIMING CONTROL	U1	1
383	3-VR23-1030-01-0S	VR	VR1	1
384	3-VR23-4730-01-0S	VR	VR2	1
387	3-XQ14-4M43-36-3D	CRYSTAL	Y1	1