

EXPLODED VIEWS AND PARTS LIST

PACKING SECTION (Page 31)

PACKING SECTION PARTS LIST


*:Non spare part

Mark	No.	Description	DEH-S5100BT/XNUC	DEH-S5200BT/XNUC
	1	Unit Box	QHG4388	QHG4534
	2	Contain Box	QHL4388	QHL4534
	5-2	Quick Start Guide	QRD3581	QRD3759
*	5-4	Web IM	See Contents of Web IM	See Contents of Web IM

Mark	No.	Description	DEH-S510BT/XNEW5	DEH-S520BT/XNEW5
	1	Unit Box	QHG4387	QHG4533
	2	Contain Box	QHL4387	QHL4533
	5-1	Owner's Manual	QRB3772	QRB3919
	5-2	Quick Start Guide	QRD3577	QRD3754
	5-3	Quick Start Guide	QRD3578	QRD3755
*	5-4	Web IM	See Contents of Web IM	See Contents of Web IM

Mark	No.	Description	DEH-X500BT/XNCS	DEH-X5000BT/XNCS
	1	Unit Box	QHG4391	QHG4538
	2	Contain Box	QHL4391	QHL4538
	5-2	Quick Start Guide	QRD3588	QRD3760
*	5-4	Web IM	See Contents of Web IM	See Contents of Web IM
	14	Microphone Assy	CPM1109	CPM1113
	15	Holder	CZN7192	Not used
	16	Cushion	CZN7193	Not used

Mark	No.	Description	DEH-S5150BT/XNGS	DEH-S5250BT/XNGS
	1	Unit Box	QHG4390	QHG4540
	2	Contain Box	QHL4390	QHL4540
	5-1	Owner's Manual	QRD3587	Not used
	5-2	Quick Start Guide	Not used	QRD3796
*	5-4	Web IM	See Contents of Web IM	See Contents of Web IM
	14	Microphone Assy	CPM1109	CPM1113
	15	Holder	CZN7192	Not used
	16	Cushion	CZN7193	Not used



Quick Start Guide, Owner's Manual

Part No.	Language
QRD3759	English, French, Spanish(Espanol)
QRB3919	Russian
QRD3754	English, French, Italian
QRD3755	Spanish(Espanol), German, Dutch
QRD3760	English, Spanish(Espanol), Portuguese(B)
QRD3796	English, Traditional Chinese, Arabic, Persian

CONTENTS OF WEB IM

Part No.	Language
*OPM_DEHS5200BTUC_3L_A (for XNUC)	English, French, Spanish(Espanol)
*OPM_DEHS520BTEW5_6L_A (for XNEW5)	English, French, Italian, Spanish(Espanol), German, Dutch
*OPM_DEHX5000BTCS_3L_A (for XNCS)	English, Spanish(Espanol), Portuguese(B)
*OPM_DEHS5250BTGS_4L_A (for XNGS)	English, Traditional Chinese, Arabic, Persian

All operation manuals are supplied in PDF files by the WEB. No printed papers are available.

EXTERIOR SECTION (Page 33)
EXTERIOR SECTION PARTS LIST

Mark	No.	Description	DEH-S5100BT/XNUC	DEH-S5200BT/XNUC
	1	Detach Grille Assy	QXA5829	QXA6162
	2	Keyboard Unit	QWM4984	QWM5096
	7	Grille Unit	QXA5499	QXA6302
	18	Plate	QNM3230	QNM3284
	25	Knob Unit	QXA5430	QXA5429
	36	Tuner Amp Unit	QWM4914	QWM5282

Mark	No.	Description	DEH-S510BT/XNEW5	DEH-S520BT/XNEW5
	1	Detach Grille Assy	QXA5610	QXA6161
	2	Keyboard Unit	QWM4985	QWM5097
	7	Grille Unit	QXA5520	QXA6301
	18	Plate	QNM3244	QNM3286
	25	Knob Unit	QXA5430	QXA6324
	36	Tuner Amp Unit	QWM4913	QWM5281

Mark	No.	Description	DEH-X500BT/XNCS	DEH-X5000BT/XNCS
	1	Detach Grille Assy	QXA5612	QXA6166
	2	Keyboard Unit	QWM4984	QWM5082
	7	Grille Unit	QXA5522	QXA6306
	18	Plate	QNM3229	QNM3283
	36	Tuner Amp Unit	QWM4917	QWM5285

Mark	No.	Description	DEH-S5150BT/XNGS	DEH-S5250BT/XNGS
	1	Detach Grille Assy	QXA5611	QXA6168
	2	Keyboard Unit	QWM4984	QWM5096
	7	Grille Unit	QXA5521	QXA6308
	18	Plate	QNM3229	QNM3283
	25	Knob Unit	QXA5430	QXA6324
	36	Tuner Amp Unit	QWM4916	QWM5284

CD MECHANISM MODULE (Page 35)
CD MECHANISM MODULE PARTS LIST

Mark	No.	Description	DEH-S5100BT/XNUC DEH-S510BT/XNEW5 DEH-X500BT/XNCS DEH-S5150BT/XNGS	DEH-S5200BT/XNUC DEH-S520BT/XNEW5 DEH-X5000BT/XNCS DEH-S5250BT/XNGS
	20	Pickup Unit(P10.6)(Service) for CXK5807	CXX3556	CXY3639

ELECTRICAL PARTS LIST (Page 61)

Tuner Amp Unit

A

Circuit Symbol and No.	Part Name	DEH-S5100BT/XNUC	DEH-S5200BT/XNUC
IC711	RAM IC	M12L128168A-5TG2N	W9812G6KH-5
IC741	Flash ROM Unit	QVQ1051	QVQ1102
IC1302	Logic IC	TC7SH32FUS2	Not used
D1204	Zener Diode	UDZV18(B)	UDZV6R2(B)
D1205	Zener Diode	UDZV18(B)	UDZV6R2(B)
D1302	Rectifier Diode	RR1VWM4STF	Not used
L520	Chip Beads	VTL1133	Not used
P1276	Poly Switch	FSMD075-24R	Not used
R113		XRS1/16SS682J	XRS1/16SS822J
R229		XRS1/16SS3902D	RS1/16SS393J
R242		XRS1/16SS4701D	RS1/16SS4701F
R519		XRS1/16SS271J	XRS1/16SS151J
R591		XRS1/16SS361J	XRS1/16SS221J
R610		Not used	XRS1/16SS222J
R690		XRS1/16SS472J	Not used
R702		XRS1/16SS472J	XRS1/16SS152J
R857		Not used	RS1/16SS0R0J
R1305		Not used	RS1/16SS0R0J
R1309		RS1/8SQ0R0J	Not used
R1312		XRS1/16SS103J	XRS1/16SS272J
R1316		Not used	XRS1/10SR0R0J
R1416		XRS1/10SR0R0J	Not used
R1432		Not used	RS1/16SS0R0J
C246		CKSRYX104K50	Not used
C267		CKSSYB104K16	Not used
C723		CKSSYB102K50	CCSSCH120J50
C794		CCSSCH101J50	CCSSCH121J50
C855		Not used	CCSSCH7R0D50
C857		CKSSYX104K50	CCSSCH120J50
C1201		CCG1345	CKSRYB104K25
C1202		CKSSYX104K50	Not used
C1255		CKSSYB331K50	CCSSCH471J50
C1276		CKSSYB104K16	Not used
C1277		CKSSYB104K16	Not used
C1280		CKSSYB102K50	CCSSCH121J50
C1281		CKSSYB102K50	CCSSCH121J50
C1305		CKSSYB104K10	Not used
C1425		Not used	CKSRYB103K50
C1426		Not used	CKSSYB103K25

F

Circuit Symbol and No.	Part Name	DEH-S510BT/XNEW5	DEH-S520BT/XNEW5
IC711	RAM IC	M12L128168A-5TG2N	W9812G6KH-5
IC741	Flash ROM Unit	QVQ1055	QVQ1101
IC1302	Logic IC	TC7SH32FUS2	Not used
D1204	Zener Diode	UDZV18(B)	UDZV6R2(B)

Circuit Symbol and No.	Part Name	DEH-S510BT/XNEW5	DEH-S520BT/XNEW5
D1205	Zener Diode	UDZV18(B)	UDZV6R2(B)
D1302	Rectifier Diode	RR1VWM4STF	Not used
L520	Chip Beads	VTL1133	Not used
P1276	Poly Switch	FSMD075-24R	Not used
R229		XRS1/16SS3902D	RS1/16SS393J
R242		XRS1/16SS4701D	RS1/16SS4701F
R519		XRS1/16SS271J	XRS1/16SS151J
R591		XRS1/16SS361J	XRS1/16SS221J
R610		Not used	XRS1/16SS222J
R690		XRS1/16SS472J	Not used
R702		XRS1/16SS472J	XRS1/16SS152J
R857		Not used	RS1/16SS0R0J
R1305		Not used	RS1/16SS0R0J
R1309		RS1/8SQ0R0J	Not used
R1312		XRS1/16SS103J	XRS1/16SS272J
R1316		Not used	XRS1/10SR0R0J
R1416		XRS1/10SR0R0J	Not used
R1432		Not used	RS1/16SS0R0J
C246		CKSRYX104K50	Not used
C267		CKSSYB104K16	Not used
C723		CKSSYB102K50	CCSSCH120J50
C794		CCSSCH101J50	CCSSCH121J50
C855		Not used	CCSSCH7R0D50
C857		CKSSYX104K50	CCSSCH120J50
C1201		CCG1345	CKSRYB104K25
C1202		CKSSYX104K50	Not used
C1255		CKSSYB331K50	CCSSCH471J50
C1276		CKSSYB104K16	Not used
C1277		CKSSYB104K16	Not used
C1280		CKSSYB102K50	CCSSCH121J50
C1281		CKSSYB102K50	CCSSCH121J50
C1305		CKSSYB104K10	Not used
C1425		Not used	CKSRYB103K50
C1426		Not used	CKSSYB103K25

Circuit Symbol and No.	Part Name	DEH-X500BT/XNCS	DEH-X5000BT/XNCS
IC711	RAM IC	M12L128168A-5TG2N	W9812G6KH-5
IC741	Flash ROM Unit	QVQ1055	QVQ1101
IC1302	Logic IC	TC7SH32FUS2	Not used
D1204	Zener Diode	UDZV18(B)	UDZV6R2(B)
D1205	Zener Diode	UDZV18(B)	UDZV6R2(B)
D1302	Rectifier Diode	RR1VWM4STF	Not used
L520	Chip Beads	VTL1133	Not used
P1276	Poly Switch	FSMD075-24R	Not used
R113		XRS1/16SS682J	XRS1/16SS822J
R229		XRS1/16SS3902D	RS1/16SS393J

	Circuit Symbol and No.	Part Name	DEH-X500BT/XNCS	DEH-X5000BT/XNCS
A	R242		XRS1/16SS4701D	RS1/16SS4701F
	R519		XRS1/16SS271J	XRS1/16SS151J
	R538		XRS1/16SS223J	Not used
	R591		XRS1/16SS361J	XRS1/16SS221J
	R610		Not used	XRS1/16SS222J
B	R690		XRS1/16SS472J	Not used
	R702		XRS1/16SS472J	XRS1/16SS152J
	R1208		XRS1/10SR0R0J	RS1/10SR131J
	R1305		Not used	RS1/16SS0R0J
	R1309		RS1/8SQ0R0J	Not used
C	R1312		XRS1/16SS103J	XRS1/16SS272J
	R1316		Not used	XRS1/10SR0R0J
	R1416		XRS1/10SR0R0J	Not used
	R1432		Not used	RS1/16SS0R0J
	C246		CKSRYX104K50	Not used
D	C267		CKSSYB104K16	Not used
	C723		CKSSYB102K50	CCSSCH120J50
	C774		CCSSCH151J50	CCSSCH390J50
	C775		CCSSCH151J50	CCSSCH390J50
	C794		CCSSCH101J50	CCSSCH121J50
E	C855		Not used	CCSSCH7R0D50
	C857		CKSSYX104K50	CCSSCH120J50
	C1201		CCG1345	CKSRYB104K25
	C1202		CKSSYX104K50	Not used
	C1255		CKSSYB331K50	CCSSCH471J50
F	C1276		CKSSYB104K16	Not used
	C1277		CKSSYB104K16	Not used
	C1280		CKSSYB102K50	CCSSCH121J50
	C1281		CKSSYB102K50	CCSSCH121J50
	C1305		CKSSYB104K10	Not used
G	C1424		CKSRYB474K10	CCG1345
	C1425		Not used	CKSRYB103K50
	C1426		Not used	CKSSYB103K25

	Circuit Symbol and No.	Part Name	DEH-S5150BT/XNGS	DEH-S5250BT/XNGS
A	IC711	RAM IC	M12L128168A-5TG2N	W9812G6KH-5
	IC741	Flash ROM Unit	QVQ1055	QVQ1101
	D1204	Zener Diode	UDZV18(B)	UDZV6R2(B)
	D1205	Zener Diode	UDZV18(B)	UDZV6R2(B)
	L520	Chip Beads	VTL1133	Not used
B	P1276	Poly Switch	FSMD075-24R	Not used
	R113		XRS1/16SS682J	XRS1/16SS822J
	R229		XRS1/16SS3902D	RS1/16SS393J
	R242		XRS1/16SS4701D	RS1/16SS4701F
	R519		XRS1/16SS271J	XRS1/16SS151J

Circuit Symbol and No.	Part Name	DEH-S5150BT/XNGS	DEH-S5250BT/XNGS	
R538		XRS1/16SS103J	XRS1/16SS473J	A
R539		XRS1/16SS473J	XRS1/16SS103J	
R591		XRS1/16SS361J	XRS1/16SS221J	
R610		Not used	XRS1/16SS222J	
R690		XRS1/16SS472J	Not used	
R702		XRS1/16SS472J	XRS1/16SS152J	
R857		Not used	RS1/16SS0R0J	
R1312		XRS1/16SS103J	XRS1/16SS272J	
R1416		XRS1/10SR0R0J	Not used	
R1432		Not used	RS1/16SS0R0J	
C246		CKSRYX104K50	Not used	B
C267		CKSSYB104K16	Not used	
C723		CKSSYB102K50	CCSSCH120J50	
C794		CCSSCH101J50	CCSSCH121J50	
C855		Not used	CCSSCH7R0D50	
C857		CKSSYX104K50	CCSSCH120J50	
C1201		CCG1345	CKSRYB104K25	
C1202		CKSSYX104K50	Not used	
C1255		CKSSYB331K50	CCSSCH471J50	
C1276		CKSSYB104K16	Not used	
C1277		CKSSYB104K16	Not used	C
C1280		CKSSYB102K50	CCSSCH121J50	
C1281		CKSSYB102K50	CCSSCH121J50	
C1425		Not used	CKSRYB103K50	
C1426		Not used	CKSSYB103K25	

Keyboard Unit

Circuit Symbol and No.	Part Name	DEH-S5100BT/XNUC DEH-S5150BT/XNGS	DEH-S5200BT/XNUC DEH-S5250BT/XNGS	
IC1851	IR RC REC Module	PNJ4833M	SIR8440B5	D
D1922	Zener Diode	Not used	RSB6R8SM	
D1923	Zener Diode	Not used	RSB6R8SM	
D1951	LED	NSSM124F-A21107	NSSM124F-A27847	
D1952	LED	NSSM124F-A21107	NSSM124F-A27847	
D1953	LED	NSSM124F-A21107	NSSM124F-A27847	E
D1954	LED	NSSM124F-A21107	NSSM124F-A27847	
D1955	LED	NSSM124F-A21107	NSSM124F-A27847	
R1802		XRS1/10SR472J	RS1/10SR472J	
R1821		XRS1/10SR273J	RS1/10SR273J	
R1854		XRS1/10SR101J	RS1/10SR101J	
R1921		XRS1/10SR221J	RS1/10SR221J	
R1922		XRS1/10SR221J	RS1/10SR221J	
R1923		XRS1/10SR0R0J	RS1/10SR0R0J	
R1941		XRS1/10SR222J	RS1/10SR222J	
R1942		XRS1/10SR222J	RS1/10SR222J	F
R1943		XRS1/10SR222J	RS1/10SR222J	
R1944		XRS1/10SR222J	RS1/10SR222J	

	Circuit Symbol and No.	Part Name	DEH-S5100BT/XNUC DEH-S5150BT/XNGS	DEH-S5200BT/XNUC DEH-S5250BT/XNGS
A	R1951		XRS1/10SR332J	RS1/10SR332J
	R1952		XRS1/10SR152J	RS1/10SR152J
	R1953		XRS1/10SR332J	RS1/10SR332J
	R1954		XRS1/10SR152J	RS1/10SR152J
	R1955		XRS1/10SR332J	RS1/10SR332J
	R1956		XRS1/10SR152J	RS1/10SR152J
	R1957		XRS1/10SR680J	RS1/10SR680J
B	R1958		XRS1/10SR680J	RS1/10SR680J
	R1959		XRS1/10SR680J	RS1/10SR680J
	R1960		XRS1/10SR332J	RS1/10SR332J
	R1961		XRS1/10SR152J	RS1/10SR152J
	R1962		XRS1/10SR332J	RS1/10SR332J
	R1963		XRS1/10SR152J	RS1/10SR152J
	R1964		XRS1/10SR332J	RS1/10SR332J
C	R1965		XRS1/10SR152J	RS1/10SR152J
	R1966		XRS1/10SR680J	RS1/10SR680J
	R1967		XRS1/10SR680J	RS1/10SR680J
	R1968		XRS1/10SR680J	RS1/10SR680J
	R1969		XRS1/10SR221J	RS1/10SR221J
	R1970		XRS1/10SR121J	RS1/10SR121J
	R1971		XRS1/10SR121J	RS1/10SR121J

	Circuit Symbol and No.	Part Name	DEH-S510BT/XNEW5	DEH-S520BT/XNEW5
D	D1922	Zener Diode	Not used	RSB6R8SM
	D1923	Zener Diode	Not used	RSB6R8SM
	D1951	LED	NSSM124F-A21107	NSSM124F-A27847
	D1952	LED	NSSM124F-A21107	NSSM124F-A27847
	D1953	LED	NSSM124F-A21107	NSSM124F-A27847
	D1954	LED	NSSM124F-A21107	NSSM124F-A27847
	D1955	LED	NSSM124F-A21107	NSSM124F-A27847
E	R1802		XRS1/10SR472J	RS1/10SR472J
	R1821		XRS1/10SR273J	RS1/10SR273J
	R1852		XRS1/10SR473J	RS1/10SR473J
	R1921		XRS1/10SR221J	RS1/10SR221J
	R1922		XRS1/10SR221J	RS1/10SR221J
	R1923		XRS1/10SR0R0J	RS1/10SR0R0J
	R1941		XRS1/10SR222J	RS1/10SR222J
F	R1942		XRS1/10SR222J	RS1/10SR222J
	R1943		XRS1/10SR222J	RS1/10SR222J
	R1944		XRS1/10SR222J	RS1/10SR222J
	R1951		XRS1/10SR332J	RS1/10SR332J
	R1952		XRS1/10SR152J	RS1/10SR152J
	R1953		XRS1/10SR332J	RS1/10SR332J
	R1954		XRS1/10SR152J	RS1/10SR152J
	R1955		XRS1/10SR332J	RS1/10SR332J

Circuit Symbol and No.	Part Name	DEH-S510BT/XNEW5	DEH-S520BT/XNEW5
R1956		XRS1/10SR152J	RS1/10SR152J
R1957		XRS1/10SR680J	RS1/10SR680J
R1958		XRS1/10SR680J	RS1/10SR680J
R1959		XRS1/10SR680J	RS1/10SR680J
R1960		XRS1/10SR332J	RS1/10SR332J
R1961		XRS1/10SR152J	RS1/10SR152J
R1962		XRS1/10SR332J	RS1/10SR332J
R1963		XRS1/10SR152J	RS1/10SR152J
R1964		XRS1/10SR332J	RS1/10SR332J
R1965		XRS1/10SR152J	RS1/10SR152J
R1966		XRS1/10SR680J	RS1/10SR680J
R1967		XRS1/10SR680J	RS1/10SR680J
R1968		XRS1/10SR680J	RS1/10SR680J
R1969		XRS1/10SR221J	RS1/10SR221J
R1970		XRS1/10SR121J	RS1/10SR121J
R1971		XRS1/10SR121J	RS1/10SR121J

Circuit Symbol and No.	Part Name	DEH-X500BT/XNCS	DEH-X5000BT/XNCS
IC1851	IR RC REC Module	PNJ4833M	SIR8440B5
D1921	Zener Diode	Not used	RSB6R8SM
D1922	Zener Diode	Not used	RSB6R8SM
D1923	Zener Diode	Not used	RSB6R8SM
D1951	LED	NSSM124F-A21107	NSSM124F-A27847
D1952	LED	NSSM124F-A21107	NSSM124F-A27847
D1953	LED	NSSM124F-A21107	NSSM124F-A27847
D1954	LED	NSSM124F-A21107	NSSM124F-A27847
D1955	LED	NSSM124F-A21107	NSSM124F-A27847
C1921		CCG1345	CKSRYB224K16

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.