Pioneer sound.vision.soul

Service Manual

ORDER NO.
RRV2510

DJ MIXER

DJM-300
DJM-300-S

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	DJM-300	DJM-300-S		
KUCXCN	○	○	AC120V	————
SYLXCN	○	○	AC110V/120V/220-230V/240V	With the voltage selector

● This service manual should be used together with the following manual(s):

Model No.	Order No.	Remarks
DJM-300/ KUC, SYL	RRV1711	

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2001

T – ZZY AUG. 2001 Printed in Japan

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES:
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *Reference Nos. indicate the pages and Nos. in the service manual for the base model.*
- *When ordering resistors, first convert resistance values into code form as shown in the following examples.*

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560 → 56 x 10^1 → 561 ····· RD1/4PU 5 6 1 J
47k → 47 x 10^3 → 473 ····· RD1/4PU 4 7 3 J
0.5 → R50 ····· RN2H R 5 0 K
1 → 1R0 ····· RS1P 1 R 0 K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k → 562 x 10^1 → 5621 ····· RN1/4PC 5 6 2 1 F

■ CONTRAST TABLE (for DJM-300/ KUCXCN)

DJM-300/KUCXCN and DJM-300/KUC are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-300/ KUC	DJM-300/ KUCXCN	
		PACKING			
P3 - 5		Packing Case	DHG1737	DHG2133	
P3 - 8	NSP	Card	DRY1032	Not used	
P3 - 9	NSP	Vinyl Bag	DHL1011	Not used	
		EXTERIOR			
P5 - 13	NSP	Rear Panel	DNC1438	DNC1568	
		FRONT PANEL SECTION			
P7 - 25		Control Panel	DNB1068	DNB1091	

■ CONTRAST TABLE (for DJM-300/ SYLXCN)

DJM-300/SYLXCN and DJM-300/SYL are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-300/ SYL	DJM-300/ SYLXCN	
		PACKING			
P3 - 5		Packing Case	DHG1736	DHG2135	
		EXTERIOR			
P5 - 13	NSP	Rear Panel	DNC1437	DNC1569	
		FRONT PANEL SECTION			
P7 - 25		Control Panel	DNB1068	DNB1091	

■ CONTRAST TABLE (for DJM-300-S/ KUCXCN)

DJM-300-S/KUCXCN and DJM-300/KUC are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-300/ KUC	DJM-300-S/ KUCXCN	
		PACKING			
P3 - 5		Packing Case	DHG1737	DHG2126	
P3 - 8	NSP	Card	DRY1032	Not used	
P3 - 9	NSP	Vinyl Bag	DHL1011	Not used	
		EXTERIOR			
P5 - 13	NSP	Rear Panel	DNC1438	DNC1566	
		FRONT PANEL SECTION			
P7 - 24		Slider Panel	DAH1825	DAH1892	
P7 - 25		Control Panel	DNB1068	DNB1070	

■ CONTRAST TABLE (for DJM-300-S/ SYLXCN)

DJM-300-S/SYLXCN and DJM-300/SYL are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			DJM-300/ SYL	DJM-300-S/ SYLXCN	
		PACKING			
P3 - 5		Packing Case	DHG1736	DHG2128	
		EXTERIOR			
P5 - 13	NSP	Rear Panel	DNC1437	DNC1565	
		FRONT PANEL SECTION			
P7 - 24		Slider Panel	DAH1825	DAH1892	
P7 - 25		Control Panel	DNB1068	DNB1070	