
EXPLODED VIEW



A	M4x8	: N09-4026-05
B	φ3x10	: N09-6117-05
C	M4x10	: N09-6128-05
D	FLAT WASHER(φ4)	: N15-1040-46
E	φ3x10(BLK)	: N80-3010-45
F	φ2x6	: N82-2006-46
G	φ3x6	: N89-3006-46
H	φ3x8(BLK)	: N89-3008-45
J	φ3x12	: N09-6118-05
K	φ3x8	: N09-6135-05
L	φ2x8(BLK)	: N82-2008-45
N	M6x6	: N07-0003-08
P	M4x6	: N09-4214-08

Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KAC-8101D/8151D					
2	1B	✻	A21-4271-03	DRESSING PANEL	KE1
2	1B	✻	A21-4288-03	DRESSING PANEL	K1
4	3A	✻	A64-3054-02	PANEL	KE1
4	3A	✻	A64-3094-02	PANEL	K1
5	2B	✻	A84-0348-02	REAR PANEL	
7	1A	✻	B03-5024-14	DRESSING PLATE	KE1
8	1B	✻	B19-2214-13	LIGHTING BOARD	
-			B46-0100-50	WARRANTY CARD	
-		✻	B64-2577-00	INSTRUCTI.MANUAL (ENG.FRE.SPA.)	
-		✻	B64-2578-00	INSTR.MANUAL (GER.DUT.ITA.POR.)	E1
10	1A		E30-6145-05	CONNECTING CORD ASSY	
11	1A		E30-6240-15	MODULAR CABLE	KE1
13	1B	✻	F01-1729-11	HEAT SINK	
⚠ F1	2B		F52-0016-05	FUSE (BLADE TYPE) 40A	
-		✻	H10-4870-13	POLYSTYRENE FOAMED FIXTURE	
-			H25-0336-04	PROTECTION BAG (170X250X0.03)	
-			H25-1179-04	PROTECTION BAG	KE1
-		✻	H25-1192-04	PROTECTION BAG (370X440)	
-		✻	H54-2881-03	ITEM CARTON CASE	E1
-		✻	H54-2882-13	ITEM CARTON CASE	K1
-		✻	H54-2926-03	ITEM CARTON CASE	K
16	1A		K23-1076-03	KNOB	KE1
18	1A		N99-1587-05	SCREW SET	
19	1A		N99-1740-05	SCREW SET	KE1
A	3A		N09-4026-05	TAPPING SCREW (4X8,TP,S)	
B	2A		N09-6117-05	TAPTITE SCREW	
C	1B		N09-6128-05	DRESSED SCREW (TORX)	
D	3A		N15-1040-46	FLAT WASHER (4)	
E	2B		N80-3010-45	PAN HEAD TAPTITE SCREW	
F	1B		N82-2006-46	BINDING HEAD TAPTITE SCREW	
G	2B		N89-3006-46	BINDING HEAD TAPTITE SCREW	
H	3B		N89-3008-45	BINDING HEAD TAPTITE SCREW	
N	2B		N07-0003-08	PAN HEAD SEMS SCREW	
P	2B		N09-4214-08	PAN HEAD SEMS SCREW	
20	1A		W01-1606-05	ACCESSORY	
AUDIO UNIT (X09-5480-1x)					
D401			B30-1669-05	LED (BLUE)	
C1,2			CF92FV1H102J	MF-C 1000PF J	
C3-8			CE04DW1V100M	ELECTRO 10UF 35WV	
C10			CK73GB1H103K	CHIP C 0.010UF K	
C21,22			CK73GB1H103K	CHIP C 0.010UF K	
C23			CC73GCH1H330J	CHIP C 33PF J	
C24			CC73GCH1H470J	CHIP C 47PF J	
C25			CC73GCH1H100D	CHIP C 10PF D	
C26			CC73GCH1H330J	CHIP C 33PF J	
C27			CC73GCH1H100D	CHIP C 10PF D	
C28			CE04DW1V100M	ELECTRO 10UF 35WV	
C31,32			CK73GB1H103K	CHIP C 0.010UF K	
C33			CF92FV1H224J	MF-C 0.22UF J	

Ref. No.	Add	New	Parts No.	Description	Destination
C34			CE04HW1H2R2M	NP-ELEC 2.2UF 50WV	
C35			CC73GCH1H471J	CHIP C 470PF J	
C36			CK73FB1C474K	CHIP C 0.47UF K	
C37,38			CK73GB1H103K	CHIP C 0.010UF K	KE1
C39,40			CC73GCH1H101J	CHIP C 100PF J	KE1
C51,52			CK73GB1H103K	CHIP C 0.010UF K	
C53			CK73FB1C474K	CHIP C 0.47UF K	
C54			CK73FB1E154K	CHIP C 0.15UF K	
C55			CE04DW1V100M	ELECTRO 10UF 35WV	
C57-59			CE04DW1H010M	ELECTRO 1.0UF 50WV	
C60			CE04DW1V100M	ELECTRO 10UF 35WV	
C61,62			CK73GB1H103K	CHIP C 0.010UF K	
C63			CE04DW1H2R2M	ELECTRO 2.2UF 50WV	
C64			CK73GB1H103K	CHIP C 0.010UF K	
C65			CE04DW1V100M	ELECTRO 10UF 35WV	
C66-68			CK73GB1H103K	CHIP C 0.010UF K	
C69			CE04DW1V100M	ELECTRO 10UF 35WV	
C71			CC73GCH1H101J	CHIP C 100PF J	
C72			CE04DW1V100M	ELECTRO 10UF 35WV	
C101,102			CK73GB1H103K	CHIP C 0.010UF K	
C103			CF92FV1H182J	MF-C 1800PF J	
C104			CK73GB1H103K	CHIP C 0.010UF K	
C105,106			CE04DW1V100M	ELECTRO 10UF 35WV	
C111			CE04DW1H010M	ELECTRO 1.0UF 50WV	
C112			CK73GB1H104K	CHIP C 0.10UF K	
C113			CE04DW1E470M	ELECTRO 47UF 25WV	
C114			CC73GCH1H470J	CHIP C 47PF J	
C115			CF92FV1H392J	MF-C 3900PF J	
C131			CE04DW1E470M	ELECTRO 47UF 25WV	
C132,133			CC45FCH1H390J	CERAMIC 39PF J	
C151,152		✻	CF92FV2A104J	MF-C 0.10UF J	
C153,154			CF92FV1H682J	MF-C 6800PF J	
C155,156			C91-2267-05	MP-C 10UF J	
C171			CK73GB1H103K	CHIP C 0.010UF K	
C191,192			CK73GB1E473K	CHIP C 0.047UF K	
C193			CE04DW1E470M	ELECTRO 47UF 25WV	
C194			CK73GB1H103K	CHIP C 0.010UF K	
C195			CK73GB1H682K	CHIP C 6800PF K	
C201,202			CK73GB1H103K	CHIP C 0.010UF K	
C203,204			CE04DW1V100M	ELECTRO 10UF 35WV	
C205			CK73FB1C684K	CHIP C 0.68UF K	
C206			CK73GB1H103K	CHIP C 0.010UF K	
C231			CE04DW1A101M	ELECTRO 100UF 10WV	
C232			CK73GB1H103K	CHIP C 0.010UF K	
C251			CE04HW1E100M	NP-ELEC 10UF 25WV	
C252,253			CE04DW1V100M	ELECTRO 10UF 35WV	
C254			CK73GB1H103K	CHIP C 0.010UF K	
C255			CE04DW1V100M	ELECTRO 10UF 35WV	
C256			CK73GB1H103K	CHIP C 0.010UF K	
C257			CK73FB1E104K	CHIP C 0.10UF K	
C271			CK73GB1H103K	CHIP C 0.010UF K	
C272			CE04HW1H2R2M	NP-ELEC 2.2UF 50WV	
C273			CE04DW1H0R1M	ELECTRO 0.1UF 50WV	
C274			CF92FV1H102J	MF-C 1000PF J	
C275			CE04DW1E470M	ELECTRO 47UF 25WV	

E1 : KAC-8151D (For Europe) **K** : KAC-8151D (For North America)
K1 : KAC-8101D (For North America)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5480-1x)

Ref. No.	Add	New	Parts No.	Description	Destination
C276			CE04DW1V100M	ELECTRO 10UF 35WV	
C302,303			C90-2921-05	ELECTRO 3900UF 16WV	
C304			CF92FV1H682J	MF-C 6800PF J	
C309-312			CK45FB1H102K	CERAMIC 1000PF K	
C313,314		✻	C90-5497-05	ELECTRO 3300UF 63WV	
C315-318			CE04DW1E470M	ELECTRO 47UF 25WV	
C319			CE04DW1V470M	ELECTRO 47UF 35WV	
C320			CE04DW1E470M	ELECTRO 47UF 25WV	
C321			CK45FB1H222K	CERAMIC 2200PF K	
C401			CK73GB1H103K	CHIP C 0.010UF K	
CN1			E40-3247-05	PIN ASSY	
J1		✻	E63-0892-05	PIN JACK	
J2			E70-0838-05	SCREW TERMINAL BOARD	
J3			E58-0919-05	RECTANGULAR RECEPTACLE	
J4			E58-0966-05	RECTANGULAR RECEPTACLE	KE1
WH1			E39-0538-05	WIRING HARNESS	
27	2B	✻	F20-2205-14	INSULATING SHEET	
L2		✻	L19-0738-05	TRANSFORMER FOR CONVERTER	
L3		✻	L33-1911-05	CHOKE COIL	
L4			L33-1818-05	CHOKE COIL	
E	2B		N80-3010-45	PAN HEAD TAPTITE SCREW	
J	2A		N09-6118-05	TAPTITE SCREW	
K	2A	✻	N09-6135-05	TAPTITE SCREW (3X8 B)	
R1,2			RD14BB2C102J	RD 1.0K J 1/6W	
R3,4			RK73GB2A103J	CHIP R 10K J 1/10W	
R5,6			RK73GB2A273J	CHIP R 27K J 1/10W	
R7,8			RD14BB2C222J	RD 2.2K J 1/6W	
R9-12			RD14BB2C473J	RD 47K J 1/6W	
R13			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R21			RK73GB2A153J	CHIP R 15K J 1/10W	
R22			RK73GB2A103J	CHIP R 10K J 1/10W	
R23			RK73GB2A333J	CHIP R 33K J 1/10W	
R24-27			RN73GH1J103D	CHIP R 10K D 1/16W	
R28			RD14BB2C103J	RD 10K J 1/6W	
R29			RK73GB2A431J	CHIP R 430 J 1/10W	
R31			RK73GB2A243J	CHIP R 24K J 1/10W	
R32			RK73GB2A301J	CHIP R 300 J 1/10W	
R33,34			RK73GB2A224J	CHIP R 220K J 1/10W	
R35			RK73GB2A221J	CHIP R 220 J 1/10W	
R36			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R37			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R38			RK73GB2A103J	CHIP R 10K J 1/10W	
R39			RK73GB2A471J	CHIP R 470 J 1/10W	
R40			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R41-43			RD14BB2C102J	RD 1.0K J 1/6W	KE1
R45,46			RD14BB2C122J	RD 1.2K J 1/6W	KE1
R47			RK73GB2A331J	CHIP R 330 J 1/10W	
R48			RK73GB2A681J	CHIP R 680 J 1/10W	
R49,50			RK73GB2A473J	CHIP R 47K J 1/10W	KE1
R51			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R52			RK73GB2A223J	CHIP R 22K J 1/10W	
R54			RK73GB2A303J	CHIP R 30K J 1/10W	
R55			RK73GB2A392J	CHIP R 3.9K J 1/10W	

Ref. No.	Add	New	Parts No.	Description	Destination
R56			RK73GB2A103J	CHIP R 10K J 1/10W	
R61			RK73GB2A243J	CHIP R 24K J 1/10W	
R62			RK73GB2A104J	CHIP R 100K J 1/10W	
R63			RK73GB2A103J	CHIP R 10K J 1/10W	
R64			RK73GB2A223J	CHIP R 22K J 1/10W	
R65-68			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R69			RK73GB2A473J	CHIP R 47K J 1/10W	
R71,72			RK73GB2A563J	CHIP R 56K J 1/10W	
R101,102			RD14BB2E151J	RD 150 J 1/4W	
R103			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R104			RK73GB2A821J	CHIP R 820 J 1/10W	
R105			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R106			RK73GB2A103J	CHIP R 10K J 1/10W	
R107			RK73GB2A302J	CHIP R 3.0K J 1/10W	
R108			RK73GB2A103J	CHIP R 10K J 1/10W	
R111			RK73GB2A154J	CHIP R 150K J 1/10W	
R112			RK73GB2A104J	CHIP R 100K J 1/10W	
R113			RK73GB2A333J	CHIP R 33K J 1/10W	
R114			RK73GB2A103J	CHIP R 10K J 1/10W	
R115			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R116			RK73GB2A823J	CHIP R 82K J 1/10W	
R117,118			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R119			RK73GB2A684J	CHIP R 680K J 1/10W	
R120			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R121			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R122			RK73GB2A471J	CHIP R 470 J 1/10W	
R123			RK73GB2A683J	CHIP R 68K J 1/10W	
R124			RD14BB2E243J	RD 24K J 1/4W	
R131			RD14BB2C751J	RD 750 J 1/6W	
R132			RK73GB2A511J	CHIP R 510 J 1/10W	
R133,134			RK73GB2A103J	CHIP R 10K J 1/10W	
R135,136			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R141,142			RD14DB2H751J	SMALL-RD 750 J 1/2W	
R143,144			RD14NB2E471J	RD 470 J 1/4W	
R145			RD14NB2E470J	RD 47 J 1/4W	
R146			RD14NB2E271J	RD 270 J 1/4W	
R147-150			RK73EB2E100J	CHIP R 10 J 1/4W	
R151			RD14NB2E331J	RD 330 J 1/4W	
R152			RD14NB2E122J	RD 1.2K J 1/4W	
R153-156			RD14NB2E101J	RD 100 J 1/4W	
R157,158			RK73GB2A473J	CHIP R 47K J 1/10W	
R159-162			RK73EB2E100J	CHIP R 10 J 1/4W	
R163			RS14KB3D4R7J	FL-PROOF RS 4.7 J 2W	
R171			RD14DB2H152J	SMALL-RD 1.5K J 1/2W	
R172			RK73GB2A473J	CHIP R 47K J 1/10W	
R173			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	
R174			RK73GB2A103J	CHIP R 10K J 1/10W	
R181-186			R92-0205-05	METAL-PLATE 0.1 K 2W	
R191,192			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R193			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R194			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R195		✻	RK73GB2A514J	CHIP R 510K J 1/10W	
R196,197			RN73GH1J472D	CHIP R 4.7K D 1/16W	
R198			RK73GB2A393J	CHIP R 39K J 1/10W	
R199			RK73GB2A222J	CHIP R 2.2K J 1/10W	

E1 : KAC-8151D (For Europe) **K** : KAC-8151D (For North America)
K1 : KAC-8101D (For North America)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5480-1x)

Ref. No.	Add	New	Parts No.	Description	Destination
R200			RK73GB2A273J	CHIP R 27K J 1/10W	
R201			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R202			RK73GB2A103J	CHIP R 10K J 1/10W	
R203			RK73GB2A104J	CHIP R 100K J 1/10W	
R205			RK73GB2A104J	CHIP R 100K J 1/10W	
R211			RK73GB2A473J	CHIP R 47K J 1/10W	
R212			RK73GB2A103J	CHIP R 10K J 1/10W	
R213-215			RK73GB2A203J	CHIP R 20K J 1/10W	
R216			RK73GB2A103J	CHIP R 10K J 1/10W	
R217			RK73GB2A132J	CHIP R 1.3K J 1/10W	
R218			RK73GB2A123J	CHIP R 12K J 1/10W	
R219			RK73GB2A203J	CHIP R 20K J 1/10W	
R220			RK73GB2A224J	CHIP R 220K J 1/10W	
R221			RK73GB2A103J	CHIP R 10K J 1/10W	
R222			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R231			RK73GB2A823J	CHIP R 82K J 1/10W	
R232			RK73GB2A103J	CHIP R 10K J 1/10W	
R233,234			RK73GB2A223J	CHIP R 22K J 1/10W	
R251-254			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R255			RK73GB2A103J	CHIP R 10K J 1/10W	
R256			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R257			RK73GB2A333J	CHIP R 33K J 1/10W	
R258			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R259			RD14BB2C333J	RD 33K J 1/6W	
R260			RD14BB2C103J	RD 10K J 1/6W	
R261			RK73GB2A333J	CHIP R 33K J 1/10W	
R262			RK73GB2A103J	CHIP R 10K J 1/10W	
R263			RK73GB2A101J	CHIP R 100 J 1/10W	
R264			RK73GB2A103J	CHIP R 10K J 1/10W	
R265,266			RK73GB2A681J	CHIP R 680 J 1/10W	
R267			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R271			RK73GB2A103J	CHIP R 10K J 1/10W	
R272			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R273,274			RK73GB2A273J	CHIP R 27K J 1/10W	
R275			RK73GB2A334J	CHIP R 330K J 1/10W	
R276			RK73GB2A103J	CHIP R 10K J 1/10W	
R277			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R278			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R279			RK73GB2A103J	CHIP R 10K J 1/10W	
R280			RK73GB2A392J	CHIP R 3.9K J 1/10W	
R281			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R282			RK73GB2A163J	CHIP R 16K J 1/10W	
R283,284			RK73GB2A103J	CHIP R 10K J 1/10W	
R301,302			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R303,304			RK73GB2A750J	CHIP R 75 J 1/10W	
R305,306			RK73GB2A100J	CHIP R 10 J 1/10W	
R307,308			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R309			RD14DB2H100J	SMALL-RD 10 J 1/2W	
R311,312			RD14DB2H220J	SMALL-RD 22 J 1/2W	
R313,314			RD14BB2C563J	RD 56K J 1/6W	
R315,316			RD14NB2E100J	RD 10 J 1/4W	
R317,318			RD14BB2C243J	RD 24K J 1/6W	
R319			RK73GB2A821J	CHIP R 820 J 1/10W	
R320			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R321			RK73GB2A103J	CHIP R 10K J 1/10W	
R322			RK73GB2A100J	CHIP R 10 J 1/10W	
R323			RK73GB2A153J	CHIP R 15K J 1/10W	
R324			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R325			RK73GB2A563J	CHIP R 56K J 1/10W	
R326			RD14DB2H100J	SMALL-RD 10 J 1/2W	
VR1			R31-0223-05	VARIABLE RESISTOR	
VR2			R31-0229-05	VARIABLE RESISTOR	
W501-516			R92-2053-05	CHIP R 0 J 1/8W	
S1			S62-0845-05	SLIDE SWITCH	
S2			S31-2630-05	SLIDE SWITCH	
S3			S62-0842-05	SLIDE SWITCH	
D1-5			1SS133	DIODE	
D6,7			RD10JS(B)	ZENER DIODE	
D8,9			1SS133	DIODE	
D10			RD5.1JS(B)	ZENER DIODE	
D11,12			1SS133	DIODE	
D13			RD5.1JS(B)	ZENER DIODE	
D14-17			1SS133	DIODE	
D18			RD5.1JS(B)	ZENER DIODE	
D19			1SS133	DIODE	
D20			RD4.7JS(B)	ZENER DIODE	
D21,22			1SS133	DIODE	
D30			MA111	DIODE	
D31,32			RM4ZLF-J1	DIODE	
D33			RD7.5JS(B)	ZENER DIODE	
D34			RD16JS(B)	ZENER DIODE	
D35,36			1SS133	DIODE	
D37			RD10JS(B)	ZENER DIODE	
D38-40			1SS133	DIODE	
D41,42			MA111	DIODE	
D43,44			1SS133	DIODE	
D45			FML22S	DIODE	
D46			FML22R	DIODE	
D47,48			RD16JS(B)	ZENER DIODE	
D49-52			S5566B	DIODE	
D53			RD15JS(B)	ZENER DIODE	
D54-57			1SS133	DIODE	KE1
D58,59			RD8.2JS(B)	ZENER DIODE	KE1
D60			1SS133	DIODE	
D62			MA3100-M	ZENER DIODE	
D71,72			RD10JS(B)	ZENER DIODE	
D73-76			1SS133	DIODE	
IC1-5			NJM4565M	ANALOGUE IC	
IC6			SA571N	ANALOGUE IC	
IC7			NJM5532MD	ANALOGUE IC	
IC8			NJM2903M	ANALOGUE IC	
IC9			NJM319D	ANALOGUE IC	
IC10,11			TC74HC00AF	MOS-IC	
IC12			TC4052BF(N)	MOS-IC	KE1
IC15			UPC494GS	ANALOGUE IC	
Q1			2SC945(A)(Q,P)	TRANSISTOR	
Q3,4			2SC2631(Q,R)	TRANSISTOR	
Q5			2SA1352(E,F)	TRANSISTOR	
Q7-10			2SA1352(E,F)	TRANSISTOR	

E1 : KAC-8151D (For Europe) **K** : KAC-8151D (For North America)
K1 : KAC-8101D (For North America)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5480-1x)

Ref. No.	Add	New	Parts No.	Description	Destination
Q11			2SC3478A(L,K)	TRANSISTOR	
Q12,13			2SA1286-T11	TRANSISTOR	
Q14			2SC3478A(L,K)	TRANSISTOR	
Q15,16			STW34NB20	FET	
Q17			2SC3478A(L,K)	TRANSISTOR	
Q18,19			2SA1376A(L,K)	TRANSISTOR	
Q20			2SC3478A(L,K)	TRANSISTOR	
Q21			2SC2631(Q,R)	TRANSISTOR	
Q22			2SA1123(Q,R)	TRANSISTOR	
Q23,24			2SC945(A)(Q,P)	TRANSISTOR	
Q25			2SA733(A)(Q,P)	TRANSISTOR	
Q26			2SA1376A(L,K)	TRANSISTOR	
Q27			2SC3478A(L,K)	TRANSISTOR	
Q28			DTC124EUA	DIGITAL TRANSISTOR	
Q31,32			2SC945(A)(Q,P)	TRANSISTOR	
Q33			2SA1534A(R,S)	TRANSISTOR	
Q34			2SA733(A)(Q,P)	TRANSISTOR	
Q36-38			2SC945(A)(Q,P)	TRANSISTOR	
Q39,40			2SA733(A)(Q,P)	TRANSISTOR	
Q41-46			FKV550T	FET	
Q47			2SC1845(F,E)	TRANSISTOR	
Q48			2SA992(F,E)	TRANSISTOR	
Q49			2SC4883A	TRANSISTOR	
Q50			2SA1859A	TRANSISTOR	
Q51,52			2SA733(A)(Q,P)	TRANSISTOR	
Q53			2SC3940A(R,S)	TRANSISTOR	
Q55			2SC945(A)(Q,P)	TRANSISTOR	
Q61,62			2SC3478A(L,K)	TRANSISTOR	
Q63,64			2SA1286-T11	TRANSISTOR	
Q65,66			STW34NB20	FET	
TH1			PTH9L04BE222TS	POSITIVE RESISTOR	
SWITCH UNIT (X16-2390-10)					
J1			E58-0966-05	RECTANGULAR RECEPTACLE	KE1
S1			S60-0807-05	ROTARY SWITCH	KE1
D1,2			1SS133	DIODE	KE1
CONTROL ASSY (X90-3750-10)					
33	3A	✻	A02-2728-12	PLASTIC CABINET	KE1
34	3A		A02-2729-02	PLASTIC CABINET	KE1
-		✻	H25-1187-04	PROTECTION BAG	KE1
L	3A		N82-2008-45	BINDING HEAD TAPTITE SCREW	KE1

Ref. No.	Add	New	Parts No.	Description	Destination

E1 : KAC-8151D (For Europe) **K** : KAC-8151D (For North America)
K1 : KAC-8101D (For North America)

⚠ Indicates safety critical components.