

EXPLODED VIEWS AND PARTS LIST

PACKING SECTION (Page 29)

PACKING SECTION PARTS LIST

*:Non spare part

Mark	No.	Description	DEH-S1100UB/XNUC	DEH-S1200UB/XNUC
*	1	Unit Box	QHG4374	QHG4578
	2	Contain Box	QHL4374	QHL4578
	5-2	Quick Start Guide	QRD3653	QRD3768
	5-3	Web IM	See Contents of Web IM	See Contents of Web IM

Mark	No.	Description	DEH-S1150UB/XNCS	DEH-S1250UB/XNCS
*	1	Unit Box	QHG4380	QHG4584
	2	Contain Box	QHL4380	QHL4584
	5-2	Quick Start Guide	QRD3654	QRD3769
	5-3	Web IM	See Contents of Web IM	See Contents of Web IM

Mark	No.	Description	DEH-S1150UB/XNGS	DEH-S1250UB/XNGS
*	1	Unit Box	QHG4376	QHG4579
	2	Contain Box	QHL4376	QHL4579
	5-1	Owner's Manual	QRD3596	Not used
	5-2	Quick Start Guide	Not used	QRD3798
	5-3	Web IM	Not used	See Contents of Web IM

Mark	No.	Description	DEH-S1150UB/XNGS1	DEH-S1250UB/XNGS1
*	1	Unit Box	QHG4377	QHG4580
	2	Contain Box	QHL4377	QHL4580
	5-1	Owner's Manual	QRD3596	Not used
	5-2	Quick Start Guide	Not used	QRD3798
	5-3	Web IM	Not used	See Contents of Web IM

Mark	No.	Description	DEH-S1152UB/XNES	DEH-S1252UB/XNES
*	1	Unit Box	QHG4379	QHG4582
	2	Contain Box	QHL4379	QHL4582
	5-1	Owner's Manual	QRD3596	Not used
	5-2	Quick Start Guide	Not used	QRD3798
	5-3	Web IM	Not used	See Contents of Web IM

Mark	No.	Description	DEH-S1152UB/XNES	DEH-S1253UB/XNES
*	1	Unit Box	QHG4379	QHG4583
	2	Contain Box	QHL4379	QHL4583
	5-1	Owner's Manual	QRD3596	Not used
	5-2	Quick Start Guide	Not used	QRD3798
	5-3	Web IM	Not used	See Contents of Web IM

Mark	No.	Description	DEH-S1190UB/XNID	DEH-S1290UB/XNID
	1	Unit Box	QHG4382	QHG4586
	2	Contain Box	QHL4382	QHL4586
	5-1	Owner's Manual	QRB3776	QRB3923

Quick Start Guide, Owner's Manual

Part No.	Language
QRD3768	English, French, Spanish(Espanol)
QRD3769	English, Spanish(Espanol), Portuguese(B)
QRD3798	English, Traditional Chinese, Arabic, Persian
QRB3923	English

CONTENTS OF WEB IM

Part No.	Language
*OPM_DEHS1200UBUC_3L_A (for XNUC)	English, French, Spanish(Espanol)
*OPM_DEHS1250UBCS_3L_A(for XNCS)	English, Spanish(Espanol), Portuguese(B)
*OPM_DEHS1253UBESGS_4L_A(for XNGS, XNGS1, XNES)	English, Traditional Chinese, Arabic, Persian

All operation manuals are supplied in PDF files by the WEB. No printed papers are available.

EXTERIOR SECTION (Page 31)

EXTERIOR SECTION PARTS LIST

Mark	No.	Description	DEH-S1100UB/XNUC	DEH-S1200UB/XNUC
*	1	Detach Grille Assy	QXA5807	QXA6052
	9	Grille Unit	QXA5457	QXA6222
	10	Grille	QNS4331	QNS4425
	12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5423	QXA5438
	32	Heat Cond Sheet	QNM3175	QNM3288
	33	Tuner Amp Unit	QWM4961	QWM5348

Mark	No.	Description	DEH-S1150UB/XNCS	DEH-S1250UB/XNCS
*	1	Detach Grille Assy	QXA5813	QXA6057
	9	Grille Unit	QXA5463	QXA6227
	10	Grille	QNS4331	QNS4425
	12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5423	QXA5438
	32	Heat Cond Sheet	QNM3175	QNM3288
	33	Tuner Amp Unit	QWM4963	QWM5349


Mark	No.	Description	DEH-S1150UB/XNGS	DEH-S1250UB/XNGS
*	1	Detach Grille Assy	QXA5809	QXA6053
	9	Grille Unit	QXA5459	QXA6223
	10	Grille	QNS4331	QNS4425
	12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5423	QXA5438
	32	Heat Cond Sheet	QNM3135	QNM3287
	33	Tuner Amp Unit	QWM4964	QWM5350

Mark	No.	Description	DEH-S1150UB/XNGS1	DEH-S1250UB/XNGS1
A	1	Detach Grille Assy	QXA5809	QXA6053
	9	Grille Unit	QXA5459	QXA6223
	* 10	Grille	QNS4331	QNS4425
	* 12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5423	QXA5438
	32	Heat Cond Sheet	QNM3135	QNM3287
	33	Tuner Amp Unit	QWM4965	QWM5351

B

Mark	No.	Description	DEH-S1152UB/XNES	DEH-S1252UB/XNES
C	1	Detach Grille Assy	QXA5812	QXA6055
	9	Grille Unit	QXA5462	QXA6225
	* 10	Grille	QNS4331	QNS4425
	* 12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5423	QXA5438
	32	Heat Cond Sheet	QNM3135	QNM3287
	33	Tuner Amp Unit	QWM4969	QWM5352

Mark	No.	Description	DEH-S1152UB/XNES	DEH-S1253UB/XNES
D	1	Detach Grille Assy	QXA5812	QXA6056
	2	Keyboard Unit	QWM5000	QWM4994
	9	Grille Unit	QXA5462	QXA6226
	* 10	Grille	QNS4331	QNS4425
	* 12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	* 15	Door	QAT3036	QAT3037
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5423	QXA5438
	31	Case	QNB3033	QNB3043
E	32	Heat Cond Sheet	QNM3135	QNM3288
	33	Tuner Amp Unit	QWM4969	QWM5357
	38	Holder	QNC3049	QNC3123



F

Mark	No.	Description	DEH-S1190UB/XNID	DEH-S1290UB/XNID
	1	Detach Grille Assy	QXA5815	QXA6059
	9	Grille Unit	QXA5465	QXA6229
*	10	Grille	QNS4331	QNS4425
*	12	Plate	QNS4295	QNS4426
	13	Button(EJECT)	* QAC3311	QAC3325
	18	Button(DETACH)	QAC3320	QAC3327
	23	Knob Unit	QXA5430	QXA5439
	32	Heat Cond Sheet	QNM3175	QNM3288
	33	Tuner Amp Unit	QWM4967	QWM5354

CD MECHANISM MODULE (Page 34)

CD MECHANISM MODULE PARTS LIST

Mark	No.	Description	DEH-S1100UB/XNUC DEH-S1150UB/XNCS DEH-S1150UB/XNGS DEH-S1150UB/XNGS1 DEH-S1152UB/XNES DEH-S1190UB/XNID	DEH-S1200UB/XNUC DEH-S1250UB/XNCS DEH-S1250UB/XNGS DEH-S1250UB/XNGS1 DEH-S1252UB/XNES DEH-S1253UB/XNES DEH-S1290UB/XNID
	20	Pickup Unit(P10.6)(Service) for CXK5807	CXX3556	CXY3639

ELECTRICAL PARTS LIST (Page 59)

Tuner Amp Unit

Circuit Symbol and No.	Part Name	DEH-S1100UB/XNUC	DEH-S1200UB/XNUC
IC371	Flash ROM Unit	QVQ1068	QVQ1118
CN701	Connector	VKN1192	CKS6763
R113		XRS1/16SS682J	XRS1/16SS822J
R177		XRS1/16SS472J	XRS1/16SS222J
R378		Not used	XRS1/16SS473J
R379		XRS1/16SS473J	Not used
C166		CKSQYX106K10	CKSRAYX106M10
C167		CKSQYX106K10	CKSRAYX106M10
C169		CKSQYX106K10	CKSRAYX106M10
C173		CKSRYX105K16	Not used
C174		CKSRYX105K16	CKSSYX105K16
C177		CKSQYX106K10	CKSRAYX106M10
C178		CCSSCH391J50	CKSSYB272K50
C179		CKSSYB102K50	CKSTYX222K25
C180		CKSQYX106K10	CKSRAYX106M10
C183		CKSRYX475K6R3	CKSRYX475K16
C192		CKSYX226M16	CKSQYX226M16
C197		CKSRYX105K16	CKSSYX105K16
C200	10 uF/35 V	CKSYX106K35	CCG1236
C253		CKSSYB104K10	CKSTYX104K10
C255		CKSRYX225K10	CKSSBYX225M16
C321		CKSSYB104K10	CKSTYX104K10
C322		CKSQYX106K10	CKSRAYX106M10

A

B

C

D

E

F

Circuit Symbol and No.	Part Name	DEH-S1100UB/XNUC	DEH-S1200UB/XNUC
C323		CKSQYX106K10	CKSRAYX106M10
C351		CKSSYB104K10	CKSTYX104K10
C352		CKSSYB104K10	CKSTYX104K10
C353		CKSSYB104K10	CKSTYX104K10
C354		CKSSYB104K10	CKSTYX104K10
C357		CKSSYB104K10	CKSTYX104K10
C361		CKSSYB104K10	CKSTYX104K10
C362		CKSSYB104K10	CKSTYX104K10
C363		CKSSYB104K10	CKSTYX104K10
C365		CCSSCH120J50	CCSTCH120J50
C366		CCSSCH120J50	CCSTCH120J50
C368		CKSSYB102K50	CKSTYX102K50
C369		CKSSYB104K10	CKSTYX104K10
C376		CCSSCH120J50	CCSTCH120J50
C379		CCSSCJ3R0C50	CCSTCJ3R0C50
C381		CKSSYB104K10	CKSTYX104K10
C383		CKSSYB104K10	CKSTYX104K10
C384		CCSSCH220J50	CCSTCH220J50
C385		CKSSYB104K10	CKSTYX104K10
C386		CKSSYB104K10	CKSTYX104K10
C387		CKSSYB104K10	CKSTYX104K10
C388		CCSSCH330J50	CCSTCH330J50
C389		CKSSYB104K10	CKSTYX104K10
C390		CCSSCH100D50	CCSTCH100D50
C391		CCSSCH220J50	CCSTCH220J50
C392		CCSSCH220J50	CCSTCH220J50
C393		CCSSCH220J50	CCSTCH220J50
C394		CKSSYB104K10	CKSTYX104K10
C395		CKSSYB103K16	CKSTYX103K16
C399		CKSSYB104K10	CKSTYX104K10
C400		CCSSCH100D50	CCSTCH100D50
C405		Not used	CKSTYX104K10
C563		CKSQYX106K10	CKSRAYX106M10
C565		CKSSYB104K10	CKSTYX104K10
C568		CKSSYB104K10	CKSTYX104K10
C569		CKSSYB104K10	CKSTYX104K10
C570		CKSQYX106K10	CKSRAYX106M10
C575		CKSQYX106K10	CKSRAYX106M10
C576		CKSSYB104K10	CKSTYX104K10
C577		CKSQYX106K10	CKSRAYX106M10
C583		CKSQYX106K10	CKSRAYX106M10
C584		CKSSYB104K10	CKSTYX104K10
C585		CKSSYB104K10	CKSTYX104K10
C586		CKSSYB104K10	CKSTYX104K10
C587		CKSSYB102K50	CKSTYX102K50

Circuit Symbol and No.	Part Name	DEH-S1100UB/XNUC	DEH-S1200UB/XNUC
C592		Not used	CKSRAYX106M10
C593		Not used	CKSRAYX106M10
C607		CKSSYB102K50	CKSTYX102K50
C610		CKSSYB152K50	CKSTYX152K50
C611		CCSSCH120J50	CCSTCH120J50
C612		CCSSCH5R0C50	CCSTCH5R0C50
C613		CCSSCH120J50	CCSTCH120J50
C615		CKSSYB104K10	CKSTYX104K10
C617		CKSSYB102K50	CKSTYX102K50
C621		CCSSCH180J50	CCSTCH180J50
C624		CKSRYX225K10	CKSSBYX225M16
C626		CKSQYX106K10	CKSRAYX106M10
C632		CKSSYB104K16	CKSTYX104K10
C633		CKSSYB104K16	CKSTYX104K10
C636		CKSSYB102K50	CKSTYX102K50
C637		CKSSYB104K10	CKSTYX104K10
C639		CCSSCH471J50	CKSTYX471K50
C701		CKSSYB103K16	CKSTYX103K16
C702		CKSSYB103K16	CKSTYX103K16
C709		CKSSYB104K10	CKSTYX104K10
C760		CKSSYB104K10	CKSTYX104K10
C801	1 000 pF	CCG1345	Not used
C802	1 000 pF	Not used	CCG1345
C811		CKSSYB104K10	CKSTYX104K10
C863		CKSRYX225K10	CKSSBYX225M16
C868		CKSQYX106K16	CKSRAYX106M16

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNCS	DEH-S1250UB/XNCS
IC371	Flash ROM Unit	QVQ1069	QVQ1117
CN701	Connector	VKN1192	CKS6763
R113		XRS1/16SS682J	XRS1/16SS822J
R177		XRS1/16SS472J	XRS1/16SS222J
R789		XRS1/16SS0R0J	Not used
C166		CKSQYX106K10	CKSRAYX106M10
C167		CKSQYX106K10	CKSRAYX106M10
C169		CKSQYX106K10	CKSRAYX106M10
C173		CKSRYX105K16	Not used
C174		CKSRYX105K16	CKSSYX105K16
C177		CKSQYX106K10	CKSRAYX106M10
C178		CCSSCH391J50	CKSSYB272K50
C179		CKSSYB102K50	CKSTYX222K25
C180		CKSQYX106K10	CKSRAYX106M10
C183		CKSRYX475K6R3	CKSRYX475K16
C192		CKSYX226M16	CKSQYX226M16
C194		CKSRYB103K50	CKSSYB103K50
C197		CKSRYX105K16	CKSSYX105K16

A

B

C

D

E

F

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNCS	DEH-S1250UB/XNCS
C200	10 uF/35 V	CKSYX106K35	CCG1236
C253		CKSSYB104K10	CKSTYX104K10
C255		CKSRYX225K10	CKSSBYX225M16
C321		CKSSYB104K10	CKSTYX104K10
C322		CKSQYX106K10	CKSRAYX106M10
C323		CKSQYX106K10	CKSRAYX106M10
C351		CKSSYB104K10	CKSTYX104K10
C352		CKSSYB104K10	CKSTYX104K10
C353		CKSSYB104K10	CKSTYX104K10
C354		CKSSYB104K10	CKSTYX104K10
C357		CKSSYB104K10	CKSTYX104K10
C361		CKSSYB104K10	CKSTYX104K10
C362		CKSSYB104K10	CKSTYX104K10
C363		CKSSYB104K10	CKSTYX104K10
C365		CCSSCH120J50	CCSTCH120J50
C366		CCSSCH120J50	CCSTCH120J50
C368		CKSSYB102K50	CKSTYX102K50
C369		CKSSYB104K10	CKSTYX104K10
C376		CCSSCH120J50	CCSTCH120J50
C379		CCSSCJ3R0C50	CCSTCJ3R0C50
C383		CKSSYB104K10	CKSTYX104K10
C384		CCSSCH220J50	CCSTCH220J50
C385		CKSSYB104K10	CKSTYX104K10
C386		CKSSYB104K10	CKSTYX104K10
C387		CKSSYB104K10	CKSTYX104K10
C388		CCSSCH330J50	CCSTCH330J50
C389		CKSSYB104K10	CKSTYX104K10
C390		CCSSCH100D50	CCSTCH100D50
C391		CCSSCH220J50	CCSTCH220J50
C392		CCSSCH220J50	CCSTCH220J50
C393		CCSSCH220J50	CCSTCH220J50
C394		CKSSYB104K10	CKSTYX104K10
C395		CKSSYB103K16	CKSTYX103K16
C399		CKSSYB104K10	CKSTYX104K10
C400		CCSSCH100D50	CCSTCH100D50
C404		CKSSYB104K10	CKSTYX104K10
C405		Not used	CKSTYX104K10
C563		CKSQYX106K10	CKSRAYX106M10
C565		CKSSYB104K10	CKSTYX104K10
C568		CKSSYB104K10	CKSTYX104K10
C569		CKSSYB104K10	CKSTYX104K10
C570		CKSQYX106K10	CKSRAYX106M10
C575		CKSQYX106K10	CKSRAYX106M10
C576		CKSSYB104K10	CKSTYX104K10
C577		CKSQYX106K10	CKSRAYX106M10

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNCS	DEH-S1250UB/XNCS
C583		CKSQYX106K10	CKSRAYX106M10
C584		CKSSYB104K10	CKSTYX104K10
C585		CKSSYB104K10	CKSTYX104K10
C586		CKSSYB104K10	CKSTYX104K10
C587		CKSSYB102K50	CKSTYX102K50
C592		Not used	CKSRAYX106M10
C593		Not used	CKSRAYX106M10
C607		CKSSYB102K50	CKSTYX102K50
C610		CKSSYB152K50	CKSTYX152K50
C611		CCSSCH120J50	CCSTCH120J50
C612		CCSSCH5R0C50	CCSTCH5R0C50
C613		CCSSCH120J50	CCSTCH120J50
C615		CKSSYB104K10	CKSTYX104K10
C617		CKSSYB102K50	CKSTYX102K50
C621		CCSSCH180J50	CCSTCH180J50
C624		CKSRYX225K10	CKSSBYX225M16
C626		CKSQYX106K10	CKSRAYX106M10
C632		CKSSYB104K16	CKSTYX104K10
C633		CKSSYB104K16	CKSTYX104K10
C635		CKSSYB104K10	CKSTYX104K10
C637		CKSSYB104K10	CKSTYX104K10
C639		CCSSCH471J50	CKSTYX471K50
C701		CKSSYB103K16	CKSTYX103K16
C702		CKSSYB103K16	CKSTYX103K16
C709		CKSSYB104K10	CKSTYX104K10
C760		CKSSYB104K10	CKSTYX104K10
C801	1 000 pF	CCG1345	Not used
C802	1 000 pF	Not used	CCG1345
C811		CKSSYB104K10	CKSTYX104K10
C863		CKSRYX225K10	CKSSBYX225M16
C868		CKSQYX106K16	CKSRAYX106M16

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNGS	DEH-S1250UB/XNGS
IC371	Flash ROM Unit	QVQ1066	QVQ1116
L603	Chip Coil	LCTAWR27J2520	LCYAR27J2016
L604	Chip Coil	LCTAW3R3J2520	LCYA3R3J2016
CN701	Connector	VKN1192	CKS6763
R113		XRS1/16SS682J	XRS1/16SS822J
R177		XRS1/16SS472J	XRS1/16SS222J
R789		XRS1/16SS0R0J	Not used
C166		CKSQYX106K10	CKSRAYX106M10
C167		CKSQYX106K10	CKSRAYX106M10
C169		CKSQYX106K10	CKSRAYX106M10
C173		CKSRYX105K16	Not used
C174		CKSRYX105K16	CKSSYX105K16
C177		CKSQYX106K10	CKSRAYX106M10

A

B

C

D

E

F

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNGS	DEH-S1250UB/XNGS
C178	10 uF/35 V	CCSSCH391J50	CKSSYB272K50
C179		CKSSYB102K50	CKSTYX222K25
C180		CKSQYX106K10	CKSRAYX106M10
C183		CKSRYX475K6R3	CKSRYX475K16
C192		CKSYX226M16	CKSQYX226M16
C194		CKSRYB103K50	CKSSYB103K50
C197		CKSRYX105K16	CKSSYX105K16
C200		CKSYX106K35	CCG1236
C253		CKSSYB104K10	CKSTYX104K10
C255		CKSRYX225K10	CKSSBYX225M16
C351		CKSSYB104K10	CKSTYX104K10
C352		CKSSYB104K10	CKSTYX104K10
C353		CKSSYB104K10	CKSTYX104K10
C354		CKSSYB104K10	CKSTYX104K10
C357		CKSSYB104K10	CKSTYX104K10
C361		CKSSYB104K10	CKSTYX104K10
C362		CCSSCH101J50	CCSTCH101J50
C363		CKSSYB102K50	CKSTYX102K50
C364		CCSSCH120J50	CCSTCH120J50
C366		CCSSCH120J50	CCSTCH120J50
C368		CKSSYB102K50	CKSTYX102K50
C369		CKSSYB104K10	CKSTYX104K10
C376		CCSSCH120J50	CCSTCH120J50
C379		CCSSCJ3R0C50	CCSTCJ3R0C50
C381		CKSSYB104K10	CKSTYX104K10
C383		CKSSYB104K10	CKSTYX104K10
C384		CCSSCH220J50	CCSTCH220J50
C385		CKSSYB104K10	CKSTYX104K10
C386		CKSSYB104K10	CKSTYX104K10
C387		CKSSYB104K10	CKSTYX104K10
C388		CCSSCH330J50	CCSTCH330J50
C389		CKSSYB104K10	CKSTYX104K10
C390		CCSSCH100D50	CCSTCH100D50
C391		CCSSCH220J50	CCSTCH220J50
C392		CCSSCH220J50	CCSTCH220J50
C393		CCSSCH220J50	CCSTCH220J50
C394		CKSSYB104K10	CKSTYX104K10
C395		CKSSYB103K16	CKSTYX103K16
C399		CKSSYB104K10	CKSTYX104K10
C400		CCSSCH100D50	CCSTCH100D50
C405		Not used	CKSTYX104K10
C563		CKSQYX106K10	CKSRAYX106M10
C565		CKSSYB104K10	CKSTYX104K10
C568		CKSSYB104K10	CKSTYX104K10
C569		CKSSYB104K10	CKSTYX104K10

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNGS	DEH-S1250UB/XNGS
C570		CKSQYX106K10	CKSRAYX106M10
C575		CKSQYX106K10	CKSRAYX106M10
C576		CKSSYB104K10	CKSTYX104K10
C577		CKSQYX106K10	CKSRAYX106M10
C583		CKSQYX106K10	CKSRAYX106M10
C584		CKSSYB104K10	CKSTYX104K10
C585		CKSSYB104K10	CKSTYX104K10
C586		CKSSYB104K10	CKSTYX104K10
C587		CKSSYB102K50	CKSTYX102K50
C592		Not used	CKSRAYX106M10
C593		Not used	CKSRAYX106M10
C602		CCSSCK2R0C50	CCSTCK2R0C50
C603		CCSSCK1R0C50	CCSTCK1R0C50
C604		CCSSCK1R0C50	CCSTCK1R0C50
C605		CCSSCH120J50	CCSTCH120J50
C607		CKSSYB102K50	CKSTYX102K50
C610		CKSSYB152K50	CKSTYX152K50
C611		CCSSCH120J50	CCSTCH120J50
C612		CCSSCH5R0C50	CCSTCH5R0C50
C613		CCSSCH120J50	CCSTCH120J50
C615		CKSSYB104K10	CKSTYX104K10
C617		CKSSYB102K50	CKSTYX102K50
C621		CCSSCH180J50	CCSTCH180J50
C624		CKSRX225K10	CKSSBYX225M16
C626		CKSQYX106K10	CKSRAYX106M10
C632		CKSSYB104K16	CKSTYX104K10
C633		CKSSYB104K16	CKSTYX104K10
C635		CKSSYB104K10	CKSTYX104K10
C639		CCSSCH471J50	CKSTYX471K50
C701		CKSSYB103K16	CKSTYX103K16
C702		CKSSYB103K16	CKSTYX103K16
C709		CKSSYB104K10	CKSTYX104K10
C760		CKSSYB104K10	CKSTYX104K10
C801	1 000 pF	CCG1345	Not used
C802	1 000 pF	Not used	CCG1345
C811		CKSSYB104K10	CKSTYX104K10
C863		CKSRX225K10	CKSSBYX225M16
C868		CKSQYX106K16	CKSRAYX106M16

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNGS1	DEH-S1250UB/XNGS1
IC371	Flash ROM Unit	QVQ1066	QVQ1116
L603	Chip Coil	LCTAWR27J2520	LCYAR27J2016
L604	Chip Coil	LCTAW3R3J2520	LCYA3R3J2016
CN701	Connector	VKN1192	CKS6763
R113		XRS1/16SS682J	XRS1/16SS822J

Circuit Symbol and No.		Part Name	DEH-S1150UB/XNGS1	DEH-S1250UB/XNGS1
A	R177		XRS1/16SS472J	XRS1/16SS222J
	R789		XRS1/16SS0R0J	Not used
	C166		CKSQYX106K10	CKSRAYX106M10
	C167		CKSQYX106K10	CKSRAYX106M10
	C169		CKSQYX106K10	CKSRAYX106M10
	C173		CKSRYX105K16	Not used
	C174		CKSRYX105K16	CKSSYX105K16
	C177		CKSQYX106K10	CKSRAYX106M10
	C178		CCSSCH391J50	CKSSYB272K50
	C179		CKSSYB102K50	CKSTYX222K25
B	C180		CKSQYX106K10	CKSRAYX106M10
	C183		CKSRYX475K6R3	CKSRYX475K16
	C192		CKSYX226M16	CKSQYX226M16
	C194		CKSRYB103K50	CKSSYB103K50
	C197		CKSRYX105K16	CKSSYX105K16
	C200	10 uF/35 V	CKSYX106K35	CCG1236
	C253		CKSSYB104K10	CKSTYX104K10
	C255		CKSRYX225K10	CKSSBYX225M16
	C351		CKSSYB104K10	CKSTYX104K10
	C352		CKSSYB104K10	CKSTYX104K10
C	C353		CKSSYB104K10	CKSTYX104K10
	C354		CKSSYB104K10	CKSTYX104K10
	C357		CKSSYB104K10	CKSTYX104K10
	C361		CKSSYB104K10	CKSTYX104K10
	C362		CCSSCH101J50	CCSTCH101J50
	C363		CKSSYB102K50	CKSTYX102K50
	C364		CCSSCH120J50	CCSTCH120J50
	C366		CCSSCH120J50	CCSTCH120J50
	C368		CKSSYB102K50	CKSTYX102K50
	C369		CKSSYB104K10	CKSTYX104K10
D	C376		CCSSCH120J50	CCSTCH120J50
	C379		CCSSCJ3R0C50	CCSTCJ3R0C50
	C381		CKSSYB104K10	CKSTYX104K10
	C383		CKSSYB104K10	CKSTYX104K10
	C384		CCSSCH220J50	CCSTCH220J50
E	C385		CKSSYB104K10	CKSTYX104K10
	C386		CKSSYB104K10	CKSTYX104K10
	C387		CKSSYB104K10	CKSTYX104K10
	C388		CCSSCH330J50	CCSTCH330J50
	C389		CKSSYB104K10	CKSTYX104K10
	C390		CCSSCH100D50	CCSTCH100D50
	C391		CCSSCH220J50	CCSTCH220J50
	C392		CCSSCH220J50	CCSTCH220J50
	C393		CCSSCH220J50	CCSTCH220J50
	C394		CKSSYB104K10	CKSTYX104K10
F				

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNGS1	DEH-S1250UB/XNGS1	
C395		CKSSYB103K16	CKSTYX103K16	A
C399		CKSSYB104K10	CKSTYX104K10	
C400		CCSSCH100D50	CCSTCH100D50	
C405		Not used	CKSTYX104K10	
C563		CKSQYX106K10	CKSRAYX106M10	
C565		CKSSYB104K10	CKSTYX104K10	
C568		CKSSYB104K10	CKSTYX104K10	
C569		CKSSYB104K10	CKSTYX104K10	
C570		CKSQYX106K10	CKSRAYX106M10	
C575		CKSQYX106K10	CKSRAYX106M10	
C576		CKSSYB104K10	CKSTYX104K10	B
C577		CKSQYX106K10	CKSRAYX106M10	
C583		CKSQYX106K10	CKSRAYX106M10	
C584		CKSSYB104K10	CKSTYX104K10	
C585		CKSSYB104K10	CKSTYX104K10	
C586		CKSSYB104K10	CKSTYX104K10	
C587		CKSSYB102K50	CKSTYX102K50	
C592		Not used	CKSRAYX106M10	
C593		Not used	CKSRAYX106M10	
C602		CCSSCK2R0C50	CCSTCK2R0C50	
C603		CCSSCK1R0C50	CCSTCK1R0C50	C
C604		CCSSCK1R0C50	CCSTCK1R0C50	
C605		CCSSCH120J50	CCSTCH120J50	
C607		CKSSYB102K50	CKSTYX102K50	
C610		CKSSYB152K50	CKSTYX152K50	
C611		CCSSCH120J50	CCSTCH120J50	
C612		CCSSCH5R0C50	CCSTCH5R0C50	
C613		CCSSCH120J50	CCSTCH120J50	
C615		CKSSYB104K10	CKSTYX104K10	
C617		CKSSYB102K50	CKSTYX102K50	
C621		CCSSCH180J50	CCSTCH180J50	
C624		CKSRYX225K10	CKSSBYX225M16	
C626		CKSQYX106K10	CKSRAYX106M10	
C632		CKSSYB104K16	CKSTYX104K10	
C633		CKSSYB104K16	CKSTYX104K10	
C635		CKSSYB104K10	CKSTYX104K10	E
C639		CCSSCH471J50	CKSTYX471K50	
C701		CKSSYB103K16	CKSTYX103K16	
C702		CKSSYB103K16	CKSTYX103K16	
C709		CKSSYB104K10	CKSTYX104K10	
C760		CKSSYB104K10	CKSTYX104K10	
C801	1 000 pF	CCG1345	Not used	
C802	1 000 pF	Not used	CCG1345	
C811		CKSSYB104K10	CKSTYX104K10	
C863		CKSRYX225K10	CKSSBYX225M16	

Circuit Symbol and No.	Part Name	DEH-S1150UB/XNGS1	DEH-S1250UB/XNGS1
C868		CKSQYX106K16	CKSRAYX106M16

A

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1252UB/XNES
IC371	Flash ROM Unit	QVQ1066	QVQ1116
L603	Chip Coil	LCTAWR27J2520	LCYAR27J2016
L604	Chip Coil	LCTAW3R3J2520	LCYA3R3J2016
CN701	Connector	VKN1192	CKS6763
R113		XRS1/16SS682J	XRS1/16SS822J
R177		XRS1/16SS472J	XRS1/16SS222J
R789		XRS1/16SS0R0J	Not used
C166		CKSQYX106K10	CKSRAYX106M10
C167		CKSQYX106K10	CKSRAYX106M10
C169		CKSQYX106K10	CKSRAYX106M10
C173		CKSRYX105K16	Not used
C174		CKSRYX105K16	CKSSYX105K16
C177		CKSQYX106K10	CKSRAYX106M10
C178		CCSSCH391J50	CKSSYB272K50
C179		CKSSYB102K50	CKSTYX222K25
C180		CKSQYX106K10	CKSRAYX106M10
C183		CKSRYX475K6R3	CKSRYX475K16
C192		CKSYX226M16	CKSQYX226M16
C194		CKSRYB103K50	CKSSYB103K50
C197		CKSRYX105K16	CKSSYX105K16
C200	10 uF/35 V	CKSYX106K35	CCG1236
C253		CKSSYB104K10	CKSTYX104K10
C255		CKSRYX225K10	CKSSBYX225M16
C351		CKSSYB104K10	CKSTYX104K10
C352		CKSSYB104K10	CKSTYX104K10
C353		CKSSYB104K10	CKSTYX104K10
C354		CKSSYB104K10	CKSTYX104K10
C357		CKSSYB104K10	CKSTYX104K10
C361		CKSSYB104K10	CKSTYX104K10
C362		CCSSCH101J50	CCSTCH101J50
C363		CKSSYB102K50	CKSTYX102K50
C364		CCSSCH120J50	CCSTCH120J50
C366		CCSSCH120J50	CCSTCH120J50
C368		CKSSYB102K50	CKSTYX102K50
C369		CKSSYB104K10	CKSTYX104K10
C376		CCSSCH120J50	CCSTCH120J50
C379		CCSSCJ3R0C50	CCSTCJ3R0C50
C381		CKSSYB104K10	CKSTYX104K10
C383		CKSSYB104K10	CKSTYX104K10
C384		CCSSCH220J50	CCSTCH220J50
C385		CKSSYB104K10	CKSTYX104K10
C386		CKSSYB104K10	CKSTYX104K10
C387		CKSSYB104K10	CKSTYX104K10

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1252UB/XNES
C388		CCSSCH330J50	CCSTCH330J50
C389		CKSSYB104K10	CKSTYX104K10
C390		CCSSCH100D50	CCSTCH100D50
C391		CCSSCH220J50	CCSTCH220J50
C392		CCSSCH220J50	CCSTCH220J50
C393		CCSSCH220J50	CCSTCH220J50
C394		CKSSYB104K10	CKSTYX104K10
C395		CKSSYB103K16	CKSTYX103K16
C399		CKSSYB104K10	CKSTYX104K10
C400		CCSSCH100D50	CCSTCH100D50
C405		Not used	CKSTYX104K10
C563		CKSQYX106K10	CKSRAYX106M10
C565		CKSSYB104K10	CKSTYX104K10
C568		CKSSYB104K10	CKSTYX104K10
C569		CKSSYB104K10	CKSTYX104K10
C570		CKSQYX106K10	CKSRAYX106M10
C575		CKSQYX106K10	CKSRAYX106M10
C576		CKSSYB104K10	CKSTYX104K10
C577		CKSQYX106K10	CKSRAYX106M10
C583		CKSQYX106K10	CKSRAYX106M10
C584		CKSSYB104K10	CKSTYX104K10
C585		CKSSYB104K10	CKSTYX104K10
C586		CKSSYB104K10	CKSTYX104K10
C587		CKSSYB102K50	CKSTYX102K50
C592		Not used	CKSRAYX106M10
C593		Not used	CKSRAYX106M10
C602		CCSSCK2R0C50	CCSTCK2R0C50
C603		CCSSCK1R0C50	CCSTCK1R0C50
C604		CCSSCK1R0C50	CCSTCK1R0C50
C605		CCSSCH120J50	CCSTCH120J50
C607		CKSSYB102K50	CKSTYX102K50
C610		CKSSYB152K50	CKSTYX152K50
C611		CCSSCH120J50	CCSTCH120J50
C612		CCSSCH5R0C50	CCSTCH5R0C50
C613		CCSSCH120J50	CCSTCH120J50
C615		CKSSYB104K10	CKSTYX104K10
C617		CKSSYB102K50	CKSTYX102K50
C621		CCSSCH180J50	CCSTCH180J50
C624		CKSRYX225K10	CKSSBYX225M16
C626		CKSQYX106K10	CKSRAYX106M10
C632		CKSSYB104K16	CKSTYX104K10
C633		CKSSYB104K16	CKSTYX104K10
C635		CKSSYB104K10	CKSTYX104K10
C639		CCSSCH471J50	CKSTYX471K50
C701		CKSSYB103K16	CKSTYX103K16

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1252UB/XNES
C702		CKSSYB103K16	CKSTYX103K16
C709		CKSSYB104K10	CKSTYX104K10
C760		CKSSYB104K10	CKSTYX104K10
C801	1 000 pF	CCG1345	Not used
C802	1 000 pF	Not used	CCG1345
C811		CKSSYB104K10	CKSTYX104K10
C863		CKSRYPX225K10	CKSSBYX225M16
C868		CKSQYX106K16	CKSRAYX106M16

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1253UB/XNES
IC321	Interface IC	Not used	STCC2540IQ
IC371	Flash ROM Unit	QVQ1066	QVQ1116
Q753	Transistor	Not used	EMH53
D302	Zener Diode	Not used	RSB6R8SM
D303	Zener Diode	Not used	RSB6R8SM
D701	Zener Diode	Not used	RSB6R8SM
D702	Zener Diode	Not used	RSB6R8SM
D815	Zener Diode	Not used	RSB6R8SM
D816	Zener Diode	Not used	RSB6R8SM
D817	Zener Diode	Not used	RSB6R8SM
L301	Noise Filter	Not used	CTF1901
L603	Chip Coil	LCTAWR27J2520	LCYAR27J2016
L604	Chip Coil	LCTAW3R3J2520	LCYA3R3J2016
CN701	Connector	VKN1192	CKS6763
JA751	Jack	CKB1109	CKB1113
R113		XRS1/16SS682J	XRS1/16SS822J
R177		XRS1/16SS472J	XRS1/16SS222J
R182		XRS1/16SS820J	XRS1/16SS680J
R184		XRS1/16SS682J	XRS1/16SS4701F
R323		Not used	XRS1/16SS2702F
R325		Not used	XRS1/16SS103J
R326		Not used	XRS1/16SS103J
R327		Not used	XRS1/16SS0R0J
R328		Not used	XRS1/16SS103J
R329		XRS1/10SR0R0J	Not used
R330		XRS1/16SS0R0J	Not used
R331		XRS1/16SS0R0J	Not used
R332		XRS1/10SR0R0J	Not used
R334		XRS1/16SS0R0J	Not used
R335		XRS1/16SS0R0J	Not used
R337		Not used	XRS1/16SS0R0J
R378		Not used	XRS1/16SS473J
R379		XRS1/16SS473J	XRS1/16SS103J
R417		Not used	XRS1/16SS101J
R420		Not used	XRS1/16SS101J

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1253UB/XNES	
R432	10 uF/35 V	Not used	XRS1/16SS103J	A
R724		Not used	XRS1/16SS0R0J	
R759		Not used	XRS1/16SS821J	
R760		Not used	XRS1/16SS821J	
R761		Not used	XRS1/16SS223J	
R762		Not used	XRS1/16SS223J	
R763		Not used	XRS1/16SS0R0J	
R764		XRS1/16SS0R0J	Not used	
R765		XRS1/16SS0R0J	Not used	
R766		Not used	XRS1/16SS0R0J	
R789		XRS1/16SS0R0J	Not used	B
C166		CKSQYX106K10	CKSRAYX106M10	
C167		CKSQYX106K10	CKSRAYX106M10	
C169		CKSQYX106K10	CKSRAYX106M10	
C173		CKSRYX105K16	Not used	
C174		CKSRYX105K16	CKSSYX105K16	C
C177		CKSQYX106K10	CKSRAYX106M10	
C178		CCSSCH391J50	CKSSYB272K50	
C179		CKSSYB102K50	CKSTYX222K25	
C180		CKSQYX106K10	CKSRAYX106M10	
C183		CKSRYX475K6R3	CKSRYX475K16	
C192		CKSYX226M16	CKSQYX226M16	
C194		CKSRYB103K50	CKSSYB103K50	
C197		CKSRYX105K16	CKSSYX105K16	
C198		Not used	CEAT102M16	
C200		CKSYX106K35	CCG1236	D
C253		CKSSYB104K10	CKSTYX104K10	
C255		CKSRYX225K10	CKSSBYX225M16	
C321		Not used	CKSTYX104K10	
C322		Not used	CKSRAYX106M10	
C323		Not used	CKSRAYX106M10	
C351		CKSSYB104K10	CKSTYX104K10	
C352		CKSSYB104K10	CKSTYX104K10	
C353		CKSSYB104K10	CKSTYX104K10	
C354		CKSSYB104K10	CKSTYX104K10	
C357		CKSSYB104K10	CKSTYX104K10	E
C361		CKSSYB104K10	CKSTYX104K10	
C362		CCSSCH101J50	CCSTCH101J50	
C363		CKSSYB102K50	CKSTYX102K50	
C364		CCSSCH120J50	CCSTCH120J50	
C366		CCSSCH120J50	CCSTCH120J50	F
C368		CKSSYB102K50	CKSTYX102K50	
C369		CKSSYB104K10	CKSTYX104K10	
C376		CCSSCH120J50	CCSTCH120J50	
C379		CCSSCJ3R0C50	CCSTCJ3R0C50	

	Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1253UB/XNES
A	C381		CKSSYB104K10	CKSTYX104K10
	C383		CKSSYB104K10	CKSTYX104K10
	C384		CCSSCH220J50	CCSTCH220J50
	C385		CKSSYB104K10	CKSTYX104K10
	C386		CKSSYB104K10	CKSTYX104K10
	C387		CKSSYB104K10	CKSTYX104K10
	C388		CCSSCH330J50	CCSTCH330J50
	C389		CKSSYB104K10	CKSTYX104K10
	C390		CCSSCH100D50	CCSTCH100D50
	C391		CCSSCH220J50	CCSTCH220J50
B	C392		CCSSCH220J50	CCSTCH220J50
	C393		CCSSCH220J50	CCSTCH220J50
	C394		CKSSYB104K10	CKSTYX104K10
	C395		CKSSYB103K16	CKSTYX103K16
	C399		CKSSYB104K10	CKSTYX104K10
	C400		CCSSCH100D50	CCSTCH100D50
	C405		Not used	CKSTYX104K10
	C563		CKSQYX106K10	CKSRAYX106M10
	C565		CKSSYB104K10	CKSTYX104K10
	C568		CKSSYB104K10	CKSTYX104K10
C	C569		CKSSYB104K10	CKSTYX104K10
	C570		CKSQYX106K10	CKSRAYX106M10
	C575		CKSQYX106K10	CKSRAYX106M10
	C576		CKSSYB104K10	CKSTYX104K10
	C577		CKSQYX106K10	CKSRAYX106M10
	C583		CKSQYX106K10	CKSRAYX106M10
	C584		CKSSYB104K10	CKSTYX104K10
	C585		CKSSYB104K10	CKSTYX104K10
	C586		CKSSYB104K10	CKSTYX104K10
	C587		CKSSYB102K50	CKSTYX102K50
D	C592		Not used	CKSRAYX106M10
	C593		Not used	CKSRAYX106M10
	C602		CCSSCK2R0C50	CCSTCK2R0C50
	C603		CCSSCK1R0C50	CCSTCK1R0C50
	C604		CCSSCK1R0C50	CCSTCK1R0C50
E	C605		CCSSCH120J50	CCSTCH120J50
	C607		CKSSYB102K50	CKSTYX102K50
	C610		CKSSYB152K50	CKSTYX152K50
	C611		CCSSCH120J50	CCSTCH120J50
	C612		CCSSCH5R0C50	CCSTCH5R0C50
	C613		CCSSCH120J50	CCSTCH120J50
	C615		CKSSYB104K10	CKSTYX104K10
	C617		CKSSYB102K50	CKSTYX102K50
	C621		CCSSCH180J50	CCSTCH180J50
	C624		CKSRYX225K10	CKSSBYX225M16
F				

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1253UB/XNES
C626		CKSQYX106K10	CKSRAYX106M10
C632		CKSSYB104K16	CKSTYX104K10
C633		CKSSYB104K16	CKSTYX104K10
C635		CKSSYB104K10	CKSTYX104K10
C639		CCSSCH471J50	CKSTYX471K50
C701		CKSSYB103K16	CKSTYX103K16
C702		CKSSYB103K16	CKSTYX103K16
C709		CKSSYB104K10	CKSTYX104K10
C760		CKSSYB104K10	CKSTYX104K10
C764		Not used	CKSQYX106K10
C765		Not used	CKSQYX106K10
C801	1 000 pF	CCG1345	Not used
C802	1 000 pF	Not used	CCG1345
C804		CKSSYX105K10	Not used
C811		CKSSYB104K10	CKSTYX104K10
C863		CKSRYX225K10	CKSSBYX225M16
C868		CKSQYX106K16	CKSRAYX106M16

Circuit Symbol and No.	Part Name	DEH-S1190UB/XNID	DEH-S1290UB/XNID
IC371	Flash ROM Unit	QVQ1066	QVQ1116
L603	Chip Coil	LCTAWR27J2520	LCYAR27J2016
L604	Chip Coil	LCTAW3R3J2520	LCYA3R3J2016
CN701	Connector	VKN1192	CKS6763
R113		XRS1/16SS682J	XRS1/16SS822J
R177		XRS1/16SS472J	XRS1/16SS222J
R789		XRS1/16SS0R0J	Not used
C166		CKSQYX106K10	CKSRAYX106M10
C167		CKSQYX106K10	CKSRAYX106M10
C169		CKSQYX106K10	CKSRAYX106M10
C173		CKSRYX105K16	Not used
C174		CKSRYX105K16	CKSSYX105K16
C177		CKSQYX106K10	CKSRAYX106M10
C178		CCSSCH391J50	CKSSYB272K50
C179		CKSSYB102K50	CKSTYX222K25
C180		CKSQYX106K10	CKSRAYX106M10
C183		CKSRYX475K6R3	CKSRYX475K16
C192		CKSYX226M16	CKSQYX226M16
C194		CKSRYB103K50	CKSSYB103K50
C197		CKSRYX105K16	CKSSYX105K16
C200	10 uF/35 V	CKSYX106K35	CCG1236
C253		CKSSYB104K10	CKSTYX104K10
C255		CKSRYX225K10	CKSSBYX225M16
C321		CKSSYB104K10	CKSTYX104K10
C322		CKSQYX106K10	CKSRAYX106M10
C323		CKSQYX106K10	CKSRAYX106M10
C351		CKSSYB104K10	CKSTYX104K10

	Circuit Symbol and No.	Part Name	DEH-S1190UB/XNID	DEH-S1290UB/XNID
A	C352		CKSSYB104K10	CKSTYX104K10
	C353		CKSSYB104K10	CKSTYX104K10
	C354		CKSSYB104K10	CKSTYX104K10
	C357		CKSSYB104K10	CKSTYX104K10
	C361		CKSSYB104K10	CKSTYX104K10
	C362		CCSSCH101J50	CCSTCH101J50
	C363		CKSSYB102K50	CKSTYX102K50
	C364		CCSSCH120J50	CCSTCH120J50
	C366		CCSSCH120J50	CCSTCH120J50
B	C368		CKSSYB102K50	CKSTYX102K50
	C369		CKSSYB104K10	CKSTYX104K10
	C376		CCSSCH120J50	CCSTCH120J50
	C379		CCSSCJ3R0C50	CCSTCJ3R0C50
	C381		CKSSYB104K10	CKSTYX104K10
	C383		CKSSYB104K10	CKSTYX104K10
	C384		CCSSCH220J50	CCSTCH220J50
	C385		CKSSYB104K10	CKSTYX104K10
	C386		CKSSYB104K10	CKSTYX104K10
	C387		CKSSYB104K10	CKSTYX104K10
C	C388		CCSSCH330J50	CCSTCH330J50
	C389		CKSSYB104K10	CKSTYX104K10
	C390		CCSSCH100D50	CCSTCH100D50
	C391		CCSSCH220J50	CCSTCH220J50
	C392		CCSSCH220J50	CCSTCH220J50
D	C393		CCSSCH220J50	CCSTCH220J50
	C394		CKSSYB104K10	CKSTYX104K10
	C395		CKSSYB103K16	CKSTYX103K16
	C399		CKSSYB104K10	CKSTYX104K10
	C400		CCSSCH100D50	CCSTCH100D50
	C405		Not used	CKSTYX104K10
	C563		CKSQYX106K10	CKSRAYX106M10
	C565		CKSSYB104K10	CKSTYX104K10
	C568		CKSSYB104K10	CKSTYX104K10
	C569		CKSSYB104K10	CKSTYX104K10
E	C570		CKSQYX106K10	CKSRAYX106M10
	C575		CKSQYX106K10	CKSRAYX106M10
	C576		CKSSYB104K10	CKSTYX104K10
	C577		CKSQYX106K10	CKSRAYX106M10
	C583		CKSQYX106K10	CKSRAYX106M10
	C584		CKSSYB104K10	CKSTYX104K10
	C585		CKSSYB104K10	CKSTYX104K10
	C586		CKSSYB104K10	CKSTYX104K10
	C587		CKSSYB102K50	CKSTYX102K50
F	C592		Not used	CKSRAYX106M10
	C593		Not used	CKSRAYX106M10

Circuit Symbol and No.	Part Name	DEH-S1190UB/XNID	DEH-S1290UB/XNID	
C602		CCSSCK2R0C50	CCSTCK2R0C50	A
C603		CCSSCK1R0C50	CCSTCK1R0C50	
C604		CCSSCK1R0C50	CCSTCK1R0C50	
C605		CCSSCH120J50	CCSTCH120J50	B
C607		CKSSYB102K50	CKSTYX102K50	
C610		CKSSYB152K50	CKSTYX152K50	
C611		CCSSCH120J50	CCSTCH120J50	
C612		CCSSCH5R0C50	CCSTCH5R0C50	
C613		CCSSCH120J50	CCSTCH120J50	
C615		CKSSYB104K10	CKSTYX104K10	
C617		CKSSYB102K50	CKSTYX102K50	
C621		CCSSCH180J50	CCSTCH180J50	
C624		CKSRYX225K10	CKSSBYX225M16	
C626		CKSQYX106K10	CKSRAYX106M10	C
C632		CKSSYB104K16	CKSTYX104K10	
C633		CKSSYB104K16	CKSTYX104K10	
C635		CKSSYB104K10	CKSTYX104K10	
C639		CCSSCH471J50	CKSTYX471K50	
C701		CKSSYB103K16	CKSTYX103K16	
C702		CKSSYB103K16	CKSTYX103K16	
C709		CKSSYB104K10	CKSTYX104K10	
C760		CKSSYB104K10	CKSTYX104K10	
C801	1 000 pF	CCG1345	Not used	
C802	1 000 pF	Not used	CCG1345	D
C811		CKSSYB104K10	CKSTYX104K10	
C863		CKSRYX225K10	CKSSBYX225M16	
C868		CKSQYX106K16	CKSRAYX106M16	

Keyboard Unit

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1253UB/XNES	
Q1953	Bipolar Transistor	HN1C01FUS1	Not used	
D1952	LED	FC-F1608BAK5	Not used	
D1953	LED	FC-F1608BAK5	Not used	
D1954	LED	FC-F1608BAK5	Not used	
D1955	LED	FC-F1608BAK5	Not used	
D1956	LED	FC-F1608BAK5	Not used	E
D1957	LED	FC-F1608BAK5	Not used	
D1959	LED	FC-F1608BAK5	Not used	
D1960	LED	FC-F1608BAK5	Not used	
D1961	LED	FC-F1608BAK5	Not used	
D1962	LED	FC-F1608BAK5	Not used	F
D1963	LED	FC-F1608BAK5	Not used	
D1964	LED	FC-F1608BAK5	Not used	
D1965	LED	FC-F1608BAK5	Not used	
D1966	LED	FC-F1608BAK5	Not used	
D1967	LED	FC-F1608BAK5	Not used	

Circuit Symbol and No.	Part Name	DEH-S1152UB/XNES	DEH-S1253UB/XNES
D1968	LED	FC-F1608BAK5	Not used
R1956		XRS1/10SR182J	Not used
R1958		XRS1/10SR561J	Not used
R1960		XRS1/10SR391J	Not used
R1964		XRS1/10SR392J	Not used
R1966		XRS1/10SR392J	Not used
R1968		XRS1/10SR392J	Not used
R1970		XRS1/10SR332J	Not used
R1972		XRS1/10SR332J	Not used
R1992		XRS1/10SR102J	Not used
R1993		XRS1/10SR103J	Not used
R1994		XRS1/10SR102J	Not used
R1995		XRS1/10SR103J	Not used
R1996		Not used	XRS1/10SR0R0J

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.