

2. CONTRAST OF MISCELLANEOUS PARTS

- NOTES: • Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 • The "!" mark found on some component parts indicates The importance of The safety factor of The part. Therefore, when replacing, be sure to use parts of identical designation.
 • Nos. indicate the pages and Nos. in the service manual for the base model.

CONTRAST TABLE

PACKING SECTION

DDJ-1000SRT/FWLXJ and DDJ-1000SRT-N/PWXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-1000SRT /FWLXJ	DDJ-1000SRT-N /PWXJ	Remarks
	P89-20	PACKING CASE	DHG3716	DHG3802	
NSP	P89-21	LABEL	DRW2799	DRW2975	

DDJ-1000SRT/UXJCB and DDJ-1000SRT-N/UXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-1000SRT /UXJCB	DDJ-1000SRT-N /UXJ	Remarks
	P89-20	PACKING CASE	DHG3716	DHG3802	
	P89-21	LABEL	DRW2798	————	
NSP		LABEL	————	DRW2976	Attached to QSG

EXTERIOR SECTION

DDJ-1000SRT/FWLXJ, DDJ-1000SRT-N/PWXJ and DDJ-1000SRT-N/UXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-1000SRT /FWLXJ	DDJ-1000SRT-N /PWXJ	DDJ-1000SRT-N /UXJ	Remarks
		BOTTOM SECTION				
	P91-18	KNOB/SLD	DNK6682	DNK5981	DNK5981	
	P91-19	DIAL KNOB	DAA1399	DAA1246	DAA1246	
	P91-21	SLIDER KNOB 1 / KNOB	DAC3540	DAC3539	DAC3539	
	P91-23	KNOB	DAC3437	DAC3238	DAC3238	
	P91-26	SLIDE SHEET 1C / SHEET	DAH2404	DAH3319	DAH3319	
		CONTROL PANEL SECTION				
!	P96-4	CONTROL PANEL	DNK6888	DNK6980	DNK6980	
	P96-5	PLATE	DAH3290	DAH3333	DAH3333	DECK L
	P96-6	PLATE	DAH3291	DAH3334	DAH3334	DECK R
	P96-8	PLATE	DAH3292	DAH3336	DAH3336	MIXER
	P96-14	BUTTON	DAC3360	DAC3573	DAC3573	DECK SELECT
	P96-16	BUTTON	DAC3506	DAC3572	DAC3572	SHIFT
	P96-17	BUTTON	DAC3507	DAC3571	DAC3571	BEAT JUMP
	P96-18	BUTTON	DXB2170	DXB2211	DXB2211	PLYA/CUE
	P96-23	BUTTON	DAC3515	DAC3574	DAC3574	KEY RESET
	P96-28	BUTTON	DAC3372	DAC3575	DAC3575	BEAT ◀, ▶
	P96-32	SHEET	DEC3865	DEC3964	DEC3964	FRONT
	P96-33	SHEET	DEC3866	DEC3965	DEC3965	REAR
		JOG DIAL SECTION				
	P98-11	JOG PLATE / PLATE	DAH2679	DAH3339	DAH3339	
	P98-13	JOG B / JOG DIAL	DNK4068	DNK6957	DNK6957	