
2. EXPLODED VIEWS AND PARTS LIST

NOTES : • Parts marked by " " are generally unavailable because they are not in our Master Spare Parts List.*
• Screw adjacent to ▽ mark on the product are used for disassembly.
• For the applying amount of lobricants or glue, follow the instructions in this manual.
(In the case of no amount instructions,apply as you think it appropriate.)

2.1 PACKING



(1) PACKING SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Polyethylene Bag	CEG1173
	2	Cord Assy	CDE7154
	3	Accessory Assy	CEA3376
	4	Spring	CBH1650
	5	Screw Assy	CEA3848
	6	Fixing screw	BPZ20P060FZK
	7	Screw	CBA1650
*	8	Polyethylene Bag	CEG-127
	9	Screw	CRZ50P090FTC
	10	Screw	TRZ50P080FTC
*	11	Polyethylene Bag	CEG-158
	12	Handle	CNC5395
	13	Holder	CND1249
	14	Holder	CND1250
	15	Bush	CNV3930
	16	Remote Control Assy	See Contrast table(2)
*	17	Battery	See Contrast table(2)
	18	Carton	See Contrast table(2)
	19	Contain Box	See Contrast table(2)
	20	Protector	CHP2663
	21	Protector	CHP2664
	22-1	Owner's Manual	See Contrast table(2)
	22-2	Installation Manual	See Contrast table(2)
*	22-3	Warranty Card	See Contrast table(2)
*	22-4	Card	See Contrast table(2)
*	22-5	Caution Card	CRP1207
*	22-6	Caution Card	See Contrast table(2)
	23	Case Assy	CXB3520
	24	Remote Control Assy	See Contrast table(2)
	25	Screw Assy	See Contrast table(2)
*	26	Polyethylene Bag	See Contrast table(2)
*	27	Hexagonal Wrench	See Contrast table(2)
*	28	Screw	See Contrast table(2)
	29	Belt	See Contrast table(2)
	30	Holder Assy	See Contrast table(2)
	31	Holder Assy	See Contrast table(2)
	32	Remote Control Assy	See Contrast table(2)
	33	Inner Box	XHW7001

(2) CONTRAST TABLE


DEH-P660/XN/UC and DEH-P6600/XN/UC are constructed the same except for the following:

Mark	NO.	Description	DEH-P660/XN/UC	DEH-P6600/XN/UC
	16	Remote Control Assy	Not used	CXC3173
*	17	Battery	Not used	CEK1065
	18	Carton	XHG7028	XHG7029
	19	Contain Box	XHL7028	XHL7029
	22-1	Owner's Manual	XRD7050	XRD7052
	22-2	Installation Manual	XRD7051	XRD7053
*	22-3	Warranty Card	CRY1070	Not used
*	22-4	Card	Not used	ARY1048
*	22-6	Caution Card	Not used	CRP1294
	24	Remote Control Assy	CXB9202	Not used
	25	Screw Assy	CZE3169	Not used
*	26	Polyethylene Bag	CEG-127	Not used
*	27	Hexagonal Wrench	CZE3176	Not used
*	28	Screw	RMZ30H060FBK	Not used
	29	Belt	CZN7661	Not used
	30	Holder Assy	CZX3172	Not used
	31	Holder Assy	CZX3173	Not used
	32	Remote Control Assy	CZX3257	Not used

Owner's Manual,Installation Manual

Part No.	Language
XRD7050, XRD7051, XRD7052, XRD7053	English, Spanish

2.2 EXTERIOR


8
90
17
91
18
7
6
2
46
15
5
70
77
81
80
82
79
78
83
84
85
75
71
72
92
87
76
74
89
88
86
73
69
10
12
48
94
93
64
52
62
16
96
68
63
50
95
3
55
53
51
60
57
54
56
61
58
59
67
66
13
9
49
47
34
35
28
36
24
22
39
41
44
30
37
29
23
32
26
25
40
43
42
45
21
20
14
38
27
31
33
11
4
1
19

(1) EXTERIOR SECTION PARTS LIST


Mark	No.	Description	Part No.
	1	Screw	BMZ30P040FZK
	2	Screw	BSZ26P060FTC
	3	Screw	BSZ30P060FTC
	4	Screw	BSZ30P200FTC
	5	Cord Assy	CDE7129
	6	Cord Assy	CDE7154
	7	Case	CNB2793
	8	Holder	CNC8659
	9	Earth Plate	CNC8915
	10	Insulator	CNM7682
	11	Insulator	CNM7935
	12	Insulator	CNM8174
	13	Cushion	CNM8890
	14	Panel	See Contrast table(2)
	15	Cap	CNV6727
	16	•••••	
	17	Remote Control Assy	See Contrast table(2)
	18	Cover	See Contrast table(2)
	19	Chassis Unit	CXB9528
	20	Button(EJECT)	CAC7752
	21	Screw(M2x4.5)	CBA1647
	22	Screw(M2x4)	CBA1649
	23	Washer	CBF1038
	24	Spring	CBH2650
	25	Spring	CBH2651
	26	Spring	CBH2652
	27	Spring	CBH2653
	28	Holder	CND1254
	29	Gear	CNV5997
	30	Arm	CNV7400
	31	Arm	CNV7401
	32	Arm	CNV7402
	33	Arm	CNV7403
	34	Panel Unit	CWM8758
	35	Socket(CN1950)	CKS3550
	36	Connector(CN1951)	CKS4806
	37	Holder Unit	CXB9501
	38	Holder Unit	CXB9502
	39	Damper Unit	CXB9503
	40	Panel Unit(Service)	CXX1691
	41	Spring	CBL1512
	42	Cover	CNM6854
	43	Panel	CNS7245
	44	Pin	CNV6486
	45	Lighting Conductor	CNV6487
	46	CD Mechanism Module(S10)	CXK5602
	47	Screw	ISS26P055FTC
	48	Cable	XDE7003
	49	Tuner Amp Unit	See Contrast table(2)
	50	Screw	ASZ26P060FTC
	51	Screw	BPZ26P080FTC
	52	Screw	BSZ26P160FTC
	53	Fuse(10A)	CEK1208
	54	Pin Jack(CN352)	CKB1051
	55	Plug(CN901)	CKM1376
	56	Plug(CN351)	CKS1238
	57	Connector(CN101)	CKS3408
	58	Plug(CN801)	CKS3537
	59	Connector(CN651)	CKS3835
	60	Connector(CN161)	CKS4124
	61	Antenna Jack(CN401)	CKX1056
	62	Holder	CND1270
	63	Holder	CND1352
	64	Heat Sink	CNR1668
	65	•••••	
	66	FM/AM Tuner Unit	CWE1646
	67	Holder	CND1054
	68	Insulator	XNM7031
	69	Detachable Assy	See Contrast table(2)
	70	Screw	BPZ20P100FZK
	71	Spring	CBL1470
	72	Knob	See Contrast table(2)
	73	Button(1-6)	XAC7005
	74	Button(OPEN)	See Contrast table(2)
	75	Button(TEXT/SCRL/AUDIO/FUNC)	XAC7041
	76	Spring	XBH7001
	77	Cover	XNS7013
	78	Keyboard Unit	See Contrast table(2)
	79	Connector(CN1901)	CKS4524
	80	Cushion	CNM6633
	81	Spacer	CNM7697
	82	Spacer	CNM7698
	83	Holder	CNV6910
	84	OEL Unit	MXS8201
	85	Holder	XNC7006
	86	Button Unit(EQ-EX)	XXA7007
	87	Button Unit(EQ)	XXA7008
	88	Sub Grille Assy	See Contrast table(2)
	89	Sub Button Assy	See Contrast table(2)
	90	Remote Control Unit	See Contrast table(2)
	91	Cover	See Contrast table(2)
	92	Cushion	XNM7041
	93	Screw	See Contrast table(2)
	94	Holder	See Contrast table(2)
	95	Transistor(Q651,911,921)	2SD 2396
	96	Choke Coil(L301)	CTH1280

(2) CONTRAST TABLE

DEH-P660/XN/UC and DEH-P6600/XN/UC are constructed the same except for the following:

Mark	NO.	Description	DEH-P660/XN/UC	DEH-P6600/XN/UC
	14	Panel	CNS6935	XNS7070
	17	Remote Control Assy	CZX3257	Not used
	18	Cover	CZN7655	Not used
	49	Tuner Amp Unit	XWM7049	XWM7050
	69	Detachable Assy	XXA7171	XXA7172
	72	Knob	XAA7009	XAA7003
	74	Button(OPEN)	XAC7026	XAC7012
	78	Keyboard Unit	XWM7055	XWM7056
	88	Sub Grille Assy	XXA7164	XXA7165
	89	Sub Button Assy	XXA7225	XXA7224
	90	Remote Control Unit	Not used	CXC3173
	91	Cover	Not used	CNS7068
	93	Screw	Not used	BMZ40P140FTC
	94	Holder	Not used	CNV7619

2.3 CD MECHANISM MODULE



CD MECHANISM MODULE SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	CD Core Unit(S10)	CWX2947
	2	Connector(CN101)	CKS4182
	3	Connector(CN701)	CKS4188
	4	Screw	BMZ20P035FTC
	5	Screw	BSZ20P040FTC
	6	Screw(M2x4)	CBA1362
	7	Screw(M2x3)	CBA1511
	8	Screw(M2x3)	CBA1527
	9	•••••	
	10	Washer	CBF1038
	11	Washer	CBF1060
	12	Spring	CBH2390
	13	Spring	CBH2606
	14	Spring	CBH2607
	15	Spring	CBH2608
	16	Spring	CBH2609
	17	Spring	CBH2610
	18	Spring	CBH2735
	19	Spring	CBH2612
	20	Spring	CBH2613
	21	Spring	CBH2614
	22	Spring	CBH2615
	23	Spring	CBH2616
	24	Spring	CBH2617
	25	Spring	CBH2620
	26	Spring	CBH2621
	27	Spring	CBH2641
	28	Spring	CBH2642
	29	Spring	CBH2643
	30	Spring	CBH2659
	31	Spring	CBH2688
	32	•••••	
	33	Shaft	CLA4441
	34	Frame	CNC9962
	35	Frame	CNC9963
	36	Bracket	CNC9966
	37	Bracket	CND1895
	38	Arm	CNC9968
	39	Arm	CND1909
	40	Lever	CND2032
	41	Lever	CNC9984
	42	Sheet	CNM8134
	43	Collar	CNV7798
	44	Guide	CNV7799
	45	Arm	CNV7800
	46	Rack	CNV7199
	47	Holder	CNV7201
	48	Holder	CNV7202
	49	Arm	CNV7203
	50	Gear	CNV7207
	51	Gear	CNV7208
	52	Gear	CNV7209
	53	Gear	CNV7210
	54	Gear	CNV7211
	55	Gear	CNV7212
	56	Rack	CNV7214
	57	Arm	CNV7215
	58	Arm	CNV7216
	59	Guide	CNV7217
	60	Roller	CNV7218
	61	Gear	CNV7219
	62	Arm	CNV7221
	63	Arm	CNV7220
	64	Arm	CNV7222
	65	Damper	CNV7313
	66	Damper	CNV7314
	67	Arm	CNV7341
	68	Arm	CNV7342
	69	Guide	CNV7360
	70	Guide	CNV7361
	71	Holder	CNV7437
	72	Arm	CNV7805
	73	Gear	CNV7595
	74	Damper	CNV7618
	75	Motor Unit(M1)	CXB6007
	76	Chassis Unit	CXC2318
	77	Screw Unit	CXB8729
	78	Gear Unit	CXC2397
	79	Arm Unit	CXC2316
	80	Arm	CND1896
	81	Arm	CND1894
	82	Motor Unit(M2)	CXB8933
	83	Bracket	CNC9985
	84	•••••	
	85	Screw(M2x5)	EBA1028
	86	Screw	JFZ20P020FTC
	87	Screw	JGZ17P022FTC
	88	•••••	
	89	Washer	YE20FTC
	90	Pickup Unit(P10)(Service)	CXX1641
	91	Screw	IMS26P030FTC
	92	Spring	CBL1635
	93	Clamper	CNV7197

5. ELECTRICAL PARTS LIST

NOTE:

- *Parts whose parts numbers are omitted are subject to being not supplied.*
- *The part numbers shown below indicate chip components.*

Chip Resistor

RS1/◯S◯◯◯J,RS1/◯◯S◯◯◯J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

A

Unit Number:XWM7049(DEH-P660)
Unit Number:XWM7050(DEH-P6600)
Unit Name:Tuner Amp Unit

MISCELLANEOUS

Circuit Symbol and No.		Part No.
IC 101	IC	HA12240FP
IC 131	IC	NJM4558MD
IC 201	IC	PML009A
IC 301	IC	PAL007A
IC 401	IC	NJM2391DL1-33
IC 601	IC	PD5923A
IC 602	IC	S-80835CNUA-B8U
IC 652	IC	TC7SET08FU
IC 653	IC	TC7SET08FU
IC 801	IC	TC7SET08FU
IC 851	IC	NJM2360M
Q 101	Transistor	2SA1576
Q 102	Transistor	DTC114EU
Q 301	Transistor	DTC124EU
Q 351	Transistor	UMH3N
Q 352	Transistor	UMH3N
Q 353	Transistor	UMH3N
Q 651	Transistor	2SD2396
Q 652	Transistor	UMD2N
Q 803	Transistor	2SD1767
Q 804	Transistor	UMD2N
Q 805	Transistor	DTC143EU
Q 807	Transistor	2SA1576
Q 808	Transistor	DTC114EU
Q 851	Transistor	2SD1760F5
Q 852	Transistor	UMD2N
Q 911	Transistor	2SD2396
Q 913	Transistor	UMD2N
Q 921	Transistor	2SD2396
Q 922	Transistor	DTC114EU
Q 923	Transistor	2SB1243
Q 931	Transistor	UMX1N
Q 932	Transistor	DTC114EU
Q 951	Transistor	2SA1576
Q 981	Transistor	2SC4081
Q 982	Transistor	UMD2N
D 131	Diode Network	DA204U
D 132	Diode Network	DA204U
D 133	Diode	DAN202U
D 134	Diode	DAP202U

Circuit Symbol and No.		Part No.
D 301	Diode	S5688G
D 302	Diode	S5688G
D 303	Diode	S5688G
D 304	Diode	S5688G
D 401	Diode	S5688G
D 402	Diode	S5688G
D 403	Diode	S5688G
D 651	Diode	HZS9L(B1)
D 803	Diode Network	DA204U
D 804	Diode	DAN202U
D 805	Diode	DAP202U
D 806	Diode	DAN202U
D 807	Diode	DAP202U
D 808	Diode	HZS11L(A1)
D 851	Diode	HZS11L(A1)
D 852	Diode	RB411D
D 911	Diode	S5688G
D 912	Diode	HZS6L(B1)
D 921	Diode	HZS9L(B3)
D 931	Diode	HZS7L(A1)
D 932	Diode	HZS7L(C3)
D 937	Diode	MA111
D 951	Diode	DAN202U
D 981	Diode	DAN202U
D 982	Diode	HZS9L(A2)
L 101	Inductor	LAU2R2K
L 201	Ferri-Inductor	LAU4R7K
L 301	Choke Coil 600µH	CTH1280
L 401	Ferri-Inductor	LAU4R7K
L 403	Inductor	LAU1R0K
L 404	Inductor	LAU1R0K
L 405	Inductor	LAUR47K
L 406	Inductor	CTF1385
L 601	Ferri-Inductor	LAU100K
L 651	Inductor	CTF1382
L 802	Inductor	CTF1382
L 852	Inductor	CTF1510
L 853	Inductor	CTF1489
L 951	Inductor	LAU2R2K
X 601	Radiator 10.00MHz	CSS1599
S 802	Switch(DETACH SENSE)	CSN1039
FU351	Fuse 3A	CEK1286
FU353	Fuse 3A	CEK1286
BZ641	Buzzer	CPV1062
AR401	Surge Protector	DSP-201M-S00B
	FM/AM Tuner Unit	CWE1646
	Fuse 10A	CEK1208

RESISTORS

Circuit Symbol and No.		Part No.
R 101		RS1/16S101J
R 102		RS1/16S620J
R 103		RS1/16S101J
R 104		RS1/16S222J
R 105		RS1/16S102J
R 106		RS1/16S472J
R 107		RS1/16S223J
R 108		RS1/16S472J
R 109		RS1/16S821J
R 110		RS1/16S821J
R 111		RS1/16S223J
R 112		RS1/16S223J
R 113		RS1/16S102J
R 114		RS1/16S102J
R 115		RS1/16S472J
R 133		RS1/16S563J
R 134		RS1/16S104J
R 139		RS1/16S563J
R 140		RS1/16S104J
R 147		RS1/16S474J
R 148		RS1/16S474J
R 161		RS1/16S102J
R 162		RS1/16S102J
R 163		RS1/16S103J
R 164		RS1/16S103J
R 201		RAB4C102J
R 241		RS1/16S0R0J
R 242		RS1/16S0R0J
R 247		RS1/16S101J
R 248		RS1/16S101J
R 249		RS1/16S101J
R 250		RS1/16S101J
R 301		RS1/16S103J
R 302		RS1/16S103J
R 303		RS1/16S153J
R 304		RS1/16S331J
R 351		RS1/16S821J
R 352		RS1/16S821J
R 353		RS1/16S821J
R 354		RS1/16S821J
R 355		RS1/16S821J
R 356		RS1/16S821J
R 357		RS1/16S223J
R 358		RS1/16S223J
R 359		RS1/16S223J
R 360		RS1/16S223J
R 361		RS1/16S223J
R 362		RS1/16S223J
R 403		RS1/16S681J
R 405		RS1/16S681J
R 406		RS1/16S681J
R 407		RS1/16S681J
R 408		RS1/16S681J
R 410		RS1/16S681J
R 416		RS1/16S681J
R 417		RS1/16S681J
R 419		RS1/16S681J
R 421		RS1/16S681J

Circuit Symbol and No.		Part No.
R 601	(DEH-P660)	RS1/16S104J
R 602	(DEH-P6600)	RS1/16S104J
R 606		RS1/16S104J
R 607		RS1/16S822J
R 616		RS1/16S473J
R 617		RS1/16S102J
R 630		RS1/16S104J
R 632		RS1/16S104J
R 641		RS1/16S102J
R 648		RS1/16S221J
R 649		RS1/16S221J
R 651		RD1/4PU221J
R 652		RD1/4PU221J
R 653		RS1/16S472J
R 654		RS1/16S222J
R 655		RS1/16S102J
R 656		RS1/16S0R0J
R 657		RS1/16S0R0J
R 658		RS1/16S102J
R 659		RS1/16S221J
R 660		RS1/16S221J
R 661		RS1/16S221J
R 662		RS1/16S221J
R 663		RS1/16S102J
R 664		RS1/16S221J
R 665		RD1/4PU0R0J
R 667		RS1/16S221J
R 668		RS1/16S222J
R 670		RS1/16S221J
R 673		RS1/16S104J
R 677		RS1/16S104J
R 682		RS1/16S221J
R 684		RS1/16S0R0J
R 689		RS1/16S0R0J
R 802		RS1/16S222J
R 803		RS1/16S472J
R 804		RS1/16S1R0J
R 805		RS1/16S391J
R 806		RS1/16S391J
R 807		RS1/16S473J
R 808		RS1/16S473J
R 809		RS1/16S102J
R 810		RS1/16S222J
R 811		RS1/16S222J
R 812		RS1/16S222J
R 813		RS1/16S222J
R 814		RS1/16S222J
R 815		RS1/16S473J
R 816		RS1/16S104J
R 817		RD1/4PU391J
R 818		RS1/16S104J
R 819		RS1/16S222J
R 820		RS1/16S222J
R 823		RS1/16S102J
R 824		RS1/16S473J
R 825		RS1/16S102J
R 826		RS1/16S102J
R 827		RS1/16S102J
R 828		RS1/16S102J
R 851		RS1/16S331J

Circuit Symbol and No.	Part No.
R 852	RD1/4PU302J
R 853	RD1/4PU302J
R 854	RS1/16S121J
R 855	RS1/16S391J
R 856	RS1/16S1R0J
R 857	RS1/16S331J
R 903	RS1/16S223J
R 912	RS1/16S222J
R 913	RS1/16S223J
R 914	RS1/16S104J
R 915	RS1/16S104J
R 916	RS1/16S104J
R 923	RS1/16S103J
R 924	RD1/4PU122J
R 925	RS1/16S182J
R 931	RS1/16S472J
R 932	RS1/16S473J
R 933	RS1/16S103J
R 934	RS1/16S473J
R 935	RS1/16S104J
R 936	RS1/16S103J
R 938	RD1/4PU102J
R 939	RD1/4PU102J
R 951	RD1/4PU153J
R 952	RS1/16S472J
R 953	RS1/16S472J
R 954	RS1/16S102J
R 983	RS1/16S223J
R 984	RS1/16S473J
R 985	RS1/16S102J

CAPACITORS

Circuit Symbol and No.	Part No.
C 101	CKSRYB104K16
C 102	CKSRYB473K25
C 131	CKSRYB104K16
C 132	CKSRYB104K16
C 141	CKSRYB104K16
C 142	CKSRYB103K50
C 143	CKSRYB474K10
C 144	CKSRYB474K10
C 145	CCSRCH101J50
C 146	CCSRCH101J50
C 147	CKSRYB104K16
C 201	CEJQ1R0M50
C 202	CEJQ1R0M50
C 203	CKSRYB104K16
C 204	CKSRYB104K16
C 205	CKSRYB105K10
C 206	CEJQ470M16
C 207	CEJQ1R0M50
C 208	CEJQ1R0M50
C 209	CEJQ1R0M50
C 210	CEJQ1R0M50
C 211	CEJQ4R7M35
C 212	CEJQ4R7M35
C 213	CEJQ4R7M35
C 214	CEJQ4R7M35
C 215	CEJQ4R7M35
C 216	CEJQ4R7M35
C 217	CEJQ4R7M35
C 218	CEJQ4R7M35
C 219	CCSRCH120J50
C 220	CCSRCH120J50
C 221	CCSRCH120J50
C 222	CCSRCH120J50
C 225	CEJQ100M16
C 306	CEJQ330M10
C 307 3300µF/16V	CCH1486
C 309	CKSRYB104K16
C 310	CEJQ100M16
C 311	CKSYB475K16
C 312	CKSYB475K16
C 317	CKSRYB474K10
C 318	CKSRYB474K10
C 321	CKSRYB474K10
C 322	CKSRYB474K10
C 323	CKSRYB474K10
C 324	CKSRYB474K10
C 325	CKSQYB225K10
C 326	CKSQYB225K10
C 327	CKSRYB474K10
C 328	CKSRYB474K10
C 351	CEJQ4R7M35
C 352	CEJQ4R7M35
C 353	CEJQ4R7M35
C 354	CEJQ4R7M35
C 355	CEJQ4R7M35
C 356	CEJQ4R7M35
C 363	CKSRYB104K16
C 401	CKSRYB103K50
C 402	CEJQ101M10
C 404	CKSYB475K16
C 406	CEJQ470M10
C 408	CKSYB475K16
C 409	CEJQ1R0M50
C 411	CCSRCH101J50
C 412	CCSRCH470J50
C 601	CEJQ4R7M35
C 602	CKSQYB105K16
C 603	CEJQ2R2M50
C 604	CCSRCH200J50
C 605	CCSRCH200J50
C 609	CCSRCH101J50
C 651	CEJQ101M10
C 652	CKSRYB473K25
C 653	CKSRYB473K25
C 656	CKSRYB473K25
C 657	CCSRCH470J50
C 662	CCSRCH471J50
C 755	CKSRYB104K16
C 805	CKSRYB473K25
C 806	CKSRYB473K25
C 807	CKSRYB473K25
C 851	CEJQ470M16
C 853 4.7µF	CCG1111
C 855	CEJQ100M25
C 856	CCSRCH331J50
C 857	CEJQ330M25
C 858	CKSRYB104K16

Circuit Symbol and No.		Part No.
C 859		CEJQ101M10
C 860		CKSRYB104K16
C 861		CKSRYB223K50
C 911	470µF/16V	CCH1331
C 912		CKSRYB472K50
C 913		CKSRYB103K50
C 914		CEJQ470M10
C 921		CEJQ221M10
C 922		CKSRYB103K50
C 923		CEJQ101M16
C 931		CEJQ1R0M50
C 932		CKSRYB104K16

C

Unit Number:XWM7055(DEH-P660)
Unit Number:XWM7056(DEH-P6600)
Unit Name:Keyboard Unit

MISCELLANEOUS

IC 1901	IC	RS-140
IC 1902	IC	S-818A33AUC-BGN
IC 1940	IC	PD5932A
IC 1990	IC(DEH-P660)	PD8123A
IC 1990	IC(DEH-P6600)	PD8119A
Q 1960	Transistor	2SC4617
Q 1961	Transistor	2SC2411K
D 1903	LED	CL-190UB2-X
D 1904	LED	CL-190UB2-X
D 1905	LED	CL-190UB2-X
D 1906	LED	CL-190UB2-X
D 1907	LED	CL-195PG-CD
D 1908	LED	CL-195PG-CD
D 1909	LED	CL-190UB2-X
D 1910	LED	CL-190UB2-X
D 1911	LED	CL-190UB2-X
D 1912	LED	CL-190UB2-X
D 1914	LED	CL-195PG-CD
D 1940	Diode	1SS355
L 1901	Inductor	CTF1530
L 1940	Inductor	CTF1530
TH1960	Thermistor	CCX1037
X 1940	Radiator 10.0MHz	CSS1577
S 1901	Encoder(VOLUME)	XSD7002
S 1902	Push Switch	CSG1112
S 1903	Push Switch	CSG1112
S 1904	Push Switch	CSG1111
S 1905	Push Switch	CSG1111
S 1906	Switch	CSG1110
S 1907	Push Switch	CSG1112
S 1908	Switch	CSG1107
S 1909	Switch	CSG1107
S 1910	Switch	CSG1107
S 1911	Switch	CSG1107
S 1912	Switch	CSG1107
S 1913	Switch	CSG1107
S 1914	Push Switch	CSG1111
S 1915	Push Switch	CSG1111
S 1916	Switch	CSG1110
S 1917	Push Switch	CSG1112

Circuit Symbol and No.		Part No.
S 1918	Switch	CSG1110
S 1919	Switch	CSG1110
S 1921	Switch	CSG1110
S 1922	Switch	CSG1110
VR1970	Semi-fixed 20kΩ(B)	CCP1231
VR1971	Semi-fixed 15kΩ(B)	CCP1230

RESISTORS

R 1901		RS1/16S222J
R 1902		RS1/16S222J
R 1903		RS1/16S473J
R 1905		RS1/16S680J
R 1906		RS1/16S680J
R 1907		RS1/16S680J
R 1908		RS1/16S680J
R 1909		RS1/16S181J
R 1910		RS1/16S151J
R 1911		RS1/16S103J
R 1912		RS1/16S682J
R 1913		RS1/16S121J
R 1914		RS1/16S184J
R 1915		RS1/16S2R2J
R 1916		RS1/16S680J
R 1917		RS1/16S680J
R 1918		RS1/16S680J
R 1919		RS1/16S680J
R 1920		RS1/16S181J
R 1922		RS1/16S560J
R 1924		RS1/16S560J
R 1940		RS1/16S222J
R 1941		RS1/16S101J
R 1942		RAB4C101J
R 1943		RAB4C101J
R 1945		RAB4C101J
R 1947		RAB4C101J
R 1948		RAB4C101J
R 1949		RAB4C101J
R 1950		RAB4C101J
R 1952		RS1/16S101J
R 1954		RAB4C473J
R 1955		RS1/16S473J
R 1956		RS1/16S103J
R 1957		RAB4C101J
R 1958		RS1/16S473J
R 1959		RS1/16S154J
R 1960		RS1/16S223J
R 1961		RS1/16S683J
R 1962		RS1/16S392J
R 1963		RS1/16S393J
R 1980		RS1/16S473J
R 1991		RS1/16S101J
R 1992		RS1/16S101J
R 1993		RS1/16S101J
R 1994		RS1/16S101J
R 1995		RS1/16S473J
R 1996		RS1/16S222J
R 1997		RS1/16S332J
R 1998		RS1/16S102J

Circuit Symbol and No.	Part No.
R 1999	RS1/16S102J
R 2104	RS1/16S101J
R 2105	RS1/16S101J
R 2106	RS1/16S101J
R 2107	RS1/16S101J
R 2108	RS1/16S101J
R 2109	RS1/16S101J
R 2110	RS1/16S101J
R 2111	RS1/16S101J
R 2112	RS1/16S102J
R 2113	RS1/16S102J
R 2114	RS1/16S102J
R 2115	RS1/16S102J

CAPACITORS

C 1908	CKSYF106Z10
C 1909	CSZSR4R7M16
C 1910	CSZSR4R7M10
C 1911	CKSRYB104K16
C 1912	CKSRYB104K16
C 1913	CKSRYB104K16
C 1914	CKSRYB104K16
C 1917	CKSRYB104K16
C 1918	CKSRYB104K16
C 1919	CKSRYB104K16
C 1920	CKSRYB104K16
C 1940	CKSRYB103K50
C 1941	CKSRYB473K25
C 1942	CKSRYB105K10
C 1943	CKSRYB103K50
C 1944	CSZSR4R7M10
C 1972	CKSRYB104K16
C 1973	CKSRYB104K25
C 1974	CKSRYB104K25
C 1975	CKSRYB104K25
C 1976	CKSRYB104K25
C 1990	CKSRYB103K50
C 1991	CKSRYB104K25
C 1992	CKSRYB104K25

B

Unit Number:CWM8758
Unit Name:Panel Unit

MISCELLANEOUS

D 1970	LED	CL220PGC
S 1970	Push Switch(EJECT)	CSG1112

RESISTORS

R 1970	RS1/16S101J
R 1971	RS1/16S101J
R 1972	RS1/16S0R0J

CAPACITORS

C 1970	CKSRYB104K16

D

Circuit Symbol and No.	Part No.

Unit Number:CWX2947
Unit Name:CD Core Unit(S10)

MISCELLANEOUS

IC 201	IC	UPD63712AGC
IC 301	IC	BA5835FP
IC 701	IC	NJM2391DL1-33
Q 101	Transistor	2SB1132
D 101	Diode	1SS355
D 701	Diode	1SR154-400
X 201	Ceramic Resonator 16.934MHz	CSS1603
S 901	Switch(HOME)	CSN1051
S 902	Switch(CLAMP)	CSN1051
S 903	Spring Switch(DSCSNS)	CSN1052
S 904	Switch(12EJ)	CSN1051
S 905	Switch(8EJ)	CSN1051

RESISTORS

R 101	RS1/10S1R5J
R 102	RS1/10S1R5J
R 103	RS1/10S1R5J
R 104	RS1/10S1R5J
R 105	RS1/10S1R5J
R 201	RS1/16S102J
R 202	RS1/16S1002D
R 203	RS1/16S1002D
R 204	RS1/16S1002D
R 205	RS1/16S1002D
R 206	RS1/16S1002D
R 207	RS1/16S1002D
R 208	RS1/16S1002D
R 209	RS1/16S1002D
R 214	RS1/16S103J
R 215	RS1/16S393J
R 216	RS1/16S122J
R 217	RS1/16S562J
R 218	RS1/16S472J
R 234	RS1/16S0R0J
R 235	RS1/16S103J
R 236	RS1/16S103J
R 301	RS1/16S183J
R 302	RS1/16S822J
R 303	RS1/16S183J
R 304	RS1/16S822J
R 305	RS1/16S183J
R 306	RS1/16S183J
R 307	RS1/16S183J
R 308	RS1/16S183J
R 501	RS1/16S102J
R 503	RS1/16S102J
R 505	RS1/16S102J
R 506	RS1/16S221J
R 507	RS1/16S221J
R 508	RS1/16S221J
R 509	RS1/16S221J
R 601	RS1/16S101J
R 602	RS1/16S101J
R 603	RS1/16S0R0J

Circuit Symbol and No.		Part No.
R 901		RS1/16S104J
R 902		RS1/16S473J
R 903		RS1/16S273J

CAPACITORS

C 101		CKSRYB104K16
C 102		CKSRYB104K16
C 103	100µF/16V	CCH1504
C 104	47µF/6.3V	CCH1506
C 108		CKSRYB104K16
C 109		CKSRYB104K16
C 201		CKSRYB104K16
C 202		CKSRYB471K50
C 205	22µF/6.3V	CCH1507
C 206		CKSRYB103K25
C 207		CKSRYB104K16
C 209		CKSRYB104K16
C 210		CKSRYB104K16
C 211		CKSRYB104K16
C 212		CKSRYB104K16
C 213		CKSRYB332K50
C 214		CKSRYB473K25
C 215		CKSRYB104K16
C 216		CKSRYB103K25
C 217		CCSRCH560J50
C 218		CCSRCH5R0C50
C 219		CKSRYB104K16
C 220		CKSRYB104K16
C 221		CKSRYB104K16
C 222		CKSRYB103K25
C 223		CCSRCH680J50
C 224		CCSRCH470J50
C 225		CKSRYB682K50
C 231		CKSRYB102K50
C 232		CKSRYB102K50
C 301	100µF/16V	CCH1504
C 302		CCSRCH221J50
C 303		CCSRCH221J50
C 304		CKSRYB472K50
C 305		CKSRYB103K25
C 306		CKSRYB104K16
C 501		CKSRYB103K25
C 502		CKSRYB103K25
C 702	100µF/16V	CCH1504
C 703		CKSRYB104K16
C 705	10µF/6.3V	CCH1470

Miscellaneous Parts List

	Pickup Unit(P10)(Service)	CXX1641
M 1	Motor Unit(SPINDLE)	CXB6007
M 2	Motor Unit(LOADING/CARRIAGE)	CXB8933