

TK-2160

PARTS LIST

* New Parts. ⚠ indicates safety critical components.
 Parts without **Parts No.** are not supplied.
 Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
 Teile ohne **Parts No.** werden nicht geliefert.

L: Scandinavia K: USA P: Canada
 Y: PX (Far East, Hawaii) T: England E: Europe
 Y: AAFES (Europe) X: Australia M: Other Areas

TK-2160 (Y50-578X-XX)
TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
TK-2160						42	1B		T07-0369-05	SPEAKER	
						TX-RX UNIT (X57-672X-XX) 0-10 : K, M					
1	1B	*	A02-3826-33	CABINET ASSY	K M	D802			B30-2156-05	LED(RED)	
2	2B	*	A10-4068-01	CHASSIS		D803			B30-2157-05	LED(YELLOW)	
3	3A	*	A82-0054-02	REAR PANEL							
4	3A		B01-0694-03	ESCUTCHEON		C1			CK73GB1H822K	CHIP C 8200PF	K
5	2D	*	B09-0676-03	CAP ACCESSORY		C2			CK73GB1H102K	CHIP C 1000PF	K
6	1C	*	B62-1716-00	INSTRUCTION MANUAL		C3			CK73GB1E123K	CHIP C 0.012UF	K
6	1C	*	B62-1747-00	INSTRUCTION MANUAL		C4			CK73GB0J225K	CHIP C 2.2UF	K
7	3B	*	B72-2153-04	MODEL NAME PLATE		C5			CK73GB1H102K	CHIP C 1000PF	K
8	3A	*	E04-0446-05	RF COAXIAL RECEPTACLE(SMA)		C6			CK73GB1H103K	CHIP C 0.010UF	K
9	3B	*	E37-1085-05	FLAT CABLE		C7			CK73GB1H102K	CHIP C 1000PF	K
10	2A	*	E37-1101-05	SPEAKER WIRE(RED)		C8			CC73GCH1H100D	CHIP C 10PF	D
11	2A	*	E37-1102-05	SPEAKER WIRE(BLACK)		C9			CK73GB1H103K	CHIP C 0.010UF	K
12	3A	*	E72-0416-13	BATT TERMINAL BLOCK		C10			CC73GCH1H100D	CHIP C 10PF	D
13		*	G10-1315-04	FIBROUS SHEET(CABINET)		C11-13			CC73GCH1H101J	CHIP C 100PF	J
14	2B	*	G11-4090-04	SHEET(FINAL FET)		C14			C92-0713-05	CHIP-TAN 10UF	6.3WV
15	3B	*	G11-4254-04	SHEET(PTT)		C15			CK73GB1H102K	CHIP C 1000PF	K
16	3A	*	G11-4287-04	SHEET(TERMINAL BLOCK)		C16			CC73GCH1H470J	CHIP C 47PF	J
17	3A	*	G11-4289-04	SHEET(CHASSIS)		C18,19			CK73GB1C104K	CHIP C 0.10UF	K
18	2B	*	G13-2001-04	CUSHION(CHASSIS)		C22			CK73GB1C104K	CHIP C 0.10UF	K
19	2B	*	G13-2014-04	CUSHION(CHASSIS BOTTOM)		C23			CK73GB0J225K	CHIP C 2.2UF	K
20	2B	*	G13-2017-04	CUSHION		C24			C92-0713-05	CHIP-TAN 10UF	6.3WV
21	2B	*	G13-2018-04	CUSHION		C25			CK73GB1H102K	CHIP C 1000PF	K
22	3A	*	G13-2019-04	CUSHION		C27			CK73GB1H102K	CHIP C 1000PF	K
23	2B	*	G13-2020-04	CUSHION		C28			CC73GCH1H560J	CHIP C 56PF	J
24	3A	*	G53-1579-02	PACKING		C30			CC73GCH1H220J	CHIP C 22PF	J
25	2B	*	G53-1580-03	PACKING(CHASSIS)		C31			CC73GCH1H560J	CHIP C 56PF	J
26	1B	*	G53-1581-22	PACKING(SPEAKER)		C32			C92-0002-05	CHIP-TAN 0.22UF	35WV
27	3B	*	G53-1582-03	PACKING(BATT TERMINAL BLOCK)		C33			CC73GCH1H470J	CHIP C 47PF	J
28	3C	*	H12-3150-02	PACKING FIXTURE		C34			CK73GB1H102K	CHIP C 1000PF	K
29		*	H25-2345-04	PROTECTION BAG		C35			CC73GCH1H680J	CHIP C 68PF	J
30	1D	*	H52-1981-02	ITEM CARTON CASE		C36			C92-0560-05	CHIP-TAN 10UF	6.3WV
31	2A	*	J19-5454-03	HOLDER		C37			CK73GB1H102K	CHIP C 1000PF	K
32	2D	*	J21-8464-04	HARDWARE FIXTURE ACCESSORY		C38,39			C92-0504-05	CHIP-TAN 0.68UF	20WV
33	2C	*	J29-0701-05	HOOK ACCESSORY		C40			CK73GB1H471K	CHIP C 470PF	K
34	3A	*	J30-1275-04	SPACER(CH KNOB)		C41			CK73GB1H103K	CHIP C 0.010UF	K
35	3A	*	J30-1281-04	SPACER(CH KNOB)		C42			CK73GB1H183K	CHIP C 0.018UF	K
36		*	J30-1283-04	SPACER		C43			CK73GB1A105K	CHIP C 1.0UF	K
37	1A	*	K29-9278-13	KNOB(VOLUME)		C44			CK73FB1A225K	CHIP C 2.2UF	K
38	1B	*	K29-9279-03	KNOB(PTT)		C45			CC73GCH1H120J	CHIP C 12PF	J
39	3A	*	K29-9280-13	KNOB(CH SELECTOR)		C46			CC73GCH1H090B	CHIP C 9.0PF	B
A	3A		N14-0583-04	CIRCULAR NUT(CH)		C47			CC73GCH1H040B	CHIP C 4.0PF	B
B	3A	*	N14-0805-04	CIRCULAR NUT(VOLUME)		C48			CK73HB1C103K	CHIP C 0.010UF	K
C	3A		N30-2604-46	PAN HEAD MACHINE SCREW		C49			CK73HB1H102K	CHIP C 1000PF	K
D	3B		N30-2612-46	PAN HEAD MACHINE SCREW		C50			CC73GCH1H120J	CHIP C 12PF	J
E	3A,3B		N30-3006-45	PAN HEAD MACHINE SCREW		C52			CC73GCH1H050B	CHIP C 5.0PF	B
F	2D		N35-3004-45	BINDING HEAD MACHINE SCREW		C53			CC73HCH1H560J	CHIP C 56PF	J
G	3A,3B	*	N78-2040-46	PAN HEAD TAPTITE SCREW		C54			CC73HCH1H220J	CHIP C 22PF	J
H	2A,2B		N83-2005-46	PAN HEAD TAPTITE SCREW		C55			CC73GCH1H050B	CHIP C 5.0PF	B
40	2A	*	R31-0650-05	VARIABLE RESISTOR		C56,57			CC73HCH1H270J	CHIP C 27PF	J
41	2A		S60-0420-05	ROTARY SWITCH		C58			CC73GCH1H150J	CHIP C 15PF	J
						C59			CC73HCH1HR75C	CHIP C 0.75PF	C
						C60			CC73GCH1H070B	CHIP C 7.0PF	B
						C61			CC73HCH1H070B	CHIP C 7.0PF	B

PARTS LIST

TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
C62			CK73GB1E103K	CHIP C 0.010UF K		C344			CC73GCH1H820J	CHIP C 82PF J	
C63			CC73GCH1H220J	CHIP C 22PF J		C349			CC73GCH1H030B	CHIP C 3.0PF B	
C64			CC73GCH1H4R5B	CHIP C 4.5PF B		C351			CK73GB1H102K	CHIP C 1000PF K	
C65			CC73HCH1H120J	CHIP C 12PF J		C352			CC73GCH1H270G	CHIP C 27PF G	
C66			CK73GB1H102K	CHIP C 1000PF K		C353			CC73GCH1H270J	CHIP C 27PF J	
C67			CK73HB1C103K	CHIP C 0.010UF K		C355			CK73GB1H102K	CHIP C 1000PF K	
C69			CK73GB1E103K	CHIP C 0.010UF K		C356			CC73GCH1H060D	CHIP C 6.0PF D	
C70			C92-0714-05	CHIP-TAN 4.7UF 6.3WV		C358			CC73GCH1H100D	CHIP C 10PF D	
C71			CC73HCH1H0R5B	CHIP C 0.5PF B		C359			CC73GCH1H240J	CHIP C 24PF J	
C72			CC73HCH1H040B	CHIP C 4.0PF B		C360			CC73GCH1H120J	CHIP C 12PF J	
C73			CK73GB1H102K	CHIP C 1000PF K		C362			CC73GCH1H110J	CHIP C 11PF J	
C74			CC73HCH1H0R5B	CHIP C 0.5PF B		C363			CC73GCH1H070D	CHIP C 7.0PF D	
CC75,76			CK73HB1H102K	CHIP C 1000PF K		C365			CC73GCH1H330J	CHIP C 33PF J	
C77			C92-0713-05	CHIP-TAN 10UF 6.3WV		C368			CC73GCH1H030C	CHIP C 3.0PF C	
C78			CK73HB1H102K	CHIP C 1000PF K		C400			CK73GB0J225K	CHIP C 2.2UF K	
C80			CC73HCH1H330J	CHIP C 33PF J		C401			CK73GB1H182K	CHIP C 1800PF K	
C81			CC73HCH1H150J	CHIP C 15PF J		CC402,403			CC73GCH1H271J	CHIP C 270PF J	
C82-84			CK73HB1H102K	CHIP C 1000PF K		C405			CC73GCH1H390J	CHIP C 39PF J	
C85			CC73HCH1H100D	CHIP C 10PF D		C406			C92-0713-05	CHIP-TAN 10UF 6.3WV	
C86			CC73GCH1H090D	CHIP C 9.0PF D		C407			CK73GB1H103K	CHIP C 0.010UF K	
C87			CC73GCH1H060B	CHIP C 6.0PF B		C408			CK73GB1C104K	CHIP C 0.10UF K	
CC201,202			CK73GB1H102K	CHIP C 1000PF K		C409			CC73GCH1H680J	CHIP C 68PF J	
C203			CC73GCH1H470J	CHIP C 47PF J		C410			CK73GB1H102K	CHIP C 1000PF K	
C212			CK73GB1H102K	CHIP C 1000PF K		C411-413			CK73GB1C104K	CHIP C 0.10UF K	
C241			CK73GB1H102K	CHIP C 1000PF K		C414			CC73GCH1H330J	CHIP C 33PF J	
C242			CC73GCH1H390J	CHIP C 39PF J		C415			CK73GB1H102K	CHIP C 1000PF K	
C243			CK73GB1C104K	CHIP C 0.10UF K		CC416,417			CK73GB1H103K	CHIP C 0.010UF K	
C246			CK73GB1H102K	CHIP C 1000PF K		C418			CK73GB1H102K	CHIP C 1000PF K	
C248			CK73GB1H102K	CHIP C 1000PF K		C419			CC73GCH1H010B	CHIP C 1.0PF B	
C249			CC73GCH1H100D	CHIP C 10PF D		C420			CK73GB1C104K	CHIP C 0.10UF K	
C255			CK73GB1H102K	CHIP C 1000PF K		C421			CC73GCH1H080B	CHIP C 8.0PF B	
C258			CK73GB1C104K	CHIP C 0.10UF K		C422			CK73GB1H103K	CHIP C 0.010UF K	
C265			CC73GCH1H220J	CHIP C 22PF J		C424			CK73GB1H103K	CHIP C 0.010UF K	
C273			CC73GCH1H101J	CHIP C 100PF J		C425			CC73GCH1H150J	CHIP C 15PF J	
C277			CC73GCH1H270J	CHIP C 27PF J		C426			CC73GCH1H020B	CHIP C 2.0PF B	
C280			CK73GB1H102K	CHIP C 1000PF K		C427			CK73GB1H103K	CHIP C 0.010UF K	
C282			CC73GCH1H100D	CHIP C 10PF D		C428			CC73GCH1H150J	CHIP C 15PF J	
C285			C92-0565-05	CHIP-TAN 6.8UF 10WV		C429			CK73GB1H102K	CHIP C 1000PF K	
C286			CK73GB1A105K	CHIP C 1.0UF K		C430			CC73GCH1H120J	CHIP C 12PF J	
C288			CK73GB1H102K	CHIP C 1000PF K		C432			CK73GB1H102K	CHIP C 1000PF K	
CC290,291			CK73GB1H102K	CHIP C 1000PF K		C434			CK73GB1H103K	CHIP C 0.010UF K	
C292			CC73GCH1H101J	CHIP C 100PF J		C435			CK73GB1H102K	CHIP C 1000PF K	
C293			CK73GB1H102K	CHIP C 1000PF K		C436			CC73GCH1H050B	CHIP C 5.0PF B	
CC295,296			CC73GCH1H050B	CHIP C 5.0PF B		C437			CC73GCH1H020B	CHIP C 2.0PF B	
C297			CK73GB1H102K	CHIP C 1000PF K		C438			CC73GCH1H090B	CHIP C 9.0PF B	
C298			CK73GB1H103K	CHIP C 0.010UF K		C439			CK73GB1H102K	CHIP C 1000PF K	
C299			CK73GB1C104K	CHIP C 0.10UF K		C440			CK73HB1H102K	CHIP C 1000PF K	
C300			CK73GB1A105K	CHIP C 1.0UF K		C441			CK73GB1H102K	CHIP C 1000PF K	
C301			CK73GB1H102K	CHIP C 1000PF K		C442			CK73HB1A104K	CHIP C 0.10UF K	
C302			CC73GCH1H180J	CHIP C 18PF J		C443			CK73GB1A105K	CHIP C 1.0UF K	
C308			CK73GB1H103K	CHIP C 0.010UF K		C444			CC73GCH1H050B	CHIP C 5.0PF B	
C309			CC73GCH1H100D	CHIP C 10PF D		C445			CC73GCH1H020B	CHIP C 2.0PF B	
C312			CC73GCH1H820J	CHIP C 82PF J		C446			CC73GCH1H010C	CHIP C 1.0PF C	
C317			CC73GCH1H100D	CHIP C 10PF D		C447			CC73GCH1H470J	CHIP C 47PF J	
C320			CC73GCH1H220J	CHIP C 22PF J		C448			CK73GB1H102K	CHIP C 1000PF K	
C326			CC73GCH1H220J	CHIP C 22PF J		C456			C92-0714-05	CHIP-TAN 4.7UF 6.3WV	
C329			CK73GB1H102K	CHIP C 1000PF K		C462			CK73HB1H102K	CHIP C 1000PF K	
C333			CC73GCH1H120J	CHIP C 12PF J		CC463,464			CC73GCH1H040B	CHIP C 4.0PF B	
C338			CC73GCH1H220J	CHIP C 22PF J		CC465,466			CK73GB1H102K	CHIP C 1000PF K	
C341			CC73GCH1H100D	CHIP C 10PF D		C467			CC73GCH1H270J	CHIP C 27PF J	

PARTS LIST

TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
C468			CC73GCH1H010B	CHIP C 1.0PF B		C660			CK73GB1A105K	CHIP C 1.0UF K	
C469			CK73GB1H102K	CHIP C 1000PF K		C661			CK73GB1H471K	CHIP C 470PF K	
C472			CK73GB1H102K	CHIP C 1000PF K		C662,663			CK73GB1C104K	CHIP C 0.10UF K	
C474			CK73GB1H102K	CHIP C 1000PF K		C664			CK73GB1H102K	CHIP C 1000PF K	
C475			CC73GCH1H4R5B	CHIP C 4.5PF B		C667			CK73GB1H102K	CHIP C 1000PF K	
C476			CC73GCH1H0R5B	CHIP C 0.5PF B		C668			CK73GB1H103K	CHIP C 0.010UF K	
C477			CC73GCH1H330J	CHIP C 33PF J		C669			CK73GB1H102K	CHIP C 1000PF K	
C478			CK73GB1H102K	CHIP C 1000PF K		C671			CK73GB1C104K	CHIP C 0.10UF K	
C479			CC73GCH1H040B	CHIP C 4.0PF B		C672,673			CK73GB1H472K	CHIP C 4700PF K	
C480			CK73GB1H102K	CHIP C 1000PF K		C674			CC73GCH1H221J	CHIP C 220PF J	
C481			CC73GCH1H220J	CHIP C 22PF J		C675,676			C92-0804-05	CHIP-TAN 1.5UF 16WV	
C483			CC73GCH1H100D	CHIP C 10PF D		C677			CK73GB1H332K	CHIP C 3300PF K	
C484			CC73GCH1H040B	CHIP C 4.0PF B		C678			CK73FB1C474K	CHIP C 0.47UF K	
C485			CK73GB1H471K	CHIP C 470PF K		C679			CC73GCH1H101J	CHIP C 100PF J	
C486			CC73GCH1H040B	CHIP C 4.0PF B		C680			C92-0560-05	CHIP-TAN 10UF 6.3WV	
C487			CK73HB1A104K	CHIP C 0.10UF K		C681			CK73GB1C683K	CHIP C 0.068UF K	
C602			CK73GB1A224K	CHIP C 0.22UF K		C684			CK73GB1C104K	CHIP C 0.10UF K	
C604			CK73GB1C104K	CHIP C 0.10UF K		C686			CK73GB1C473K	CHIP C 0.047UF K	
C605		*	C92-0632-05	CHIP-TAN 6.8UF 6.3WV		C687			C92-0560-05	CHIP-TAN 10UF 6.3WV	
C606			CK73GB1H332K	CHIP C 3300PF K		C688			CC73GCH1H221J	CHIP C 220PF J	
C607			CK73GB1H103K	CHIP C 0.010UF K		C689			CK73GB1C223K	CHIP C 0.022UF K	
C608			CK73GB1H392K	CHIP C 3900PF K		C690			CK73GB1H102K	CHIP C 1000PF K	
C609			CK73GB1H103K	CHIP C 0.010UF K		C691			C92-0665-05	CHIP-TAN 100UF 6.3WV	
C610			C92-0714-05	CHIP-TAN 4.7UF 6.3WV		C692			CC73GCH1H221J	CHIP C 220PF J	
C611			CK73GB0J105K	CHIP C 1.0UF K		C693			CK73GB1H471K	CHIP C 470PF K	
C613-615			CK73GB1C104K	CHIP C 0.10UF K		C695			CK73GB1H102K	CHIP C 1000PF K	
C618			CK73GB1C104K	CHIP C 0.10UF K		C696			CK73GB1A224K	CHIP C 0.22UF K	
C619			CK73GB1H472K	CHIP C 4700PF K		C801			CK73GB1A105K	CHIP C 1.0UF K	
C621,622			C92-0714-05	CHIP-TAN 4.7UF 6.3WV		C802			CK73GB1H103K	CHIP C 0.010UF K	
C624			CK73GB1C104K	CHIP C 0.10UF K		C803,804			CK73GB1A105K	CHIP C 1.0UF K	
C625			CC73GCH1H680J	CHIP C 68PF J		C805			CK73GB1H102K	CHIP C 1000PF K	
C627			CK73GB1E123K	CHIP C 0.012UF K		C807			CK73GB1H102K	CHIP C 1000PF K	
C628			CK73GB1H222K	CHIP C 2200PF K		C809			CK73GB1A105K	CHIP C 1.0UF K	
C629			CK73GB1H103K	CHIP C 0.010UF K		C811			CK73GB1C104K	CHIP C 0.10UF K	
C630			CC73GCH1H101J	CHIP C 100PF J		C812			CK73GB1H103K	CHIP C 0.010UF K	
C631			CK73GB1E123K	CHIP C 0.012UF K		C814			CK73GB1H103K	CHIP C 0.010UF K	
C632			CK73GB1C104K	CHIP C 0.10UF K		C815			CK73GB1A105K	CHIP C 1.0UF K	
C633			CC73GCH1H020B	CHIP C 2.0PF B		C816,817			CK73GB1H102K	CHIP C 1000PF K	
C634			CK73GB1H102K	CHIP C 1000PF K		C818			CK73GB1H103K	CHIP C 0.010UF K	
C635			CK73GB1C104K	CHIP C 0.10UF K		C819			CK73GB1H102K	CHIP C 1000PF K	
C636			CK73GB1C683K	CHIP C 0.068UF K		C820,821			CK73GB1A105K	CHIP C 1.0UF K	
C637			CC73GCH1H101J	CHIP C 100PF J		C822			CK73GB1H102K	CHIP C 1000PF K	
C638			CK73GB1H102K	CHIP C 1000PF K		C823			CK73GB1H103K	CHIP C 0.010UF K	
C639			CC73GCH1H470J	CHIP C 47PF J		C825			C92-0713-05	CHIP-TAN 10UF 6.3WV	
C640			CC73GCH1H101J	CHIP C 100PF J		C828			CK73GB1H102K	CHIP C 1000PF K	
C641,642			CK73GB1C104K	CHIP C 0.10UF K		C830			CK73GB1C104K	CHIP C 0.10UF K	
C643			CC73GCH1H680J	CHIP C 68PF J		C833			CK73GB1A105K	CHIP C 1.0UF K	
C645			CK73GB0J225K	CHIP C 2.2UF K		C834			CK73GB1C104K	CHIP C 0.10UF K	
C646			CK73GB1H821K	CHIP C 820PF K		C835,836			CK73GB1A105K	CHIP C 1.0UF K	
C647			CK73GB1H102K	CHIP C 1000PF K		C837			CK73GB1H102K	CHIP C 1000PF K	
C648,649			CK73GB1C104K	CHIP C 0.10UF K		C840			CK73GB1H102K	CHIP C 1000PF K	
C650			C92-0713-05	CHIP-TAN 10UF 6.3WV		C841			CK73GB1H103K	CHIP C 0.010UF K	
C652			CK73GB1H102K	CHIP C 1000PF K		C842			CC73GCH1H150J	CHIP C 15PF J	
C653			CK73GB1A224K	CHIP C 0.22UF K		C843			CC73GCH1H030C	CHIP C 3.0PF C	
C654			CK73GB1H103K	CHIP C 0.010UF K		C845			CC73GCH1H150J	CHIP C 15PF J	
C655			CK73GB1E223J	CHIP C 0.022UF J		C846			CK73GB1H103K	CHIP C 0.010UF K	
C656			CK73GB1C104K	CHIP C 0.10UF K		C847			C92-0712-05	CHIP-TAN 22UF 6.3WV	
C657			CC73GCH1H470J	CHIP C 47PF J		C848			CC73GCH1H101J	CHIP C 100PF J	
C658			CK73GB1C104K	CHIP C 0.10UF K		C849			CK73GB1H471K	CHIP C 470PF K	
C659			CK73GB1H103K	CHIP C 0.010UF K		C850			CK73GB1H103K	CHIP C 0.010UF K	

PARTS LIST

TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
C852,853 C854 CTC1,2			CK73GB1H102K CK73GB1H103K C05-0384-05	CHIP C 1000PF K CHIP C 0.010UF K CERAMIC TRIMMER CAP(10PF)		L413 L416 L601 L602 L801			L40-3975-92 L40-5681-86 L92-0140-05 L92-0149-05 L92-0149-05	SMALL FIXED INDUCTOR(39NH) SMALL FIXED INDUCTOR(0.56UH) FERRITE CHIP FERRITE CHIP FERRITE CHIP	
CN801 J601			E40-5932-05 E11-0457-05	PIN ASSY SOCKET PHONE JACK		L802 L803-807 X1 X801 XF401			L92-0140-05 L92-0138-05 L77-1932-05 L77-1933-05 L71-0617-05	FERRITE CHIP FERRITE CHIP TCXO(16.8MHZ) CRYSTAL RESONATOR(7.3728MHZ) MCF(49.95MHZ)	
F801			F53-0190-05	FUSE				*			
		*	J99-0374-04	ADHESIVE TAPE				*			
CD401 CF401 L1 L3 L5		*	L79-1582-05 L72-1008-05 L40-4795-85 L40-1581-86 L92-0138-05	TUNING COIL CERAMIC FILTER SMALL FIXED INDUCTOR(4.7UH) SMALL FIXED INDUCTOR(0.15UH) FERRITE CHIP		RCP1,2 RCP3,4 RCP801,802 CP803-805 CP806			RK75HA1J473J RK75HA1J102J RK75HA1J473J RK75HA1J102J RK75HA1J473J	CHIP-COM 47K J 1/16W CHIP-COM 1.0K J 1/16W CHIP-COM 47K J 1/16W CHIP-COM 1.0K J 1/16W CHIP-COM 47K J 1/16W	
L6 L7 L8 L9 L10			L40-1085-92 L92-0141-05 L40-1075-92 L40-1001-86 L40-1802-86	SMALL FIXED INDUCTOR(100NH) FERRITE CHIP SMALL FIXED INDUCTOR(10NH) SMALL FIXED INDUCTOR(10UH) SMALL FIXED INDUCTOR(18UH)		CP807 CP808 CP809-818 R1 R2			RK75HA1J102J RK75HA1J472J RK75HA1J102J RK73GB1J223J RK73GB1J103J	CHIP-COM 1.0K J 1/16W CHIP-COM 4.7K J 1/16W CHIP-COM 1.0K J 1/16W CHIP R 22K J 1/16W CHIP R 10K J 1/16W	
L11 L12 L14 L16 L17		*	L40-2775-92 L40-1502-86 L40-1502-86 L41-3378-14 L41-2278-14	SMALL FIXED INDUCTOR(27NH) SMALL FIXED INDUCTOR(15UH) SMALL FIXED INDUCTOR(15UH) SMALL FIXED INDUCTOR SMALL FIXED INDUCTOR		R3 R4 R5 R6 R7			RK73GB1J473J R92-1252-05 RK73GB1J224J RK73GB1J473J R92-1252-05	CHIP R 47K J 1/16W CHIP R 0 OHM J 1/16W CHIP R 220K J 1/16W CHIP R 47K J 1/16W CHIP R 0 OHM J 1/16W	
L18 L19,20 L21 L23 L24,25			L40-2275-92 L40-1001-86 L40-2785-92 L92-0138-05 L40-1085-92	SMALL FIXED INDUCTOR(22NH) SMALL FIXED INDUCTOR(10UH) SMALL FIXED INDUCTOR(270NH) FERRITE CHIP SMALL FIXED INDUCTOR(100NH)		R9 R12 R13 R14 R15			RK73GB1J393J RK73GB1J101J R92-1252-05 RK73GB1J222J R92-1252-05	CHIP R 39K J 1/16W CHIP R 100 J 1/16W CHIP R 0 OHM J 1/16W CHIP R 2.2K J 1/16W CHIP R 0 OHM J 1/16W	
L208 L209 L213 L214 L216			L40-1085-92 L92-0138-05 L40-2775-92 L40-4775-92 L40-1585-54	SMALL FIXED INDUCTOR(100NH) FERRITE CHIP SMALL FIXED INDUCTOR(27NH) SMALL FIXED INDUCTOR(47NH) SMALL FIXED INDUCTOR(150NH)		R16 R17 R18 R19 R20,21			RK73GB1J102J RK73GB1J101J RK73GB1J474J RK73GB1J100J R92-1252-05	CHIP R 1.0K J 1/16W CHIP R 100 J 1/16W CHIP R 470K J 1/16W CHIP R 10 J 1/16W CHIP R 0 OHM J 1/16W	
L217 L218 L219 L220 L221			L92-0149-05 L40-2775-54 L34-4577-05 L92-0149-05 L34-4563-05	FERRITE CHIP SMALL FIXED INDUCTOR(27NH) AIR-CORE COIL FERRITE CHIP AIR-CORE COIL		R22 R23 R24 R25 R26			RK73GB1J561J RK73GB1J121J RK73GB1J471J RK73GB1J103J RK73GB1J223J	CHIP R 560 J 1/16W CHIP R 120 J 1/16W CHIP R 470 J 1/16W CHIP R 10K J 1/16W CHIP R 22K J 1/16W	
L222 L223 L224 L225 L226			L34-4573-05 L34-4563-05 L40-2295-85 L34-4576-05 L34-4575-05	AIR-CORE COIL AIR-CORE COIL SMALL FIXED INDUCTOR(2.2UH) AIR-CORE COIL AIR-CORE COIL		R27 R28 R29 R30 R31			RK73GB1J103J RK73GB1J472J RK73GB1J103J RK73GB1J393J RK73GB1J472J	CHIP R 10K J 1/16W CHIP R 4.7K J 1/16W CHIP R 10K J 1/16W CHIP R 39K J 1/16W CHIP R 4.7K J 1/16W	
L227 L228 L229 L230 L401			L34-4567-05 L40-5675-92 L34-4566-05 L40-1092-81 L92-0138-05	AIR-CORE COIL SMALL FIXED INDUCTOR(56NH) AIR-CORE COIL SMALL FIXED INDUCTOR FERRITE CHIP		R32 R33 R35 R37 R38			RK73GB1J104J RK73HB1J103J RK73HB1J223J RK73HB1J274J RK73HB1J271J	CHIP R 100K J 1/16W CHIP R 10K J 1/16W CHIP R 22K J 1/16W CHIP R 270K J 1/16W CHIP R 270 J 1/16W	
L402 L403 L404 L405 L406			L40-3975-92 L40-5685-85 L40-2785-92 L40-1285-92 L40-2785-92	SMALL FIXED INDUCTOR(39NH) SMALL FIXED INDUCTOR(0.56UH) SMALL FIXED INDUCTOR(270NH) SMALL FIXED INDUCTOR(120NH) SMALL FIXED INDUCTOR(270NH)		R39 R40 R41 R42 R43,44			RK73GB1J220J RK73HB1J221J RK73GB1J331J RK73GB1J683J RK73HB1J220J	CHIP R 22 J 1/16W CHIP R 220 J 1/16W CHIP R 330 J 1/16W CHIP R 68K J 1/16W CHIP R 22 J 1/16W	
L407 L408 L409 L411 L412			L41-6878-14 L92-0138-05 L41-6878-14 L41-6878-14 L41-5678-14	SMALL FIXED INDUCTOR FERRITE CHIP SMALL FIXED INDUCTOR SMALL FIXED INDUCTOR SMALL FIXED INDUCTOR		R46 R47 R49 R50 R51			RK73HB1J154J RK73HB1J472J RK73HB1J101J RK73HB1J332J RK73HB1J103J	CHIP R 150K J 1/16W CHIP R 4.7K J 1/16W CHIP R 100 J 1/16W CHIP R 3.3K J 1/16W CHIP R 10K J 1/16W	

PARTS LIST

TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
R55		*	RK73G1J1333D	CHIP R 33K D 1/16W		R440			RK73GB1J470J	CHIP R 47 J 1/16W	
R56			RK73HB1J331J	CHIP R 330 J 1/16W		R441			RK73GB1J221J	CHIP R 220 J 1/16W	
R57		*	RK73G1J1104D	CHIP R 100K D 1/16W		R443			RK73HB1J224J	CHIP R 220K J 1/16W	
R58			RK73HB1J222J	CHIP R 2.2K J 1/16W		R457			RK73HB1J104J	CHIP R 100K J 1/16W	
R59			RK73HB1J470J	CHIP R 47 J 1/16W		R459			RK73GB1J184J	CHIP R 180K J 1/16W	
R60			RK73GB1J472J	CHIP R 4.7K J 1/16W		R460			RK73GB1J104J	CHIP R 100K J 1/16W	
R61			RK73GB1J103J	CHIP R 10K J 1/16W		R461			RK73GB1J101J	CHIP R 100 J 1/16W	
R201			RK73GB1J101J	CHIP R 100 J 1/16W		R462			R92-1252-05	CHIP R 0 OHM J 1/16W	
R202			RK73GB1J472J	CHIP R 4.7K J 1/16W		R463			RK73GB1J105J	CHIP R 1.0M J 1/16W	
R203			R92-1252-05	CHIP R 0 OHM J 1/16W		R465			RK73GB1J105J	CHIP R 1.0M J 1/16W	
R214			RK73GB1J223J	CHIP R 22K J 1/16W		R466,467			R92-0670-05	CHIP R 0 OHM	
R215			RK73GB1J103J	CHIP R 10K J 1/16W		R468			RK73GB1J332J	CHIP R 3.3K J 1/16W	
R252			RK73GB1J331J	CHIP R 330 J 1/16W		R469			RK73GB1J221J	CHIP R 220 J 1/16W	
R254			R92-1252-05	CHIP R 0 OHM J 1/16W		R601			R92-1252-05	CHIP R 0 OHM J 1/16W	
R256			RK73GB1J683J	CHIP R 68K J 1/16W		R602			RK73GB1J184J	CHIP R 180K J 1/16W	
R257			RK73GB1J473J	CHIP R 47K J 1/16W		R603			R92-1252-05	CHIP R 0 OHM J 1/16W	
R258			R92-1252-05	CHIP R 0 OHM J 1/16W		R604			RK73GB1J184J	CHIP R 180K J 1/16W	
R259			RK73GB1J150J	CHIP R 15 J 1/16W		R607-609			RK73GB1J103J	CHIP R 10K J 1/16W	
R260			RK73GB1J331J	CHIP R 330 J 1/16W		R610			RK73GB1J472J	CHIP R 4.7K J 1/16W	
R261-263			R92-1252-05	CHIP R 0 OHM J 1/16W		R612			RK73GB1J682J	CHIP R 6.8K J 1/16W	
R264,265			RK73EB2ER39K	CHIP R 0.39 K 1/4W		R613			RK73GB1J824J	CHIP R 820K J 1/16W	
R267			RK73GB1J123J	CHIP R 12K J 1/16W		R615			RK73GB1J334J	CHIP R 330K J 1/16W	
R268			RK73GB1J820J	CHIP R 82 J 1/16W		R616			R92-1252-05	CHIP R 0 OHM J 1/16W	
R269			RK73GB1J473J	CHIP R 47K J 1/16W		R617			RK73GB1J103J	CHIP R 10K J 1/16W	
R270			RK73EB2ER39K	CHIP R 0.39 K 1/4W		R618	*		RK73G1J364D	CHIP R 360K D 1/16W	
R272-277			RK73GH1J154D	CHIP R 150K D 1/16W		R621			RK73GB1J473J	CHIP R 47K J 1/16W	
R278			RK73GB1J103J	CHIP R 10K J 1/16W		R622			RK73GB1J684J	CHIP R 680K J 1/16W	
R279			RK73GB1J473J	CHIP R 47K J 1/16W		R623			RK73GB1J274G	CHIP R 270K G 1/16W	
R280			R92-1252-05	CHIP R 0 OHM J 1/16W		R624			RK73GB1J822J	CHIP R 8.2K J 1/16W	
R281			RK73GB1J222J	CHIP R 2.2K J 1/16W		R625			RK73GB1J563J	CHIP R 56K J 1/16W	
R282			RK73GB1J105J	CHIP R 1.0M J 1/16W		R626,627			RK73GB1J184J	CHIP R 180K J 1/16W	
R283,284			RK73GB1J104J	CHIP R 100K J 1/16W		R628			RK73GB1J224J	CHIP R 220K J 1/16W	
R285,286			RK73GB1J271J	CHIP R 270 J 1/16W		R629			RK73GB1J394J	CHIP R 390K J 1/16W	
R287			R92-1252-05	CHIP R 0 OHM J 1/16W		R630			RK73GB1J684J	CHIP R 680K J 1/16W	
R401			RK73GB1J100J	CHIP R 10 J 1/16W		R631			RK73GB1J394J	CHIP R 390K J 1/16W	
R403			RK73GB1J102J	CHIP R 1.0K J 1/16W		R632			RK73GB1J823J	CHIP R 82K J 1/16W	
R404			RK73GB1J334J	CHIP R 330K J 1/16W		R633			RK73GB1J223J	CHIP R 22K J 1/16W	
R406			RK73GB1J332J	CHIP R 3.3K J 1/16W		R634			RK73GB1J103J	CHIP R 10K J 1/16W	
R407			RK73GB1J474J	CHIP R 470K J 1/16W		R636			RK73GB1J474J	CHIP R 470K J 1/16W	
R408			RK73GB1J332J	CHIP R 3.3K J 1/16W		R637			RK73GB1J394J	CHIP R 390K J 1/16W	
R409			RK73GB1J392J	CHIP R 3.9K J 1/16W		R639			RK73GB1J393J	CHIP R 39K J 1/16W	
R412			RK73GB1J122J	CHIP R 1.2K J 1/16W		R640			RK73GB1J184J	CHIP R 180K J 1/16W	
R413			RK73GB1J124J	CHIP R 120K J 1/16W		R641,642			RK73GB1J124J	CHIP R 120K J 1/16W	
R414			RK73GB1J681J	CHIP R 680 J 1/16W		R643			RK73GB1J154J	CHIP R 150K J 1/16W	
R415			RK73GB1J472J	CHIP R 4.7K J 1/16W		R644,645			RK73GB1J472J	CHIP R 4.7K J 1/16W	
R416			RK73GB1J101J	CHIP R 100 J 1/16W		R646			RK73GB1J223J	CHIP R 22K J 1/16W	
R417			R92-1252-05	CHIP R 0 OHM J 1/16W		R647			R92-1252-05	CHIP R 0 OHM J 1/16W	
R418			RK73GB1J561J	CHIP R 560 J 1/16W		R648			RK73GB1J103J	CHIP R 10K J 1/16W	
R419			RK73GB1J221J	CHIP R 220 J 1/16W		R649			RK73GB1J104J	CHIP R 100K J 1/16W	
R421-424			RK73GB1J823J	CHIP R 82K J 1/16W		R650			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R425			R92-1252-05	CHIP R 0 OHM J 1/16W		R651			R92-1252-05	CHIP R 0 OHM J 1/16W	
R427			RK73GB1J105J	CHIP R 1.0M J 1/16W		R652			RK73GB1J273J	CHIP R 27K J 1/16W	
R428,429			RK73HB1J562J	CHIP R 5.6K J 1/16W		R653			RK73GB1J392J	CHIP R 3.9K J 1/16W	
R431			RK73GB1J105J	CHIP R 1.0M J 1/16W		R654			RK73GB1J103J	CHIP R 10K J 1/16W	
R433			R92-1252-05	CHIP R 0 OHM J 1/16W		R655,656			RK73GB1J105J	CHIP R 1.0M J 1/16W	
R434			RK73HB1J103J	CHIP R 10K J 1/16W		R657			RK73GB1J332J	CHIP R 3.3K J 1/16W	
R435			RK73HB1J224J	CHIP R 220K J 1/16W		R658			RK73GB1J103J	CHIP R 10K J 1/16W	
R436			RK73HB1J473J	CHIP R 47K J 1/16W		R660			RK73GB1J154J	CHIP R 150K J 1/16W	
R437			RK73HB1J224J	CHIP R 220K J 1/16W		R661			RK73GB1J684J	CHIP R 680K J 1/16W	
R438			RK73GB1J471J	CHIP R 470 J 1/16W		R665			R92-1252-05	CHIP R 0 OHM J 1/16W	

PARTS LIST

TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
R666			RK73GB1J822J	CHIP R 8.2K J 1/16W		R851			R92-1368-05	CHIP R 0 OHM	
R667			RK73GB1J104J	CHIP R 100K J 1/16W		R852			RK73HB1J473J	CHIP R 47K J 1/16W	
R668			RK73GB1J473J	CHIP R 47K J 1/16W		R854			RK73GB1J680J	CHIP R 68 J 1/16W	
R669			RK73GB1J222J	CHIP R 2.2K J 1/16W		R855-857			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R670			RK73GB1J102J	CHIP R 1.0K J 1/16W		R858			R92-1368-05	CHIP R 0 OHM	
R671			RK73GB1J683J	CHIP R 68K J 1/16W		R859			RK73GB1J104J	CHIP R 100K J 1/16W	
R672			RK73GB1J102J	CHIP R 1.0K J 1/16W		R860			RK73GB1J223J	CHIP R 22K J 1/16W	
R673			RK73GB1J272J	CHIP R 2.7K J 1/16W		VR1			R12-7491-05	TRIMMING POT.(68K)	
R674			R92-1252-05	CHIP R 0 OHM J 1/16W							
R675			RK73GB1J103J	CHIP R 10K J 1/16W		S802-805			S70-0457-05	TACT SWITCH	
R676			RK73GB1J151J	CHIP R 150 J 1/16W		MIC60			T91-0543-05	MIC ELEMENT	
R677-679			R92-1252-05	CHIP R 0 OHM J 1/16W							
R681			RK73GB1J222J	CHIP R 2.2K J 1/16W		D2			HSC277	DIODE	
R682			RK73GB1J100J	CHIP R 10 J 1/16W		D3-10			1SV325	VARIABLE CAPACITANCE DIODE	
R683			RK73GB1J474J	CHIP R 470K J 1/16W		D11			HSC277	DIODE	
R684			RK73GB1J182J	CHIP R 1.8K J 1/16W		D12			1SV278	VARIABLE CAPACITANCE DIODE	
R686			RK73GB1J471J	CHIP R 470 J 1/16W		D13			MA2S111	DIODE	
R687			RK73GB1J102J	CHIP R 1.0K J 1/16W		D14			HSC277	DIODE	
R688,689			RK73GB1J101J	CHIP R 100 J 1/16W		D201			HSC277	DIODE	
R691			RK73GB1J333J	CHIP R 33K J 1/16W		D203			HZU5CLL	ZENER DIODE	
R692			R92-1252-05	CHIP R 0 OHM J 1/16W		D204			HVC131	DIODE	
R693			RK73GB1J273J	CHIP R 27K J 1/16W		D206			HVC131	DIODE	
R694,695			R92-1252-05	CHIP R 0 OHM J 1/16W		D208			HVC131	DIODE	
R696			RK73GB1J103J	CHIP R 10K J 1/16W		D212			HVC131	DIODE	
R697			R92-1252-05	CHIP R 0 OHM J 1/16W		D401			HSC277	DIODE	
R698			RK73GB1J152J	CHIP R 1.5K J 1/16W		D402-405			1SV305	VARIABLE CAPACITANCE DIODE	
R802			RK73GB1J101J	CHIP R 100 J 1/16W		D603-606			RB706F-40	DIODE	
R803,804			R92-1252-05	CHIP R 0 OHM J 1/16W		D801			RB521S-30	DIODE	
R805			RK73GB1J153J	CHIP R 15K J 1/16W		D805			1SR154-400	DIODE	
R807			RK73GB1J103J	CHIP R 10K J 1/16W		IC1			MB15E03SL	MOS IC	
R808			RK73GB1J102J	CHIP R 1.0K J 1/16W		IC201			TA75W01FU	MOS IC	
R809			RK73GB1J272J	CHIP R 2.7K J 1/16W		IC401			TA31136FN	MOS IC	
R810			RK73GB1J334J	CHIP R 330K J 1/16W		IC601		*	AQUA	MOS IC	
R811			RK73GB1J332J	CHIP R 3.3K J 1/16W		IC602			TC75S51FE	MOS IC	
R812			RK73GB1J334J	CHIP R 330K J 1/16W		IC603			TC75W51FU	MOS IC	
R813			RK73GB1J332J	CHIP R 3.3K J 1/16W		IC604			TC75S51FE	MOS IC	
R814			RK73GB1J153J	CHIP R 15K J 1/16W		IC605			TA7368F	MOS IC	
R815			R92-1252-05	CHIP R 0 OHM J 1/16W		IC606			TC75S51FE	MOS IC	
R816			RK73GB1J224J	CHIP R 220K J 1/16W		IC801			XC6204B502MR	MOS IC	
R817			RK73GB1J272J	CHIP R 2.7K J 1/16W		IC802		*	PST9134NR	MOS IC	
R818			RK73GB1J821J	CHIP R 820 J 1/16W		IC803			XC61CN5002NR	MOS IC	
R819			RK73GB1J103J	CHIP R 10K J 1/16W		IC804		*	CAT24WC64JI	ROM IC	
R820			RK73GB1J561J	CHIP R 560 J 1/16W		IC805		*	30622MCA-7G7GP	MPU	
R821			RK73GB1J331J	CHIP R 330 J 1/16W		IC806			TC7W74FU	MOS IC	
R823			RK73GB1J102J	CHIP R 1.0K J 1/16W		Q1			DTC144EE	DIGITAL TRANSISTOR	
R824			RK73GB1J183J	CHIP R 18K J 1/16W		Q2,3			UMG9N	TRANSISTOR	
R825			RK73GB1J473J	CHIP R 47K J 1/16W		Q4			KTC4082	TRANSISTOR	
R827			RK73GB1J102J	CHIP R 1.0K J 1/16W		Q5,6			2SK508NV(K52)	FET	
R828			RK73GB1J332J	CHIP R 3.3K J 1/16W		Q7			2SC5108(Y)	TRANSISTOR	
R829			RK73GB1J272J	CHIP R 2.7K J 1/16W		Q8			2SJ347	FET	
R830			RK73GB1J821J	CHIP R 820 J 1/16W		Q9			2SC5108(Y)	TRANSISTOR	
R833,834			RK73GH1J474D	CHIP R 470K D 1/16W		Q10			2SC4617(S)	TRANSISTOR	
R835,836			RK73HB1J102J	CHIP R 1.0K J 1/16W		Q11			2SC5108(Y)	TRANSISTOR	
R839,840			RK73GB1J473J	CHIP R 47K J 1/16W		Q12			2SJ347	FET	
R841			R92-1252-05	CHIP R 0 OHM J 1/16W		Q206		*	2SK3077	FET	
R842			R92-1368-05	CHIP R 0 OHM		Q207			2SK2596	FET	
R844			RK73GB1J473J	CHIP R 47K J 1/16W		Q208			DTC114EE	DIGITAL TRANSISTOR	
R845			R92-1368-05	CHIP R 0 OHM		Q209			2SK879(GR)	FET	
R847,848			RK73GB1J102J	CHIP R 1.0K J 1/16W		Q210			DTC114EE	DIGITAL TRANSISTOR	
R849			R92-1252-05	CHIP R 0 OHM J 1/16W		Q211			2SK2595	FET	

PARTS LIST

TX-RX UNIT (X57-672X-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
Q212			2SK1824	FET							
Q213			DTA144EE	DIGITAL TRANSISTOR							
Q400			2SK1824	FET							
Q401			DTA144EE	DIGITAL TRANSISTOR							
Q402			2SC4649(N,P)	TRANSISTOR							
Q403,404			3SK318	FET							
Q601,602			2SK1824	FET							
Q603			DTC144EE	DIGITAL TRANSISTOR							
Q604			2SA1362(GR)	TRANSISTOR							
Q605			2SC4116(Y)	TRANSISTOR							
Q606			2SA1586(Y,GR)	TRANSISTOR							
Q607			DTC144EE	DIGITAL TRANSISTOR							
Q608			2SK1588	FET							
Q801			UMG3N	TRANSISTOR							
Q802			UPA672T	FET							
Q803			FP210	TRANSISTOR							
Q804			UMG3N	TRANSISTOR							
Q805			UMG9N	TRANSISTOR							
Q806			KTA1298(Y)	TRANSISTOR							
Q807			UMG3N	TRANSISTOR							
Q808,809			DTA123JE	DIGITAL TRANSISTOR							
Q810			2SK1824	FET							
TH1,2			B57331V2104J	THERMISTOR							



PACKING

