

4

A

- B

C



PACKING SECTION PARTS LIST

Mark	No.	Description	AVIC-X910BT/XS/UC	AVIC-F910BT/XS/EU5	AVIC-F910BT/XS/AU
	1	Polyethylene Bag	CEG1402	CEG1401	CEG1401
	2	Unit Box	CHG6774	CHG6772	CHG6775
	3	Contain Box	CHL6774	CHL6772	CHL6775
	4	Protector	CHP3552	CHP3550	CHP3552
	5	Protector	CHP3553	CHP3551	CHP3553
	6	Cord	CDE6825	CDE6825	CDE6825
	7	Cord Assy	CDP1095	CDP1097	CDP1095
	8	Cord	CDP1157	CDP1157	CDP1157
	9	Cord Assy	CDP1241	CDP1241	CDP1241
	10	Screw Assy	CEA3797	CEA7395	CEA3797
*	11	Screw	BMZ50P060FTC	BMZ50P060FTC	BMZ50P060FTC
	12	Polyethylene Bag	CEG-127	CEG-127/CNM4388	CEG-127
	13	Screw	CMZ50P060FTC	CMZ50P060FTC	CMZ50P060FTC
	14	Polyethylene Bag	CEG1116	CEG1116	CEG1116
	15	Sub Unit Box	CHG6491	CHG6491	CHG6491
	16	Connector	CKX1049	CKX1049	CKX1049
	17	*****			
	18	Microphone Assy	CPM1064	CPM1083	CPM1083
	19	Clip Holder	CZN5471	*CZN7912	*CZN7912
	20	Microphone Holder	CZN5472	Not used	Not used
*	21	Cushion	CZN5473	*CZN7913	*CZN7913
	22	GPS Antenna Assy	CXC8574	CXC8574	CXC8574
	23	Clamper Assy	CZE3090	CZE3090	CZE3090
	24	Water Proof Pad	CZN5442	CZN5442	CZN5442
	25	Sheet	CZN7151	CZN7151	CZN7151
*	26	Seal	CNN2515	CNN2515	CNN2515
	27	Panel	Not used	CNS8665	Not used
	28	IM CD-ROM/PEE	Not used	CPJ1273	CPJ1273
	29-1	Owner's Manual	CRB2985	Not used	Not used
	29-2	Owner's Manual	CRB2986	Not used	Not used
	29-3	Installation Manual	CRD4409	CRD4411	CRB3008
	29-4	Quick Start Guide	CRB2987	CRB2995	CRB3006
	29-5	Quick Start Guide	CRB2988	CRB2996	Not used
	29-6	Quick Start Guide	Not used	CRB2997	Not used
	29-7	Quick Start Guide	Not used	CRB2998	Not used
*	29-8	Quick Start Guide	Not used	CRB2999	Not used
	29-9	Quick Start Guide	Not used	CRB3000	Not used
	29-10	Important Information	Not used	CRD4410	CRB3007
	29-11	Caution Card	CRP1310	Not used	CRP1310
	29-12	Warranty Card	CRY1246	CRY1265	Not used
*	29-13	Registration Card	CRY1271	Not used	Not used
*	29-14	Passport	Not used	CRY1268	Not used

Owner's Manual, Installation Manual

Part No.	Language
CRB2985	English
CRB2986	French
CRB2987	English
CRB2988	French
CRD4409	English, French
CRB2995	English
CRB2996	Spanish(Espanol)
CRB2997	German
CRB2998	French
CRB2999	Italian
CRB3000	Dutch
CRD4410	English, Spanish(Espanol), German, French, Italian, Dutch
CRD4411	English, Spanish(Espanol), German, French, Italian, Dutch
CRB3006	English
CRB3007	English
CRB3008	English


CONTENTS OF CD-ROM (Operation Manual), CPJ1274

Part No.	Language
* CRB2989	English
* CRB2990	Spanish(Espanol)
* CRB2991	German
* CRB2992	French
* CRB2993	Italian
* CRB2994	Dutch
* CRB3005	English

All operation manuals are supplied in PDF files by the CD-ROM.

Regarding the availability of paper manual, contact Pioneer Service representative in your region.

9.2 EXTERIOR(1)



(1) EXTERIOR(1) SECTION PARTS LIST


Mark No.	Description	Part No.	Mark No.	Description	Part No.	
1	Screw	BMZ26P050FTC	23	Lighting Conductor	CNW1561	
2	Screw(M2.6 x 5)	CBA2145	24	Touch Panel	CSX1136	A
3	FFC	CDE9039	25	SD Unit	CWX3652	
4	Case	CNB3472				
5	Card	CNW1231	26	Grille Unit	See Contrast table (2)	
			27	Knob Unit	CXE1633	
6	Screw	BMZ26P050FTC	* 28	Spring	YBL5013	
7	Screw	BPZ20P080FTC	29	Screw(M2 x 2)	CBA1771	
8	Button(MENU, MAP)	CAI1705	30	Holder	CND3758	
9	Button(RESET, EJECT)	CAI2435				
10	Screw(M2 x 3)	CBA1797	31	Holder	CND3759	
			32	Holder	CND4319	
11	Cord Assy	CDE8559	33	Insulator	CNN2044	B
12	FFC	CDE9037	34	Insulator	CNN2045	
13	FFC	CDE9038	35	LCD Module	CWX3850	
14	Spacer	See Contrast table (2)				
15	Cover	CNN2046	36	Panel Unit	CWX3785	
			37	Screw	PMB20P040FTC	
16	Gasket	CNN2501	38	Screw	IMS26P040FTC	
17	Gasket	CNN2533	39	Holder	See Contrast table (2)	
18	Insulator	CNN2534	40	Holder	See Contrast table (2)	
19	Cushion	See Contrast table (2)				
20	Gasket	See Contrast table (2)	41	Screw	See Contrast table (2)	
			42	Screw	See Contrast table (2)	C
21	Insulator	See Contrast table (2)	43	Keyboard Unit	CWN4250	
22	Holder	CNV9903				

(2) CONTRAST TABLE

AVIC-X910BT/XS/UC, AVIC-F910BT/XS/EU5 and AVIC-F910BT/XS/AU are constructed the same except for the following:

Mark	No.	Description	AVIC-X910BT/XS/UC	AVIC-F910BT/XS/EU5	AVIC-F910BT/XS/AU
	14	Spacer	CNM9246	Not used	CNM9246
	19	Cushion	CNN2723	Not used	CNN2723
	20	Gasket	CNN2724	Not used	CNN2724
	21	Insulator	CNN2725	Not used	CNN2725
	26	Grille Unit	CXE1623	CXE1624	CXE1625
	39	Holder	Not used	CND3431	Not used
	40	Holder	Not used	CND3430	Not used
	41	Screw	Not used	CMZ50P060FTC	Not used
	42	Screw	Not used	BMZ30P060FTC	Not used

9.3 EXTERIOR(2)




(A) GYH1031(Mylar tape)

* Hold the flexible cable to the shield on the Navi Unit.

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
1	Screw	ASZ26P050FTC	
2	Screw	BMZ26P050FTC	A
3	Screw	BMZ26P160FTB	
4	Screw(M2.6 x 12)	CBA2102	
5	Cord Assy	CDE8393	
6	FFC	CDE8911	
7	FFC	CDE8912	
8	FFC	CDE9036	
9	Cord Assy	CDH1381	
10	Chassis	CNA3114	
11	Cover	CND3917	B
12	Bracket	CND4564	
13	Insulator	CNN2042	
14	Sheet	CNN2294	
15	Gasket	CNN2529	
16	Insulator	CNN2807	
17	Sheet	CNN2808	
18	Heat Sink	CNR1944	
19	CK Unit	CWN4251	
20	Navi Unit(UC)	CWX3739	C
	Navi Unit(EU5)	CWX3740	
	Navi Unit(AU)	CWX3741	
21	Chassis Unit	CXE1631	
22	DVD Mechanism Module(LS1)	CXK6801	
23	Fan Motor	CXM1320	
24	Cord Assy(UC)	CDE9102	
	Cord Assy(EU5)	CDE8913	
	Cord Assy(AU)	CDE8913	D


9.4 EXTERIOR(3)

A




AVIC-X910BT/XS/UC
AVIC-F910BT/XS/AU

B




AVIC-F910BT/XS/EU5


C



D



E



F

(1) EXTERIOR(3) SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Cord Assy	See Contrast table (2)	13	Holder	See Contrast table (2)
2	Cord Assy	CDP1241	14	Shield	CND4320
3	Cap	CNW1490	15	Shield	CND4563
4	AV Unit	See Contrast table (2)			
5	Screw	BMZ26P060FTC	16	Sheet	CNM9805
⚠ 6	Fuse(10 A)	CEK1208	17	FM/AM Tuner Unit(Y1461)	See Contrast table (2)
7	Holder	CNC9921	18	Holder	CND4324
8	Shield	CND3004	19	Shield Unit	CXC8983
9	Holder	CND3181	20	Terminal Cover	See Contrast table (2)
10	Holder	CND3693			
			21	Cord	CDE6825
11	Holder	CND3695	22	Cap	CNS1472
12	Shield	CND3769	23	Resistor	RS1/2PMF102J

(2) CONTRAST TABLE

AVIC-X910BT/XS/UC, AVIC-F910BT/XS/EU5 and AVIC-F910BT/XS/AU are constructed the same except for the following:

Mark	No.	Description	AVIC-X910BT/XS/UC	AVIC-F910BT/XS/EU5	AVIC-F910BT/XS/AU
	1	Cord Assy	CDP1095	CDP1097	CDP1095
	4	AV Unit	CWN4237	CWN4238	CWN4239
	13	Holder	CND4314	CND4315	CND4315
	17	FM/AM Tuner Unit(Y1461)	CWE2128	CWE2127	CWE2128
	20	Terminal Cover	Not used	CKX-003	Not used

9.5 DVD MECHANISM MODULE

A


B

C

D

E

F



- (A) : GEM1045
- (B) : GEM1038
- (C) : GEM1024

Mark No.	Description	Part No.	Mark No.	Description	Part No.	
1	Screw	BMZ20P020FTC	50	Holder	CNW1195	
2	Screw	BSZ20P040FTC				
3	Screw(M2 x 4)	CBA1835	51	Damper	CNW1197	A
4	Washer	CBF1038	52	Damper	CNW1198	
5	Spring	CBH2860	*	53 Connect PCB Unit	CWX3618	
			54			
6	Spring	CBH3010	55			
7	Spring	CBH3011				
8	Spring	CBH3012	56	Motor	EXM1050 ①	
9	Spring	CBH3013	57	Screw Unit	CXC8894	
10	Spring	CBH3014	58	Chassis Unit	CXC8895	
			59	Arm Assy	CXC8896	
11	Spring	CBH3015	60	Washer	CBF1037	B
12	Spring	CBH3016				
13	Spring	CBH3017	61	Washer	CBF1038	
14	Spring	CBH3018	62	Arm	CND4554	
15	Spring	CBH3019	63	Collar	CNV6906	
			64	Roller	CNW1196	
16	Spring	CBH3020	65	Gear Unit	CXC8893	
17	Spring	CBH3030				
18	Plate Spring	CBL1797	66	Screw(M2 x 5)	EBA1028	
19	Cable	CDE8631	67	Motor Unit	CXC4026 ①	
20	Service PU Unit	CXX2398	68	Screw	JFZ20P025FTC	
			69	Screw	JGZ17P022FTC	C
21	Bracket	CND4553	70	Washer	YE15FTC	
22	Arm	CND4555				
23	Lever	CND4556				
24	Frame	CND4557	71	Screw	IMS20P030FTC	
25	Frame	CND4558	72	DVD Core Unit	YWX5009	
26	Sheet	CNN2280				
27	Rack	CNW1170				
28	Guide	CNW1171				
29	Roller	CNW1172				
30	Arm	CNW1173				D
31	Arm	CNW1174				
32	Roller	CNW1175				
33	Lever	CNW1176				
34	Arm	CNW1177				
35	Arm	CNW1178				
36	Gear	CNW1180				
37	Gear	CNW1181				
38	Gear	CNW1182				E
39	Gear	CNW1183				
40	Rack	CNW1184				
41	Gear	CNW1185				
42	Gear	CNW1186				
43	Gear	CNW1187				
44	Gear	CNW1188				
45	Clamper	CNW1190				
46	Arm	CNW1191				
47	Arm	CNW1192				F
48	Holder	CNW1193				
49	Holder	CNW1194				

12. ELECTRICAL PARTS LIST

NOTE:

- Parts whose parts numbers are omitted are subject to being not supplied.
- The part numbers shown below indicate chip components.

Chip Resistor

RS1/○S○○○○J,RS1/○○S○○○○J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Meaning of the figures and others in the parentheses in the parts list.

Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.

IC 301 (A, 91, 111) IC NJM2068V

Circuit Symbol and No.	Part No.	Circuit Symbol and No.	Part No.
Unit Number : CWN4237(UC)		IC 1008 (A,56,39) IC	NJM2125F
Unit Number : CWN4238(EU5)		IC 1015 (A,65,47) IC	NJM4558V
Unit Number : CWN4239(AU)		IC 1016 (B,70,33) IC	BA4558RFVM
Unit Name : AV Unit		IC 2801 (A,169,99) IC	BA00CC0WCP-V5
Unit Number : CWN4251		IC 2820 (A,169,88) IC	BA00CC0WCP-V5
Unit Name : CK Unit		IC 2830 (B,34,37) IC	BA00BC0WFP
Unit Number : YWX5009		IC 2890 (B,157,105) IC	TPD1018F
Unit Name : DVD Core Unit		IC 3601 (A,12,20) IC	M62343FP
Unit Number :		IC 4171 (B,68,49) IC	AN15887A
Unit Name : Connect PCB		IC 4251 (B,104,107) IC	NJM2505AF
Unit Number :		IC 4271 (B,69,74) IC	PML018A
Unit Name : Keyboard Unit		IC 4601 (B,118,65) IC	TPS5103IDB
		IC 4641 (B,151,25) IC	TPS5103IDB
		IC 4661 (B,151,41) IC	TPS5103IDB
		IC 4701 (B,89,55) IC	BD3931HFP
		IC 4703 (A,87,45) IC	S-L2980A33MC-C6S
		IC 4721 (B,45,129) IC(UC)	HA12241FP
		Q 601 (B,117,20) Chip Transistor	2SA1576A
		Q 661 (B,117,47) Chip Transistor	DTC114EUA
		Q 662 (B,114,23) Chip Transistor	DTC114EUA
		Q 751 (A,80,34) Chip Transistor(EU5)	DTC124EUA
		Q 752 (A,85,40) Chip Transistor(EU5)	DTC124EUA
		Q 753 (A,82,38) Chip Transistor(EU5)	DTC124EUA
		Q 754 (A,85,35) Chip Transistor(EU5)	DTC124EUA
		Q 1016 (A,56,32) Transistor	IMD2A
		Q 1401 (B,39,105) Transistor	2SC3357
		Q 1421 (B,39,96) Transistor	2SC3127
		Q 1441 (A,35,87) Transistor	2SC3130
		Q 2810 (B,103,99) Transistor	2SD1760F5
		Q 2811 (A,104,97) Chip Transistor	DTA114EUA
		Q 2812 (A,111,99) Chip Transistor	DTC114EUA
		Q 2840 (B,144,9) Transistor	DTC114WK
		Q 2841 (A,158,7) Chip Transistor	DTC114EUA
		Q 2860 (B,121,107) Transistor	UMD2N
		Q 2861 (B,121,110) Transistor	UMD2N
		Q 2862 (B,113,104) Transistor	2SC4081
		Q 2863 (B,119,113) Transistor	UMD2N
		Q 2864 (B,116,112) Chip Transistor	DTC114EUA
		Q 2865 (B,113,112) Chip Transistor	DTC124EUA
		Q 2870 (A,151,113) Transistor	2SC4116
		Q 2880 (A,165,112) Chip Transistor	DTC114EUA
MISCELLANEOUS			
IC 601 (B,47,7) IC	TC7SH08FUS1		
IC 603 (B,121,45) IC	TC7SH04FUS1		
IC 604 (B,122,42) IC	TC7S32FU		
IC 605 (A,43,9) IC	TC74VHCT08AFTS1		
IC 607 (B,106,30) IC	TC74VHC08FTS1		
IC 608 (B,97,45) IC	BD5335FVE		
IC 609 (B,28,9) IC	TC74VHC08FTS1		
IC 610 (A,108,35) IC(UC)	PEG562A8		
(A,108,35) IC(EU5)	PEG561A8		
(A,108,35) IC(AU)	PEG563A8		
IC 612 (B,110,42) Logic IC	TC74VHCT32AFT		
IC 1002 (A,148,8) IC	NJM2904M		
IC 1007 (A,89,128) IC	PAL007C		

1

2

3

4

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

Q 2881 (B,125,24) Chip Transistor DTC114EUA

D 2880 (B,153,131) Diode

1SR154-400

Q 2882 (B,122,20) Chip Transistor 2SA1576A

D 2890 (A,156,110) Diode

1SR154-400

Q 2900 (A,166,124) Transistor 2SC4116

D 2891 (A,159,110) Diode

1SR154-400

Q 3041 (A,77,51) Transistor IMD3A

D 2900 (A,170,126) Diode

HZU8R2(B1)

Q 3042 (A,72,54) Transistor FMG12

D 2910 (B,146,73) Diode

KS926S2

Q 3601 (B,31,21) Transistor UMX1N

D 2911 (A,59,94) Diode

RB060L-40

Q 3602 (B,23,19) Transistor UMX1N

D 2912 (B,145,103) Diode

KS926S2

Q 3603 (B,15,19) Transistor UMX1N

D 2930 (A,141,108) Diode

ST70-27F

Q 3604 (B,29,16) Transistor UMX1N

D 3041 (A,72,50) Diode

DAP202K

Q 3605 (B,20,18) Transistor UMX1N

D 4061 (A,61,48) Diode

EDZ4R3(B)

Q 3606 (B,11,17) Transistor UMX1N

D 4062 (A,59,49) Diode

1SS355

Q 4231 (B,60,24) Transistor 2SC4081

D 4311 (B,83,31) Diode

DAN202K

Q 4232 (B,56,18) Chip Transistor 2SA1576A

D 4312 (B,87,33) Diode

DAN202K

Q 4312 (B,78,39) Transistor IMD3A

D 4331 (B,92,96) Diode

DAP202K

Q 4314 (B,78,35) Transistor DTC323TK

D 4351 (B,110,114) Diode

MAL5180X

Q 4331 (B,103,92) Transistor FMG12

D 4353 (B,124,133) Diode

MAL5180X

Q 4332 (B,93,85) Transistor FMG12

D 4354 (B,125,133) Diode

MAL5180X

Q 4333 (B,93,92) Transistor FMG12

D 4355 (A,121,109) Diode

DAN202U

Q 4601 (B,107,65) Chip Transistor DTC114EUA

D 4356 (A,112,120) Diode

MAL5068X

Q 4602 (A,118,65) FET SP8K2

D 4357 (A,108,120) Diode

MAL5068X

Q 4631 (A,120,86) Transistor 2SD1767

D 4358 (A,118,120) Diode

MAL5068X

Q 4632 (A,127,87) Transistor UMD2N

D 4359 (A,122,120) Diode

MAL5068X

Q 4641 (B,140,23) Chip Transistor DTC114EUA

D 4360 (B,129,113) Diode

1SR154-400

Q 4642 (A,151,25) FET SP8K2

D 4361 (A,132,108) Diode

1SS355

Q 4661 (B,112,72) Chip Transistor DTC114EUA

D 4362 (B,129,107) Diode

1SR154-400

Q 4662 (B,140,38) Chip Transistor DTC114EUA

D 4363 (B,114,119) Diode

MAL5068X

Q 4663 (A,152,41) FET SP8K2

D 4364 (A,129,107) Diode

PTZ27(B)

Q 4731 (B,144,88) Transistor 2SC4081

D 4365 (A,126,107) Diode

PTZ27(B)

Q 4732 (B,129,99) Chip Transistor(UC) DTC114EUA

D 4366 (B,122,133) Diode

MAL5180X

Q 4733 (B,151,90) Transistor 2SC4081

D 4371 (A,42,118) Diode

UDZS5R6(B)

Q 4734 (B,123,99) Chip Transistor(UC) 2SA1576A

D 4372 (B,44,124) Diode

UDZS5R6(B)

Q 4738 (B,142,91) Transistor 2SC4081

D 4601 (B,127,61) Diode

RB400D

Q 4751 (A,32,12) Chip Transistor 2SA1576A

D 4602 (A,115,71) Diode

RB060L-40

Q 4752 (A,33,8) Chip Transistor 2SA1576A

D 4631 (A,123,89) Diode

UDZS9R1(B)

Q 4753 (B,36,11) Chip Transistor DTC114EUA

D 4641 (B,160,22) Diode

RB400D

Q 4754 (B,33,7) Chip Transistor 2SA1576A

D 4642 (A,148,31) Diode

RB060L-40

Q 4771 (B,110,94) Chip Transistor DTA114EUA

D 4643 (A,164,17) Diode

RB083L-20

Q 4772 (B,113,92) Chip Transistor DTC114EUA

D 4661 (B,159,36) Diode

RB400D

Q 4773 (B,116,92) Transistor 2SA1587

D 4662 (A,148,46) Diode

RB060L-40

Q 4774 (B,115,86) Transistor IMX1

D 4721 (B,49,122) Diode(UC)

MAL5180X

Q 4775 (B,128,85) Chip Transistor DTC114EUA

D 4722 (B,51,119) Diode(UC)

MAL5180X

Q 4776 (B,123,94) Transistor 2SD1760F5

D 4723 (B,55,116) Diode(UC)

MAL5068X

D 2802 (A,160,105) Diode RB060L-40

D 4724 (B,50,127) Diode(UC)

MAL5068X

D 2810 (A,107,95) Diode UDZS5R6(B)

D 4725 (B,56,116) Diode(UC)

UDZS18(B)

D 2821 (A,159,93) Diode RB060L-40

D 4726 (B,63,116) Diode(UC)

UDZS18(B)

D 2822 (A,111,95) Diode DAN202U

D 4727 (B,59,116) Diode(UC)

UDZS18(B)

D 2823 (A,121,81) Diode 1SR154-400

D 4731 (B,147,89) Diode

HZU7R5(B3)

D 2824 (A,128,81) Diode 1SR154-400

D 4732 (B,147,93) Diode

RB500V-40

D 2825 (A,132,48) Diode 1SS400G

D 4733 (B,151,93) Diode

RB500V-40

D 2831 (B,38,27) Diode RR264M-400

D 4734 (B,146,97) Diode

EDZ20(B)

D 2840 (B,153,7) Diode 1SS355

D 4735 (B,149,93) Diode

RB500V-40

D 2860 (B,124,106) Diode MA111

D 4736 (B,142,97) Diode

RB500V-40

D 2861 (B,120,105) Diode UDZS8R2(B)

D 4737 (B,142,95) Diode

HZU7R5(B3)

D 2862 (B,116,108) Diode DAN202U

D 4751 (A,29,14) Diode

1SS355

D 2863 (B,114,108) Diode DAN202U

D 4752 (A,28,14) Diode

1SS355

D 2870 (A,153,107) Diode UDZS5R1(B)

D 4771 (B,121,86) Diode

RB500V-40

D 2871 (B,170,131) Diode UDZS18(B)

D 4772 (B,123,87) Diode

RB500V-40

D 2872 (B,170,126) Diode UDZS18(B)

D 4773 (B,124,84) Diode

HZU8R2(B1)

D 2873 (B,168,131) Diode 1SS355

D 4774 (B,126,88) Diode

HZU11(B2)

D 2874 (B,159,112) Diode PTZ18A

D 4775 (B,139,132) Diode

MAL5180X

1

2

3

4

5		6	
<u>Circuit Symbol and No.</u>		<u>Part No.</u>	
ZNR1401	(B,17,112) Surge Protector	CSA30-201N	
L 601	(B,124,42) Inductor	CTF1410	
L 602	(B,42,6) Inductor	CTF1410	
L 604	(B,121,48) Inductor	CTF1410	
L 605	(A,43,14) Inductor	CTF1410	
L 607	(B,104,35) Inductor	CTF1410	
L 608	(B,101,33) Inductor	CTF1410	
L 609	(B,100,48) Inductor	CTF1410	
L 610	(B,33,12) Inductor	CTF1410	
L 611	(A,99,21) Inductor	CTF1410	
L 612	(A,103,47) Inductor	CTF1410	
L 613	(A,110,20) Inductor	CTF1410	
L 614	(B,122,25) Inductor	CTF1410	
L 615	(A,121,34) Inductor	CTF1410	
L 617	(B,116,45) Inductor	CTF1410	
L 704	(A,80,72) Inductor	CTF1357	
L 705	(A,90,70) Inductor	CTF1463	
L 706	(A,95,64) Inductor	CTF1306	
L 707	(A,81,67) Inductor	CTF1306	
L 708	(A,93,65) Inductor	CTF1306	
L 709	(A,79,65) Inductor	CTF1306	
L 710	(A,91,64) Inductor	CTF1306	
L 711	(A,79,64) Inductor	CTF1306	
L 712	(A,77,62) Inductor	CTF1306	
L 713	(A,80,61) Inductor	CTF1306	
L 714	(A,93,61) Inductor	CTF1306	
L 1004	(A,149,13) Inductor	CTF1334	
L 1401	(B,23,112) Inductor	LCTAWR12J2520	
L 1402	(B,29,111) Inductor	LCYCR10K2125	
L 1403	(A,45,89) Inductor	LCTAW101J2520	
L 1421	(B,42,96) Inductor	LCTCR22K2125	
L 1422	(B,30,105) Inductor	LCTCR10K2125	
L 1423	(B,44,89) Inductor	LCTAW101J2520	
L 1441	(A,38,85) Inductor	LCTCR15K2125	
L 1443	(A,45,83) Chip Coil	LCTAW1R0J2520	
L 1461	(B,17,110) Chip Coil	LCTAW4R7J2520	
L 1462	(A,39,70) Inductor	LCTAW2R2J3225	
L 1463	(B,25,57) Inductor	LCTAW2R2J2520	
L 1464	(B,27,54) Chip Ferrite Bead	CTF1399	
L 1465	(A,34,41) Inductor	LCTAW2R2J3225	
L 2870	(B,167,127) Inductor	CTF1410	
L 2871	(B,160,115) Inductor	CTF1410	
L 2872	(B,149,114) Inductor	CTF1410	
L 2930	(A,135,95) Choke Coil 600 uH	CTH1347	
L 2931	(B,92,117) Inductor	CTF1689	
L 2932	(B,79,115) Inductor	CTF1689	
L 2933	(B,79,117) Inductor	CTF1689	
L 2934	(B,96,118) Inductor	CTF1689	
L 2940	(A,90,11) Inductor	CTF1334	
L 2943	(B,61,12) Inductor	CTF1556	
L 2944	(B,61,14) Inductor	CTF1556	
L 2945	(B,58,13) Inductor	CTF1556	
L 2946	(B,66,8) Inductor	CTF1556	
L 2947	(A,60,21) Inductor	CTF1675	
L 2948	(A,61,21) Inductor	CTF1675	
L 2949	(A,65,21) Inductor	CTF1675	
L 2950	(A,66,21) Inductor	CTF1675	
L 3601	(A,17,14) Chip Coil	LCTAW100J2520	
L 4171	(B,72,62) Chip Coil	LCTAW100J2520	
L 4172	(B,60,61) Chip Coil	LCTAW100J2520	

7		8	
<u>Circuit Symbol and No.</u>		<u>Part No.</u>	
L 4173	(B,80,57) Inductor	CTF1689	
L 4174	(A,82,53) Inductor	CTF1689	
L 4175	(B,82,50) Inductor	CTF1689	
L 4176	(A,82,48) Inductor	CTF1689	
L 4231	(B,64,25) Inductor	CTF1473	
L 4271	(A,66,86) Inductor	LCYA2R2J2520	
L 4351	(A,125,111) Inductor	LCTC2R2K1608	
L 4352	(A,130,113) Inductor	CTF1556	
L 4371	(A,38,118) Inductor	CTF1334	
L 4372	(B,40,124) Inductor	CTF1334	
L 4601	(A,106,64) Choke Coil 27 uH	CTH1402	
L 4602	(A,130,63) Choke Coil 10 uH	CTH1403	
L 4641	(A,141,22) Inductor	CTH1255	
L 4642	(A,161,24) Inductor	CTH1257	
L 4661	(A,141,35) Inductor	CTH1255	
L 4662	(A,162,40) Inductor	CTH1257	
L 4701	(B,87,44) Inductor	CTF1393	
L 4721	(A,44,130) Inductor(UC)	LCYC2R2K1608	
L 4722	(B,50,124) Inductor(UC)	CTF1334	
L 4723	(B,50,120) Inductor(UC)	CTF1334	
L 4724	(B,53,115) Inductor(UC)	CTF1334	
L 4725	(B,49,125) Inductor(UC)	CTF1334	
T 1401	(A,41,105) Coil	CTC1194	
T 1402	(A,43,95) Coil	CTC1193	
T 1403	(A,33,96) Coil	CTC1192	
TH601	(A,70,29) Thermistor	CCX1051	
X 601	(A,92,33) Ceramic Resonator 20.000 MHz	VSS1186	
VR4231	(A,55,25) Semi-fixed 1 kohm(OB)	CCP1483	
△FU2900	(B,72,8) Fuse 250 mA	CEK1276	
FU4351	(B,117,118) Poly Switch	MINISMDC075F/24	
△FU4352	(B,129,133) Fuse 3.15 A	CEK1259	
△FU4601	(B,104,61) Fuse 5 A	CEK1261	
△FU4602	(B,144,58) Fuse 5 A	CEK1261	
△FU4631	(A,115,86) Fuse 200 mA	CEK1247	
△FU4641	(A,141,8) Fuse 3.15 A	CEK1259	
△FU4642	(B,158,72) Fuse 2.5 A	CEK1258	
△FU4661	(A,137,8) Fuse 2.5 A	CEK1258	
△FU4662	(B,148,55) Fuse 2.5 A	CEK1258	
△FU4771	(A,115,106) Fuse 1 A	CEK1254	
FB701	(A,93,77) Inductor	CTF1453	
EF4351	(B,121,119) EMI Filter	CCG1067	
EF4352	(B,126,119) EMI Filter	CCG1067	
EF4353	(A,128,119) EMI Filter	CCG1067	
EF4354	(A,110,120) EMI Filter	CCG1067	
EF4355	(A,114,120) EMI Filter	CCG1067	
EF4356	(A,116,120) EMI Filter	CCG1067	
EF4357	(A,120,120) EMI Filter	CCG1067	
EF4358	(A,124,120) EMI Filter	CCG1067	
EF4359	(B,124,119) EMI Filter	CCG1067	
EF4360	(B,129,119) EMI Filter	CCG1067	
EF4361	(A,131,119) EMI Filter	CCG1067	
EF4731	(B,157,78) EMI Filter	CCG1172	
EF4732	(B,154,57) EMI Filter	CCG1172	
ANT1401	(A,19,119) Antenna Jack	CKX1060	
Y 1461	(A,18,93) FM/AM Tuner Unit(UC,AU)	CWE2128	
	(A,18,93) FM/AM Tuner Unit(EU5)	CWE2127	
U 695	(B,92,27) IR Remote(AU)	RPMS2401-H19	
CN702	(A,85,66) Connector	CKS5627	
CN1000	(A,74,9) Connector	CKS5732	
CN1001	(A,94,103) Connector	CKS4674	

1

2

3

4

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

CN1005 (A,149,129) Plug

CKM1550

R 681 (B,119,49)

RS1/16SS473J

R 682 (A,125,36)

RS1/16SS0R0J

R 683 (A,123,43)

RAB4C104J

CN1015 (A,37,129) Jack

CKN1042

CN1016 (A,122,132) Connector

CKM1460

CN1021 (A,58,129) Connector(UC)

CKS3408

CN1441 (A,53,84) Mini Pin Jack

CKX1046

R 684 (A,123,39)

RAB4C681J

R 685 (A,69,27)

RS1/16S102J

R 686 (B,109,37)

RS1/16SS104J

R 687 (B,118,43)

RS1/16SS104J

R 688 (B,44,9)

RS1/16SS104J

RESISTORS

R 601 (A,39,7)

RS1/16S104J

R 602 (B,39,6)

RS1/16S104J

R 603 (A,96,24) (UC,EU5)

RS1/16SS220J

R 604 (A,97,22) (UC,EU5)

RS1/16S220J

R 605 (B,121,39)

RS1/16SS104J

R 689 (B,40,10)

RS1/16SS104J

R 690 (A,110,49)

RS1/16SS472J

R 695 (B,97,24) (AU)

RS1/16SS470J

R 696 (B,96,30) (AU)

RS1/16SS470J

R 697 (B,99,24)

RS1/16SS104J

R 607 (A,86,32) (EU5)

RS1/16SS681J

R 608 (A,89,40) (EU5)

RAB4C681J

R 609 (B,101,37)

RS1/16SS104J

R 610 (B,96,38)

RS1/16SS102J

R 612 (B,98,32)

RS1/16SS104J

R 698 (B,106,27)

RS1/16SS104J

R 699 (B,110,49)

RS1/16SS104J

R 714 (A,95,76)

RS1/10S0R0J

R 715 (B,95,75)

RS1/10S0R0J

R 717 (A,82,57)

RS1/16SS0R0J

R 613 (A,95,42)

RS1/16SS471J

R 614 (A,93,41)

RS1/16SS471J

R 615 (A,95,41)

RS1/16SS222J

R 616 (A,93,40)

RS1/16SS0R0J

R 617 (A,95,39)

RS1/16SS0R0J

R 718 (A,94,63)

RS1/16SS221J

R 722 (A,82,69)

RS1/16S104J

R 731 (B,95,35)

RS1/16SS0R0J

R 751 (A,78,54)

RS1/16S0R0J

R 1016 (B,70,16)

RS1/16SS0R0J

R 618 (B,25,10)

RS1/16SS104J

R 619 (B,111,38)

RS1/16SS104J

R 620 (A,96,35)

RS1/16SS101J

R 626 (B,101,30)

RS1/16SS221J

R 627 (A,96,26)

RS1/16SS104J

R 1401 (B,41,109) Inductor

CTF1742

R 1409 (B,20,112)

RS1/16S105J

R 1410 (A,36,103)

RS1/16S821J

R 1411 (A,35,108)

RS1/16S330J

R 1412 (A,44,89)

RS1/16S332J

R 628 (B,89,40) (EU5)

RAB4C223J

R 632 (B,100,45)

RS1/16SS0R0J

R 633 (B,103,42)

RS1/16SS102J

R 634 (A,102,22)

RS1/16SS104J

R 636 (B,101,40)

RS1/16SS104J

R 1413 (A,33,91)

RS1/16S101J

R 1421 (B,38,92)

RS1/16S151J

R 1422 (B,36,94)

RS1/16S680J

R 1423 (B,41,93)

RS1/16S152J

R 1424 (B,43,93)

RS1/16S681J

R 639 (B,106,40)

RS1/16SS102J

R 640 (B,103,40)

RS1/16SS103J

R 641 (B,100,41)

RS1/16SS103J

R 642 (B,106,25)

RS1/16SS220J

R 643 (A,100,18)

RS1/16SS104J

R 1425 (B,44,96)

RS1/16S181J

R 1441 (A,32,85)

RS1/16S151J

R 1442 (A,33,87)

RS1/16S680J

R 1443 (A,39,88)

RS1/16S152J

R 1444 (A,41,86)

RS1/16S681J

R 646 (A,102,18)

RS1/16SS104J

R 648 (B,108,24)

RS1/16S104J

R 649 (B,104,46)

RS1/16SS220J

R 650 (A,103,18)

RS1/16SS104J

R 652 (B,106,44)

RS1/16SS220J

R 1445 (A,39,84)

RS1/16S151J

R 1461 (B,25,71)

RS1/16SS681J

R 1462 (B,25,70)

RS1/16SS681J

R 1463 (B,25,69)

RS1/16SS681J

R 1464 (B,25,68)

RS1/16SS681J

R 653 (A,109,47)

RS1/16SS102J

R 654 (A,105,18)

RS1/16SS104J

R 657 (A,106,18)

RS1/16SS104J

R 659 (A,112,21)

RS1/16S220J

R 660 (A,115,19)

RS1/16S104J

R 1465 (B,25,67)

RS1/16SS681J

R 1466 (B,27,66)

RS1/16SS223J

R 1467 (B,25,65) (EU5)

RS1/16SS681J

R 1468 (B,25,59)

RS1/16SS681J

R 1470 (B,26,47)

RS1/16SS0R0J

R 661 (A,109,17)

RS1/16S104J

R 662 (A,113,18)

RS1/16S104J

R 663 (A,117,20)

RS1/16SS102J

R 664 (A,117,18)

RS1/16SS473J

R 665 (B,118,49)

RS1/16SS104J

R 1471 (B,26,45)

RS1/16SS0R0J

R 1474 (B,30,47)

RS1/16SS0R0J

R 1475 (B,33,45)

RS1/16SS0R0J

R 1476 (B,28,49) (EU5)

RS1/16SS0R0J

R 1477 (B,27,51) (EU5)

RS1/16SS0R0J

R 666 (B,116,24)

RS1/16SS104J

R 668 (B,119,22)

RS1/16SS472J

R 670 (A,125,33)

RS1/16SS104J

R 671 (A,121,31)

RS1/16SS102J

R 676 (A,121,28)

RS1/16SS0R0J

R 1478 (B,28,50) (EU5)

RS1/16SS0R0J

R 1479 (B,27,52) (EU5)

RS1/16SS0R0J

R 2801 (B,160,96)

RN1/16SE1002D

R 2802 (B,159,94)

RN1/16SE2701D

R 2803 (B,158,96)

RN1/16SE2201D

R 677 (A,121,27)

RS1/16SS0R0J

R 680 (B,120,22)

RS1/16SS472J

R 2804 (B,159,99)

RS1/16S104J

R 2810 (B,111,99)

RS1/8S0R0J

5		6		7		8		
<u>Circuit Symbol and No.</u>		<u>Part No.</u>		<u>Circuit Symbol and No.</u>		<u>Part No.</u>		
R 2811	(A,100,98)	RS1/16S471J		R 2940	(B,61,7)	RS1/16S0R0J		
R 2820	(B,160,85)	RS1/16S2201D		R 2941	(A,57,10)	RS1/16SS101J		
R 2821	(B,159,87)	RS1/16S1002D		R 2942	(A,61,15)	RS1/16SS101J		
R 2822	(B,159,89)	RS1/16S2201D		R 2951	(B,67,18)	RS1/16SS0R0J		A
R 2823	(A,139,49)	RS1/16SS105J		R 2952	(B,68,18)	RS1/16SS0R0J		
R 2830	(B,33,28)	RS1/16S3601D		R 2953	(B,66,13)	RS1/16SS0R0J		
R 2831	(B,31,24)	RS1/16S10R0D		R 2954	(B,70,11)	RS1/16SS0R0J		
R 2832	(A,28,36)	RS1/16S2201D		R 2959	(B,77,5)	RS1/16S0R0J		
R 2833	(A,33,28)	RS1/16S0R0J		R 2960	(B,74,8)	RS1/16SS0R0J		
R 2834	(B,38,30)	RS1/16S104J		R 2961	(B,75,8)	RS1/16SS0R0J		
R 2840	(A,146,11)	RS1/16SS104J		R 2962	(A,77,18)	RS1/16SS0R0J		
R 2841	(A,146,12)	RS1/16SS473J		R 2963	(A,79,18)	RS1/16SS0R0J		
R 2842	(B,145,6)	RS1/16SS563J		R 2964	(A,81,21)	RS1/16SS0R0J		
R 2843	(B,148,9)	RS1/16SS513J		R 2967	(B,77,18)	RS1/16SS0R0J		
R 2844	(B,149,8)	RS1/16SS104J		R 2968	(B,76,8)	RS1/16SS0R0J		B
R 2845	(B,150,6)	RS1/16SS513J		R 2969	(B,78,8)	RS1/16SS0R0J		
R 2846	(A,153,6)	RS1/16SS513J		R 2970	(B,80,15)	RS1/16SS0R0J		
R 2847	(B,151,8)	RS1/16SS102J		R 2971	(B,79,8)	RS1/16SS0R0J		
R 2848	(B,149,6)	RS1/16SS102J		R 2972	(B,81,8)	RS1/16SS0R0J		
R 2849	(B,151,6)	RS1/16SS564J		R 2973	(B,82,15)	RS1/16SS0R0J		
R 2850	(B,153,10)	RS1/16SS202J		R 2974	(B,82,8)	RS1/16SS0R0J		
R 2851	(B,152,10)	RS1/16SS822J		R 2975	(B,83,8)	RS1/16SS0R0J		
R 2852	(A,154,11)	RS1/16SS203J		R 2976	(B,84,8)	RS1/16SS0R0J		
R 2853	(A,152,13)	RS1/16SS333J		R 2977	(B,85,8)	RS1/16SS0R0J		
R 2860	(B,126,108)	RS1/16SS391J		R 2978	(A,85,21)	RS1/16SS0R0J		C
R 2861	(B,124,109)	RS1/16SS391J		R 2979	(A,87,18)	RS1/16SS0R0J		
R 2862	(B,122,103)	RS1/16SS473J		R 2980	(A,88,19)	RS1/16SS0R0J		
R 2863	(B,116,105)	RS1/16SS223J		R 2981	(A,87,22)	RS1/16SS0R0J		
R 2864	(B,118,106)	RS1/16SS103J		R 2982	(A,90,9)	RS1/16SS0R0J		
R 2865	(B,123,112)	RS1/10S102J		R 2983	(A,156,8)	RS1/16SS0R0J		
R 2866	(B,114,116)	RS1/16SS103J		R 3041	(A,75,56)	RS1/16S182J		
R 2867	(B,117,114)	RS1/16SS103J		R 3042	(A,75,57)	RS1/16S182J		
R 2868	(B,115,114)	RS1/16SS221J		R 3043	(A,76,54)	RS1/16S473J		
R 2869	(B,113,114)	RS1/16SS101J		R 3044	(A,74,54)	RS1/16S473J		
R 2870	(A,153,110)	RS1/16S473J		R 3601	(B,29,22)	RS1/16S224J		
R 2871	(A,153,112)	RS1/16S104J		R 3602	(B,34,21)	RS1/16S102J		D
R 2872	(B,154,109)	RS1/16S102J		R 3603	(B,27,24)	RS1/16S222J		
R 2873	(B,157,109)	RS1/16S472J		R 3604	(B,23,21)	RS1/16S224J		
R 2874	(B,150,110)	RS1/4S102J		R 3605	(B,18,14)	RS1/16S102J		
R 2875	(B,152,114)	RS1/4S472J		R 3606	(B,24,23)	RS1/16S222J		
R 2880	(A,166,120)	RS1/16S103J		R 3607	(B,16,21)	RS1/16S224J		
R 2881	(B,148,132)	RS1/4S472J		R 3608	(B,16,15)	RS1/16S102J		
R 2882	(B,143,132)	RS1/4S102J		R 3609	(B,15,24)	RS1/16S222J		
R 2883	(B,124,22)	RS1/16SS472J		R 3610	(B,29,19)	RS1/16S121J		
R 2884	(B,122,22)	RS1/16SS472J		R 3611	(B,27,21)	RS1/16S101J		
R 2900	(A,169,124)	RS1/16S473J		R 3612	(B,31,15)	RS1/16S101J		
R 2901	(A,170,122)	RS1/16S104J		R 3616	(B,20,20)	RS1/16S121J		E
R 2902	(A,167,128)	RS1/4S102J		R 3617	(B,20,23)	RS1/16S151J		
R 2903	(A,167,131)	RS1/4S472J		R 3618	(B,21,16)	RS1/16S101J		
R 2910	(B,154,71)	RS1/16S473J		R 3622	(B,11,20)	RS1/16S151J		
R 2911	(B,145,109)	RS1/16S473J		R 3623	(B,12,23)	RS1/16S181J		
R 2912	(A,60,90)	RS1/4S4R7J		R 3624	(B,14,16)	RS1/16S101J		
R 2913	(A,65,92)	RS1/4S4R7J		R 3629	(B,71,8)	RS1/16S0R0J		
R 2920	(B,90,109)	RS1/16S102J		R 4001	(B,57,61)	RS1/16S750J		
R 2921	(B,89,113)	RS1/16S102J		R 4021	(A,54,50)	RS1/16S750J		
R 2922	(B,91,113)	RS1/16S102J		R 4041	(B,57,37)	RS1/16S750J		
R 2923	(B,95,108)	RS1/16S102J		R 4061	(A,57,48)	RS1/16S102J		F
R 2924	(A,96,120)	RS1/16S103J		R 4071	(A,69,46)	RS1/16SS473J		
R 2925	(A,93,120)	RS1/16S103J		R 4072	(A,68,47)	RS1/16SS473J		
R 2926	(A,102,119)	RS1/16S103J		R 4073	(A,65,57)	RS1/16SS473J		

1

2

3

4

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

R 4074 (A,66,42)
R 4075 (A,64,43)
R 4076 (A,67,50)

RS1/16SS473J
RS1/16SS473J
RS1/16SS473J

R 4333 (B,97,86)
R 4334 (B,90,86)
R 4335 (B,97,93)

RS1/16SS821J
RS1/16SS821J
RS1/16SS821J

A

R 4077 (A,65,56)
R 4078 (A,65,52)
R 4079 (A,63,42)
R 4080 (A,63,55)
R 4151 (B,65,32)

RS1/16SS473J
RS1/16SS473J
RS1/16SS330J
RS1/16SS330J
RS1/16SS103J

R 4336 (B,90,93)
R 4337 (B,105,92)
R 4338 (B,96,86)
R 4339 (B,96,93)
R 4340 (B,101,92)

RS1/16SS821J
RS1/16SS223J
RS1/16SS223J
RS1/16SS223J
RS1/16SS223J

R 4152 (B,64,34)
R 4153 (B,67,34)
R 4154 (B,66,32)
R 4155 (B,69,36)
R 4156 (B,70,36)

RS1/16SS103J
RS1/16SS103J
RS1/16SS103J
RS1/16SS102J
RS1/16SS104J

R 4341 (B,91,86)
R 4342 (B,91,93)
R 4343 (B,104,89)
R 4344 (B,94,83)
R 4345 (B,94,90)

RS1/16SS223J
RS1/16SS223J
RS1/16SS471J
RS1/16SS471J
RS1/16SS471J

B

R 4157 (B,73,35)
R 4158 (B,75,33)
R 4159 (B,73,33)
R 4170 (B,80,54)
R 4171 (B,80,50)

RS1/16SS104J
RS1/16SS683J
RS1/16SS473J
RS1/16SS223J
RS1/16SS223J

R 4346 (B,102,89)
R 4347 (B,93,83)
R 4348 (B,93,90)
R 4351 (A,127,112)
R 4352 (A,131,111)

RS1/16SS471J
RS1/16SS471J
RS1/16SS471J
RS1/16S153J
RS1/10S103J

R 4174 (B,66,22)
R 4175 (B,64,22)
R 4176 (B,75,57)
R 4194 (B,63,42)
R 4195 (B,64,41)

RS1/16SS223J
RS1/16SS223J
RS1/16SS0R0J
RS1/16SS221J
RS1/16SS221J

R 4601 (B,107,62)
R 4602 (B,111,59)
R 4603 (B,112,59)
R 4604 (B,113,59)
R 4605 (B,109,59)

RS1/10S0R0J
RS1/16S2200D
RS1/16S4701D
RS1/16S1501D
RS1/16S101J

C

R 4200 (A,76,39)
R 4231 (B,60,26)
R 4232 (B,60,22)
R 4233 (B,58,22)
R 4234 (B,57,24)

RS1/16S750J
RS1/16SS223J
RS1/16SS303J
RS1/16SS681J
RS1/16SS102J

R 4606 (B,116,59)
R 4607 (B,119,59)
R 4608 (B,115,70)
R 4609 (B,112,65)
R 4610 (B,110,63)

RS1/16S332J
RS1/16S104J
RS1/16S473J
RS1/16S1503D
RS1/16S8203D

R 4235 (B,62,22)
R 4236 (B,54,19)
R 4237 (B,58,18)
R 4240 (B,60,27)
R 4251 (B,102,113)

RS1/16SS681J
RS1/16SS152J
RS1/16SS0R0J
RS1/16SS0R0J
RS1/16S750J

R 4611 (B,121,60)
R 4612 (B,126,68)
R 4614 (B,126,65)
R 4615 (B,143,56)
R 4616 (B,93,99)

RS1/10S100J
RS1/16S100J
RS1/16S184J
RS1/16S105J
RS1/16S222J

D

R 4252 (B,104,113)
R 4253 (B,102,112)
R 4254 (B,100,112)
R 4255 (B,106,113)
R 4263 (A,105,110)

RS1/16SS473J
RS1/16SS473J
RS1/16SS101J
RS1/16SS101J
RS1/16SS0R0J

R 4633 (A,129,86)
R 4641 (B,141,8)
R 4643 (B,142,19)
R 4644 (B,139,20)
R 4645 (B,144,19)

RS1/16SS821J
RS1/4SA561J
RS1/16S331J
RS1/16S0R0J
RS1/16S5600D

R 4271 (B,58,66)
R 4272 (B,86,65) (UC)
R 4273 (B,56,68) (UC)
R 4274 (B,87,67) (UC)
R 4275 (B,85,67) (UC)

RS1/16S0R0J
RS1/16S181J
RS1/16S181J
RS1/16S223J
RS1/16S102J

R 4646 (B,145,19)
R 4647 (B,146,19)
R 4648 (B,148,30)
R 4649 (B,149,19)
R 4650 (B,151,19)

RS1/16S8201D
RS1/16S1501D
RS1/16S473J
RS1/16S332J
RS1/16S104J

E

R 4276 (B,53,69) (UC)
R 4277 (B,51,70) (UC)
R 4285 (B,59,73)
R 4286 (B,85,71)
R 4287 (B,76,75)

RS1/16S223J
RS1/16S102J
RS1/16SS0R0J
RS1/16SS0R0J
RS1/16SS102J

R 4651 (B,145,24)
R 4652 (B,143,22)
R 4653 (B,154,20)
R 4654 (B,158,24)
R 4656 (B,158,26)

RS1/16S1503D
RS1/16S8203D
RS1/10S100J
RS1/16S184J
RS1/16S100J

R 4289 (B,76,76)
R 4291 (B,76,77)
R 4293 (B,77,80)
R 4295 (B,59,77)
R 4296 (A,54,75)

RS1/16SS102J
RS1/16SS102J
RS1/16SS0R0J
RS1/16SS0R0J
RS1/16S0R0J

R 4657 (A,159,18)
R 4662 (B,138,36)
R 4663 (B,143,35)
R 4664 (B,144,35)
R 4665 (B,146,35)

RS1/16S105J
RS1/10S0R0J
RS1/16S1800D
RS1/16S4701D
RS1/16S1501D

F

R 4297 (A,63,87)
R 4312 (B,78,32)
R 4313 (B,79,37)
R 4316 (B,84,44)
R 4317 (B,80,45)

RS1/16S0R0J
RS1/16SS821J
RS1/16SS104J
RS1/16SS0R0J
RS1/16SS0R0J

R 4666 (B,112,70)
R 4667 (B,142,35)
R 4668 (B,148,35)
R 4669 (B,151,35)
R 4670 (B,147,45)

RS1/16S473J
RS1/16S101J
RS1/16S332J
RS1/16S104J
RS1/16S473J

R 4331 (B,106,92)
R 4332 (B,100,92)

RS1/16SS821J
RS1/16SS821J

R 4671 (B,144,40)
R 4672 (B,142,38)

RS1/16S1503D
RS1/16S8203D

1

2

3

4

5		6		7		8	
<u>Circuit Symbol and No.</u>		<u>Part No.</u>		<u>Circuit Symbol and No.</u>		<u>Part No.</u>	
R 4673	(B,154,36)	RS1/10S100J		C 617	(A,100,21)	CKSRYB104K16	A
R 4674	(B,158,43)	RS1/16S100J		C 618	(A,105,47)	CKSRYB104K16	
R 4676	(B,158,41)	RS1/16S184J		C 619	(B,97,42)	CKSRYB104K16	
				C 620	(A,109,20)	CKSRYB104K16	
R 4677	(B,148,58)	RS1/16S105J		C 621	(A,122,26)	CKSRYB104K16	
R 4678	(B,138,9)	RS1/4SA221J		C 622	(A,121,36)	CKSRYB104K16	
R 4680	(B,143,46)	RS1/16SS0R0J		C 623	(B,71,16)	CKSRYB103K16	
R 4721	(A,43,128) (UC,EU5)	RS1/16S472J		C 630	(B,113,45)	CKSRYB104K50	
R 4722	(A,41,130) (UC)	RS1/16S101J		C 632	(B,104,25)	CKSRYB104K16	
R 4723	(A,43,130) (UC)	RS1/16S101J		C 636	(B,95,40)	CKSSYB104K16	
R 4724	(A,56,117) (UC)	RS1/16S102J		C 671	(B,52,10)	CKSSYB104K16	
R 4725	(A,60,117) (UC)	RS1/16S101J		C 672	(A,48,33)	CKSSYB104K16	
R 4726	(A,63,117) (UC)	RS1/16S101J		C 685	(A,72,29)	CKSSYB104K16	
R 4727	(B,61,117) (UC)	RS1/16S620J		C 696	(B,97,29) (AU)	CKSQYB106K6R3	
R 4728	(B,43,134) (UC,EU5)	RS1/16S472J		C 705	(A,82,76)	CKSRYB104K25	B
R 4731	(B,126,100) (UC)	RS1/16S222J		C 706	(A,90,75)	CKSRYB104K25	
R 4732	(B,147,87)	RS1/16S473J		C 707	(A,80,76)	CKSRYF104Z25	
R 4733	(B,126,98) (UC)	RS1/16S682J		C 708	(A,89,75)	CKSRYF104Z25	
R 4734	(B,153,93)	RS1/16S103J		C 709	(A,88,70)	CKSRYF104Z25	
R 4735	(B,150,87)	RS1/16S104J		C 711	(B,96,64)	CKSRYB103K16	
R 4736	(B,121,99) (UC)	RS1/16S332J		C 1020	(B,70,8)	CKSRYB102K50	
R 4737	(B,151,96)	RS1/16S103J		C 1021	(B,68,8)	CKSRYB102K50	
R 4738	(B,143,93)	RS1/16S473J		C 1022	(B,63,9)	CKSRYB104K50	
R 4739	(B,145,92)	RS1/16S104J		C 1077	(A,54,29)	CKSRYB104K25	
R 4749	(B,35,7)	RS1/16S472J		C 1078	(A,57,29)	CKSRYB104K25	C
R 4750	(B,33,10)	RS1/16S472J		C 1401	(B,21,110)	CCSRCH270J50	
R 4751	(A,34,13)	RS1/16S101J		C 1402	(B,25,111)	CCSRCH220J50	
R 4752	(A,35,6)	RS1/16S101J		C 1403	(B,26,113)	CCSRCH270J50	
R 4753	(A,36,12)	RS1/16S105J		C 1404	(B,32,111)	CCSRCH330J50	
R 4754	(A,34,11)	RS1/16S103J		C 1405	(B,31,109)	CCSRCH470J50	
R 4755	(A,37,9)	RS1/16S105J		C 1406	(A,36,102)	CKSRYB103K50	
R 4756	(A,33,5)	RS1/16S103J		C 1407	(A,36,108)	CKSRYB103K50	
R 4757	(A,30,6)	RS1/16S0R0J		C 1408	(A,41,88)	CKSRYB103K50	
R 4758	(A,30,17)	RS1/16S272J		C 1409	(A,38,94)	CKSRYB222K50	
R 4771	(B,111,91)	RS1/16SS472J		C 1421	(B,35,93)	CKSRYB222K50	D
R 4772	(B,110,88)	RS1/16SS472J		C 1422	(B,40,93)	CKSRYB222K50	
R 4773	(B,116,95)	RS1/16SS103J		C 1423	(B,31,100)	CCSRCH150J50	
R 4774	(B,114,95)	RS1/16SS512J		C 1424	(B,43,92)	CKSRYB103K50	
R 4775	(B,113,86)	RS1/16SS224J		C 1426	(B,30,102)	CCSRCH270J50	
R 4776	(B,113,84)	RS1/16SS472J		C 1441	(A,32,87)	CKSRYB222K50	
R 4777	(B,116,89)	RS1/10S221J		C 1442	(A,38,88)	CKSRYB222K50	
R 4778	(B,119,85)	RS1/4S471J		C 1443	(A,37,83)	CCSRCH220J50	
R 4783	(B,122,29)	RS1/16SS332J		C 1444	(A,42,84)	CKSRYB103K50	
R 4784	(B,122,26)	RS1/16SS332J		C 1452	(B,27,70)	CKSSYB102K50	
R 4811	(A,8,44) (EU5)	RS1/16SS0R0J		C 1458	(B,29,59)	CKSRYB103K50	
R 4812	(A,8,46) (UC)	RS1/16SS0R0J		C 1461	(A,32,70)	CEVW221M10	
R 4815	(A,8,54) (AU)	RS1/16SS0R0J		C 1462	(A,32,59)	CEVW221M10	
				C 1464	(A,22,86)	CCSRCH101J50	
				C 1465	(A,39,73)	CKSRYB103K50	E
C 601	(B,123,40)	CKSRYB104K16		C 1466	(A,28,75)	CKSRYB103K50	
C 602	(B,44,6)	CKSRYB104K50		C 1468	(B,25,51) 10 uF	CCG1203	
C 604	(B,121,47)	CKSRYB104K50		C 1469	(B,23,51)	CKSRYB103K50	
C 605	(A,40,13)	CKSRYB104K16		C 1476	(A,36,38)	CKSSYB103K25	
C 606	(B,105,34)	CKSRYB104K50		C 2800	(B,95,104)	CKSRYB102K50	
C 607	(B,95,46)	CKSRYB153K50		C 2801	(A,159,99) 100 uF/16 V	CCH1565	
C 608	(B,97,36)	CKSSYB104K16		C 2802	(A,163,99)	CCSRCH102J50	
C 609	(B,97,33)	CKSRYB104K16		C 2804	(A,163,102)	CKSRYB104K50	
C 613	(B,97,47)	CKSRYB104K16		C 2805	(B,94,101)	CKSRYB104K50	
C 614	(B,102,46)	CKSRYB104K16		C 2810	(A,106,102)	CEVW101M16	F
C 615	(B,32,10)	CKSRYB104K16		C 2811	(B,102,103)	CKSRYB104K50	

CAPACITORS

1

2

3

4

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

C 2812 (A,107,97)
 C 2820 (A,159,87) 100 uF/16 V
 C 2821 (A,163,88)
 C 2823 (A,163,91)

CKSRYB104K50
 CCH1565
 CKSRYB103K50
 CKSRYB104K50

C 4076 (A,62,48)
 C 4078 (A,64,53)
 C 4079 (A,61,40)
 C 4080 (A,63,57)

CKSRYB104K50
 CCSRCH330J50
 CKSRYB103K50
 CKSRYB103K50

C 2830 (A,32,34)
 C 2831 (B,33,30)
 C 2833 (B,36,29)
 C 2840 (A,151,11)
 C 2841 (B,150,10)

CEVW101M16
 CKSRYB103K50
 CKSRYB104K50
 CKSRYB104K50
 CKSRYB102K50

C 4151 (B,63,31) 10 uF
 C 4152 (B,61,32) 10 uF
 C 4153 (B,67,32)
 C 4154 (B,70,31)
 C 4155 (B,67,36)

CCG1203
 CCG1203
 CCSSCH221J50
 CKSSYB104K16
 CKSSYB103K25

C 2842 (A,153,9)
 C 2843 (A,156,11)
 C 2844 (A,156,10)
 C 2860 (A,120,114)
 C 2861 (B,121,115)

CKSRYB104K50
 CKSRYB103K50
 CKSRYB823K16
 CEVW470M16
 CKSRYB104K50

C 4156 (B,75,35)
 C 4157 (B,74,35)
 C 4158 (B,72,35)
 C 4159 (B,78,30)
 C 4160 (B,66,34)

CKSSYB104K16
 CCSSCH151J50
 CCSSCH151J50
 CKSQYB225K10
 CCSSCH221J50

C 2862 (A,111,114)
 C 2870 (A,151,110)
 C 2871 (B,147,114)
 C 2872 (B,157,115)
 C 2881 (A,167,110)

CEVW330M10
 CKSRYB102K50
 CKSRYB102K50
 CKSRYB102K50
 CKSQYB105K16

C 4171 (A,71,62)
 C 4172 (B,73,61)
 C 4173 (A,59,59)
 C 4174 (B,75,61)
 C 4181 (B,62,58)

CEVLW470M16
 CKSRYB104K50
 CEVLW470M16
 CKSYB226K6R3
 CKSRYB104K50

C 2882 (B,146,133)
 C 2890 (B,161,104)
 C 2891 (B,161,107)
 C 2892 (A,162,111)
 C 2901 (A,170,130)

CKSRYB102K50
 CKSRYB104K50
 CKSRYB102K50
 CKSRYB102K50
 CKSRYB104K50

C 4182 (B,77,59)
 C 4183 (B,63,60)
 C 4184 (B,65,61)
 C 4185 (B,58,40)
 C 4186 (B,58,50)

CKSRYB104K50
 CKSYB226K6R3
 CKSRYB104K50
 CKSQYB475K10
 CKSQYB475K10

C 2910 (A,151,65)
 C 2911 (A,60,105)
 C 2912 (A,77,96)
 C 2920 (B,93,114)
 C 2921 (B,85,115)

CEAT103M16(P30)
 CEAT103M16(P30)
 CEAT103M16(P30)
 CKSQYB105K16
 CKSQYB105K16

C 4187 (B,59,43)
 C 4188 (B,67,61)
 C 4189 (B,69,61)
 C 4190 (B,70,59)
 C 4191 (B,71,59)

CKSQYB475K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10

C 2922 (B,85,117)
 C 2923 (B,96,114)
 C 2924 (A,100,120)
 C 2925 (B,94,117)
 C 2926 (B,81,115)

CKSQYB105K16
 CKSQYB105K16
 CKSRYB104K50
 CKSRYB105K10
 CKSRYB105K10

C 4192 (B,68,59)
 C 4193 (B,79,60)
 C 4194 (B,66,59)
 C 4195 (B,58,55)
 C 4197 (B,58,58)

CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10
 CKSQYB475K10
 CKSQYB475K10

C 2927 (B,81,117)
 C 2928 (B,96,116)
 C 2929 (A,94,115)
 C 2930 (A,103,115)
 C 2931 (A,100,119)

CKSRYB105K10
 CKSRYB105K10
 CEVW101M25
 CKSRYB104K50
 CKSRYB105K10

C 4198 (B,80,60)
 C 4199 (A,58,53)
 C 4200 (B,79,53)
 C 4201 (A,58,52)
 C 4202 (B,78,54)

CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10

C 2932 (A,81,120)
 C 2933 (A,85,120)
 C 2934 (A,83,116)
 C 2935 (A,147,81) 3 300 uF/16 V
 C 3041 (A,78,59) 10 uF

CKSQYB225K10
 CKSYB225K16
 CEVW100M16
 CCH1018(P30)
 CCG1203

C 4203 (B,58,53)
 C 4204 (B,78,51)
 C 4206 (B,78,50)
 C 4207 (B,58,48)
 C 4208 (A,79,23)

CKSQYB475K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10

C 3042 (A,76,60) 10 uF
 C 3601 (B,27,23)
 C 3602 (A,16,18) 10 uF
 C 3604 (B,22,23)
 C 3607 (B,14,23)

CCG1203
 CKSQYB475K6R3
 CCG1203
 CKSQYB475K6R3
 CKSQYB475K6R3

C 4210 (A,75,21)
 C 4211 (B,57,43)
 C 4212 (A,72,22)
 C 4213 (A,69,22)
 C 4215 (B,77,44)

CKSRYB105K10
 CKSQYB475K10
 CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10

C 3611 (A,8,25)
 C 3612 (A,7,23)
 C 3613 (A,7,22)
 C 4061 (A,54,38)
 C 4062 (A,59,44)

CKSSYB102K50
 CKSSYB102K50
 CKSSYB102K50
 CKSRYB103K50
 CEVW100M16

C 4216 (B,59,37)
 C 4217 (B,76,43)
 C 4219 (A,73,34)
 C 4220 (A,73,44)
 C 4221 (B,73,40)

CKSQYB475K10
 CKSRYB105K10
 CEVW331M16
 CEVWNP220M10
 CKSRYB105K10

C 4063 (A,54,41)
 C 4070 (A,68,56) 10 uF
 C 4071 (A,69,49) 10 uF
 C 4072 (A,68,54) 10 uF
 C 4073 (A,68,52) 10 uF

CKSRYB104K50
 CCG1203
 CCG1203
 CCG1203
 CCG1203

C 4222 (B,74,40)
 C 4224 (B,58,47)
 C 4231 (B,62,24)
 C 4232 (A,64,27)
 C 4233 (A,55,17)

CKSRYB105K10
 CKSRYB105K10
 CKSRYB105K10
 CEVWNP220M10
 CEVQW101M10

C 4075 (A,64,41)

CCSRCH330J50

C 4251 (B,105,113)

CKSRYB473K50

1

2

3

4

5			6			7			8		
<u>Circuit Symbol and No.</u>			<u>Part No.</u>			<u>Circuit Symbol and No.</u>			<u>Part No.</u>		
C 4252	(B,100,110)	10 uF	CCG1203			C 4616	(B,140,59)		CKSRYB102K50		
C 4253	(B,106,110)	10 uF	CCG1203			C 4617	(B,140,60)		CKSRYB104K50		
C 4254	(B,102,104)		CKSRYB104K25			C 4618	(B,111,54)	10 uF	CCG1223		
C 4264	(A,86,109)		CEVQW101M10			C 4619	(B,114,56)		CKSRYB104K50		A
C 4271	(B,82,67)	10 uF(UC)	CCG1203			C 4631	(A,123,91)		CKSRYB104K50		
C 4273	(B,85,66)	(UC)	CKSRYB105K6R3			C 4641	(B,141,19)		CKSRYB103K25		
C 4274	(B,79,64)		CKSRYB105K6R3			C 4642	(B,148,19)		CCSRCH101J50		
C 4275	(B,60,64)		CKSRYB105K6R3			C 4643	(B,150,19)		CKSRYB104K50		
C 4276	(B,59,67)		CKSRYB105K6R3			C 4644	(B,145,22)		CKSRYB473K50		
C 4277	(B,54,71)	10 uF(UC)	CCG1203			C 4645	(B,145,23)	33 pF	CCG1252		
C 4280	(B,61,68)	(UC)	CKSRYB105K6R3			C 4646	(B,144,26)		CKSRYB105K10		
C 4281	(B,60,72)		CKSRYB105K6R3			C 4647	(B,157,24)		CKSRYF104Z25		
C 4284	(B,83,69)		CKSRYB105K6R3			C 4648	(B,144,28)		CKSQYB475K10		
C 4285	(B,61,70)		CKSRYB105K6R3			C 4649	(B,157,21)		CKSRYF474Z16		
C 4286	(B,79,71)		CKSRYB105K6R3			C 4650	(B,157,29)	4.7 uF	CCG1222		B
C 4287	(B,61,73)		CKSRYB105K6R3			C 4651	(A,133,21)	220 uF/10 V	CCH1409		
C 4288	(A,68,70)		CEVW100M16			C 4652	(A,154,32)	10 uF	CCG1223		
C 4289	(A,60,70)		CEVW470M16			C 4653	(A,151,32)	10 uF	CCG1223		
C 4291	(A,65,72)		CKSRYB104K16			C 4654	(A,158,32)	10 uF	CCG1223		
C 4293	(A,62,83)		CKSRYB104K16			C 4655	(B,134,23)	10 uF	CCG1223		
C 4294	(A,63,78)		CEVW100M16			C 4656	(B,141,13)		CKSRYB104K50		
C 4295	(A,58,78)		CEVW4R7M16			C 4657	(B,142,13)		CKSRYB102K50		
C 4296	(B,58,64)		CKSRYB104K16			C 4658	(B,164,22)		CKSRYB102K50		
C 4297	(A,76,66)		CKSRYB105K10			C 4659	(B,163,22)		CKSRYB104K50		
C 4298	(B,62,75)		CCSRCH100D50			C 4661	(B,140,35)		CKSRYB103K25		C
C 4299	(B,62,82)		CKSRYB102K50			C 4662	(B,147,35)		CCSRCH102J50		
C 4300	(A,60,83)		CCSRCH101J50			C 4663	(B,150,35)		CKSRYB104K16		
C 4305	(A,67,75)		CKSRYB103K50			C 4664	(B,144,37)		CKSRYB473K50		
C 4331	(A,108,91)		CEVW4R7M16			C 4665	(B,144,39)	33 pF	CCG1252		
C 4332	(A,103,91)		CEVW4R7M16			C 4666	(B,144,42)		CKSRYB105K10		
C 4333	(A,98,85)		CEVW4R7M16			C 4667	(B,157,45)	4.7 uF	CCG1222		
C 4334	(A,93,85)		CEVW4R7M16			C 4668	(B,143,43)		CKSQYB475K10		
C 4335	(A,98,94)		CEVW4R7M16			C 4669	(B,157,37)		CKSRYF474Z16		
C 4336	(A,93,94)		CEVW4R7M16			C 4670	(B,157,41)		CKSRYB104K16		
C 4337	(B,106,90)		CKSRYB222K50			C 4671	(A,133,36)	330 uF/6.3 V	CCH1366		
C 4338	(B,97,84)		CKSRYB222K50			C 4672	(A,157,48)	10 uF	CCG1223		D
C 4339	(B,97,91)		CKSRYB222K50			C 4673	(A,151,48)	10 uF	CCG1223		
C 4340	(B,100,90)		CKSRYB222K50			C 4674	(A,154,48)	10 uF	CCG1223		
C 4341	(B,90,84)		CKSRYB222K50			C 4675	(B,134,33)	10 uF	CCG1223		
C 4342	(B,90,91)		CKSRYB222K50			C 4676	(B,137,32)		CKSRYB104K50		
C 4351	(B,132,110)		CKSRYB104K25			C 4677	(B,138,32)		CKSRYB102K50		
C 4352	(A,133,113)		CKSRYF103Z50			C 4678	(B,163,36)		CKSRYB102K50		
C 4353	(A,124,108)		CKSRYB102K50			C 4679	(B,164,36)		CKSRYB104K50		
C 4371	(A,38,117)		CKSRYB102K50			C 4701	(B,87,48)		CKSYB105K16		
C 4372	(A,42,123)		CKSRYB102K50			C 4702	(A,89,48)		CKSRYB104K16		
C 4600	(B,114,55)		CKSRYB102K50			C 4704	(A,87,51)		CEVW100M16		
C 4601	(B,108,59)		CKSRYB103K25			C 4705	(A,93,48)		CEVW100M16		E
C 4602	(B,115,59)		CCSRCH102J50			C 4706	(B,92,48)		CKSYB105K25		
C 4603	(B,117,59)		CKSRYB104K16			C 4707	(B,89,45)		CKSRYB104K16		
C 4604	(B,112,62)		CKSRYB473K50			C 4709	(B,87,46)		CKSRYB104K16		
C 4605	(B,112,63)	33 pF	CCG1252			C 4710	(A,86,48)		CKSRYB104K16		
C 4606	(B,111,66)		CKSRYB105K10			C 4721	(A,57,117)	(UC)	CKSRYB472K50		
C 4607	(B,124,69)	4.7 uF	CCG1222			C 4724	(B,59,133)	(UC)	CKSRYB104K50		
C 4608	(B,110,68)		CKSQYB475K10			C 4731	(B,152,54)		CKSRYB104K50		
C 4609	(B,124,62)		CKSRYF474Z16			C 4732	(B,155,73)		CKSRYB104K50		
C 4610	(B,124,65)		CKSRYB104K16			C 4751	(A,36,10)		CKSRYB104K50		
C 4611	(A,118,57)	330 uF/6.3 V	CCH1366			C 4771	(B,112,88)		CKSRYB104K50		F
C 4612	(A,119,72)	10 uF	CCG1223			C 4772	(B,111,84)		CKSRYB472K50		
C 4613	(A,122,72)	10 uF	CCG1223			C 4773	(B,126,90)		CKSRYB103K50		
C 4614	(A,125,72)	10 uF	CCG1223			C 4774	(A,118,94)		CEVW470M16		

1

2

3

4

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

C 4775	(B,115,102)	CKSRYB103K50
C 4776	(A,119,101)	CEVW101M16
C 4784	(B,120,30)	CCSSCH470J50
C 4785	(B,120,29)	CCSSCH470J50
C 4786	(A,111,17)	CKSRYB104K16

R 1025	(B,19,11)
R 1027	(A,27,19)
R 1101	(A,35,36)
R 1102	(A,43,42)
R 1103	(A,34,41)
R 1104	(A,36,36)
R 1105	(A,42,44)
R 1106	(A,45,39)
R 1109	(A,34,43)
R 1110	(A,41,43)

RS1/16SS101J
RS1/16SS101J
RS1/16SS104J
RS1/16SS104J
RS1/16SS391J
RS1/16SS511J
RS1/16SS391J
RS1/16SS561J
RS1/16SS3R3J
RS1/16SS3R3J

B**Unit Number : CWN4251****Unit Name : CK Unit****MISCELLANEOUS**

CN882	(A,21,23) Connector	CKS5660
CN883	(A,10,31) Connector	CKS6115

R 1111	(A,38,39)
R 1112	(A,38,38)
R 1113	(A,49,46)
R 1114	(A,48,46)
R 1115	(A,41,38)

RS1/10SR1R5J
RS1/10SR1R5J
RS1/10SR1R5J
RS1/10SR1R5J
RS1/10SR1R5J

RESISTORS

R 898	(A,17,40)	RS1/16S0R0J
-------	-----------	-------------

R 1116	(A,41,39)
R 1117	(A,48,43)
R 1118	(A,49,43)
R 1201	(A,16,36)
R 1202	(A,17,35)

RS1/10SR1R5J
RS1/10SR1R5J
RS1/10SR1R5J
RS1/16SS221J
RS1/16SS221J

C**Unit Number : YWX5009****Unit Name : DVD Core Unit****MISCELLANEOUS**

IC 1002	(B,21,41) Regulator IC	S-1133B50-U5
IC 1003	(B,35,23) IC	S-1200B50-M5
IC 1004	(B,25,11) IC	NJM2885DL1-33
IC 1005	(B,19,21) IC	R1232D121B
IC 1201	(A,15,29) IC	BD8231EFV
*IC1401	(B,63,36) Flash ROM Unit	CWW1825
*IC1402	(B,50,36) Flash ROM Unit	CWW1826
IC 1480	(B,59,13) SDRAM(64M)	K4S641632N-LC75
IC 1501	(A,60,20) IC	MN2DS0018MAUB
IC 1801	(B,37,16) D/A Converter	PCM1753DBQ

R 1203	(A,22,35)
R 1204	(A,19,35)
R 1212	(A,7,36)
R 1213	(B,8,29)
R 1214	(B,8,27)

RS1/16SS103J
RS1/16SS153J
RS1/16SS271J
RS1/16SS1R0J
RS1/16SS1R0J

Q 1101	(A,35,39) Transistor	2SC4081
Q 1102	(A,46,42) Transistor	2SC4081
Q 1103	(A,38,45) Transistor	2SB1132
Q 1104	(A,45,49) Transistor	2SB1132

R 1215	(B,8,28)
R 1216	(B,8,24)
R 1217	(B,8,25)
R 1218	(B,8,26)
R 1222	(B,26,39)

RS1/16SS1R0J
RS1/16SS1R0J
RS1/16SS1R0J
RS1/16SS1R0J
RS1/16SS271J

L 1003	(B,22,26) Inductor	CTF1677
L 1004	(B,14,17) Inductor	CTF1678
L 1512	(A,57,5) Inductor	CTF1743
L 1902	(B,5,8) Inductor	CTF1487
L 1903	(B,12,11) Inductor	CTF1558

R 1300	(B,39,24)
R 1401	(B,63,49)
R 1402	(B,70,27)
R 1405	(B,56,24)
R 1406	(B,54,25)

RS1/16SS0R0J
RS1/16SS221J
RS1/16SS104J
RS1/16SS104J
RS1/16SS104J

L 1904	(B,46,19) Inductor	CTF1473
X 1501	(B,43,7) Oscillator 27.000 MHz	CSS1768
EF1001	(B,5,12) Chip EMI Filter	DTF1106
EF1002	(B,11,13) Chip EMI Filter	DTL1106
CN1101	(A,66,49) Connector	CKS5775

R 1480	(B,52,21)
R 1481	(B,56,21)
R 1482	(B,61,21)
R 1483	(B,64,21)
R 1484	(B,67,21)

RAB4CQ560J
RAB4CQ560J
RAB4CQ560J
RAB4CQ560J
RAB4CQ560J

CN1201	(A,16,44) Connector	CKS6003
CN1901	(A,21,7) Connector	CKS6025

R 1485	(B,50,5)
R 1486	(B,55,5)
R 1487	(B,64,5)
R 1488	(B,68,5)
R 1489	(B,59,5)

RAB4CQ560J
RAB4CQ560J
RAB4CQ560J
RAB4CQ560J
RS1/16SS560J

RESISTORS

R 1002	(B,18,27)	RS1/16SS101J
R 1004	(A,29,27)	RS1/16SS4702D
R 1007	(A,29,26)	RS1/16SS6801D
R 1019	(B,15,9)	RS1/16SS101J
R 1021	(A,27,15)	RS1/16SS0R0J

R 1490	(B,50,21)
R 1501	(B,46,7)
R 1503	(B,45,8)
R 1504	(B,45,13)
R 1505	(A,43,13)

RS1/16SS560J
RS1/16SS122J
RS1/16SS105J
RS1/16SS120J
RS1/16SS101J

R 1506	(A,37,14)
R 1507	(A,44,14)
R 1508	(A,43,15)
R 1509	(A,63,35)
R 1510	(A,64,35)

RS1/16SS101J
RS1/16SS101J
RS1/16SS221J
RS1/16SS102J
RS1/16SS102J

R 1511	(B,46,13)
R 1512	(A,58,5)
R 1513	(A,66,35)
R 1514	(A,68,35)
R 1516	(A,65,36)

RS1/16S0R0J
RS1/16SS101J
RS1/16SS103J
RS1/16SS183J
RS1/16SS103J

5		6		7		8	
<u>Circuit Symbol and No.</u>		<u>Part No.</u>		<u>Circuit Symbol and No.</u>		<u>Part No.</u>	
R 1517	(A,76,16)	RS1/16SS103J		C 1107	(A,41,49)	CKSSYB103K16	A
R 1518	(A,74,24)	RS1/16SS103J		C 1108	(A,74,42)	CKSSYB103K16	
R 1519	(A,70,34)	RS1/16SS102J		C 1109	(A,56,41)	CKSRYB224K10	
R 1522	(A,65,38)	RS1/16SS104J		C 1110	(A,71,42)	CKSSYB103K16	
R 1523	(A,66,37)	RS1/16SS221J		C 1111	(A,61,39)	CKSRYB224K10	
R 1524	(A,64,37)	RS1/16SS472J		C 1112	(B,40,39) 22 uF	CCG1178	
R 1525	(A,71,34)	RS1/16SS103J		C 1113	(B,36,38) 22 uF	CCG1178	
R 1526	(A,67,34)	RS1/16SS103J		C 1201	(B,12,34)	CEVW101M16	
R 1527	(B,77,29)	RS1/16SS682J		C 1204	(A,8,24)	CKSSYB222K50	
R 1528	(A,78,20)	RS1/16SS103J		C 1205	(A,13,23)	CKSSYB104K16	
R 1529	(A,76,18)	RS1/16SS103J		C 1207	(A,22,25)	CKSSYB104K16	B
R 1530	(A,77,20)	RS1/16SS103J		C 1208	(A,15,36)	CKSSYB103K16	
R 1531	(A,75,24)	RS1/16SS103J		C 1209	(B,10,25)	CKSSYB104K16	
R 1533	(A,75,29)	RS1/16SS104J		C 1210	(B,6,23)	CKSSYB104K16	
R 1534	(A,78,30)	RS1/16SS221J		C 1211	(B,9,22)	CKSYB475K16	
R 1535	(B,70,34)	RS1/16SS104J		C 1401	(B,63,48)	CKSSYB103K16	
R 1536	(A,78,31)	RS1/16SS104J		C 1403	(B,69,23)	CKSSYB104K10	
R 1537	(A,73,35)	RS1/16SS104J		C 1404	(B,58,25)	CKSQYB475K6R3	
R 1538	(A,61,4)	RS1/16SS104J		C 1408	(B,47,25)	CKSSYB104K10	
R 1539	(A,77,23)	RS1/16SS104J		C 1409	(B,47,23)	CKSQYB475K6R3	
R 1540	(A,73,32)	RS1/16SS221J		C 1480	(B,47,21)	CKSSYB104K10	C
R 1541	(A,75,32)	RS1/16SS221J		C 1481	(B,49,23)	CKSSYB104K10	
R 1542	(A,77,29)	RS1/16SS103J		C 1482	(B,54,21)	CKSSYB104K10	
R 1546	(B,75,29)	RS1/16SS682J		C 1484	(B,59,20)	CKSSYB104K10	
R 1601	(A,42,25)	RS1/16SS123J		C 1485	(B,69,21)	CKSSYB104K10	
R 1602	(A,44,25)	RS1/16SS123J		C 1487	(B,58,4)	CKSSYB104K10	
R 1603	(A,43,30)	RN1/16SE1002D		C 1488	(B,52,5)	CKSSYB104K10	
R 1604	(A,50,35)	RS1/16SS105J		C 1489	(B,45,20)	CKSQYB106K6R3	
R 1605	(A,49,37)	RS1/16SS105J		C 1490	(B,45,23)	CKSSYB102K50	
R 1670	(A,34,21)	RS1/16SS1002D		C 1501	(B,72,9)	CKSQYB106K6R3	
R 1671	(A,36,21)	RS1/16SS2402D		C 1502	(A,35,32)	CKSQYB106K6R3	D
R 1672	(A,45,19)	RS1/16SS2000D		C 1503	(A,60,4)	CKSSYB104K10	
R 1674	(A,45,20)	RS1/16SS3002D		C 1504	(A,51,5)	CKSSYB104K10	
R 1801	(B,35,6)	RS1/16SS104J		C 1505	(A,53,5)	CKSSYB104K10	
R 1802	(B,33,6)	RS1/16SS104J		C 1506	(A,55,5)	CKSSYB104K10	
R 1803	(B,35,11)	RS1/16SS821J		C 1507	(A,62,5)	CKSSYB104K10	
R 1804	(B,34,11)	RS1/16SS821J		C 1508	(A,66,5)	CKSSYB104K10	
<u>CAPACITORS</u>				C 1509	(A,69,5)	CKSSYB104K10	
C 1001	(B,36,21)	CKSRYB105K10		C 1510	(B,46,5)	CCSSCH120J50	
C 1003	(B,18,44)	CKSSYB104K16		C 1511	(A,46,9)	CKSSYB104K10	
C 1004	(B,24,40)	CKSQYB475K10		C 1512	(B,43,10)	CCSSCH100D50	E
C 1005	(B,32,23)	CKSRYB105K16		C 1513	(B,74,12)	CKSSYB104K10	
C 1008	(B,20,31) 10 uF	DCH1201		C 1514	(A,46,13)	CKSSYB104K10	
C 1009	(B,18,31) 10 uF	DCH1201		C 1515	(A,45,15)	CKSSYB104K10	
C 1010	(B,26,18)	CKSQYB225K10		C 1516	(A,75,15)	CKSSYB104K10	
C 1011	(B,22,18)	CKSRYB105K10		C 1517	(A,74,16)	CKSSYB104K10	
C 1013	(B,15,25) 10 uF	DCH1201		C 1518	(A,75,22)	CKSSYB104K10	
C 1014	(B,13,25) 10 uF	DCH1201		C 1519	(A,74,26)	CKSSYB104K10	
C 1015	(B,7,8)	CKSSYB102K50		C 1520	(A,75,30)	CKSSYB104K10	
C 1016	(B,12,10)	CKSSYB102K50		C 1521	(A,60,37)	CKSSYB104K10	
C 1018	(A,28,28)	CKSSYB104K10		C 1522	(A,65,34)	CKSSYB104K10	
C 1019	(A,10,17)	CKSSYB104K10		C 1523	(A,68,37)	CKSSYB104K10	
C 1021	(B,34,4)	CCSRCH681J50		C 1524	(A,69,37)	CKSSYB473K10	
C 1022	(A,23,21)	CCSRCH681J50		C 1526	(A,68,37)	CKSSYB103K16	
C 1101	(B,31,40) 10 uF	DCH1201		C 1528	(A,78,29)	CCSSCH471J16	
C 1104	(A,34,42)	CKSSYB104K10		C 1601	(A,44,29)	CKSSYB103K16	F
C 1105	(A,42,45)	CKSSYB104K10		C 1602	(A,42,24)	CCSSCH101J50	
C 1106	(A,37,48)	CKSSYB103K16		C 1603	(A,44,27)	CCSSCH101J50	
				C 1604	(A,41,27)	CCSSCH680J50	
				C 1605	(A,43,27)	CCSSCH680J50	

1

2

3

4

Circuit Symbol and No.**Part No.****Circuit Symbol and No.****Part No.**

C 1606 (A,41,23) CKSSYB104K10
 C 1607 (A,41,35) CKSQYB106K6R3
 C 1608 (A,43,36) CKSRYB105K10
 C 1609 (A,48,35) CKSSYB104K10
 C 1610 (A,50,37) CKSSYB104K10

D 812 (B,15,84) Diode RB521S-30
 D 815 (A,14,24) LED SMLE12BC7T(NP)
 D 852 (B,11,80) Diode HZU5R6(B2)
 D 853 (B,13,80) Diode HZU5R6(B2)
 D 854 (A,15,78) Diode HZU5R6(B2)
 D 855 (A,12,76) Diode HZU5R6(B2)
 D 856 (B,21,82) Diode HZU5R6(B2)
 D 857 (A,25,70) Diode HZU5R6(B2)
 D 858 (A,25,72) Diode HZU5R6(B2)

C 1611 (A,51,37) CKSSYB104K10
 C 1612 (A,52,34) CKSSYB104K10
 C 1613 (A,52,37) CKSSYB104K10
 C 1614 (A,53,34) CKSSYB104K10
 C 1615 (A,54,34) CKSSYB104K10

D 859 (B,11,75) Diode HZU11(B2)
 D 860 (B,11,73) Diode HZU11(B2)
 D 861 (A,18,72) Diode HZU11(B2)
 D 862 (A,22,66) Diode HZU11(B2)
 D 863 (A,23,63) Diode HZU5R6(B2)

C 1616 (A,54,37) CKSSYB104K10
 C 1617 (A,54,38) CKSSYB104K10
 C 1618 (A,56,34) CCSSCH101J50
 C 1619 (A,57,34) CKSSYB562K25
 C 1620 (A,58,34) CKSSYB224K6R3

D 864 (B,8,72) Diode HZU5R6(B2)
 D 866 (A,16,64) Diode HZU5R6(B2)
 D 867 (B,15,65) Diode HZU5R6(B2)
 D 871 (A,11,68) Diode MALSO68X
 S 801 (A,9,90) Push Switch CSG1155

C 1621 (A,57,37) CKSSYB224K6R3
 C 1622 (A,59,35) CKSSYB333K16
 C 1623 (A,45,35) CKSRYB105K10
 C 1624 (A,58,37) CKSSYB104K10
 C 1625 (A,56,37) CKSSYB104K10

S 802 (A,13,81) Push Switch CSG1155
 S 803 (A,19,52) Switch(MULTI-CONTROL) CSX1135
 S 804 (A,21,90) Push Switch CSG1155
 S 805 (A,25,81) Push Switch CSG1155
 ANT801 (A,6,40) Antenna CTX1095

C 1671 (A,44,17) CKSSYB104K10
 C 1672 (A,45,18) CKSSYB104K10
 C 1673 (A,45,22) CKSSYB104K10
 C 1674 (A,43,21) CKSSYB104K10
 C 1676 (A,38,22) CKSRYB105K10

CN801 (B,19,73) Connector CKS5862
 CN802 (A,13,9) Jack CKN1049
 CN803 (B,18,29) Connector CKS5749

C 1801 (B,34,8) CKSQYB475K6R3
 C 1802 (B,32,8) CKSQYB475K6R3
 C 1803 (B,36,8) CCSRCH182J50
 C 1804 (B,31,7) CCSRCH182J50
 C 1805 (B,32,19) CKSSYB104K10

RESISTORS

C 1806 (B,39,9) 10 uF DCH1201
 C 1809 (B,43,16) CKSSYB104K10
 C 1934 (B,42,29) CCSRCH680J50

R 801 (B,25,58) RS1/16S0R0J
 R 802 (A,12,63) RS1/16S0R0J
 R 803 (B,12,64) RS1/16S102J
 R 804 (B,18,51) RS1/16S162J
 R 805 (B,8,77) RS1/16S123J

D
Unit Number :
Unit Name : Connect PCB

MISCELLANEOUS

S 101 (B,51,37) Switch(HOME) CSN1068
 S 102 (B,12,23) Switch(DSCSNS) CSN1068
 S 103 (B,22,10) Switch(8SNS) CSN1068
 R 101 (B,52,27) RS1/16S101J
 R 102 (B,15,29) RS1/16S101J
 R 103 (B,16,11) RS1/16S101J
 C 101 (B,51,23) CKSRYB104K50

R 806 (B,21,51) RS1/16S302J
 R 807 (A,19,78) RS1/16S132J
 R 808 (B,21,84) RS1/16S103J
 R 809 (A,19,80) RS1/16S272J
 R 810 (A,24,67) RS1/16S241J

CAPACITORS

C 803 (A,20,64) CKSRYB103K25
 C 804 (A,12,64) CKSRYB103K25
 C 805 (A,14,68) CKSRYB104K25
 C 806 (A,16,68) CKSRYB104K25

Miscellaneous Parts List

E
Unit Number :
Unit Name : Keyboard Unit

MISCELLANEOUS

D 801 (A,19,68) LED NSSM025-6502
 D 802 (A,14,16) Diode MALSO68X
 D 805 (A,8,15) Diode MALSO68X
 D 806 (B,6,9) Diode MALSO68X
 D 807 (B,6,5) Diode MALSO68X
 D 808 (B,10,77) Diode RB521S-30

M 1 Pickup Unit(Service) CXX2398
 M 2 Motor Unit(LOAD/CRG) CXC4026
 M 2 Motor(SPINDLE) EXM1050

1

2

3

4

Revision History

[illegible]