Pioneer sound.vision.soul

Service Manual

ORDER NO.
CRT4084

CD RECEIVER

DEH-2000MP /XS/UC







This service manual should be used together with the following manual(s) listed below. For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
DEH-2050MP/XN/ES	CRT4044		
CX-3195	CRT3815	S10.5COMP2	CD Mech.Module : Circuit Descriptions, Mech. Descriptions, Dissassembly

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
ⓒ**PIONEER CORPORATION 2007**
K-ZZU. OCT. 2007 Printed in Japan

SAFTY INFORMATION

WARNING

This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.
Health & Safety Code Section 25249.6 - Proposition 65

EXPLODED VIEWS AND PARTS LIST

PACKING(Page 26)

PACKING SECTION PARTS LIST


*:Non spare part

Mark	No.	Description	DEH-2050MP/XN/ES	DEH-2000MP/XS/UC
	2	Accessory Assy	CEA6708	* YEA5029
	3	Screw	Not used	BPZ20P060FTC
	12	Polyethylene Bag	CEG1373	CEG1374
	13	Unit Box	YHG5313	YHG5338
	14	Contain Box	YHL5313	YHL5338
	15	Protector	YHP5039	YHP5041
	16	Protector	YHP5040	YHP5042
	17-1	Installation Manual	YRD5147	Not used
	17-2	Owner's Manual	YRD5145	YRD5144
*	17-4	Warranty Card	Not used	CRY1246
	18	Case Assy	YXB5009	Not used

EXTERIOR(Page 28)

EXTERIOR SECTION PARTS LIST

Mark	No.	Description	DEH-2050MP/XN/ES	DEH-2000MP/XS/UC
	11	Tuner Amp Unit	YWM5234	YWM5232(Tuner Amp Assy)
	44	Grille Assy	YXA5374	YXA5319(Detachable Assy)
	45	Grille Unit	YXA5334	YXA5302
	46	Knob Unit	YXC5072	Not used
	68	Screw	Not used	BMZ40P140FTC
	69	Earth Plate	Not used	CNC8915
	70	Cushion	Not used	CNM8890
	71	Holder	Not used	CNV7619




ELECTRICAL PARTS LIST(Page 52)


TUNER AMP UNIT

Circuit Symbol and No. Part Name	DEH-2050MP/XN/ES	DEH-2000MP/XS/UC
R644	RS1/16S0R0J	Not used
R645	RS1/16S0R0J	Not used
R646	RS1/16S0R0J	Not used
R647	Not used	RS1/16S0R0J
R648	RS1/16S0R0J	Not used
R670	Not used	RS1/16S473J
R671	RS1/16S473J	RS1/16S563J
C406	CCSRCH390J50	Not used
C409	CCSRCH100D50	Not used
C637	CKSRYB103K50	Not used
C646	CKSRYB103K50	Not used

Page 37 Address 6D



Page 34 Address 4E



KEYBOARD UNIT

Circuit Symbol and No.	Part Name	DEH-2050MP/XN/ES	DEH-2000MP/XS/UC
D1803	LED	CL-195SR-CD	CL-195PG-CD
D1805	LED	CL-195SR-CD	CL-195PG-CD
D1806	LED	CL-195SR-CD	CL-195PG-CD
D1807	LED	CL-195SR-CD	CL-195PG-CD
D1808	LED	CL-195SR-CD	CL-195PG-CD
D1809	LED	CL-195SR-CD	CL-195PG-CD
D1810	LED	CL-195SR-CD	CL-195PG-CD
D1811	LED	CL-195SR-CD	CL-195PG-CD
D1812	LED	CL-195SR-CD	CL-195PG-CD
D1813	LED	CL-195SR-CD	CL-195PG-CD
D1814	LED	CL-195SR-CD	CL-195PG-CD
D1815	LED	CL-195SR-CD	CL-195PG-CD
D1816	LED	CL-195SR-CD	CL-195PG-CD
D1817	LED	CL-195SR-CD	CL-195PG-CD
D1818	LED	CL-195SR-CD	CL-195PG-CD
D1819	LED	CL-195SR-CD	CL-195PG-CD
D1821	LED	CL-195SR-CD	CL-195PG-CD
R1803		RS1/4SA821J	RS1/4SA561J
R1804		RS1/4SA821J	RS1/4SA561J
R1805		RS1/4SA821J	RS1/4SA561J
R1806		RS1/4SA681J	RS1/4SA391J
R1807		RS1/4SA681J	RS1/4SA391J