





PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
KDC-9023R/PSW9524/X969						242	2D	*	E30-6209-05	CORD WITH PINPLUG (3PR+1AUX)	KM1
201	1C	*	A02-2731-03	PLASTIC CABINET ASSY		242	2D	*	E30-6210-05	CORD WITH PINPLUG (3PR)	E1
204	3C	*	A22-2988-03	SUB PANEL ASSY		243	2D	*	E30-6216-05	CORD WITH DIN CONNECTOR (CH)	KM1
206	1D	*	A52-0831-02	TOP PLATE		243	2D	*	E30-6217-05	CORD WITH DIN CONNECTOR (CH+DIS)	E1
PA1	1D	*	A64-2975-01	PANEL ASSY	K	245	3D	*	E41-0351-05	FLAT CABLE CONNECTOR	
PA1	1D	*	A64-2982-01	PANEL ASSY	M1	△ DC1	1C		E30-4942-05	DC CORD (ISO)	M1E1
PA1	1D	*	A64-2984-01	PANEL ASSY	E1	△ DC2	1C		E30-6062-05	DC CORD	K
PA2	1C	*	A64-2993-02	PANEL ASSY	K	FC1	2D	*	E39-0565-05	FLAT CABLE (24P)	
PA2	1C	*	A64-3002-02	PANEL ASSY	M1E1	249	2C	*	F07-1121-03	COVER	
PME1	2C	*	A10-5029-11	CHASSIS ASSY		250	3C	*	F07-1122-03	COVER	
RM1	1C		A70-2026-05	REMOTE CONTROLLER ASSY (RC-420)	M1E1	251	3C	*	F07-1123-03	COVER	
RM2	1C		A70-2040-05	REMOTE CONTROLLER ASSY (RC-505)	K	252	2C	*	F09-1794-04	SHEET	
-			B46-0100-50	WARRANTY CARD		253	3C	*	F09-1798-04	SHEET	
-			B46-0606-04	ID CARD	K	256	2D	*	F09-1842-04	SHEET	
-			B46-0612-14	ID CARD	M1E1	262	2D		F29-0049-05	INSULATING COVER	
-		*	B46-0648-13	USER CARD	K	△ F1	2D		F52-0006-05	FUSE (MINI BLADE TYPE) 10A	
-		*	B46-0653-03	USER CARD	K	264	2C	*	G01-3162-04	EXTENSION SPRING	
-		*	B64-2458-00	INSTRUCTION MANUAL (ENGLISH)	K	265	3C	*	G01-3188-04	EXTENSION SPRING	
-		*	B64-2459-00	INSTRUCTION MANUAL (FRE.SPA.)	K	266	3C	*	G01-3189-04	TORSION COIL SPRING	
-		*	B64-2462-00	INSTRUCTION MANUAL (ENG.T-CHI.)	M1	267	3D	*	G01-3199-04	TORSION COIL SPRING	
-		*	B64-2464-00	INSTRUCTION MANUAL (ENGLISH)	E1	270	2C	*	G11-3539-04	CUSHION (VOL)	
-		*	B64-2465-00	INSTRUCTION MANUAL (FRE.GER.)	E1	272	3D	*	G11-3559-04	CUSHION	
-		*	B64-2466-00	INSTRUCTION MANUAL (DUT.ITA.)	E1	-		*	H10-4854-12	POLYSTYRENE FOAMED FIXTURE	
-		*	B64-2467-00	INSTRUCTION MANUAL (SPA.POR.)	E1	-		*	H21-1151-04	PROTECTION SHEET	
208	3C	*	B03-5016-03	DRESSING PLATE ASSY		-			H25-0329-04	PROTECTION BAG (280X450X0.03)	KM1
210	1C	*	B07-3079-01	ESCUTCHEON		-			H25-0337-04	PROTECTION BAG (180X300X0.03)	
212	3C	*	B07-3080-02	ESCUTCHEON		-			H25-1111-04	PROTECTION BAG (280X450X0.03)	E1
213	1D	*	B10-4382-01	FRONT GLASS	K	-		*	H54-2715-03	ITEM CARTON CASE	K
213	1D	*	B10-4389-01	FRONT GLASS	M1	-		*	H54-2722-03	ITEM CARTON CASE	M1
213	1D	*	B10-4391-01	FRONT GLASS	E1	-		*	H54-2724-03	ITEM CARTON CASE	E1
214	1C	*	B12-1221-04	INDICATOR		277	3C	*	J19-5220-03	HOLDER	
215	1C	*	B12-1222-03	INDICATOR ASSY		278	1C	*	J21-9823-03	MOUNTING HARDWARE ASSY	
216	1C	*	B19-2201-04	LIGHTING BOARD		279	3D	*	J21-9951-03	MOUNTING HARDWARE ASSY	
219	1C	*	B43-1505-04	KENWOOD BADGE		280	3D	*	J21-9954-02	MOUNTING HARDWARE ASSY	
220	1C		D10-4674-04	LEVER		281	2C	*	J21-9956-12	MOUNTING HARDWARE ASSY	
222	2C	*	D10-4716-04	ARM ASSY		283	3D	*	J21-9997-03	MOUNTING HARDWARE ASSY	
223	3C	*	D10-4718-04	ARM ASSY		284	2C	*	J21-9999-02	MOUNTING HARDWARE ASSY	
224	3D	*	D10-4721-11	SLIDER ASSY		285	3C	*	J31-1055-04	COLLAR	
225	2C	*	D10-4749-03	LEVER		286	3C	*	J31-1056-04	COLLAR	
226	3D	*	D10-4750-04	LEVER		287	3D	*	J74-1444-04	RIGID PRINTED WIRING BOARD	
227	3D	*	D12-0637-03	CAM		FPC1	2D	*	J84-0153-05	FLEXIBLE PRINTED WIRING BOARD	
228	2D	*	D13-2270-04	GEAR		FPC2	3D	*	J84-0156-04	FLEXIBLE PRINTED WIRING BOARD	
229	3D	*	D13-2272-04	GEAR		292	1C	*	K24-4004-04	KNOB (PLAY)	
230	3C	*	D13-2273-14	GEAR		293	1C	*	K24-4005-04	KNOB (EJECT)	
232	3C	*	D13-2274-14	GEAR		294	1C	*	K24-4006-04	KNOB (ATT)	
233	3D	*	D13-2276-04	GEAR		295	2C	*	K24-4007-04	KNOB (OPEN)	
234	3D	*	D13-2277-04	GEAR		296	1C	*	K25-1527-03	KNOB (SRC,Q)	
235	3D	*	D13-2278-04	GEAR		297	1C	*	K25-1529-03	KNOB (AM/FM)	
236	3D	*	D13-2289-03	RACK (GEAR)		298	1C	*	K25-1530-04	KNOB (SCRL)	
237	3C	*	D13-2290-04	GEAR ASSY		299	2C	*	K25-1532-03	KNOB (1-6)	
238	3C	*	D16-0617-05	BELT		300	1C	*	K29-7031-03	KNOB ASSY (VOL)	
239	3C	*	D23-0958-04	RETAINER		302	1C		N99-1723-05	SCREW SET	KM1

E : Europe K : North America
M : Other Areas W : Without EuropeK : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

KDC-9023R/PSW9524/X969

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
303	1C	*	N99-1734-05	SCREW SET	M1E1
A	3D		N09-4448-05	MACHINE SCREW	
B	3C	*	N09-6073-05	STEPPED SCREW	
C	3D	*	N09-6087-05	MACHINE SCREW	
D	3C	*	N09-6088-05	STEPPED SCREW	
E	3D	*	N09-6089-05	MACHINE SCREW	
F	2C	*	N09-6093-05	TAPTITE SCREW	
G	2C	*	N09-6094-05	MACHINE SCREW	
H	2C	*	N09-6095-05	MACHINE SCREW	
J	2C	*	N09-6096-05	MACHINE SCREW	
K	3C	*	N09-6097-05	MACHINE SCREW	
M	2C	*	N09-6105-05	STEPPED SCREW	
N	2C	*	N19-2175-04	FLAT WASHER	
P	3D	*	N19-2176-04	FLAT WASHER	
Q	2C		N24-3015-60	E TYPE RETAINING RING	
R	3C		N38-2025-46	PAN HEAD MACHIN SCREW	
S	3D	*	N38-2650-45	PAN HEAD MACHIN SCREW	
T	2D		N67-3005-46	PAN HEAD SEMS SCREW	
U	2D		N83-3005-46	PAN HEAD TAPTITE SCREW	
V	2D		N83-3008-46	PAN HEAD TAPTITE SCREW	
W	3C		N86-2004-45	BINDING HEAD TAPTITE SCREW	
RLED			RK73GB2A102J	CHIP R 1.0K J 1/10W	
RPH			RK73GB2A104J	CHIP R 100K J 1/10W	
SW1			S68-0871-05	PUSH SWITCH (PANEL MECHA)	
SW2-3			S68-0863-05	PUSH SWITCH (PANEL MECHA)	
SW4			S68-0864-05	PUSH SWITCH (PANEL MECHA)	
306	1C		T90-0552-05	ANTENNA ADAPTOR	
PH			T95-0212-05	OPTO ISOLATOR (PANEL MECHA)	
PM1	3D	*	T42-1076-14	MOTOR ASSY	
PM2	3D	*	T42-1077-04	MOTOR ASSY	
DME1	2D	*	X92-4710-01	CD MECHANISM ASSY	
SUB-CIRCUIT UNIT (X16-2080-10)					
J1			E59-0833-15	RECTANGULAR PLUG	
CP1			R90-1019-05	MULTI-COMP 100 X2	
IC1		*	BR24C01AFV-W	MEMORY IC	
SUB-CIRCUIT UNIT (X16-2100-10)					
D7			B30-1564-05	LED (1608,BLUE)	
C1-3			CK73GB1C104K	CHIP C 0.10UF K	
C1-3			CK73GB1H104K	CHIP C 0.10UF K	
C4			CK73FB1A225K	CHIP C 2.2UF K	
C5			C93-1217-05	CHIP C 0.047UF K	
C6			CK73GB1C104K	CHIP C 0.10UF K	
C6			CK73GB1H104K	CHIP C 0.10UF K	
C7			CK73FB1A225K	CHIP C 2.2UF K	
C8			CK73EB0J106K	CHIP C 10UF K	
C9			CK73FB1A225K	CHIP C 2.2UF K	
C10			CC73GCH1H101J	CHIP C 100PF J	
C11			CK73GB1H103K	CHIP C 0.010UF K	
C20,21			CK73EB1A475K	CHIP C 4.7UF K	
C30,31			CK73GB1C104K	CHIP C 0.10UF K	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C30,31			CK73GB1H104K	CHIP C 0.10UF K	
C32,33			CK73GB1H103K	CHIP C 0.010UF K	
C34,35			CK73GB1C104K	CHIP C 0.10UF K	
C34,35			CK73GB1H104K	CHIP C 0.10UF K	
C36			CK73GB0J105K	CHIP C 1.0UF K	
C37			CK73GB1C104K	CHIP C 0.10UF K	
C37			CK73GB1H104K	CHIP C 0.10UF K	
C38			CK73GB1H103K	CHIP C 0.010UF K	
C39-47			CK73GB1C104K	CHIP C 0.10UF K	
C39-47			CK73GB1H104K	CHIP C 0.10UF K	
C50-52			C92-0628-05	CHIP-TAN 10UF 10WV	
C57			CK73GB1C104K	CHIP C 0.10UF K	
C57			CK73GB1H104K	CHIP C 0.10UF K	
CN1			E40-9364-05	FLAT CABLE CONNECTOR	
CN2			E41-0166-05	FLAT CABLE CONNECTOR	
-		*	H30-0573-04	ADHESIVE DOUBLE-COATED TAPE	
L1			L92-0332-05	CHIP FERRITE	
L2,3			L40-1005-34	SMALL FIXED INDUCTOR	
L2,3			L40-1005-68	SMALL FIXED INDUCTOR	
L10			L92-0315-05	CHIP FERRITE	
L11-13			L92-0332-05	CHIP FERRITE	
X1			L78-0868-05	RESONATOR (5.00MHZ)	
CP1			R90-1502-05	MULTI-COMP 470 X4	
CP2			R90-1022-05	MULTI-COMP 470 X2	
CP3			R90-0726-05	MULTI-COMP 10K X2	
CP4			R90-1524-05	MULTI-COMP 220 X4	
CP5			R90-0726-05	MULTI-COMP 10K X2	
CP6			R90-1022-05	MULTI-COMP 470 X2	
CP7,8			R90-1094-05	MULTI-COMP 1K X4	
CP9,10			R90-1021-05	MULTI-COMP 3.3K X2	
CP11			R90-1094-05	MULTI-COMP 1K X4	
CP12			R90-1085-05	MULTI-COMP 22K X4	
CP13			R90-1019-05	MULTI-COMP 100 X2	
CP14-17			R90-1524-05	MULTI-COMP 220 X4	
CP18-21			R90-1502-05	MULTI-COMP 470 X4	
CP22			R90-1022-05	MULTI-COMP 470 X2	
CP23			R90-1502-05	MULTI-COMP 470 X4	
CP24-31			R90-1085-05	MULTI-COMP 22K X4	
CP32			R90-1020-05	MULTI-COMP 22K X2	
CP33			R90-1085-05	MULTI-COMP 22K X4	
CP34			R90-1502-05	MULTI-COMP 470 X4	
CP35			R90-1085-05	MULTI-COMP 22K X4	
CP37			R90-1085-05	MULTI-COMP 22K X4	
CP38			R90-1503-05	MULTI-COMP 47K X4	
CP39			R90-0723-05	MULTI-COMP 47K X2	
CP40,41			R90-1022-05	MULTI-COMP 470 X2	
R1			RK73GB2A471J	CHIP R 470 J 1/10W	
R2			RK73GB2A473J	CHIP R 47K J 1/10W	
R3			RK73GB2A104J	CHIP R 100K J 1/10W	
R4,5			RK73GB2A473J	CHIP R 47K J 1/10W	
R6			RK73GB2A104J	CHIP R 100K J 1/10W	
R7			RK73GB2A103J	CHIP R 10K J 1/10W	

E : Europe K : North America
M : Other Areas W : Without EuropeK : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

SUB-CIRCUIT UNIT (X16-2100-10)

Ref. No.	Added	New	Parts No.	Description	Destination
R8			RK73GB2A182J	CHIP R 1.8K J 1/10W	
R9			RK73GB2A220J	CHIP R 22 J 1/10W	
R10-12			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R13			RK73GB2A101J	CHIP R 100 J 1/10W	
R14			RK73GB2A104J	CHIP R 100K J 1/10W	
R15			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R16,17			RK73GB2A153J	CHIP R 15K J 1/10W	
R18,19			RK73GB2A274J	CHIP R 270K J 1/10W	
R20			RK73GB2A223J	CHIP R 22K J 1/10W	
R21			RK73GB2A333J	CHIP R 33K J 1/10W	
R22,23			RK73GB2A104J	CHIP R 100K J 1/10W	
R29			RK73GB2A104J	CHIP R 100K J 1/10W	
R30			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R31			RK73GB2A471J	CHIP R 470 J 1/10W	
R32			RK73GB2A223J	CHIP R 22K J 1/10W	
R33-35			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R36,37			RK73GB2A471J	CHIP R 470 J 1/10W	
R38			RK73GB2A101J	CHIP R 100 J 1/10W	
R39			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R68			RK73GB2A100J	CHIP R 10 J 1/10W	
R69-72			RK73GB2A103J	CHIP R 10K J 1/10W	
R80			RK73GB2A101J	CHIP R 100 J 1/10W	
R81			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R82			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R83			RK73GB2A104J	CHIP R 100K J 1/10W	
D1-6			DA204U	DIODE	
D8-12			DA204U	DIODE	
D13			FTZ6.8E	ZENER DIODE	
D14			MA3062WA	ZENER DIODE	
ED1		*	CN2068M	FLUORESCENT INDICATOR TUBE	
IC2		*	MX23L3213T112	MEMORY IC	
IC3		*	61LV641615TI	SRAM IC	
IC4			M25P20	ROM IC	
IC5			TC7SH08F	MOS-IC	
IC6			S-816A34AMC-T2	ANALOGUE IC	
IC7			TC74HC4050AFT	MOS-IC	
IC8			TC7WT126FU	MOS-IC	
IC9			RS-171	ANALOGUE IC	
IC10			BA3830F	ANALOGUE IC	
IC11		*	703107AGJ152	MI-COM IC	
Q1			2SB1188(Q,R)	TRANSISTOR	
Q2			2SA1163	TRANSISTOR	
Q3			2SC2713	TRANSISTOR	
Q4			DTA114EUA	DIGITAL TRANSISTOR	
Q4			UN5111	DIGITAL TRANSISTOR	
Q5			2SB1295	TRANSISTOR	
Q6			2SA1576A	TRANSISTOR	
Q7,8			2SC4081	TRANSISTOR	
Q10			DTC114EUA	DIGITAL TRANSISTOR	
Q10			UN5211	DIGITAL TRANSISTOR	
SWITCH UNIT (X16-2170-10)					
D1-11			B30-1605-05	LED (2COLOR PG/RED)	
D12			B30-1564-05	LED (1608, BLUE)	
D13			B30-1605-05	LED (2COLOR PG/RED)	
D14			B30-1564-05	LED (1608, BLUE)	

Ref. No.	Added	New	Parts No.	Description	Destination
D15			B30-1605-05	LED (2COLOR PG/RED)	
D16			B30-1564-05	LED (1608, BLUE)	
D17			B30-1605-05	LED (2COLOR PG/RED)	
D18,19			B30-1564-05	LED (1608, BLUE)	
D21			B30-1566-05	LED (1608, RED)	
C1-5			CK73GB1H103K	CHIP C 0.010UF K	
CN1		*	E41-0419-05	FLAT CABLE CONNECTOR	
R1			RK73FB2B241J	CHIP R 240 J 1/8W	
R3-5			RK73FB2B241J	CHIP R 240 J 1/8W	
R6,7			RK73FB2B301J	CHIP R 300 J 1/8W	
R8			RK73FB2B241J	CHIP R 240 J 1/8W	
R9			RK73FB2B301J	CHIP R 300 J 1/8W	
R10			RK73FB2B470J	CHIP R 47 J 1/8W	
R15			RK73GB2A241J	CHIP R 240 J 1/10W	
R16			RK73GB2A471J	CHIP R 470 J 1/10W	
R17			RK73GB2A103J	CHIP R 10K J 1/10W	
R18			RK73GB2A471J	CHIP R 470 J 1/10W	
R19			RK73GB2A103J	CHIP R 10K J 1/10W	
S1		*	S70-0901-05	TACT SWITCH	
S2,3			S70-0864-05	TACT SWITCH	
S4			S70-0856-05	TACT SWITCH	
S5-8			S70-0864-05	TACT SWITCH	
S9			S70-0856-05	TACT SWITCH	
S10-13			S70-0864-05	TACT SWITCH	
S14			S70-0856-05	TACT SWITCH	
S15-18			S70-0864-05	TACT SWITCH	
S19			S70-0856-05	TACT SWITCH	
S20			S70-0864-05	TACT SWITCH	
S21		*	T99-0445-05	ROTARY ENCODER	
D20			DAP202U	DIODE	
D20			MA142WA	DIODE	
D22			MA8068-M	ZENER DIODE	
Q1			DTA114YUA	DIGITAL TRANSISTOR	
Q2,3			2SC4081	TRANSISTOR	
SUB-CIRCUIT UNIT (X16-2210-10)					
315	2C	*	E58-0968-05	RECTANGULAR RECEPTACLE	
FPC3	2C	*	J84-0154-05	FLEXIBLE PRINTED WIRING BOARD	
ELECTRIC UNIT (X25-964x-xx)					
C2			CK73GB1H103K	CHIP C 0.010UF K	
C3			C90-2866-05	ELECTRO 220UF 16WV	
C4			CK73GB1H103K	CHIP C 0.010UF K	
C5			CE04NW1C100M	ELECTRO 10UF 16WV	
C6			CE04NW0J101M	ELECTRO 100UF 6.3WV	
C7			CK73FB1C105K	CHIP C 1.0UF K	
C8			CE04CW1A221M	ELECTRO 220UF 10WV	
C9			CE04CW1A101M	ELECTRO 100UF 10WV	
C10		*	CE32AZ1E221M	CHIP EL 220UF 25WV	
C11			CK73GB1H332K	CHIP C 3300PF K	
C12		*	CE32AZ1C221M	CHIP EL 220UF 16WV	
C13			CK73GB0J105K	CHIP C 1.0UF K	
C14			CK73EB1C225K	CHIP C 2.2UF K	

E : Europe K : North America
M : Other Areas W : Without EuropeK : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-964x-xx)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C15			CK73GB1H103K	CHIP C 0.010UF K	
C16		*	CE32AZ1C101M	CHIP EL 100UF 16WV	
C17			CK73GB1H103K	CHIP C 0.010UF K	
C18		*	CE32AZ1C101M	CHIP EL 100UF 16WV	
C21			CK73FB1A225K	CHIP C 2.2UF K	
C22			C93-1218-05	CHIP C 0.010UF K	
C23			C90-5375-05	ELECTRO 33UF 63WV.	
C30			CE04NW1E4R7M	ELECTRO 4.7UF 25WV	
C31			C90-2962-05	ELECTRO 100UF 16WV	
C32-35			CK73EB1C225K	CHIP C 2.2UF K	
C36			CE04NW1C220M	ELECTRO 22UF 16WV	
C37			CK73GB1E223K	CHIP C 0.022UF K	
C37			CK73GB1H223K	CHIP C 0.022UF K	
C38			CK73GB1H103K	CHIP C 0.010UF K	
C39,40			CK73EB1C225K	CHIP C 2.2UF K	
C41			CK73GB1H103K	CHIP C 0.010UF K	M1E1
C42			CK73GB1E223K	CHIP C 0.022UF K	
C42			CK73GB1H223K	CHIP C 0.022UF K	
C43			CK73FB1C105K	CHIP C 1.0UF K	
C44,45			CK73GB1H103K	CHIP C 0.010UF K	
C46			CK73GB1H102K	CHIP C 1000PF K	
C48			CK73GB1H103K	CHIP C 0.010UF K	
C100			C90-2822-05	ELECTRO 3900UF 16WV	M1
C100			C90-5484-05	ELECTRO 3900UF 16WV	KE1
C101			CE04NW0J470M	ELECTRO 47UF 6.3WV	
C102			CC73GCH1H220J	CHIP C 22PF J	
C103			CC73GCH1H270J	CHIP C 27PF J	
C104			CK73GB0J105K	CHIP C 1.0UF K	
C106			CK73GB0J105K	CHIP C 1.0UF K	
C107			CK73GB1H103K	CHIP C 0.010UF K	
C109			CK73GB1H102K	CHIP C 1000PF K	
C110,111			CK73GB1H103K	CHIP C 0.010UF K	
C199			CK73GB1C104K	CHIP C 0.10UF K	
C199			CK73GB1H104K	CHIP C 0.10UF K	
C201,202			CE04NW1HR47M	ELECTRO 0.47UF 50WV	
C203,204			CK73FB1C474K	CHIP C 0.47UF K	KM1
C205,206			CE04NW0J470M	ELECTRO 47UF 6.3WV	KM1
C206			CE04NW0J470M	ELECTRO 47UF 6.3WV	E1
C207,208			CK73FB1C474K	CHIP C 0.47UF K	
C209			CK73GB1E223K	CHIP C 0.022UF K	
C209			CK73GB1H223K	CHIP C 0.022UF K	
C210			CK73GB1H103K	CHIP C 0.010UF K	
C211			CK73GB1A474K	CHIP C 0.47UF K	
C212			CC73GCH1H151J	CHIP C 150PF J	
C213			CK73GB1C104K	CHIP C 0.10UF K	
C213			CK73GB1H104K	CHIP C 0.10UF K	
C214			CK73GB1H103K	CHIP C 0.010UF K	
C215			CE04NW1C470M	ELECTRO 47UF 16WV	
C216-223			CK73FB1C105K	CHIP C 1.0UF K	
C224			CK73GB1C104K	CHIP C 0.10UF K	
C224			CK73GB1H104K	CHIP C 0.10UF K	
C225			CK73GB1H103K	CHIP C 0.010UF K	
C226-231			CK73GB1E473K	CHIP C 0.047UF K	
C226-231			CK73GB1H473K	CHIP C 0.047UF K	
C232			CK73FB1C105K	CHIP C 1.0UF K	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C233			C92-0667-05	ELECTRO 10UF 10WV	
C234			CK73GB1E333K	CHIP C 0.033UF K	
C234			CK73GB1H333K	CHIP C 0.033UF K	
C235			CK73GB1H103K	CHIP C 0.010UF K	
C236			CK73GB1A334K	CHIP C 0.33UF K	
C237			CK73GB1A474K	CHIP C 0.47UF K	
C238			CC73GCH1H221J	CHIP C 220PF J	
C239			CK73GB1H103K	CHIP C 0.010UF K	
C240,241			C92-0667-05	ELECTRO 10UF 10WV	
C250		*	CE32AT1H2R2M	CHIP EL 2.2UF 50WV	KE1
C250			C92-0687-05	ELECTRO 2.2UF 50WV	M1
C251			CK73FB1C334K	CHIP C 0.33UF K	
C252			CK73GB1A334K	CHIP C 0.33UF K	
C253			CK73FB1C334K	CHIP C 0.33UF K	
C254			CK73GB1A334K	CHIP C 0.33UF K	
C255			CK73FB1C334K	CHIP C 0.33UF K	
C256			CK73GB1A334K	CHIP C 0.33UF K	
C257			CK73FB1C334K	CHIP C 0.33UF K	
C258			CK73GB1A334K	CHIP C 0.33UF K	
C259		*	CE32AT1H010M	CHIP EL 1.0UF 50WV	KE1
C259			C92-0686-05	ELECTRO 1UF 50WV	M1
C260-263			CK73GB1C104K	CHIP C 0.10UF K	
C260-263			CK73GB1H104K	CHIP C 0.10UF K	
C264,265			CE04NW1C220M	ELECTRO 22UF 16WV	
C266,267			CE04NW1C100M	ELECTRO 10UF 16WV	
C268,269			CE04NW1C220M	ELECTRO 22UF 16WV	
C270,271			CE04NW1C100M	ELECTRO 10UF 16WV	
C272-275			C90-5296-05	NP-ELECT 0.22UF 50WV	
C276			CK73FB1C105K	CHIP C 1.0UF K	
C277			CE04NW1C330M	ELECTRO 33UF 16WV	
C278			C90-2935-05	ELECTRO 1.0UF 50WV	
C279			CE04NW1H010M	ELECTRO 1.0UF 50WV	
C280-285			CK73GB1H222K	CHIP C 2200PF K	
C286			CK73GB1H103K	CHIP C 0.010UF K	KM1
C287-289			CK73FB1H104K	CHIP C 0.10UF K	
C290,291			CK73GB1H103K	CHIP C 0.010UF K	
C292-296			CK73EB1A475K	CHIP C 4.7UF K	
C297,298			C92-0672-05	ELECTRO 22UF 16WV	
C299,300			CE04NW1C100M	ELECTRO 10UF 16WV	
C303-305			CK73GB1H103K	CHIP C 0.010UF K	
C307			CK73GB1H103K	CHIP C 0.010UF K	
C309,310			CC73GCH1H100D	CHIP C 10PF D	
C311			CC73GCH1H331J	CHIP C 330PF J	
C312			CK73FB1A225K	CHIP C 2.2UF K	
C313			CK73GB1H103K	CHIP C 0.010UF K	
C314			CE04NW1C100M	ELECTRO 10UF 16WV	
C316-319			CK73GB1A224K	CHIP C 0.22UF K	
C501			CK73FB1C105K	CHIP C 1.0UF K	M1E1
C502-504			CK73GB1H103K	CHIP C 0.010UF K	
C601,602			CK73GB1C104K	CHIP C 0.10UF K	
C601,602			CK73GB1H104K	CHIP C 0.10UF K	
C603			CK73GB1H103K	CHIP C 0.010UF K	
C701			CK73GB1A474K	CHIP C 0.47UF K	
CN1			E41-0224-05	PIN ASSY	

E : Europe K : North America
M : Other Areas W : Without Europe

K : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-964x-xx)

Ref. No.	Added	New	Parts No.	Description	Destination	Ref. No.	Added	New	Parts No.	Description	Destination
CN2			E40-3237-05	PIN ASSY		R28			RK73FB2B472J	CHIP R 4.7K J 1/8W	
CN3		*	E41-0384-05	PIN ASSY		R29			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	K
CN4			E40-9527-05	FLAT CABLE CONNECTOR		R30			RK73GB2A223J	CHIP R 22K J 1/10W	K
CN4			E41-0213-05	FLAT CABLE CONNECTOR		R31			RK73FB2B472J	CHIP R 4.7K J 1/8W	
CN5			E40-9368-05	FLAT CABLE CONNECTOR		R32			RK73FB2B561J	CHIP R 560 J 1/8W	
CN6		*	E41-0399-05	FLAT CABLE CONNECTOR		R33			RK73GB2A473J	CHIP R 47K J 1/10W	M1E1
CN7			E41-0009-05	PIN ASSY		R34			RK73GB2A223J	CHIP R 22K J 1/10W	M1E1
△ J1			E58-0863-15	RECTANGULAR RECEPTACLE		R34,35			RK73GB2A104J	CHIP R 100K J 1/10W	K
W2		*	E30-6218-05	CORD WITH PLUG		R35			RK73GB2A104J	CHIP R 100K J 1/10W	M1E1
						R36			RK73FB2B103J	CHIP R 10K J 1/8W	
L1			L33-1170-05	CHOKE COIL ASSY		R37			RK73GB2A103J	CHIP R 10K J 1/10W	
L2			L33-1126-05	CHOKE COIL		R38			RK73GB2A822J	CHIP R 8.2K J 1/10W	
L3			L33-1029-05	SMALL FIXED INDUCTOR		R41			RK73GB2A223J	CHIP R 22K J 1/10W	
L4			L40-2205-34	SMALL FIXED INDUCTOR (22UH)		R42			RD14DB2H332J	SMALL-RD 3.3K J 1/2W	
L7			L33-1039-05	LINE FILTER COIL		R43			RK73EB2E473J	CHIP R 47K J 1/4W	
L101			L40-4795-34	SMALL FIXED INDUCTOR		R44			RK73GB2A183J	CHIP R 18K J 1/10W	
L101			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)		R45			RK73GB2A104J	CHIP R 100K J 1/10W	
L102			L92-0075-05	CHIP FERRITE		R46			RK73EB2E103J	CHIP R 10K J 1/4W	K
L201			L40-4795-34	SMALL FIXED INDUCTOR		R46,47			RK73EB2E103J	CHIP R 10K J 1/4W	M1E1
L201			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)		R48			RK73EB2E102J	CHIP R 1.0K J 1/4W	
L303-307			L40-4795-34	SMALL FIXED INDUCTOR		R49			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	K
L303-307			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)		R101			RK73GB2A103J	CHIP R 10K J 1/10W	
X1			L78-0821-05	RESONATOR		R102			RK73GB2A153J	CHIP R 15K J 1/10W	
X2			L77-2738-05	CRYSTAL RESONATOR		R103			RK73GB2A104J	CHIP R 100K J 1/10W	
X3			L77-2002-05	CRYSTAL RESONATOR		R106			RK73GB2A103J	CHIP R 10K J 1/10W	M1
U	2D		N83-3005-46	PAN HEAD TAPTITE SCREW		R108,109			RK73GB2A103J	CHIP R 10K J 1/10W	KE1
X	2D		N80-3008-46	PAN HEAD TAPTITE SCREW		R109			RK73GB2A103J	CHIP R 10K J 1/10W	M1
Y	2D		N83-3010-46	PAN HEAD TAPTITE SCREW		R110			RK73GB2A104J	CHIP R 100K J 1/10W	
Z	2D		N84-2004-46	PAN HEAD TAPTITE SCREW		R111,112			RK73GB2A103J	CHIP R 10K J 1/10W	
						R115,116			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R1			RK73FB2B223J	CHIP R 22K J 1/8W		R117			RK73GB2A103J	CHIP R 10K J 1/10W	
R2			RK73GB2A101J	CHIP R 100 J 1/10W		R118-120			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R3			RK73GB2A223J	CHIP R 22K J 1/10W		R121			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R4			RK73GB2A222J	CHIP R 2.2K J 1/10W		R122-126			RK73GB2A101J	CHIP R 100 J 1/10W	E1
R5			RK73FB2B221J	CHIP R 220 J 1/8W		R122,123			RK73GB2A101J	CHIP R 100 J 1/10W	KM1
R6			RK73GB2A153J	CHIP R 15K J 1/10W		R127			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R7			R92-3032-05	CHIP R 4.3K D 1/10W		R128			RK73GB2A104J	CHIP R 100K J 1/10W	
R8			R92-3047-05	CHIP R 24K D 1/10W		R129			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R9			RK73FB2B152J	CHIP R 1.5K J 1/8W		R130			RK73GB2A104J	CHIP R 100K J 1/10W	
R10			R92-3022-05	METAL R 750 D 1/10W		R131			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R11			R92-3028-05	CHIP R 2.2K D 1/10W		R132			RK73GB2A104J	CHIP R 100K J 1/10W	
R12			RK73GB2A103J	CHIP R 10K J 1/10W		R133-136			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R13			R92-2104-05	CHIP R 2.2 J 1W		R137			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R14			RK73FB2B751J	CHIP R 750 J 1/8W		R138-140			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R15			RK73GB2A473J	CHIP R 47K J 1/10W		R141			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R16			RK73FB2B103J	CHIP R 10K J 1/8W		R142,143			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R17			RK73GB2A102J	CHIP R 1.0K J 1/10W		R144			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R18			RK73GB2A750J	CHIP R 75 J 1/10W		R145,146			RK73GB2A473J	CHIP R 47K J 1/10W	
R19			RK73GB2A272J	CHIP R 2.7K J 1/10W		R150,151			RK73GB2A104J	CHIP R 100K J 1/10W	
R20			RK73GB2A470J	CHIP R 47 J 1/10W		R152,153			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R21			RK73GB2A752J	CHIP R 7.5K J 1/10W		R156			RK73GB2A104J	CHIP R 100K J 1/10W	
R22			RK73GB2A274J	CHIP R 270K J 1/10W		R158			RK73GB2A104J	CHIP R 100K J 1/10W	
R23			RK73GB2A563J	CHIP R 56K J 1/10W		R159,160			RK73GB2A471J	CHIP R 470 J 1/10W	
R24			RK73GB2A470J	CHIP R 47 J 1/10W		R161			RK73GB2A104J	CHIP R 100K J 1/10W	
R25			RK73GB2A103J	CHIP R 10K J 1/10W		R162			RK73GB2A103J	CHIP R 10K J 1/10W	
R26,27			RK73GB2A913J	CHIP R 91K J 1/10W							

E : Europe K : North America
M : Other Areas W : Without EuropeK : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-964x-xx)

Ref. No.	A d	N e w	Parts No.	Description	Desti- nation
R163,164 R165,166 R167 R169 R170			RK73GB2A471J RK73GB2A472J RK73GB2A102J RK73GB2A102J RK73GB2A222J	CHIP R 470 J 1/10W CHIP R 4.7K J 1/10W CHIP R 1.0K J 1/10W CHIP R 1.0K J 1/10W CHIP R 2.2K J 1/10W	
R171,172 R173,174 R175 R176 R177			RK73GB2A471J RK73GB2A472J RK73GB2A333J RK73GB2A473J RK73GB2A222J	CHIP R 470 J 1/10W CHIP R 4.7K J 1/10W CHIP R 33K J 1/10W CHIP R 47K J 1/10W CHIP R 2.2K J 1/10W	
R178,179 R180 R181 R182 R183,184			RK73GB2A103J RK73GB2A222J RK73GB2A473J RK73GB2A104J RK73GB2A222J	CHIP R 10K J 1/10W CHIP R 2.2K J 1/10W CHIP R 47K J 1/10W CHIP R 100K J 1/10W CHIP R 2.2K J 1/10W	
R185 R186 R201 R202-204 R205			RK73GB2A103J RK73GB2A102J RK73GB2A103J RK73GB2A472J RK73GB2A134J	CHIP R 10K J 1/10W CHIP R 1.0K J 1/10W CHIP R 10K J 1/10W CHIP R 4.7K J 1/10W CHIP R 130K J 1/10W	M1E1
R206 R207 R208 R209 R210			RK73GB2A823J RK73GB2A473J RK73GB2A912J RK73GB2A363J RK73GB2A622J	CHIP R 82K J 1/10W CHIP R 47K J 1/10W CHIP R 9.1K J 1/10W CHIP R 36K J 1/10W CHIP R 6.2K J 1/10W	
R217 R218 R219 R220,221 R222,223			RK73GB2A682J RK73GB2A332J RK73GB2A392J RK73FB2B361J RK73FB2B222J	CHIP R 6.8K J 1/10W CHIP R 3.3K J 1/10W CHIP R 3.9K J 1/10W CHIP R 360 J 1/8W CHIP R 2.2K J 1/8W	
R224,225 R226,227 R228,229 R232,233 R234,235			RK73FB2B103J RK73FB2B223J RK73FB2B820J RK73FB2B361J RK73FB2B222J	CHIP R 10K J 1/8W CHIP R 22K J 1/8W CHIP R 82 J 1/8W CHIP R 360 J 1/8W CHIP R 2.2K J 1/8W	
R236,237 R238,239 R240,241 R244,245 R246,247			RK73FB2B103J RK73FB2B223J RK73FB2B820J RK73FB2B361J RK73FB2B222J	CHIP R 10K J 1/8W CHIP R 22K J 1/8W CHIP R 82 J 1/8W CHIP R 360 J 1/8W CHIP R 2.2K J 1/8W	
R248,249 R250,251 R252,253 R256 R257			RK73FB2B103J RK73FB2B223J RK73FB2B820J RK73GB2A221J RK73GB2A223J	CHIP R 10K J 1/8W CHIP R 22K J 1/8W CHIP R 82 J 1/8W CHIP R 220 J 1/10W CHIP R 22K J 1/10W	
R259 R260 R261 R262 R263,264			RK73GB2A432J RK73GB2A100J RK73GB2A752J RK73EB2E4R7J RK73EB2E100J	CHIP R 4.3K J 1/10W CHIP R 10 J 1/10W CHIP R 7.5K J 1/10W CHIP R 4.7 J 1/4W CHIP R 10 J 1/4W	KM1 KM1
R265,266 R266 R267 R268 R269			RK73GB2A102J RK73GB2A102J RK73EB2E100J RK73EB2E4R7J RK73EB2E100J	CHIP R 1.0K J 1/10W CHIP R 1.0K J 1/10W CHIP R 10 J 1/4W CHIP R 4.7 J 1/4W CHIP R 10 J 1/4W	KM1 E1

Ref. No.	A d	N e w	Parts No.	Description	Desti- nation
R270 R271 R272,273 R274 R275			RK73GB2A473J RK73GB2A821J RK73GB2A103J RK73GB2A153J RK73GB2A473J	CHIP R 47K J 1/10W CHIP R 820 J 1/10W CHIP R 10K J 1/10W CHIP R 15K J 1/10W CHIP R 47K J 1/10W	
R276 R277 R278 R279,280 R303			RK73GB2A102J RK73GB2A473J RK73GB2A333J RK73GB2A334J RK73FB2B102J	CHIP R 1.0K J 1/10W CHIP R 47K J 1/10W CHIP R 33K J 1/10W CHIP R 330K J 1/10W CHIP R 1.0K J 1/8W	
R304 R305 R306-308 R501,502 R503-507			RK73GB2A223J RK73GB2A472J RK73GB2A222J RK73EB2E101J RK73EB2E472J	CHIP R 22K J 1/10W CHIP R 4.7K J 1/10W CHIP R 2.2K J 1/10W CHIP R 100 J 1/4W CHIP R 4.7K J 1/4W	
R508 R509-511 R512 R513 R514-516			RK73EB2E101J RK73EB2E471J RK73EB2E102J RK73GB2A223J RK73GB2A472J	CHIP R 100 J 1/4W CHIP R 470 J 1/4W CHIP R 1.0K J 1/4W CHIP R 22K J 1/10W CHIP R 4.7K J 1/10W	E1 E1
R517,518 R519 R520 R522-524 R525			RK73EB2E101J RK73EB2E471J RK73EB2E472J RK73GB2A222J RK73GB2A102J	CHIP R 100 J 1/4W CHIP R 470 J 1/4W CHIP R 4.7K J 1/4W CHIP R 2.2K J 1/10W CHIP R 1.0K J 1/10W	
R526,527 R601,602 R603 R604,605 R606			RK73GB2A473J RK73GB2A104J RK73GB2A222J RK73GB2A103J RK73GB2A222J	CHIP R 47K J 1/10W CHIP R 100K J 1/10W CHIP R 2.2K J 1/10W CHIP R 10K J 1/10W CHIP R 2.2K J 1/10W	
R607 R608,609 R610 R611,612 R613			RK73GB2A911J RK73GB2A104J RK73GB2A222J RK73GB2A103J RK73GB2A222J	CHIP R 910 J 1/10W CHIP R 100K J 1/10W CHIP R 2.2K J 1/10W CHIP R 10K J 1/10W CHIP R 2.2K J 1/10W	
R614 R615-618 R620 R621 R623,624			RK73GB2A911J RK73GB2A102J RK73EB2E102J RK73GB2A472J RK73GB2A332J	CHIP R 910 J 1/10W CHIP R 1.0K J 1/10W CHIP R 1.0K J 1/4W CHIP R 4.7K J 1/10W CHIP R 3.3K J 1/10W	
R625,626 R701 W3			RK73GB2A102J RK73GB2A104J R92-1252-05	CHIP R 1.0K J 1/10W CHIP R 100K J 1/10W CHIP R 0 OHM J 1/16W	M1E1
D1 D2 D3 D4 D5			1N5393G-M5 RB160L-40 MA8056-M MA8082-L SFPB-54V	DIODE DIODE ZENER DIODE ZENER DIODE DIODE	
D6 D7 D8 D9 D16			MA8100-L MA4062(N)-L MA8110-M MA8056-M MA3056-M	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	
D17			MA3047-M	ZENER DIODE	M1E1

E : Europe **K** : North America
M : Other Areas **W** : Without Europe

K : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-964x-xx)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
D18			MA8068-M	ZENER DIODE		Q15			2SB1443	TRANSISTOR	
D19			MA8062-M	ZENER DIODE		Q16,17			2SC4081	TRANSISTOR	
D20,21			DAP202U	DIODE		Q18,19			2SA1576A	TRANSISTOR	
D20,21			MA142WA	DIODE		Q20			2SC4081	TRANSISTOR	
D101			DAP202U	DIODE		Q21			2SA1576A	TRANSISTOR	
D101			MA142WA	DIODE		Q22			2SC4081	TRANSISTOR	
D201,202			RD6.8M(B2)	ZENER DIODE		Q23			DTC114YUA	DIGITAL TRANSISTOR	K
D203			RD6.8MW	ZENER DIODE	KM1	Q23			UN5214	DIGITAL TRANSISTOR	K
D204,205			RD6.8M(B2)	ZENER DIODE	KM1	Q24			2SB1240	TRANSISTOR	K
D205			RD6.8M(B2)	ZENER DIODE	E1	Q25			DTA123JK	DIGITAL TRANSISTOR	
D206			RD6.8MW	ZENER DIODE		Q25			KRA105S	DIGITAL TRANSISTOR	
D207,208			DAP202U	DIODE		Q26			DTC144EUA	DIGITAL TRANSISTOR	
D207,208			MA142WA	DIODE		Q26			UN5213	DIGITAL TRANSISTOR	
D209-216			S1J	DIODE		Q27			2SC4081	TRANSISTOR	
D209-216			1SR154-400	DIODE		Q29			2SC4081	TRANSISTOR	
D217			DA204K	DIODE		Q30,31			DTA124EUA	DIGITAL TRANSISTOR	
D301			IMSA-6801	SURGE ABSORBER		Q30,31			UN5112	DIGITAL TRANSISTOR	
D501-505			MA3062WA	ZENER DIODE	E1	Q201			DTC143TUA	DIGITAL TRANSISTOR	
D503-505			MA3062WA	ZENER DIODE	KM1	Q201			UN5216	DIGITAL TRANSISTOR	
D506-509			DA204K	DIODE		Q202			DTC124EUA	DIGITAL TRANSISTOR	
D601			DA204K	DIODE		Q202			UN5212	DIGITAL TRANSISTOR	
IC1		*	703033BGC020	MI-COM IC		Q203-208			DTC143TUA	DIGITAL TRANSISTOR	
IC2			TDA7411	ANALOGUE IC		Q203-208			UN5216	DIGITAL TRANSISTOR	
IC3			M5237ML	ANALOGUE IC		Q210			2SC4081	TRANSISTOR	
IC4			TDA7560	ANALOGUE IC		Q303			DTC124EUA	DIGITAL TRANSISTOR	
IC5			TDA7401	ANALOGUE IC		Q303			UN5212	DIGITAL TRANSISTOR	
IC6		*	NJM2195FJ1	ANALOGUE IC		Q304			2SB1188(Q,R)	TRANSISTOR	
IC7			ICL7660SIBA	ANALOGUE IC		Q305			DTC143TUA	DIGITAL TRANSISTOR	
IC8			S-80837CNNB	MOS-IC		Q305			UN5216	DIGITAL TRANSISTOR	
IC9			TC74HC02AF	MOS-IC		Q501			DTA124EUA	DIGITAL TRANSISTOR	
IC10-13			NJM4565M-TE2	ANALOGUE IC		Q501			UN5112	DIGITAL TRANSISTOR	
IC14			TDA7479D	ANALOGUE IC		Q502			2SB1427	TRANSISTOR	
IC15,16			LB1930M	ANALOGUE IC		Q503			DTC124EUA	DIGITAL TRANSISTOR	
IC17			BR24C01AF-W	ROM IC		Q503			UN5212	DIGITAL TRANSISTOR	
IC18			L9820D013TR	ANALOGUE IC		Q601			DTC124EUA	DIGITAL TRANSISTOR	
IC19			LM2672M-ADJ	ANALOGUE IC		Q601			UN5212	DIGITAL TRANSISTOR	
IC20		*	TC7W66FK	MOS-IC		Q602			2SC4081	TRANSISTOR	
Q1			2SA2057	TRANSISTOR		Q603			DTC124EUA	DIGITAL TRANSISTOR	
Q2			2SC4081	TRANSISTOR		Q603			UN5212	DIGITAL TRANSISTOR	
Q3			2SA1576A	TRANSISTOR		TH1			PTH9C42BD471Q	POSITIVE RESISTOR	
Q4			DTA124EUA	DIGITAL TRANSISTOR		A2		*	W02-3430-05	ELECTRIC CIRCUIT MODULE	
Q4			UN5112	DIGITAL TRANSISTOR		A1		*	X86-3730-11	FRONT-END UNIT	K
Q5			DTC124EUA	DIGITAL TRANSISTOR		A1		*	X86-3732-70	FRONT-END UNIT	M1E1
Q5			UN5212	DIGITAL TRANSISTOR		CD PLAYER UNIT (X32-5440-00)					
Q6			DTC144EUA	DIGITAL TRANSISTOR		C1			C92-0628-05	CHIP-TAN 10UF 10WV	
Q6			UN5213	DIGITAL TRANSISTOR		C2			CK73FB1A105K	CHIP C 1.0UF K	
Q7			DTA124EUA	DIGITAL TRANSISTOR		C3			CK73FB1A225K	CHIP C 2.2UF K	
Q7			UN5112	DIGITAL TRANSISTOR		C4			CK73GB1H103K	CHIP C 0.010UF K	
Q8,9			2SA2057	TRANSISTOR		C5			CC73GCH1H680J	CHIP C 68PF J	
Q11			DTC124EUA	DIGITAL TRANSISTOR		C6			CC73GCH1H681J	CHIP C 680PF J	
Q11			UN5212	DIGITAL TRANSISTOR		C7			CK73GB1H104K	CHIP C 0.10UF K	
Q12			DTA124EUA	DIGITAL TRANSISTOR		C8			CK73GB1H222K	CHIP C 2200PF K	
Q12			UN5112	DIGITAL TRANSISTOR		C9,10			CK73GB1H104K	CHIP C 0.10UF K	
Q13			2SA2057	TRANSISTOR		C11			CC73GCH1H681J	CHIP C 680PF J	
Q14			2SC4081	TRANSISTOR							

E : Europe K : North America
M : Other Areas W : Without EuropeK : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

CD PLAYER UNIT (X32-5440-00)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C12			CK73GB1H222K	CHIP C 2200PF K	
C13			CC73GCH1H680J	CHIP C 68PF J	
C15			CK73EB1A475K	CHIP C 4.7UF K	
C16			CK73GB1H104K	CHIP C 0.10UF K	
C17			CK73GB1H331K	CHIP C 330PF K	
C18			CK73GB1H472K	CHIP C 4700PF K	
C19,20			CK73GB1H104K	CHIP C 0.10UF K	
C21			CK73EB1A475K	CHIP C 4.7UF K	
C22			CK73GB0J105K	CHIP C 1.0UF K	
C23,24			CK73FB1A225K	CHIP C 2.2UF K	
C25			C92-0712-05	CHIP-TAN 22UF 6.3WV	
C26			CK73GB1H104K	CHIP C 0.10UF K	
C27			C92-0712-05	CHIP-TAN 22UF 6.3WV	
C28			CK73GB1H102K	CHIP C 1000PF K	
C29			CK73GB1H331K	CHIP C 330PF K	
C30			CK73GB1H152K	CHIP C 1500PF K	
C31-35			CK73GB1H104K	CHIP C 0.10UF K	
C36			C92-0712-05	CHIP-TAN 22UF 6.3WV	
C37			CK73EB1A475K	CHIP C 4.7UF K	
C38-41			CK73GB1H104K	CHIP C 0.10UF K	
C42,43			CK73EB1A475K	CHIP C 4.7UF K	
C44,45			CK73GB1H102K	CHIP C 1000PF K	
C46			CK73GB1H104K	CHIP C 0.10UF K	
C47			C92-0628-05	CHIP-TAN 10UF 10WV	
C48			CK73GB1H104K	CHIP C 0.10UF K	
C50,51			CK73GB1H104K	CHIP C 0.10UF K	
C52			CK73GB1H152K	CHIP C 1500PF K	
C53,54			CK73GB1H104K	CHIP C 0.10UF K	
C55			CC73GCH1H470J	CHIP C 47PF J	
C56			CC73GCH1H820J	CHIP C 82PF J	
C57-61			CK73GB1H104K	CHIP C 0.10UF K	
C63			CC73GCH1H020C	CHIP C 2.0PF C	
C64-66			CK73GB1H104K	CHIP C 0.10UF K	
C67			CK73GB1H222K	CHIP C 2200PF K	
C68			CC73GCH1H060D	CHIP C 6.0PF D	
C69-73			CK73GB1H104K	CHIP C 0.10UF K	
C74			CK73GB1H682K	CHIP C 6800PF K	
C75			CK73GB1H332K	CHIP C 3300PF K	
C76			CK73GB1H103K	CHIP C 0.010UF K	
C77			CK73GB1H104K	CHIP C 0.10UF K	
C78			CK73EB1A475K	CHIP C 4.7UF K	
C79-82			CK73GB1H152K	CHIP C 1500PF K	
C83			CK73GB1H104K	CHIP C 0.10UF K	
C84			C92-0628-05	CHIP-TAN 10UF 10WV	
C85,86			CK73GB1H104K	CHIP C 0.10UF K	
C87			CK73EB1A475K	CHIP C 4.7UF K	
C88			CK73GB1H104K	CHIP C 0.10UF K	
CN1			E41-0213-05	FLAT CABLE CONNECTOR	
CN2			E40-9536-05	FLAT CABLE CONNECTOR	
L1,2			L92-0329-05	CHIP FERRITE	
L4,5			L92-0329-05	CHIP FERRITE	
X1			L78-0851-05	RESONATOR (16.93MHZ)	
X2			L78-0862-05	RESONATOR (16.00MHZ)	
X3			L78-0861-05	RESONATOR (24.57MHZ)	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
CP1,2			R90-1019-05	MULTI-COMP 100 X2	
CP4			R90-0719-05	MULTI-COMP 4.7K X2	
CP6			R90-1019-05	MULTI-COMP 100 X2	
CP8			R90-0737-05	MULTI-COMP 100K X2	
CP9-13			R90-0720-05	MULTI-COMP 100K X4	
CP14			R90-1019-05	MULTI-COMP 100 X2	
CP15			R90-0718-05	MULTI-COMP 4.7K X4	
CP16-22			R90-1014-05	MULTI-COMP 100 X4	
CP23			R90-0714-05	MULTI-COMP 10K X4	
R1			R92-3044-05	CHIP R 18K D 1/10W	
R2			R92-3041-05	CHIP R 11K D 1/10W	
R3			RK73FB2B303J	CHIP R 30K J 1/8W	
R4			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R5			RK73FB2B272J	CHIP R 2.7K J 1/8W	
R6			RK73FB2B331J	CHIP R 330 J 1/8W	
R7,8			RK73FB2B752J	CHIP R 7.5K J 1/8W	
R9			RK73FB2B272J	CHIP R 2.7K J 1/8W	
R10			RK73FB2B331J	CHIP R 330 J 1/8W	
R11			R92-3041-05	CHIP R 11K D 1/10W	
R12			RK73FB2B303J	CHIP R 30K J 1/8W	
R13			R92-3044-05	CHIP R 18K D 1/10W	
R14			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R16			RK73GB2A123J	CHIP R 12K J 1/10W	
R17			RK73GB2A133J	CHIP R 13K J 1/10W	
R18			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R19,20			RK73GB2A123J	CHIP R 12K J 1/10W	
R21			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R22			RK73GB2A133J	CHIP R 13K J 1/10W	
R23,24			RK73GB2A104J	CHIP R 100K J 1/10W	
R25			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R26			RK73GB2A104J	CHIP R 100K J 1/10W	
R27			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R28			RK73GB2A103J	CHIP R 10K J 1/10W	
R29			RK73GB2A133J	CHIP R 13K J 1/10W	
R30			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R31			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R32			RK73GB2A103J	CHIP R 10K J 1/10W	
R33			RK73GB2A104J	CHIP R 100K J 1/10W	
R34			RK73GB2A183J	CHIP R 18K J 1/10W	
R35			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R36			RK73GB2A163J	CHIP R 16K J 1/10W	
R37			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R39-41			RK73GB2A103J	CHIP R 10K J 1/10W	
R42,43			RK73GB2A104J	CHIP R 100K J 1/10W	
R45			RK73GB2A103J	CHIP R 10K J 1/10W	
R46			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R47			RK73GB2A104J	CHIP R 100K J 1/10W	
R48			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R49			RK73GB2A104J	CHIP R 100K J 1/10W	
R50			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R51			RK73GB2A103J	CHIP R 10K J 1/10W	
R52			RK73GB2A104J	CHIP R 100K J 1/10W	
R53			RK73GB2A473J	CHIP R 47K J 1/10W	
R55			RK73GB2A103J	CHIP R 10K J 1/10W	
R56			RK73GB2A223J	CHIP R 22K J 1/10W	

E : Europe **K** : North America
M : Other Areas **W** : Without Europe

K : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

CD PLAYER UNIT (X32-5440-00)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R57			RK73GB2A472J	CHIP R 4.7K J 1/10W		24	3B		D13-2153-04	GEAR	
R58			RK73GB2A101J	CHIP R 100 J 1/10W		25	3B		D13-2154-04	GEAR	
R59			RK73GB2A164J	CHIP R 160K J 1/10W		26	3B		D13-2155-04	WORM	
R60,61			RK73GB2A101J	CHIP R 100 J 1/10W		27	3B		D13-2156-14	GEAR	
R62,63			RK73GB2A302J	CHIP R 3.0K J 1/10W		28	3B		D13-2157-04	GEAR	
R64-66			RK73GB2A101J	CHIP R 100 J 1/10W		29	3B		D13-2158-04	GEAR	
R67			RK73GB2A682J	CHIP R 6.8K J 1/10W		30	3B		D13-2168-04	GEAR	
R68			RK73GB2A101J	CHIP R 100 J 1/10W		31	3B		D13-2171-04	GEAR	
R69			RK73GB2A333J	CHIP R 33K J 1/10W		32	2B		D13-2172-03	RACK (GEAR)	
R70			RK73GB2A103J	CHIP R 10K J 1/10W		33	2A		D14-0759-04	ROLLER	
R71,72			RK73GB2A101J	CHIP R 100 J 1/10W		35	2B		D21-2382-04	SHAFT	
R73			RK73GB2A241J	CHIP R 240 J 1/10W		36	1A		D23-0954-04	RETAINER	
R74			RK73GB2A104J	CHIP R 100K J 1/10W		37	1B		D39-0246-05	DAMPER	
R76			RK73GB2A101J	CHIP R 100 J 1/10W		38	2B		G01-3072-04	EXTENSION SPRING	
R77			RK73GB2A102J	CHIP R 1.0K J 1/10W		39	2A		G01-3073-04	TORSION COIL SPRING	
R78			RK73GB2A104J	CHIP R 100K J 1/10W		40	2A		G01-3074-04	EXTENSION SPRING	
W1			R92-1252-05	CHIP R 0 OHM J 1/16W		41	1B		G01-3075-04	EXTENSION SPRING	
S1,2			S68-0863-05	PUSH SWITCH		42	2A		G01-3076-04	EXTENSION SPRING	
S3			S68-0862-05	PUSH SWITCH		43	1B		G01-3077-04	EXTENSION SPRING	
D1			DAP202U	DIODE		44	2B		G02-1399-04	FLAT SPRING	
D2			M1F60	DIODE		45	2B		G02-1408-04	FLAT SPRING	
IC1			TAR5S33	ANALOGUE IC		51	1A		J21-9676-22	MOUNTING HARDWARE	
IC2			NJM4580V	ANALOGUE IC		52	3B		J21-9677-02	MOUNTING HARDWARE	
IC4			BA5824FP	ANALOGUE IC		53	1B		J21-9678-03	MOUNTING HARDWARE	
IC5			UPC3025	ANALOGUE IC		55	1A		J90-1001-11	GUIDE	
IC6			L88MS33T	ANALOGUE IC		56	1B		J90-1023-03	GUIDE	
IC7		*	703030BYGC-J02	MI-COM IC		A	2B		N09-4460-05	TAPTITE SCREW (OVAL P TAPTIT)	
IC8			TC74HCT7007AF	MOS-IC		B	1B		N09-4472-05	MACHINE SCREW (M1.7X8.5)	
IC9			UPD61002GC-E01	MOS-IC		C	2B		N09-6004-05	MACHINE SCREW (M1.7X2.5 IB-L)	
IC10			TC7SHU04FU	MOS-IC		E	2B		N09-6007-05	MACHINE SCREW (PAN M2X2)	
IC11			UPD63760GJ	MOS-IC		F	1A		N09-6051-05	TAPTITE SCREW (BIND P 2X5)	
IC12			HD74LV14AT	MOS-IC		G	2A		N19-2163-04	FLAT WASHER	
IC13			IS41LV16257	DRAM IC		H	1B		N39-2020-46	PAN HEAD MACHIN SCREW	
Q1			DTA143XUA	DIGITAL TRANSISTOR		J	1B		N09-6108-05	MACHINE SCREW (M2*3.5TYPE3)	
Q2,3			DTC124EUA	DIGITAL TRANSISTOR		DM1	3B		T42-1066-04	DC MOTOR ASSY (SP)	
Q4			MCH6101	TRANSISTOR		DM2	2B		T42-1067-04	DC MOTOR ASSY (LO)	
Q5			DTA143EUA	DIGITAL TRANSISTOR		DPU1	2D		X93-2010-00	OPTICAL PICKUP ASSY	
CD MECHANISM ASSY (X92-4710-01)											
2	1B		A10-4827-12	CHASSIS							
5	1B		D10-4576-33	ARM ASSY							
8	2A		D10-4579-03	LEVER ASSY							
10	3A		D10-4581-13	ARM							
11	2A		D10-4582-13	ARM							
12	3A		D10-4583-03	ARM							
13	3A		D10-4584-03	ARM							
14	3B		D10-4585-03	ARM							
15	2A		D10-4586-13	SLIDER							
16	3B		D10-4587-22	SLIDER							
17	3B	*	D10-4588-13	SLIDER							
18	3B		D10-4595-04	ARM							
19	3B		D10-4596-14	ARM							
22	2A		D13-2151-04	GEAR							
23	2B		D13-2152-04	GEAR							

E : Europe K : North America
M : Other Areas W : Without EuropeK : KDC-X969
M1 : KDC-9023R
E1 : KDC-PSW9524

△ Indicates safety critical components.