

PARTS LIST

* New Parts. Δ indicates safety critical components.
 Parts without **Parts No.** are not supplied.
 Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
 Teile ohne **Parts No.** werden nicht geliefert.

L: Scandinavia K: USA P: Canada
 Y: PX (Far East, Hawaii) T: England E: Europe
 Y: AAFES (Europe) X: Australia M: Other Areas

TK-3202L (Y50-6180-XX) TX-RX UNIT (X57-6890-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination
TK-3202L					
1	1A	*	A02-3883-23	PLASTIC CABINET	
2	1A	*	A02-3974-03	PLASTIC CABINET ASSY(16CH)	
3	3A		A10-4078-31	CHASSIS	
4	1B		A21-1644-23	DRESSING PANEL(16CH)	
5	2C		B09-0680-03	CAP(SP/MIC) ACCESSORY	
6	2B		B11-1817-04	ILLUMINATION GUIDE	
7	1B		B43-1156-04	BADGE(KENWOOD)	
8	1A	*	B43-1199-04	BADGE(TK-3202L)	
9	1C	*	B62-1971-00	INSTRUCTION MANUAL	
11	1A		D10-0649-03	LEVER	
12	1A		D21-0863-04	SHAFT	
13	1A		D32-0441-03	STOPPER	
14	2A		E04-0465-05	RF COAXIAL RECEPTACLE(SMA)	
15	3B		E23-1253-04	TERMINAL(BATT-)	
16	2B		E37-1175-05	PROCESSED LEAD WIRE(BROWN:SP+)	
17	2B		E37-1176-05	PROCESSED LEAD WIRE(GREEN:SP-)	
18	3A		F20-3353-14	INSULATING SHEET(CHASSIS BATT+)	
19	2A		G01-4542-04	COIL SPRING(LEVER)	
20	1A		G01-4543-04	COIL SPRING(STOPPER)	
21	2B		G10-1330-04	FIBROUS SHEET(IC302:AUDIO IC)	
22	3A		G11-4283-04	RUBBER SHEET(Q103:FINAL FET)	
23	2A		G11-4313-04	SHEET(MIC ELEMENT)	
24	3B		G13-2009-04	CUSHION(CHASSIS)	
29	3B		G13-2033-04	CUSHION(TERMINAL BATT-)	
30	3A		G13-2034-14	CUSHION(TERMINAL BATT-)	
31	3A		G13-2038-24	CUSHION(CHASSIS-CERAMIC FILTER)	
32	2A		G13-2039-14	CUSHION(PCB-CERAMIC FILTER)	
33	2A		G13-2051-04	CUSHION(VCO)	
34	2B		G13-2088-04	CUSHION(CHASSIS VOL/CH)	
35	3A		G53-1604-03	PACKING(CHASSIS)	
36	3A		G53-1605-03	PACKING(TERMINAL BATT+)	
37	2B		G53-1606-13	PACKING(VOL/CH/LED)	
38	1B		G53-1607-03	PACKING(SP/MIC)	
39	2B		G53-1608-03	PACKING(SP)	
40	2A		G53-1609-14	PACKING(MIC ELEMENT)	
41	2B		G53-1610-04	PACKING(SMA)	
43	2D	*	H12-4221-05	PACKING FIXTURE	
45	1C		H25-0085-04	PROTECTION BAG (100/200/0.07)	
46	3D	*	H52-2160-02	ITEM CARTON CASE	
48	2C		J19-5472-03	HOLDER(SP/MIC) ACCESSORY	
49	2A		J19-5473-03	HOLDER ASSY(TERMINAL BATT+)	
50	2B		J21-8478-04	MOUNTING HARDWARE(SP/MIC)	
51	2B		J21-8525-03	MOUNTING HARDWARE(VOL/CH)	
52	2D	*	J29-0734-05	BELT CLIP ACCESSORY	
54	2B		J82-0092-05	FPC	
57	1A		K29-9308-23	BUTTON KNOB(PTT)	
58	1B		K29-9309-03	KNOB(VOL)	
59	1B		K29-9318-03	KNOB(CH)	
60	1A		K29-9364-03	BUTTON KNOB(SIDE1/SIDE2)	
A	2B		N14-0819-04	CIRCULAR NUT(VOL KNOB)	
B	2B		N14-0832-04	CIRCULAR NUT(CH KNOB)	
C	2A,2B		N30-2604-48	PAN HEAD MACHINE SCREW(SMA)	
D	3A		N30-2606-48	PAN HEAD MACHINE SCREW(CHASSIS)	
TX-RX UNIT (X57-6890-XX) -26 :K,M -27 :K2,M2 -28 :K3					
E	2A,2B,3B		N83-2005-48	PAN HEAD TAPTITE SCREW(PCB)	
61	2C		N99-2046-05	SCREW SET ACCESSORY	
62	2B		R31-0661-05	VARIABLE RESISTOR(POWER SW/VOL)	
63	2B		S60-0434-05	ROTARY SWITCH(16CH)	
64	1B		T07-0369-15	SPEAKER	
65	3C		T90-1039-15	WHIP ANTENNA ACCESSORY	K,M
65	3C		T90-1040-15	WHIP ANTENNA ACCESSORY	K2,M2
65	3C		T90-1041-15	WHIP ANTENNA ACCESSORY	K3
66	1D		W08-0988-05	CHARGER ACCESSORY	
67	1D		W08-0989-05	AC ADAPTER(AC120V) ACCESSORY	K,K2,K3
67	1D		W08-0992-05	AC ADAPTER(AC220-240V) ACCESSORY	M,M2
D403			B30-2156-05	LED(RED)	
D404			B30-2157-05	LED(YELLOW)	
C1			CK73HB1H332K	CHIP C 3300PF K	
C2			CK73HB1C682K	CHIP C 6800PF K	
C3			CK73GB1A105K	CHIP C 1.0UF K	
C4			CK73HB1C103K	CHIP C 0.010UF K	
C5			CK73HB1H102K	CHIP C 1000PF K	
C6			CK73HB1A104K	CHIP C 0.10UF K	
C7 ,8			CC73HC1H101J	CHIP C 100PF J	
C9			CC73HC1H100D	CHIP C 10PF D	
C10			CS77CP0J100M	CHIP TNL 10UF 6.3WV	
C11			CC73HC1H101J	CHIP C 100PF J	
C12			CK73HB1H102K	CHIP C 1000PF K	
C13			CK73HB1A104K	CHIP C 0.10UF K	
C14			CK73HB1C103K	CHIP C 0.010UF K	
C15			CC73HC1H100D	CHIP C 10PF D	
C16			CK73HB1H102K	CHIP C 1000PF K	
C17			CC73HC1H470J	CHIP C 47PF J	
C18			CC73HC1H180J	CHIP C 18PF J	
C19			CK73HB1A104K	CHIP C 0.10UF K	
C21			CS77CP0J100M	CHIP TNL 10UF 6.3WV	
C22			CS77AA1VR33M	CHIP TNL 0.33UF 35WV	
C24			CK73HB1H102K	CHIP C 1000PF K	
C25			CC73HC1H020B	CHIP C 2.0PF B	
C26			CC73HC1H300J	CHIP C 30PF J	
C27			CS77CA1C3R3M	CHIP TNL 3.3UF 16WV	
C29 ,30			CK73HB1H471K	CHIP C 470PF K	
C32			CS77CA1V0R1M	CHIP TNL 0.1UF 35WV	
C33 ,34			CK73HB1H102K	CHIP C 1000PF K	
C35			CC73HC1H270J	CHIP C 27PF J	
C38			CC73HC1H050B	CHIP C 5.0PF B	
C39			CK73GB1H332K	CHIP C 3300PF K	
C40			CC73HC1H030B	CHIP C 3.0PF B	
C41			CK73GB1H682K	CHIP C 6800PF K	
C42			CC73HC1H050B	CHIP C 5.0PF B	
C43			CC73HC1H100C	CHIP C 10PF C	
C44			CK73HB1H471K	CHIP C 470PF K	
C45			CK73GB1A105K	CHIP C 1.0UF K	
C47			CC73HC1H101J	CHIP C 100PF J	
C48			CK73HB1H471K	CHIP C 470PF K	
C49			CC73HC1H101J	CHIP C 100PF J	

PARTS LIST

TX-RX UNIT (X57-6890-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
C50			CC73HCH1H100D	CHIP C 10PF D		C116			CC73GCH1H110J	CHIP C 11PF J	K,K2,M
C52			CC73HCH1H110J	CHIP C 11PF J	K,K3,M	C116			CC73GCH1H110J	CHIP C 11PF J	M2
C52			CC73HCH1H130J	CHIP C 13PF J	K2,M2	C119			CK73GB1H471K	CHIP C 470PF K	
C53			CC73HCH1H020B	CHIP C 2.0PF B	K,K2,M	C121			CC73GCH1H120J	CHIP C 12PF J	K3
C53			CC73HCH1H020B	CHIP C 2.0PF B	M2	C122			CC73GCH1H330J	CHIP C 33PF J	
C53			CC73HCH1H040B	CHIP C 4.0PF B	K3	C123			CC73GCH1H330G	CHIP C 33PF G	
C54			CC73HCH1H060B	CHIP C 6.0PF B	K,M	C124			CC73HCH1H100D	CHIP C 10PF D	
C54			CC73HCH1H070B	CHIP C 7.0PF B	K3	C125			CC73GCH1H060B	CHIP C 6.0PF B	K,K2,M
C54			CC73HCH1H090B	CHIP C 9.0PF B	K2,M2	C125			CC73GCH1H060B	CHIP C 6.0PF B	M2
C55			CC73HCH1H110J	CHIP C 11PF J	K,M	C125			CC73GCH1H110G	CHIP C 11PF G	K3
C55			CC73HCH1H120J	CHIP C 12PF J	K2,K3,M2	C126			CS77CA1C010M	CHIP TINTL 1.0UF 16WV	
C56			CC73HCH1H020B	CHIP C 2.0PF B	K,M	C127			CC73GCH1H200J	CHIP C 20PF J	K,K2,M
C56			CC73HCH1H050B	CHIP C 5.0PF B	K3	C127			CC73GCH1H200J	CHIP C 20PF J	M2
C57			CC73HCH1H0R5B	CHIP C 0.5PF B	K3	C128			CK73HB1H471K	CHIP C 470PF K	
C58			CC73HCH1H060B	CHIP C 6.0PF B	K,M	C129			CK73GB1H471K	CHIP C 470PF K	
C58			CC73HCH1H070B	CHIP C 7.0PF B	K3	C130			CK73HB1H471K	CHIP C 470PF K	
C58			CC73HCH1H090B	CHIP C 9.0PF B	K2,M2	C132			CC73GCH1H200J	CHIP C 20PF J	K,M
C59			CC73HCH1H1R5B	CHIP C 1.5PF B	K3	C132			CC73GCH1H270J	CHIP C 27PF J	K2,M2
C59_60			CC73HCH1H010B	CHIP C 1.0PF B	K,K2,M	C132			CC73GCH1H390J	CHIP C 39PF J	K3
C59_60			CC73HCH1H010B	CHIP C 1.0PF B	M2	C133			CK73GB1H471K	CHIP C 470PF K	
C60			CC73HCH1H010B	CHIP C 1.0PF B	K3	C134			CK73GB1H103K	CHIP C 0.010UF K	
C60			CC73HCH1H010B	CHIP C 1.0PF B	K3	C135			CK73GB1C104K	CHIP C 0.10UF K	
C61			CC73HCH1H030B	CHIP C 3.0PF B	K,M	C136			CK73GB1A105K	CHIP C 1.0UF K	
C61			CC73HCH1H040B	CHIP C 4.0PF B	K2,K3,M2	C138			CK73GB1H102K	CHIP C 1000PF K	
C62			CC73HCH1H020B	CHIP C 2.0PF B	K,K2,M	C140			CC73GCH1H101J	CHIP C 100PF J	
C62			CC73HCH1H020B	CHIP C 2.0PF B	M2	C145			CC73GCH1H180J	CHIP C 18PF J	K,K2,M
C62			CC73HCH1H030B	CHIP C 3.0PF B	K3	C145			CC73GCH1H180J	CHIP C 18PF J	M2
C63			CC73HCH1H101J	CHIP C 100PF J		C145			CC73GCH1H300J	CHIP C 30PF J	K3
C64			CC73HCH1H040B	CHIP C 4.0PF B	K,K3,M	C146			CK73GB1H102K	CHIP C 1000PF K	
C64_65			CC73HCH1H050B	CHIP C 5.0PF B	K2,M2	C148			CK73GB1H102K	CHIP C 1000PF K	
C65_66			CC73HCH1H050B	CHIP C 5.0PF B	K3	C149			CC73GCH1H070B	CHIP C 7.0PF B	K,K3,M
C65_66			CC73HCH1H060B	CHIP C 6.0PF B	K,M	C151			CC73GCH1H070B	CHIP C 7.0PF B	K2,K3,M2
C66			CC73HCH1H060B	CHIP C 6.0PF B	K2,M2	C152			CC73GCH1H200J	CHIP C 20PF J	
C67			CC73HCH1H040B	CHIP C 4.0PF B	K3	C154			CK73GB1H471K	CHIP C 470PF K	
C67			CC73HCH1H050B	CHIP C 5.0PF B	K,K2,M	C156			CC73GCH1H030B	CHIP C 3.0PF B	K3
C67			CC73HCH1H050B	CHIP C 5.0PF B	M2	C156			CC73GCH1H040B	CHIP C 4.0PF B	K,M
C68-70			CK73HB1H471K	CHIP C 470PF K		C156			CC73GCH1H3R5B	CHIP C 3.5PF B	K2,M2
C71_72			CK73HB1A104K	CHIP C 0.10UF K		C157			CC73GCH1H040B	CHIP C 4.0PF B	K2,K3,M2
C73_74			CC73HCH1H0R5B	CHIP C 0.5PF B		C157			CC73GCH1H2R5B	CHIP C 2.5PF B	K,M
C75_76			CK73HB1H102K	CHIP C 1000PF K		C158			CC73GCH1H101J	CHIP C 100PF J	
C77			CK73HB1H471K	CHIP C 470PF K		C159			CC73GCH1H020C	CHIP C 2.0PF C	K,K3,M
C78			CC73HCH1H330J	CHIP C 33PF J		C159			CC73GCH1H030B	CHIP C 3.0PF B	K2,M2
C79			CS77CP0J100M	CHIP TINTL 10UF 6.3WV		C160			CC73GCH1H020B	CHIP C 2.0PF B	K,K3,M
C80			CK73HB1H471K	CHIP C 470PF K		C160			CC73GCH1H1R5B	CHIP C 1.5PF B	K2,M2
C83			CC73HCH1H150J	CHIP C 15PF J		C161			CC73GCH1H050B	CHIP C 5.0PF B	K,K3,M
C84-86			CK73HB1H102K	CHIP C 1000PF K		C161			CC73GCH1H060B	CHIP C 6.0PF B	K2,M2
C87			CC73HCH1H100D	CHIP C 10PF D		C163			CC73GCH1H030B	CHIP C 3.0PF B	
C90			CK73HB1H102K	CHIP C 1000PF K		C164			CC73GCH1H050B	CHIP C 5.0PF B	K,K3,M
C100			CK73HB1H471K	CHIP C 470PF K		C164			CC73GCH1H060B	CHIP C 6.0PF B	K2,M2
C101			CK73GB1H471K	CHIP C 470PF K		C166			CC73GCH1HR75B	CHIP C 0.75PF B	K,K3,M
C102			CC73GCH1H120J	CHIP C 12PF J		C166			CC73GCH1H1R5B	CHIP C 1.5PF B	K2,M2
C106			CK73HB1H471K	CHIP C 470PF K		C168			CC73GCH1H0R3B	CHIP C 0.3PF B	K2,M2
C107			CC73GCH1H060B	CHIP C 6.0PF B	K,K2,M	C168			CC73GCH1H010B	CHIP C 1.0PF B	K,M
C107			CC73GCH1H060B	CHIP C 6.0PF B	M2	C169			CC73GCH1H030B	CHIP C 3.0PF B	K2,M2
C107			CC73GCH1H070D	CHIP C 7.0PF D	K3	C169			CC73GCH1H040B	CHIP C 4.0PF B	K,M
C108			CK73HB1H471K	CHIP C 470PF K		C169			CC73GCH1H100C	CHIP C 10PF C	K3
C110,111			CK73GB1H471K	CHIP C 470PF K		C190			CK73GB1A105K	CHIP C 1.0UF K	
C112			CC73GCH1H070D	CHIP C 7.0PF D		C191			CK73GB1H103K	CHIP C 0.010UF K	
C113			CK73GB1C104K	CHIP C 0.10UF K		C201			CK73GB1A224K	CHIP C 0.22UF K	
C116			CC73GCH1H030B	CHIP C 3.0PF B	K3						

PARTS LIST

TX-RX UNIT (X57-6890-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
C206			CK73HB1H102K	CHIP C 1000PF K		C259			CK73GB1H471K	CHIP C 470PF K	
C207			CK73HB1H182K	CHIP C 1800PF K		C262,263			CK73HB1H471K	CHIP C 470PF K	
C208			CK73HB1H471K	CHIP C 470PF K		C265			CK73HB1H471K	CHIP C 470PF K	
						C266			CK73GB1H471K	CHIP C 470PF K	
C209			CS77CP0J100M	CHIP TNL 10UF 6.3WV		C267			CC73GCH1H050B	CHIP C 5.0PF B	K2,M2
C210			CK73HB1H471K	CHIP C 470PF K		C267			CC73GCH1H060B	CHIP C 6.0PF B	K3
C211			CK73HB1C103K	CHIP C 0.010UF K		C267			CC73GCH1H3R5B	CHIP C 3.5PF B	K,M
C213			CK73HB1A104K	CHIP C 0.10UF K		C268			CC73GCH1H180J	CHIP C 18PF J	K2,M2
C214			CC73HCH1H680J	CHIP C 68PF J		C268			CC73GCH1H220J	CHIP C 22PF J	K,K3,M
C215			CK73HB1H102K	CHIP C 1000PF K		C269			CC73GCH1H020B	CHIP C 2.0PF B	K,K3,M
C216			CK73GB1C104K	CHIP C 0.10UF K		C269			CC73GCH1H2R5B	CHIP C 2.5PF B	K2,M2
C217			CK73HB1A104K	CHIP C 0.10UF K		C269,271			CK73HB1H471K	CHIP C 470PF K	
C218			CK73GB1C104K	CHIP C 0.10UF K		C272			CC73GCH1H020B	CHIP C 2.0PF B	
C219			CC73HCH1H330J	CHIP C 33PF J		C273			CC73GCH1H180J	CHIP C 18PF J	K2,M2
C220			CK73HB1H102K	CHIP C 1000PF K		C273			CC73GCH1H220J	CHIP C 22PF J	K,K3,M
C221			CK73GB1C104K	CHIP C 0.10UF K		C274			CC73GCH1H010B	CHIP C 1.0PF B	K,M
C222			CK73HB1H102K	CHIP C 1000PF K		C274			CC73GCH1H020B	CHIP C 2.0PF B	K2,M2
C224,225			CK73HB1C103K	CHIP C 0.010UF K		C274			CC73GCH1H040B	CHIP C 4.0PF B	K3
C228			CC73GCH1H100C	CHIP C 10PF C		C275			CC73GCH1H020B	CHIP C 2.0PF B	K,K3,M
C230			CK73HB1C103K	CHIP C 0.010UF K		C275			CC73GCH1H090B	CHIP C 9.0PF B	K2,M2
C231			CK73GB1H103K	CHIP C 0.010UF K		C276			CC73GCH1H040B	CHIP C 4.0PF B	K2,K3,M2
C232			CK73HB1C103K	CHIP C 0.010UF K		C276			CC73GCH1H3R5B	CHIP C 3.5PF B	K,M
C233			CC73GCH1H060B	CHIP C 6.0PF B		C290			CC73GCH1H020B	CHIP C 2.0PF B	
C234			CK73HB1H102K	CHIP C 1000PF K		C291			CC73GCH1H060B	CHIP C 6.0PF B	
C236			CC73GCH1H180J	CHIP C 18PF J		C292			CK73HB1H471K	CHIP C 470PF K	
C237			CK73HB1H102K	CHIP C 1000PF K		C301			CK73HB1H392K	CHIP C 3900PF K	
C238			CK73GB1C104K	CHIP C 0.10UF K		C302			CK73HB1H271K	CHIP C 270PF K	
C239			CK73GB1H102K	CHIP C 1000PF K		C304			CK73GB1A224K	CHIP C 0.22UF K	
C240			CC73GCH1H010B	CHIP C 1.0PF B	K3	C306			CS77CP0J4R7M	CHIP TNL 4.7UF 6.3WV	
C240			CC73GCH1H3R5B	CHIP C 3.5PF B	K,K2,M	C307,308			CK73HB1A104K	CHIP C 0.10UF K	
C240			CC73GCH1H3R5B	CHIP C 3.5PF B	M2	C309			CC73GCH1H820J	CHIP C 82PF J	
C241			CK73GB1H471K	CHIP C 470PF K		C310			CK73HB1A683K	CHIP C 0.068UF K	
C244			CC73GCH1H030B	CHIP C 3.0PF B	K,M	C311			CK73GB1A105K	CHIP C 1.0UF K	
C244			CC73GCH1H3R5B	CHIP C 3.5PF B	K2,M2	C312			CC73GCH1H120J	CHIP C 12PF J	
C245			CC73GCH1H180J	CHIP C 18PF J	K2,M2	C313			CC73GCH1H121J	CHIP C 120PF J	
C245			CC73GCH1H220J	CHIP C 22PF J	K,M	C314			CK73HB1A104K	CHIP C 0.10UF K	
C246			CC73GCH1HR75B	CHIP C 0.75PF B	K2,M2	C315			CK73GB1A105K	CHIP C 1.0UF K	
C246			CC73GCH1H010B	CHIP C 1.0PF B	K,M	C316			CK73GB1C104K	CHIP C 0.10UF K	
C247			CK73HB1H471K	CHIP C 470PF K	K,K2,M	C317			CK73HB1A104K	CHIP C 0.10UF K	
C247			CK73HB1H471K	CHIP C 470PF K	M2	C318			CS77CP0J4R7M	CHIP TNL 4.7UF 6.3WV	
C248			CC73GCH1H010B	CHIP C 1.0PF B	K2,M2	C319			CC73GCH1H271J	CHIP C 270PF J	
C248			CC73GCH1H020B	CHIP C 2.0PF B	K,M	C320			CK73HB1C103K	CHIP C 0.010UF K	
C249			CC73GCH1H050B	CHIP C 5.0PF B	K3	C321			CK73GB1A105K	CHIP C 1.0UF K	
C249			CC73GCH1H060B	CHIP C 6.0PF B	K,K2,M	C322			CK73HB1C153K	CHIP C 0.015UF K	
C249			CC73GCH1H060B	CHIP C 6.0PF B	M2	C323			CC73GCH1H820J	CHIP C 82PF J	
C250			CC73GCH1H180J	CHIP C 18PF J	K2,M2	C324			CC73HCH1H820J	CHIP C 82PF J	
C250			CC73GCH1H220J	CHIP C 22PF J	K,K3,M	C325			CK73HB1A104K	CHIP C 0.10UF K	
C251			CK73HB1H471K	CHIP C 470PF K		C326			CK73HB1H102K	CHIP C 1000PF K	
C252			CC73GCH1HR75B	CHIP C 0.75PF B	K2,M2	C327			CC73HCH1H101J	CHIP C 100PF J	
C252			CC73GCH1H1R5B	CHIP C 1.5PF B	K3	C328			CK73HB1H391K	CHIP C 390PF K	
C252,253			CC73GCH1H020B	CHIP C 2.0PF B	K,M	C329,330			CK73GB1A105K	CHIP C 1.0UF K	
C253			CC73GCH1H020B	CHIP C 2.0PF B	K2,K3,M2	C331			CK73HB1A104K	CHIP C 0.10UF K	
C254			CK73HB1H471K	CHIP C 470PF K		C332			CK73HB1H471K	CHIP C 470PF K	
C255			CC73GCH1H180J	CHIP C 18PF J	K2,M2	C333,334			CK73GB1C104K	CHIP C 0.10UF K	
C255			CC73GCH1H220J	CHIP C 22PF J	K,K3,M	C335			CC73GCH1H221J	CHIP C 220PF J	
C256			CS77CP0J4R7M	CHIP TNL 4.7UF 6.3WV		C336			CK73FB1C474K	CHIP C 0.47UF K	
C257			CC73GCH1H060B	CHIP C 6.0PF B	K2,M2	C338			CC73GCH1H101J	CHIP C 100PF J	
C257			CC73GCH1H070B	CHIP C 7.0PF B	K3	C339			CS77AA0J100M	CHIP TNL 10UF 6.3WV	
C257			CC73GCH1H4R5B	CHIP C 4.5PF B	K,M	C340			CK73GB1C104K	CHIP C 0.10UF K	
C258			CK73HB1H471K	CHIP C 470PF K							

PARTS LIST

TX-RX UNIT (X57-6890-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
C341			CK73GB1C473K	CHIP C 0.047UF K		L10,11			L40-1085-92	SMALL FIXED INDUCTOR(100NH)	
C342			CS77AA0J100M	CHIP TNL 10UF 6.3WV		L12			L92-0138-05	CHIP FERRITE	
C343			CK73GB1C473J	CHIP C 0.047UF J		L13,14			L40-1085-92	SMALL FIXED INDUCTOR(100NH)	
C344			CC73GCH1H221J	CHIP C 220PF J		L16			L40-1878-67	SMALL FIXED INDUCTOR(18NH)	K2,M2
C345			CS77CC0J101M	CHIP TNL 100UF 6.3WV		L16			L40-2278-67	SMALL FIXED INDUCTOR(22NH)	K,M
C346			CK73GB1H102K	CHIP C 1000PF K		L16			L40-2778-67	SMALL FIXED INDUCTOR(27NH)	K3
C348			CK73HB1H471K	CHIP C 470PF K		L17			L40-2278-67	SMALL FIXED INDUCTOR(22NH)	K2,M2
C349			CK73HB1A333K	CHIP C 0.033UF K		L17			L40-2778-67	SMALL FIXED INDUCTOR(27NH)	K,M
C351,352			CK73HB1C103K	CHIP C 0.010UF K	K3	L17			L40-3378-67	SMALL FIXED INDUCTOR(33NH)	K3
C354			CK73HB1A104K	CHIP C 0.10UF K		L18,19			L41-2285-03	SMALL FIXED INDUCTOR(220NH)	
C401			CC73GCH1H471J	CHIP C 470PF J		L20,21			L40-3391-86	SMALL FIXED INDUCTOR(3.3UH)	
C402			CK73HB1H102K	CHIP C 1000PF K		L22			L92-0138-05	CHIP FERRITE	
C403			CK73GB1C104K	CHIP C 0.10UF K		L23			L40-2275-92	SMALL FIXED INDUCTOR(22NH)	
C405			CC73GCH1H101J	CHIP C 100PF J		L24			L92-0470-05	CHIP FERRITE	
C406			CC73HCH1H101J	CHIP C 100PF J		L25			L40-2275-92	SMALL FIXED INDUCTOR(22NH)	
C407			CK73HB1H102K	CHIP C 1000PF K		L100			L40-3375-92	SMALL FIXED INDUCTOR(33NH)	K3
C408			CC73HCH1H101J	CHIP C 100PF J		L100,101			L40-1575-92	SMALL FIXED INDUCTOR(15NH)	K,K2,M
C409,410			CK73GB1A105K	CHIP C 1.0UF K		L100,101			L40-1575-92	SMALL FIXED INDUCTOR(15NH)	M2
C411			CK73HB1H102K	CHIP C 1000PF K		L101			L40-2275-92	SMALL FIXED INDUCTOR(22NH)	K3
C412-414			CC73HCH1H101J	CHIP C 100PF J		L102			L92-0138-05	CHIP FERRITE	
C415			CK73HB1H471K	CHIP C 470PF K		L103,104			L40-8265-92	SMALL FIXED INDUCTOR(8.2NH)	
C417			CK73GB1A105K	CHIP C 1.0UF K		L105			L40-1575-54	SMALL FIXED INDUCTOR(15NH)	K,K3,M
C418			CK73HB1E562K	CHIP C 5600PF K		L105			L40-2275-54	SMALL FIXED INDUCTOR(22NH)	K2,M2
C419			CK73HB1H102K	CHIP C 1000PF K		L106			L92-0149-05	CHIP FERRITE	
C420			CC73HCH1H101J	CHIP C 100PF J		L107			L40-1263-92	SMALL FIXED INDUCTOR(1.2NH)	K,K2,M
C421			CK73GB1A105K	CHIP C 1.0UF K		L107			L40-1263-92	SMALL FIXED INDUCTOR(1.2NH)	M2
C422			CC73HCH1H101J	CHIP C 100PF J		L109			L92-0149-05	CHIP FERRITE	
C424			CC73HCH1H101J	CHIP C 100PF J		L110			L40-2285-54	SMALL FIXED INDUCTOR(220NH)	
C426,427			CK73GB1A105K	CHIP C 1.0UF K		L111			L41-1092-44	SMALL FIXED INDUCTOR(1UH)	
C428,429			CK73HB1H102K	CHIP C 1000PF K		L201			L40-1091-37	SMALL FIXED INDUCTOR(1.000UH)	
C430			CK73GB1H103K	CHIP C 0.010UF K		L202			L92-0138-05	CHIP FERRITE	
C431			CK73HB1C103K	CHIP C 0.010UF K		L203			L41-5685-39	SMALL FIXED INDUCTOR(0.56UH)	
C432			CC73HCH1H050B	CHIP C 5.0PF B		L204			L40-2785-92	SMALL FIXED INDUCTOR(270NH)	
C433,434			CC73HCH1H030B	CHIP C 3.0PF B		L206			L40-2775-92	SMALL FIXED INDUCTOR(27NH)	K2,M2
C435			CC73HCH1H050B	CHIP C 5.0PF B		L206			L40-3975-92	SMALL FIXED INDUCTOR(39NH)	K3
C440			CC73GCH1H1R5B	CHIP C 1.5PF B		L211,212			L41-8268-14	SMALL FIXED INDUCTOR(8.2NH)	K,K2,M
C443			CK73GB1A474K	CHIP C 0.47UF K		L211,212			L41-8268-14	SMALL FIXED INDUCTOR(8.2NH)	M2
C444			CC73GCH1H020B	CHIP C 2.0PF B		L212			L41-8268-14	SMALL FIXED INDUCTOR(8.2NH)	K3
C445			CC73GCH1H200J	CHIP C 20PF J		L214			L41-6868-14	SMALL FIXED INDUCTOR(6.8NH)	K2,M2
C453,454			CC73HCH1H101J	CHIP C 100PF J	K3 K2,M2	L214			L41-8268-14	SMALL FIXED INDUCTOR(8.2NH)	K,K3,M
C901,902			CK73GB1A105K	CHIP C 1.0UF K		L215			L41-2285-03	SMALL FIXED INDUCTOR(220NH)	
TC1,2			C05-0384-05	CERAMIC TRIMMER CAPACITOR(10PF)		L220			L34-4602-05	AIR-CORE COIL	
CN201			E23-1278-05	TERMINAL		L223			L34-4572-05	AIR-CORE COIL	K,K2,M
CN401			E40-6573-05	FLAT CABLE CONNECTOR		L223			L34-4572-05	AIR-CORE COIL	M2
J301			E11-0707-05	PHONE JACK(2.5/3.5)		L224-226			L34-4564-05	AIR-CORE COIL	
F401			F53-0324-05	FUSE(2.5A)		L228			L41-6868-14	SMALL FIXED INDUCTOR(6.8NH)	K2,M2
101	2A		J30-1282-14	SPACER(MIC ELEMENT)		L228,229			L41-8268-14	SMALL FIXED INDUCTOR(8.2NH)	K,K3,M
CD201			L79-1582-05	TUNING COIL		L229			L41-8268-14	SMALL FIXED INDUCTOR(8.2NH)	K2,M2
CF201	2A		L72-0973-05	CERAMIC FILTER		L230			L41-4778-03	SMALL FIXED INDUCTOR(47NH)	K2,M2
L1			L40-4791-37	SMALL FIXED INDUCTOR(4.700UH)		L230			L41-4778-03	SMALL FIXED INDUCTOR(47NH)	M2
L3			L40-5681-86	SMALL FIXED INDUCTOR(0.56UH)		L230			L41-5678-03	SMALL FIXED INDUCTOR(56NH)	K3
L5			L40-5681-86	SMALL FIXED INDUCTOR(0.56UH)		L250			L40-1875-92	SMALL FIXED INDUCTOR(18NH)	
L6,7			L92-0138-05	CHIP FERRITE		L290			L41-3078-17	SMALL FIXED INDUCTOR(30NH)	K,M
L8,9			L40-1875-92	SMALL FIXED INDUCTOR(18NH)		L301			L92-0140-05	CHIP FERRITE	
						L302			L92-0149-05	CHIP FERRITE	
						L401			L92-0149-05	CHIP FERRITE	
						L402-404			L92-0138-05	CHIP FERRITE	
						L410			L92-0138-05	CHIP FERRITE	
						L411			L40-1875-92	SMALL FIXED INDUCTOR(18NH)	
						L412			L34-4564-05	AIR-CORE COIL	K3

PARTS LIST

TX-RX UNIT (X57-6890-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
X1			L77-1931-05	TCXO(12.8MHZ)		R111,112			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
X2			L78-1414-05	RESONATOR(7.37MHZ)		R114			RK73GB2A124J	CHIP R 120K J 1/10W	K2,M2
XF201			L71-0619-05	MCF(38.85MHZ)		R114			RK73GB2A473J	CHIP R 47K J 1/10W	K,M
CP404			RK75HA1J473J	CHIP-COM 47K J 1/16W		R114			RK73GB2A683J	CHIP R 68K J 1/10W	K3
CP405			RK75HA1J102J	CHIP-COM 1.0K J 1/16W		R115			RK73GB2A103J	CHIP R 10K J 1/10W	
R1			RK73HB1J104J	CHIP R 100K J 1/16W	K2,M2	R116			RK73GB2A220J	CHIP R 22 J 1/10W	
R1			RK73HB1J223J	CHIP R 22K J 1/16W	K,K3,M	R120			RK73GB2A000JX	CHIP R 0.0 J 1/10W	K3
R2			RK73HB1J103J	CHIP R 10K J 1/16W		R121			RK73GB2A220J	CHIP R 22 J 1/10W	
R3			RK73HB1J333J	CHIP R 33K J 1/16W		R123			RK73FB2B000JX	CHIP R 0.0 J 1/8W	
R4			RK73HB1J563J	CHIP R 56K J 1/16W		R124			RK73GB2A473J	CHIP R 47K J 1/10W	
R5			RK73HB1J104J	CHIP R 100K J 1/16W		R126			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R6			RK73HB1J823J	CHIP R 82K J 1/16W		R127-129			RK73EB2ER39K	CHIP R 0.39 K 1/4W	
R7			RK73HB1J101J	CHIP R 100 J 1/16W		R130-135			RK73GH2A154D	CHIP R 150K D 1/10W	
R8 -11			RK73HB1J000J	CHIP R 0.0 J 1/16W		R137			RK73FB2B000JX	CHIP R 0.0 J 1/8W	
R12			RK73HB1J222J	CHIP R 2.2K J 1/16W		R138			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R13			RK73GB2A000JX	CHIP R 0.0 J 1/10W		R139			RK73GB2A473J	CHIP R 47K J 1/10W	
R14			RK73HB1J334J	CHIP R 330K J 1/16W		R140			RK73GB2A563J	CHIP R 56K J 1/10W	
R15			RK73GB2A221J	CHIP R 220 J 1/10W		R141			RK73GB2A104J	CHIP R 100K J 1/10W	
R16			RK73GB2A561J	CHIP R 560 J 1/10W		R142			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R17			RK73HB1J101J	CHIP R 100 J 1/16W		R143			RK73GB2A104J	CHIP R 100K J 1/10W	
R18			RK73GB2A181J	CHIP R 180 J 1/10W		R145			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R19			RK73GB2A122J	CHIP R 1.2K J 1/10W		R147			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R20			RK73HB1J100J	CHIP R 10 J 1/16W		R190			RK73GB2A101J	CHIP R 100 J 1/10W	
R21			RK73GB2A681J	CHIP R 680 J 1/10W		R191,192			RK73GB2A271J	CHIP R 270 J 1/10W	
R22			RK73GB2A000JX	CHIP R 0.0 J 1/10W		R193			RK73GB2A473J	CHIP R 47K J 1/10W	K3
R23			RK73GB2A103J	CHIP R 10K J 1/10W		R193,194			RK73GB2A473J	CHIP R 47K J 1/10W	K,K2,M M2
R25			RK73HB1J223J	CHIP R 22K J 1/16W		R194			RK73GB2A683J	CHIP R 68K J 1/10W	K3
R26			RK73HB1J103J	CHIP R 10K J 1/16W		R203			RK73HB1J184J	CHIP R 180K J 1/16W	
R27			RK73HB1J220J	CHIP R 22 J 1/16W		R206			RK73GB2A100J	CHIP R 10 J 1/10W	
R30			RK73HB1J333J	CHIP R 33K J 1/16W		R207			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R31			RK73HB1J474J	CHIP R 470K J 1/16W		R208			RK73HB1J823J	CHIP R 82K J 1/16W	
R32			RK73HB1J102J	CHIP R 1.0K J 1/16W		R209			RK73HB1J272J	CHIP R 2.7K J 1/16W	
R33			RK73HB1J154J	CHIP R 150K J 1/16W		R210,211			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R34			RK73HB1J474J	CHIP R 470K J 1/16W		R212			RK73HB1J823J	CHIP R 82K J 1/16W	
R35 ,36			RK73HB1J274J	CHIP R 270K J 1/16W		R213			RK73HB1J392J	CHIP R 3.9K J 1/16W	
R37			RK73HB1J101J	CHIP R 100 J 1/16W		R215			RK73HB1J101J	CHIP R 100 J 1/16W	
R38			RK73HB1J181J	CHIP R 180 J 1/16W	K,K3,M	R216			RK73HB1J124J	CHIP R 120K J 1/16W	
R38 ,39			RK73HB1J181J	CHIP R 180 J 1/16W	K2,M2	R217			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R39			RK73HB1J151J	CHIP R 150 J 1/16W	K,K3,M	R218			RK73HB1J561J	CHIP R 560 J 1/16W	
R40			RK73HB1J101J	CHIP R 100 J 1/16W		R219			RK73GB2A561J	CHIP R 560 J 1/10W	
R41			RK73HB1J154J	CHIP R 150K J 1/16W		R226,227			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R42			RK73HB1J472J	CHIP R 4.7K J 1/16W		R228			RK73GB2A151J	CHIP R 150 J 1/10W	
R43			RK73HB1J101J	CHIP R 100 J 1/16W		R233			RK73HB1J104J	CHIP R 100K J 1/16W	
R46			RK73HB1J103J	CHIP R 10K J 1/16W		R236			RK73HB1J563J	CHIP R 56K J 1/16W	
R47			RK73HB1J220J	CHIP R 22 J 1/16W		R238			RK73HB1J104J	CHIP R 100K J 1/16W	
R48			RK73HB1J331J	CHIP R 330 J 1/16W		R239			RK73HB1J563J	CHIP R 56K J 1/16W	
R49			RK73HB1J222J	CHIP R 2.2K J 1/16W		R240			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R50			RK73HB1J472J	CHIP R 4.7K J 1/16W		R241			RK73HB1J105J	CHIP R 1.0M J 1/16W	K,K2,M
R100			RK73HB1J472J	CHIP R 4.7K J 1/16W		R241			RK73HB1J105J	CHIP R 1.0M J 1/16W	M2
R103			RK73GB2A333J	CHIP R 33K J 1/10W	K3	R243,244			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R103			RK73GB2A473J	CHIP R 47K J 1/10W	K,K2,M	R248			RK73GB2A221J	CHIP R 220 J 1/10W	
R103			RK73GB2A473J	CHIP R 47K J 1/10W	M2	R249			RK73GB2A220J	CHIP R 22 J 1/10W	
R105			RK73GB2A331J	CHIP R 330 J 1/10W		R251			RK73HB1J104J	CHIP R 100K J 1/16W	
R106			RK73GB2A121J	CHIP R 120 J 1/10W	K3	R253			RK73HB1J104J	CHIP R 100K J 1/16W	
R106			RK73GB2A220J	CHIP R 22 J 1/10W	K,K2,M	R254			RK73HB1J683J	CHIP R 68K J 1/16W	
R106			RK73GB2A220J	CHIP R 22 J 1/10W	M2	R255			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R107			RK73HB1J101J	CHIP R 100 J 1/16W		R256,257			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R110			RK73GB2A331J	CHIP R 330 J 1/10W		R258			RK73FB2B000JX	CHIP R 0.0 J 1/8W	

PARTS LIST

TX-RX UNIT (X57-6890-XX)


Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
R301			RK73HB1J103J	CHIP R 10K J 1/16W		R424,425			RK73HB1J473J	CHIP R 47K J 1/16W	
R304			RK73HB1J273J	CHIP R 27K J 1/16W		R426			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R305			RK73HB1J104J	CHIP R 100K J 1/16W		R435			RK73HB1J473J	CHIP R 47K J 1/16W	
R306			RK73HB1J102J	CHIP R 1.0K J 1/16W		R436			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R307,308			RK73HB1J000J	CHIP R 0.0 J 1/16W		R437,438			RK73HB1J473J	CHIP R 47K J 1/16W	
R310			RK73GB2A394J	CHIP R 390K J 1/10W		R445,446			RK73GB2A000JX	CHIP R 0.0 J 1/10W	
R311			RK73HB1J123J	CHIP R 12K J 1/16W		R447			RK73HB1J123J	CHIP R 12K J 1/16W	
R312			RK73GB2A334J	CHIP R 330K J 1/10W		R449,450			RK73GB2A000JX	CHIP R 0.0 J 1/10W	K3
R313			RK73GB2A104J	CHIP R 100K J 1/10W		R452			RK73HB1J103J	CHIP R 10K J 1/16W	
R314			RK73GB2A103J	CHIP R 10K J 1/10W		R453			RK73HB1J223J	CHIP R 22K J 1/16W	
R315			RK73GB2A334J	CHIP R 330K J 1/10W		R454			RK73GB2A000JX	CHIP R 0.0 J 1/10W	K2,M2
R316			RK73GB2A124J	CHIP R 120K J 1/10W		R901,902			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R317			RK73GB2A474J	CHIP R 470K J 1/10W		VR1			R32-0736-05	SEMI FIXED VARIABLE RESISTOR(68K)	
R318			RK73GB2A122J	CHIP R 1.2K J 1/10W		S1 -3			S70-0414-05	TACT SWITCH	
R319			RK73HB1J563J	CHIP R 56K J 1/16W		MIC301	2A		T91-0649-15	MIC ELEMENT	
R320			RK73HB1J332J	CHIP R 3.3K J 1/16W		D1			MA2S111-F	DIODE	
R321			RK73HB1J224J	CHIP R 220K J 1/16W		D2 -9			HVC376B	VARIABLE CAPACITANCE DIODE	
R322			RK73HB1J184J	CHIP R 180K J 1/16W		D10			1SV278F	VARIABLE CAPACITANCE DIODE	
R323			RK73HB1J563J	CHIP R 56K J 1/16W		D11			MA2S111-F	DIODE	
R324,325			RK73GB2A104J	CHIP R 100K J 1/10W		D101			HSC277	DIODE	
R326			RK73GB2A000JX	CHIP R 0.0 J 1/10W		D102			HZU5CLL	ZENER DIODE	
R327			RK73GB2A184J	CHIP R 180K J 1/10W		D103,104			HVC131	DIODE	
R328			RK73GB2A103J	CHIP R 10K J 1/10W		D106			HVC131	DIODE	
R329			RK73GB2A823J	CHIP R 82K J 1/10W		D122			HVC131	DIODE	
R330			RK73HB1J332J	CHIP R 3.3K J 1/16W		D202			HSC277	DIODE	
R331			RK73GB2A154J	CHIP R 150K J 1/10W		D203-206			HVC355B	VARIABLE CAPACITANCE DIODE	
R332			RK73GB2A153J	CHIP R 15K J 1/10W		D210			HVC355B	VARIABLE CAPACITANCE DIODE	K,K2,M
R334			RK73GB2A473J	CHIP R 47K J 1/10W		D210			HVC355B	VARIABLE CAPACITANCE DIODE	M2
R335			RK73GB2A222J	CHIP R 2.2K J 1/10W		D301,302			RB706F-40	DIODE	
R336			RK73GB2A102J	CHIP R 1.0K J 1/10W		D303			DAN222	DIODE	
R337			RK73GB2A151J	CHIP R 150 J 1/10W		D401			RB521S-30	DIODE	
R338			RK73GB2A222J	CHIP R 2.2K J 1/10W		D402			1SR154-400	DIODE	
R339			RK73GB2A471J	CHIP R 470 J 1/10W		IC1			MB15A02PFV2E1	MOS-IC	
R340			RK73GB2A182J	CHIP R 1.8K J 1/10W		IC101			TA75W01FUF	MOS-IC	
R341			RK73GB2A103J	CHIP R 10K J 1/10W		IC201			TA31136FNG	MOS-IC	
R342			RK73GB2A101J	CHIP R 100 J 1/10W		IC301			AQUA-L	MOS-IC	
R343			RK73GB2A474J	CHIP R 470K J 1/10W		IC302			TA7368FG	MOS-IC	
R344			RK73GB2A102J	CHIP R 1.0K J 1/10W		IC401,402			XC6204B502MR	MOS-IC	
R345,346			RK73GB2A101J	CHIP R 100 J 1/10W		IC403			BD4840FVE	MOS-IC	
R347			RK73GB2A104J	CHIP R 100K J 1/10W		IC404			BD4845FVE	MOS-IC	
R348			RK73GB2A563J	CHIP R 56K J 1/10W		IC405	*		30622MCAC02GU	MICROCONTROLLER IC	
R349			RK73GB2A333J	CHIP R 33K J 1/10W		IC406			BR24L08F-W	ROM IC	
R350			RK73HB1J000J	CHIP R 0.0 J 1/16W	K,K2,M	Q1			KTC4082	TRANSISTOR	
R350			RK73HB1J000J	CHIP R 0.0 J 1/16W	M2	Q2			2SC5108(Y)F	TRANSISTOR	
R350			RK73HB1J103J	CHIP R 10K J 1/16W	K3	Q3 ,4			2SK508NV(K52)	FET	
R354,355			RK73HB1J103J	CHIP R 10K J 1/16W		Q5			DTA143TE	DIGITAL TRANSISTOR	
R357			RK73HB1J000J	CHIP R 0.0 J 1/16W		Q6			2SC5108(Y)F	TRANSISTOR	
R360			RK73HB1J000J	CHIP R 0.0 J 1/16W		Q7			DTA143TE	DIGITAL TRANSISTOR	
R403			RK73GB2A101J	CHIP R 100 J 1/10W		Q8			2SC4617(S)	TRANSISTOR	
R404			RK73HB1J474D	CHIP R 470K D 1/16W		Q9			2SC4619(P,Q)	TRANSISTOR	
R405			RK73GB2A334J	CHIP R 330K J 1/10W		Q100			2SC4619(P,Q)	TRANSISTOR	
R406			RK73HB1J474D	CHIP R 470K D 1/16W		Q101			2SK3077F	FET	
R407			RK73HB1J334J	CHIP R 330K J 1/16W		Q102			2SK2596	FET	
R408-412			RK73HB1J473J	CHIP R 47K J 1/16W		Q103			2SK3476-F	FET	
R413,414			RK73GB2A331J	CHIP R 330 J 1/10W		Q104			DTC114EE	DIGITAL TRANSISTOR	
R415,416			RK73GB2A473J	CHIP R 47K J 1/10W		Q105			2SK879(Y)F	FET	
R417-420			RK73HB1J473J	CHIP R 47K J 1/16W		Q107			DTC114EE	DIGITAL TRANSISTOR	
R421,422			RK73HB1J102J	CHIP R 1.0K J 1/16W							
R423			RK73HB1J000J	CHIP R 0.0 J 1/16W							

PARTS LIST

TX-RX UNIT (X57-6890-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination	Ref. No.	Address	New parts	Parts No.	Description	Destination
Q108			2SK1824-A	FET							
Q109			DTA144EE	DIGITAL TRANSISTOR							
Q202			DTA144EE	DIGITAL TRANSISTOR							
Q203			2SC4649(N,P)	TRANSISTOR							
Q204,205			3SK318	FET							
Q301			DTA114EE	DIGITAL TRANSISTOR							
Q302			2SC4919	TRANSISTOR							
Q303			DTC144EE	DIGITAL TRANSISTOR							
Q304			2SA1362-F(GR)	TRANSISTOR							
Q305			DTC144EE	DIGITAL TRANSISTOR							
Q306			2SK3577-A	FET							
Q316			2SK3577-A	FET							
Q401,402			DTC114EE	DIGITAL TRANSISTOR							
Q403,404			CPH3317	FET							
Q405			DTA123JE	DIGITAL TRANSISTOR							
Q407,408			2SK1830F	FET							
Q901			2SK1824-A	FET							
TH101			157-104-65001	THERMISTOR							
TH203			157-104-65001	THERMISTOR							

EXPLODED VIEW



- A :N14-0819-04
- B :N14-0832-04
- C :N30-2604-48
- D :N30-2606-48
- E :N83-2005-48

Note: If a part reference number is listed in a box on the exploded view of the PCB, that part does not come with the PCB. These parts must be ordered separately.

PACKING

