



A

B

- A : N09-6108-15
 B : N09-6426-15
 C : N09-6735-05
 D : N09-6737-15
 E : N09-6738-15
 F : N19-2335-14
 G : N35-2003-48
 H : N39-1720-48





*Depends on the models. Refer to the parts list.

Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Ref.No.	A d d w	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d w	N e w	Parts No.	Description	Dest inati on
KDC-448U/5051U/5751SD/BT51U/BT848U/U6049//U7049BT//X595/X895						232	2D		F11-1874-03	SHIELDING COVER (MECHA)	M4E3K
201	1C		A02-2757-13	PLASTIC CABINET ASSY	M2	232	2D	*	F11-1884-13	SHIELDING COVER (MECHA)	E2
201	1C		A02-2757-13	PLASTIC CABINET ASSY	M3M4M1	F1	2D		F52-0023-05	FUSE (MINI BLADE TYPE) (10A)	
202	1D	*	A52-1156-01	TOP COVER		236	3C		G01-3244-04	COMPRESSION SPRING (RELEASE)	
203	3C	*	A21-6800-02	DRESSING PANEL		238	1C		GE40504-001A	SPRING (TORSION)	
204	2C	*	A46-1917-01	REAR COVER		239	2C		GE40505-001A	SPRING (COMPRESSION)	
205	3D	*	A40-1410-01	BOTTOM PLATE		-		*	H54-4999-03	ITEM CARTON CASE	K2
208	2C	*	A22-3297-03	SUB PANEL ASSY	K1E1M1	-		*	H54-5000-03	ITEM CARTON CASE	K3
208	2C	*	A22-3297-03	SUB PANEL ASSY	K2K3M3	-		*	H54-5001-03	ITEM CARTON CASE	E3
208	2C	*	A22-3297-03	SUB PANEL ASSY	M2	-		*	H54-5002-03	ITEM CARTON CASE	M3
208	2C	*	A22-3297-03	SUB PANEL ASSY	M4E3K	-		*	H54-5003-03	ITEM CARTON CASE	M4
208	2C	*	A22-3298-13	SUB PANEL ASSY	E2	-		*	H54-5014-03	ITEM CARTON CASE	K
PA1	3C	*	A64-5175-12	PANEL ASSY	K2	-		*	H54-5015-03	ITEM CARTON CASE	K1
PA1	3C	*	A64-5176-12	PANEL ASSY	K3	-		*	H54-5016-03	ITEM CARTON CASE	E1
PA1	3C	*	A64-5177-12	PANEL ASSY	E3	-		*	H54-5017-03	ITEM CARTON CASE	E2
PA1	3C	*	A64-5178-12	PANEL ASSY	M3M4	-		*	H54-5018-03	ITEM CARTON CASE	M1
PA1	3C	*	A64-5180-12	PANEL ASSY	K	-		*	H54-5019-03	ITEM CARTON CASE	M2
PA1	3C	*	A64-5181-12	PANEL ASSY	K1						
PA1	3C	*	A64-5182-12	PANEL ASSY	E1	241	1C	*	J22-2049-03	MOUNTING HARDWARE ASSY	
PA1	3C	*	A64-5183-12	PANEL ASSY	E2	243	3C	*	K24-5084-13	PUSH KNOB (SRC)	
PA1	3C	*	A64-5184-12	PANEL ASSY	M1M2	244	3C	*	K24-5085-13	PUSH KNOB (SEARCH)	
RC1	1C		A70-2104-05	REMOTE CONTROLLER ASSY (RC-405)	K2K3M3	245	3C	*	K24-5086-13	PUSH KNOB (RETURN)	
RC1	1C		A70-2104-05	REMOTE CONTROLLER ASSY (RC-405)	M1M2	246	3C	*	K24-5087-13	PUSH KNOB (DISP)	
RC1	1C		A70-2104-05	REMOTE CONTROLLER ASSY (RC-405)	M4KK1	247	3C	*	K24-5088-13	PUSH KNOB (PRESET)	
-		*	B59-2056-00	SUB-INST. MANUAL (ENG.FRE.SPA.)	K1	248	3C	*	K24-5089-13	PUSH KNOB (LOG)	
-		*	B59-2056-00	SUB-INST. MANUAL (ENG.FRE.SPA.)	K2K3K	249	3C	*	K24-5090-03	PUSH KNOB (EJECT)	
-		*	B59-2057-00	SUB-INST. MANUAL (ENG.FRE.)	E3E1E2	250	3C	*	K24-5091-04	PUSH KNOB (RELEASE)	
-		*	B59-2057-00	SUB-INST. MANUAL (GER.DUT.)	E3E1E2	252	3C	*	K28-0436-04	KNOB ASSY (VOL)	
-		*	B59-2058-00	SUB-INST. MANUAL (ENG.FRE.)	E3E1E2	255	3C	*	K28-0439-13	KNOB ASSY (BT)	KK1E1
-		*	B59-2058-00	SUB-INST. MANUAL (GER.DUT.)	E3E1E2	255	3C	*	K28-0439-13	KNOB ASSY (BT)	M1M2
-		*	B59-2058-00	SUB-INST. MANUAL (ITA.SPA.POR.)	E3E1E2	255	3C	*	K28-0442-13	KNOB ASSY (SD)	E2
-		*	B59-2064-00	SUB-INST. MANUAL (ENGLISH)	M2	255	3C	*	K28-0443-13	KNOB ASSY (iPod)	K2K3M
-		*	B59-2064-00	SUB-INST. MANUAL (S-CHI.KOR.)	M2	255	3C	*	K28-0443-13	KNOB ASSY (iPod)	M4E3
-		*	B59-2064-00	SUB-INST. MANUAL (ENGLISH)	M3M4M1						
-		*	B59-2064-00	SUB-INST. MANUAL (S-CHI.KOR.)	M3M4M1	261	1C		N99-1757-15	SCREW SET	K2K3M
-		*	B64-4810-00	INST. MANUAL (ENGLISH)	M2	261	1C		N99-1757-15	SCREW SET	M1M2
-		*	B64-4810-00	INST. MANUAL (ENGLISH)	M3M4M1	261	1C		N99-1757-15	SCREW SET	M4KK1
-		*	B64-4811-00	INST. MANUAL (S-CHINESE)	M3M1	263	1C		N80-2008-48	TAP SCREW (ACCESSORY)	K2K3M
-		*	B64-4812-00	INST. MANUAL (ARABIC)	M4M2	263	1C		N80-2008-48	TAP SCREW (ACCESSORY)	M1M2
217	1C	*	B07-3361-02	ESCUTCHEON (ACCESSORY)		263	1C		N80-2008-48	TAP SCREW (ACCESSORY)	M4KK1
220	3C		B43-1545-14	BADGE (KENWOOD)		A	3C		N80-2006-48	PAN HEAD TAPTITE SCREW	
221	2C		GE34045-001A	LOCK LEVER		B	3D		N09-6358-05	TAPTITE SCREW	E2
222	2C		GE34046-001A	RELEASE LEVER		C	2C		N09-6758-05	TAPTITE SCREW	
223	1C	*	D10-7139-04	LEVER		D	3D		N35-2610-48	BINDING HEAD MACHINE SCREW	
⚠ DC1	1C		E30-6939-05	DC CORD	K2K3M3	E	2C		N80-2008-43	PAN HEAD TAPTITE SCREW	
⚠ DC1	1C		E30-6939-05	DC CORD	M1M2	G	1D		N86-2604-43	BINDING HEAD TAPTITE SCREW	
⚠ DC1	1C		E30-6939-05	DC CORD	M4KK1	H	1D		N86-2606-48	BINDING HEAD TAPTITE SCREW	
⚠ DC2	1C		E30-6940-05	DC CORD	E3E1E2	266	1C		W01-1664-05	CARRYING CASE (EXCELON)	K3K1
FC1	2D		E39-1077-05	FLAT CABLE		266	1C		W01-1710-05	CARRYING CASE	E1E2
226	3C	*	F07-2237-03	COVER (USB)		266	1C		W01-1710-05	CARRYING CASE	K2E3K
232	2D		F11-1874-03	SHIELDING COVER (MECHA)	K1E1M1	268	1C		W01-1768-15	MICROPHONE (3m)	KK1E1
232	2D		F11-1874-03	SHIELDING COVER (MECHA)	K2K3M3	268	1C		W01-1768-15	MICROPHONE (3m)	M1M2
232	2D		F11-1874-03	SHIELDING COVER (MECHA)	M2	269	1C		W01-2006-05	COMPACT DISC (INST. MANUAL)	E3E1E

K: KDC-BT848U **K1:** KDC-X895 **K2:** KDC-448U **K3:** KDC-X595 **M1:** KDC-U7049BT **M2:** KDC-U7049BTL

M3: KDC-U6049 **M4:** KDC-U6049L **E1:** KDC-BT51U **E2:** KDC-5751SD **E3:** KDC-5051U

⚠ indicates safety critical components.

PARTS LIST

Ref.No.	A d d w	N e w	Parts No.	Description	Dest inati on
DME1	1D	*	X92-6370-04	MECHANISM ASSY (DXM-9B24W)	
SYNTHESIZER UNIT (X15-1552-70)					
C1 -3			CC73HCH1H221J	CHIP C 220PF J	E2
CN1		*	E41-3250-05	PIN ASSY	E2
J1			E68-0826-05	JACK (SD CARD SLOT)	E2
P1			E23-0766-05	TERMINAL	E2
SWITCH UNIT (X16-709x-xx)					
D10 ,11			B30-1779-05	LED (1608,SR)	
ED1	2C	*	B38-1229-05	LCD (107 X 25 DOTS)	
C1			CK73HB0J105K	CHIP C 1.0UF K	
C2 ,3			CK73HB1E103K	CHIP C 0.010UF K	
C4			CK73GB1H103K	CHIP C 0.010UF K	
C5			CK73GB0J225K	CHIP C 2.2UF K	
C7			CK73FB1C105K	CHIP C 1.0UF K	
C9			CK73GB1A105K	CHIP C 1.0UF K	
C11			CK73GB1A105K	CHIP C 1.0UF K	
C13 ,14			CK73HB0J105K	CHIP C 1.0UF K	
C15 ,16			CK73GB1A105K	CHIP C 1.0UF K	
C17 ,18			CK73FB1C105K	CHIP C 1.0UF K	
C19			CK73HB1H472K	CHIP C 4700PF K	
C20			CK73GB1H103K	CHIP C 0.010UF K	
C101			CK73EB1C106K	CHIP C 10UF K	
C102,103			CC73GCH1H471J	CHIP C 470PF J	
C104			CK73GB1H103K	CHIP C 0.010UF K	
CN3		*	E41-3246-05	FLAT CABLE CONNECTOR	
J1		*	E59-0864-05	RECTANGULAR PLUG	
J2			QNZ1057-001	USB CONNECTOR	
J4			QNS0308-001	DIA 3.5 TYPE JACK	
L2			L92-0639-05	CHIP FERRITE	E2
L2			L92-0639-05	CHIP FERRITE	KK1E1
L2			L92-0639-05	CHIP FERRITE	K2K3E3
X1			L78-1409-05	RESONATOR (8MHZ)	
CP3			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP4			RK74HB1J332J	CHIP-COM 3.3K J 1/16W	
CP5 -7			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
CP8 -10			RK74HB1J223J	CHIP-COM 22K J 1/16W	
CP11			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
CP12			RK74HB1J473J	CHIP-COM 47K J 1/16W	
R1			RK73EB2E431J	CHIP R 430 J 1/4W	
R2			RK73EB2E201J	CHIP R 200 J 1/4W	
R3			RK73EB2E391J	CHIP R 390 J 1/4W	
R4			RK73EB2E751J	CHIP R 750 J 1/4W	
R5			RK73EB2E361J	CHIP R 360 J 1/4W	
R6			RK73EB2E561J	CHIP R 560 J 1/4W	
R7			RK73EB2E751J	CHIP R 750 J 1/4W	
R7			RK73EB2E751J	CHIP R 750 J 1/4W	
R8			RK73EB2E361J	CHIP R 360 J 1/4W	K2K3M3 M4E3E2
R9			RK73EB2E561J	CHIP R 560 J 1/4W	
R10			RK73EB2E751J	CHIP R 750 J 1/4W	
R11			RK73EB2E361J	CHIP R 360 J 1/4W	
R12			RK73EB2E561J	CHIP R 560 J 1/4W	
R13			RK73EB2E391J	CHIP R 390 J 1/4W	
R14			RK73EB2E201J	CHIP R 200 J 1/4W	
R15			RK73EB2E431J	CHIP R 430 J 1/4W	
R16 ,17			RK73EB2E821J	CHIP R 820 J 1/4W	
R21			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R22			RK73GB2A473J	CHIP R 47K J 1/10W	
R23			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R24			RK73GB2A103J	CHIP R 10K J 1/10W	
R25			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R26			RK73HB1J104J	CHIP R 100K J 1/16W	E2
R26			RK73HB1J104J	CHIP R 100K J 1/16W	KK1E1
R26			RK73HB1J104J	CHIP R 100K J 1/16W	K2K3E
R26			RK73HB1J823J	CHIP R 82K J 1/16W	M4M2
R26			RK73HB1J913J	CHIP R 91K J 1/16W	M3M1
R33			RK73HB1J101J	CHIP R 100 J 1/16W	
R35			RK73HB1J101J	CHIP R 100 J 1/16W	
R44 ,45			RK73HB1J220J	CHIP R 22 J 1/16W	
R111			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R120			RK73EB2E101J	CHIP R 100 J 1/4W	
R121			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R131			RK73GB2A000J	CHIP R 0.0 J 1/10W	M2
R131			RK73GB2A000J	CHIP R 0.0 J 1/10W	M3M4
S1 -8			S70-0960-05	TACT SWITCH	
S9		*	S70-0965-05	TACT SWITCH	
D1 ,2		*	NSSM065T-X	LED	
D4 -6		*	NSSM065T-X	LED	
D8 ,9		*	NSSM065T-X	LED	
D109			HZM6.8ZMWA-E	ZENER DIODE	
D110			DA204U	DIODE	
IC1		*	W05-1664-00	MICROCONTROLLER IC	E2
IC1		*	W05-1664-00	MICROCONTROLLER IC	KK1E1
IC1		*	W05-1664-00	MICROCONTROLLER IC	K2K3E
IC1		*	W05-1665-00	MICROCONTROLLER IC	M3M1
IC1		*	W05-1666-00	MICROCONTROLLER IC	M2M4
IC3			PIC95603	ANALOGUE IC	
Q1 -12			RT1N237M-T111	TRANSISTOR	K2K3M
Q1 -12			RT1N237M-T111	TRANSISTOR	M4E3E
Q1 -3			RT1N237M-T111	TRANSISTOR	KK1E1
Q1 -3			RT1N237M-T111	TRANSISTOR	M1M2
Q5 -12			RT1N237M-T111	TRANSISTOR	KK1E1
Q5 -12			RT1N237M-T111	TRANSISTOR	M1M2
Q13 ,14			RT1N436M-T111	TRANSISTOR	
CD PLAYER UNIT (X32-6250-02) IN CD MECHA					
C1			CK73FB0J106K	CHIP C 10UF K	
C3			CC73GCH1H680J	CHIP C 68PF J	
C4			CK73GB1A105K	CHIP C 1.0UF K	
C6			CK73FB1C105K	CHIP C 1.0UF K	
C8			CK73GB1H222K	CHIP C 2200PF K	
C9 ,10			CK73GB1C104K	CHIP C 0.10UF K	
C11			CK73GB1H153K	CHIP C 0.015UF K	
C12			CK73GB1C104K	CHIP C 0.10UF K	
C13			CK73GB1H332K	CHIP C 3300PF K	
C14			CK73GB1H103K	CHIP C 0.010UF K	
C15			CK73GB1C333K	CHIP C 0.033UF K	

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

▲ indicates safety critical components.

PARTS LIST

CD PLAYER UNIT (X32-6250-02) IN CD MECHA

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
C16			CK73GB1C104K	CHIP C 0.10UF K	
C18			CK73GB1H153K	CHIP C 0.015UF K	
C19			CK73GB1H103K	CHIP C 0.010UF K	
C20			CK73GB1C104K	CHIP C 0.10UF K	
C22			CK73GB1H103K	CHIP C 0.010UF K	
C23			CK73GB1H153K	CHIP C 0.015UF K	
C24			CC73GCH1H470J	CHIP C 47PF J	
C25			CK73GB1C104K	CHIP C 0.10UF K	
C26			CK73GB1A105K	CHIP C 1.0UF K	
C27			CK73GB1C104K	CHIP C 0.10UF K	
C29 ,30			CK73GB1C104K	CHIP C 0.10UF K	
C31			CK73GB1A105K	CHIP C 1.0UF K	
C36			CK73GB1A105K	CHIP C 1.0UF K	
C41 ,42			CK73GB1C104K	CHIP C 0.10UF K	
C43 ,44			CK73GB1H102K	CHIP C 1000PF K	
C45			CK73GB1H103K	CHIP C 0.010UF K	
C46			CK73GB1A105K	CHIP C 1.0UF K	
C47			CC73GCH1H560J	CHIP C 56PF J	
C48			CC73GCH1H101J	CHIP C 100PF J	
C49			CK73GB1A105K	CHIP C 1.0UF K	
C50			CK73FB1A225K	CHIP C 2.2UF K	
C51			CK73FB0J106K	CHIP C 10UF K	
C54			CK73FB0J106K	CHIP C 10UF K	
C57			CK73GB1C104K	CHIP C 0.10UF K	
C59			CK73GB1H472K	CHIP C 4700PF K	
C61			CK73GB1C104K	CHIP C 0.10UF K	
C101			CK73GB1A105K	CHIP C 1.0UF K	
C103			CK73GB1C104K	CHIP C 0.10UF K	
CN1			E41-2954-05	FLAT CABLE CONNECTOR	
CN2			E41-2630-05	FLAT CABLE CONNECTOR	
X1			L78-1221-05	RESONATOR (16.93MHZ)	
CP7			RK74GB1J103J	CHIP-COM 10K J 1/16W	
R1			RK73GB2A560J	CHIP R 56 J 1/10W	
R2			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R3			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R4			RK73GB2A104J	CHIP R 100K J 1/10W	
R5			RK73GB2A225J	CHIP R 2.2M J 1/10W	
R6			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R7			RK73GB2A221J	CHIP R 220 J 1/10W	
R8			RK73GB2A622J	CHIP R 6.2K J 1/10W	
R9			RK73GB2A913J	CHIP R 91K J 1/10W	
R10			RK73GB2A334J	CHIP R 330K J 1/10W	
R11			RK73GB2A153J	CHIP R 15K J 1/10W	
R13			RK73GB2A104J	CHIP R 100K J 1/10W	
R14			RK73GB2A103J	CHIP R 10K J 1/10W	
R15			RK73GB2A101J	CHIP R 100 J 1/10W	
R17 ,18			RK73GB2A103J	CHIP R 10K J 1/10W	
R25			RK73GB2A103J	CHIP R 10K J 1/10W	
R27			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R39			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R40			RK73GB2A681J	CHIP R 680 J 1/10W	
R43 ,44			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R49			RK73GB2A393J	CHIP R 39K J 1/10W	

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R50			RK73GB2A363J	CHIP R 36K J 1/10W	
R51			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R52 -58			RK73GB2A101J	CHIP R 100 J 1/10W	
R59			RK73GB2A204J	CHIP R 200K J 1/10W	
R64			RK73GB2A223J	CHIP R 22K J 1/10W	
R65			RK73GB2A333J	CHIP R 33K J 1/10W	
R69 -73			RK73GB2A101J	CHIP R 100 J 1/10W	
R74 ,75			RK73GB2A103J	CHIP R 10K J 1/10W	
R76			RK73GB2A202J	CHIP R 2.0K J 1/10W	
R102			RK73GB2A102J	CHIP R 1.0K J 1/10W	
S1 ,2			S68-0924-05	PUSH SWITCH	
D2			DAP202U	DIODE	
D3 ,4			DA204U	DIODE	
IC3			BD8222EFV	ANALOGUE IC	
IC4			JCV8023	MOS-IC	
IC5			XC6415S001P1	MOS-IC	
Q1		*	2SA2188-T1(E)	TRANSISTOR	
Q14			RUE003N02	FET	
ELECTRIC UNIT (X34-69xx-xx)					
C1			C90-6906-05	ELECTRO 3300UF 16WV	
C4			CK73GB1C104K	CHIP C 0.10UF K	
C6			CK73GB1H104K	CHIP C 0.10UF K	E3E1E
C6 ,7			CK73GB1H104K	CHIP C 0.10UF K	K2K3M
C6 ,7			CK73GB1H104K	CHIP C 0.10UF K	M1M2
C6 ,7			CK73GB1H104K	CHIP C 0.10UF K	M4KK1
C8			CD04BN1C221M	ELECTRO 220UF 16WV	
C9			CD04AV0J101M	ELECTRO 100UF 6.3WV	
C11 -13			CK73GB1C104K	CHIP C 0.10UF K	
C15			CK73GB1C224K	CHIP C 0.22UF K	
C21			CK73GB1H103K	CHIP C 0.010UF K	
C22 ,23			CK73GB1A105K	CHIP C 1.0UF K	
C24			CD04AV0J470M	ELECTRO 47UF 6.3WV	
C52			CK73FB0J106K	CHIP C 10UF K	
C53			CC73HCH1H151J	CHIP C 150PF J	
C54			CK73GB1C104K	CHIP C 0.10UF K	
C55			CK73GB1H102K	CHIP C 1000PF K	
C58			CK73EB1H475K	CHIP C 4.7UF K	
C71			CK73HB1A104K	CHIP C 0.10UF K	
C72			CK73GB1C104K	CHIP C 0.10UF K	
C73		*	C90-6990-05	ELECTRO 220UF 10WV	
C91			CD04AV1V100M	ELECTRO 10UF 35WV	K3K1
C92 ,93			CK73GB1H102K	CHIP C 1000PF K	K3K1
C94			CD04AV1V100M	ELECTRO 10UF 35WV	K3K1
C101			CK73HB1E103K	CHIP C 0.010UF K	
C102			CK73GB1H104K	CHIP C 0.10UF K	
C105			CK73HB0J105K	CHIP C 1.0UF K	
C106			CK73GB1H223K	CHIP C 0.022UF K	
C201			CK73GB1C104K	CHIP C 0.10UF K	
C202,203			CC73HCH1H220J	CHIP C 22PF J	
C204			CK73GB1C104K	CHIP C 0.10UF K	
C205			CK73GB1H102K	CHIP C 1000PF K	
C210-212			CK73HB1A104K	CHIP C 0.10UF K	
C213			CK73GB1C104K	CHIP C 0.10UF K	
C214-216			CK73HB1A104K	CHIP C 0.10UF K	

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

▲ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-69xx-xx)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
C217,218			CC73HCH1H080D	CHIP C 8.0PF D		C603			CD04AV0J470M	ELECTRO 47UF 6.3WV	K1E2
C261			CK73HB1A104K	CHIP C 0.10UF K		C603			CD04AV0J470M	ELECTRO 47UF 6.3WV	K2K3M
C301,302			CD04AV1HR47M	ELECTRO 0.47UF 50WV		C603			CD04AV0J470M	ELECTRO 47UF 6.3WV	M4E3K
C303,304			CK73GB1C104K	CHIP C 0.10UF K		C701-706			CD04AV1V100M	ELECTRO 10UF 35WV	
C305,306			CK73GB1H102K	CHIP C 1000PF K		C711-716			CK73GB1H102K	CHIP C 1000PF K	
C307			CD04AV0J470M	ELECTRO 47UF 6.3WV		C801-804			CK73GB1C224K	CHIP C 0.22UF K	
C308			CK73GB1H103K	CHIP C 0.010UF K		C805			CD04AV1C330M	ELECTRO 33UF 16WV	
C311			CC73GCH1H040C	CHIP C 4.0PF C		C806			CK73GB1A105K	CHIP C 1.0UF K	
C401			CK73GB1A105K	CHIP C 1.0UF K		C807			CK73HB0J105K	CHIP C 1.0UF K	
C402			CK73GB1A474K	CHIP C 0.47UF K		C808			CK73GB1A105K	CHIP C 1.0UF K	
C403			CK73GB1A105K	CHIP C 1.0UF K		C821-828			CC73GCH1H471J	CHIP C 470PF J	
C404			CK73GB1A474K	CHIP C 0.47UF K		C901			CK73GB1C104K	CHIP C 0.10UF K	KK1E1
C405-409			CK73GB1A105K	CHIP C 1.0UF K		C901			CK73GB1C104K	CHIP C 0.10UF K	M1M2
C410	*		CD04AV1H2R2M	ELECTRO 2.2UF 50WV		C902			CK73FB0J106K	CHIP C 10UF K	KK1E1
C411			CD04AV1V100M	ELECTRO 10UF 35WV	E2M1M2	C902			CK73FB0J106K	CHIP C 10UF K	M1M2
C411			CD04AV1V100M	ELECTRO 10UF 35WV	K2E3M3	C903,904			CC73GCH1H101J	CHIP C 100PF J	KK1E1
C411			CD04AV1V100M	ELECTRO 10UF 35WV	M4KE1	C903,904			CC73GCH1H101J	CHIP C 100PF J	M1M2
C411,412			CD04AV1C470M	ELECTRO 47UF 16WV	K3K1	C905,906			CK73GB1C104K	CHIP C 0.10UF K	KK1E1
C412			CD04AV1C470M	ELECTRO 47UF 16WV	E2M1M2	C905,906			CK73GB1C104K	CHIP C 0.10UF K	M1M2
C412			CD04AV1C470M	ELECTRO 47UF 16WV	K2E3M3	C908			CD04AV1V100M	ELECTRO 10UF 35WV	KK1E1
C412			CD04AV1C470M	ELECTRO 47UF 16WV	M4KE1	C908			CD04AV1V100M	ELECTRO 10UF 35WV	M1M2
C415-418			CC73GCH1H100D	CHIP C 10PF D		C909			CK73GB1C104K	CHIP C 0.10UF K	KK1M1
C419			CC73GCH1H470J	CHIP C 47PF J		C909			CK73GB1C104K	CHIP C 0.10UF K	M2E1E
C451			CK73EB1A475K	CHIP C 4.7UF K		C910	*		C90-6989-05	ELECTRO 330UF 6.3WV	KK1E1
C452			CC73GCH1H101J	CHIP C 100PF J		C910	*		C90-6989-05	ELECTRO 330UF 6.3WV	M1M2
C453-456			CK73GB1A105K	CHIP C 1.0UF K		C912			CK73HB1A104K	CHIP C 0.10UF K	KK1E1
C457			CK73GB1H103K	CHIP C 0.010UF K		C912			CK73HB1A104K	CHIP C 0.10UF K	M1M2
C458			CK73GB0J225K	CHIP C 2.2UF K		C913			CK73GB1H102K	CHIP C 1000PF K	KK1E1
C501			CK73GB1H102K	CHIP C 1000PF K		C913			CK73GB1H102K	CHIP C 1000PF K	M1M2
C502			CK73GB1A105K	CHIP C 1.0UF K		C914			CK73GB0J225K	CHIP C 2.2UF K	KK1M1
C505			CK73GB1C224K	CHIP C 0.22UF K		C914			CK73GB0J225K	CHIP C 2.2UF K	M2E1E
C506			CK73GB1C104K	CHIP C 0.10UF K		C915			CK73FB1H334K	CHIP C 0.33UF K	KK1M1
C507			CC73GCH1H090D	CHIP C 9.0PF D		C915			CK73FB1H334K	CHIP C 0.33UF K	M2E1E
C509-511			CK73GB1A105K	CHIP C 1.0UF K		C916,917			CK73GB1C104K	CHIP C 0.10UF K	KK1E1
C512-514			CK73GB1H103K	CHIP C 0.010UF K		C916,917			CK73GB1C104K	CHIP C 0.10UF K	M1M2
C515			CK73GB1C104K	CHIP C 0.10UF K		CN301			E41-1828-05	FLAT CABLE CONNECTOR	
C516			CK73GB1H103K	CHIP C 0.010UF K		CN901			E41-3043-05	PIN ASSY	KK1M1
C517			CK73GB1C104K	CHIP C 0.10UF K		CN901			E41-3043-05	PIN ASSY	M2E1E
C518			CK73GB1H102K	CHIP C 1000PF K	⚠	J1			E58-0991-05	RECTANGULAR RECEPTACLE	
C519			CD04AV1C470M	ELECTRO 47UF 16WV		J301	*		E58-1144-05	RECTANGULAR RECEPTACLE	
C520			CK73GB1C104K	CHIP C 0.10UF K		J601			E56-0855-05	CYLINDRICAL RECEPTACLE	K1E2
C523			CK73GB1H102K	CHIP C 1000PF K		J601			E56-0855-05	CYLINDRICAL RECEPTACLE	K2K3M
C524			CK73GB1C224K	CHIP C 0.22UF K		J601			E56-0855-05	CYLINDRICAL RECEPTACLE	M4E3K
C525			CC73GCH1H270J	CHIP C 27PF J		J701			E63-0972-05	PIN JACK	
C527			CC73GCH1H150J	CHIP C 15PF J		J921			E11-0625-05	PHONE JACK	KK1E1
C528			CC73GCH1H471J	CHIP C 470PF J		J921			E11-0625-05	PHONE JACK	M1M2
C530			CK73GB1H102K	CHIP C 1000PF K		W551	2D		E30-6803-05	CORD WITH PLUG	
C531			CC73GCH1H070D	CHIP C 7.0PF D		F1			F53-0406-05	FUSE (UL,CSA) (2.5A)	
C532			CC73GCH1H060D	CHIP C 6.0PF D		L1			L33-2459-05	CHOKE COIL ASSY	
C533			CC73GCH1H020C	CHIP C 2.0PF C	⚠	L51			L33-2462-05	SMALL FIXED INDUCTOR (22UH)	
C539,540			CC73GCH1H040C	CHIP C 4.0PF C		L52, 53			L92-0639-05	CHIP FERRITE	
C541			CK73GB1H102K	CHIP C 1000PF K		L302			L92-0616-05	CHIP FERRITE	
C601,602			CK73GB1C104K	CHIP C 0.10UF K	K1E2	L401-405			L92-0648-05	CHIP FERRITE	
C601,602			CK73GB1C104K	CHIP C 0.10UF K	K2K3M3						
C601,602			CK73GB1C104K	CHIP C 0.10UF K	M4E3K						

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-69xx-xx)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
L501			L40-4791-58	SMALL FIXED INDUCTOR		R121			RK73EB2E103J	CHIP R 10K J 1/4W	
L502,503			L33-1031-05	SMALL FIXED INDUCTOR		R124			RK73HB1J363J	CHIP R 36K J 1/16W	
L504			L40-2781-58	SMALL FIXED INDUCTOR (0.27UH)		R125			RK73HB1J104J	CHIP R 100K J 1/16W	
L505			L40-4791-58	SMALL FIXED INDUCTOR		R151			RK73HB1J000J	CHIP R 0.0 J 1/16W	K2K3M
L506			L40-4781-58	SMALL FIXED INDUCTOR		R151			RK73HB1J000J	CHIP R 0.0 J 1/16W	M1M2
L507			L40-1891-58	SMALL FIXED INDUCTOR (1.8UH)		R151			RK73HB1J000J	CHIP R 0.0 J 1/16W	M4KK1
L508			L40-4781-58	SMALL FIXED INDUCTOR		R152			RK73HB1J000J	CHIP R 0.0 J 1/16W	E3E1E
L509			L92-0607-05	CHIP FERRITE	K1	R201,202			RK73GB2A102J	CHIP R 1.0K J 1/10W	
L509			L92-0607-05	CHIP FERRITE	K2K3K	R203			RK73GB2A223J	CHIP R 22K J 1/10W	
L551			QQR1872-001	RF COIL		R204			RK73GB2A104J	CHIP R 100K J 1/10W	
X201		*	L77-3846-05	CRYSTAL RESONATOR (12MHZ)		R205			RK73HB1J102J	CHIP R 1.0K J 1/16W	
X202		*	L77-2921-15	CRYSTAL RESONATOR (32.768KHZ)		R206			RK73GB2A100J	CHIP R 10 J 1/10W	
X501			L77-3824-05	CRYSTAL RESONATOR (4.000MHZ)		R207			RK73HB1J153J	CHIP R 15K J 1/16W	
J	2D		N80-3008-48	PAN HEAD TAPTITE SCREW		R208			RK73GB2A100J	CHIP R 10 J 1/10W	
K	2D		N83-3005-48	PAN HEAD TAPTITE SCREW		R209			RK73HB1J153J	CHIP R 15K J 1/16W	
L	2D		N84-3014-48	PAN HEAD TAPTITE SCREW		R212			RK73GB2A473J	CHIP R 47K J 1/10W	K2KE2
M	3D		N86-2606-48	BINDING HEAD TAPTITE SCREW		R213			RK73GB2A473J	CHIP R 47K J 1/10W	K3M4K
N	2D		N89-3010-48	BINDING HEAD TAPTITE SCREW		R213			RK73GB2A473J	CHIP R 47K J 1/10W	M2
CP901			RK74GA1J101J	CHIP-COM 100 J 1/16W	M2E1E2	R213,214			RK73GB2A473J	CHIP R 47K J 1/10W	E3M3E
R1			RD14BB2C102J	RD 1.0K J 1/6W		R213,214			RK73GB2A473J	CHIP R 47K J 1/10W	M1
R2			RK73HB1J102J	CHIP R 1.0K J 1/16W		R214			RK73GB2A223J	CHIP R 22K J 1/10W	M4M2
R51			RK73GH2A303D	CHIP R 30K D 1/10W		R214			RK73GB2A473J	CHIP R 47K J 1/10W	E2
R52			RK73GH2A164D	CHIP R 160K D 1/10W		R215			RK73GB2A223J	CHIP R 22K J 1/10W	M3M1
R53			RK73HB1J164J	CHIP R 160K J 1/16W		R215			RK73GB2A473J	CHIP R 47K J 1/10W	KK1M2
R54			RK73GH2A823D	CHIP R 82K D 1/10W		R215			RK73GB2A473J	CHIP R 47K J 1/10W	K2K3M
R55			RK73GH2A134D	CHIP R 130K D 1/10W		R216			RK73HB1J104J	CHIP R 100K J 1/16W	
R57			RK73HB1J102J	CHIP R 1.0K J 1/16W		R217			RK73GB2A473J	CHIP R 47K J 1/10W	
R59			RK73EB2E150J	CHIP R 15 J 1/4W		R218			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R71			RK73GB2A223J	CHIP R 22K J 1/10W		R219			RK73GB2A473J	CHIP R 47K J 1/10W	
R91			RK73GB2A362J	CHIP R 3.6K J 1/10W	K3K1	R220			RK73HB1J104J	CHIP R 100K J 1/16W	
R92			RK73GB2A432J	CHIP R 4.3K J 1/10W	K3K1	R222			RK73HB1J101J	CHIP R 100 J 1/16W	
R93			RK73GB2A562J	CHIP R 5.6K J 1/10W	K3K1	R223			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R94			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	K3K1	R224,225			RK73HB1J101J	CHIP R 100 J 1/16W	
R95			RK73FB2B102J	CHIP R 1.0K J 1/8W	K3K1	R226,227			RK73HB1J223J	CHIP R 22K J 1/16W	
R96			RK73GB2A222J	CHIP R 2.2K J 1/10W	K3K1	R228,229			RK73GB2A101J	CHIP R 100 J 1/10W	
R97			RK73GB2A101J	CHIP R 100 J 1/10W	K3K1	R230			RK73HB1J223J	CHIP R 22K J 1/16W	
R99			RK73EB2E000J	CHIP R 0.0 J 1/4W	E2M1M2	R231			RK73HB1J101J	CHIP R 100 J 1/16W	
R99			RK73EB2E000J	CHIP R 0.0 J 1/4W	K2E3M3	R232			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R99			RK73EB2E000J	CHIP R 0.0 J 1/4W	M4KE1	R233			RK73HB1J101J	CHIP R 100 J 1/16W	
R101,102			RK73FB2B472J	CHIP R 4.7K J 1/8W		R234			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R103-105			RK73EB2E102J	CHIP R 1.0K J 1/4W		R238			RK73EB2E471J	CHIP R 470 J 1/4W	
R106			RK73EB2E333J	CHIP R 33K J 1/4W		R239			RK73HB1J104J	CHIP R 100K J 1/16W	
R107			RK73HB1J103J	CHIP R 10K J 1/16W		R240			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R108			RK73GB2A223J	CHIP R 22K J 1/10W		R241			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R109			RK73FB2B683J	CHIP R 68K J 1/8W		R261			RK73GB2A223J	CHIP R 22K J 1/10W	
R110			RK73GB2A473J	CHIP R 47K J 1/10W		R262			RK73HB1J223J	CHIP R 22K J 1/16W	
R111			RK73EB2E203J	CHIP R 20K J 1/4W		R263			RK73HB1J333J	CHIP R 33K J 1/16W	
R112			RK73HB1J104J	CHIP R 100K J 1/16W		R266,267			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R113			RK73GB2A103J	CHIP R 10K J 1/10W		R271			RK73HB1J101J	CHIP R 100 J 1/16W	
R114,115			RK73HB1J103J	CHIP R 10K J 1/16W		R301			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R117			RK73GB2A123J	CHIP R 12K J 1/10W		R302			RK73HB1J101J	CHIP R 100 J 1/16W	
R118			RK73GB2A683J	CHIP R 68K J 1/10W		R303			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R119			RK73HB1J103J	CHIP R 10K J 1/16W		R304			RK73HB1J101J	CHIP R 100 J 1/16W	
R120			RK73GB2A104J	CHIP R 100K J 1/10W		R305,306			RK73GB2A222J	CHIP R 2.2K J 1/10W	
						R307			RK73HB1J222J	CHIP R 2.2K J 1/16W	

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-69xx-xx)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R308			RK73GB2A222J	CHIP R 2.2K J 1/10W		R605			RK73EB2E101J	CHIP R 100 J 1/4W	K2K3M
R309,310			RK73HB1J101J	CHIP R 100 J 1/16W		R605			RK73EB2E101J	CHIP R 100 J 1/4W	M4E3K
R311			RK73GB2A101J	CHIP R 100 J 1/10W		R606,607			RK73EB2E473J	CHIP R 47K J 1/4W	K1E2
R312,313			RK73HB1J101J	CHIP R 100 J 1/16W		R606,607			RK73EB2E473J	CHIP R 47K J 1/4W	K2K3M
R314			RK73GB2A223J	CHIP R 22K J 1/10W		R606,607			RK73EB2E473J	CHIP R 47K J 1/4W	M4E3K
R315			RK73GB2A100J	CHIP R 10 J 1/10W		R608			RK73EB2E101J	CHIP R 100 J 1/4W	K1E2
R316,317			RK73HB1J473J	CHIP R 47K J 1/16W		R608			RK73EB2E101J	CHIP R 100 J 1/4W	K2K3M
R321			RK73GB2A473J	CHIP R 47K J 1/10W		R608			RK73EB2E101J	CHIP R 100 J 1/4W	M4E3K
R323			RK73GB2A102J	CHIP R 1.0K J 1/10W		R609			RK73EB2E473J	CHIP R 47K J 1/4W	K1E2
R324			RK73EB2E102J	CHIP R 1.0K J 1/4W		R609			RK73EB2E473J	CHIP R 47K J 1/4W	K2K3M
R327			RK73HB1J473J	CHIP R 47K J 1/16W		R609			RK73EB2E473J	CHIP R 47K J 1/4W	M4E3K
R331,332			RK73EB2E102J	CHIP R 1.0K J 1/4W		R610			RK73EB2E472J	CHIP R 4.7K J 1/4W	K1E2
R333			RK73EB2E222J	CHIP R 2.2K J 1/4W		R610			RK73EB2E472J	CHIP R 4.7K J 1/4W	K2K3M
R334-336			RK73EB2E102J	CHIP R 1.0K J 1/4W		R610			RK73EB2E472J	CHIP R 4.7K J 1/4W	M4E3K
R337,338			RK73GB2A103J	CHIP R 10K J 1/10W		R611			RK73EB2E432J	CHIP R 4.3K J 1/4W	K1E2
R339,340			RK73EB2E100J	CHIP R 10 J 1/4W		R611			RK73EB2E432J	CHIP R 4.3K J 1/4W	K2K3M
R341			RK73EB2E4R7J	CHIP R 4.7 J 1/4W		R611			RK73EB2E432J	CHIP R 4.3K J 1/4W	M4E3K
R342			RK73EB2E102J	CHIP R 1.0K J 1/4W		R612			RK73EB2E472J	CHIP R 4.7K J 1/4W	K1E2
R343			RK73GB2A102J	CHIP R 1.0K J 1/10W		R612			RK73EB2E472J	CHIP R 4.7K J 1/4W	K2K3M
R346			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1M1	R612			RK73EB2E472J	CHIP R 4.7K J 1/4W	M4E3K
R346			RK73GB2A000J	CHIP R 0.0 J 1/10W	M2E1E2	R616			RK73GB2A473J	CHIP R 47K J 1/10W	K1E2
R347			RK73GB2A000J	CHIP R 0.0 J 1/10W	K2K3M3	R616			RK73GB2A473J	CHIP R 47K J 1/10W	K2K3M
R347			RK73GB2A000J	CHIP R 0.0 J 1/10W	M4E3	R616			RK73GB2A473J	CHIP R 47K J 1/10W	M4E3K
R401,402			RK73GB2A103J	CHIP R 10K J 1/10W		R617			RK73HB1J104J	CHIP R 100K J 1/16W	K1E2
R403			RK73HB1J472J	CHIP R 4.7K J 1/16W		R617			RK73HB1J104J	CHIP R 100K J 1/16W	K2K3M
R404			RK73EB2E2R2J	CHIP R 2.2 J 1/4W		R617			RK73HB1J104J	CHIP R 100K J 1/16W	M4E3K
R451			RK73GB2A473J	CHIP R 47K J 1/10W		R618			RK73GB2A683J	CHIP R 68K J 1/10W	K1E2
R452			RK73GB2A333J	CHIP R 33K J 1/10W		R618			RK73GB2A683J	CHIP R 68K J 1/10W	K2K3M
R453			RK73GB2A473J	CHIP R 47K J 1/10W		R618			RK73GB2A683J	CHIP R 68K J 1/10W	M4E3K
R454			RK73GB2A102J	CHIP R 1.0K J 1/10W		R619,620			RK73HB1J683J	CHIP R 68K J 1/16W	K1E2
R455			RK73HB1J821J	CHIP R 820 J 1/16W		R619,620			RK73HB1J683J	CHIP R 68K J 1/16W	K2K3M
R456			RK73HB1J473J	CHIP R 47K J 1/16W		R619,620			RK73HB1J683J	CHIP R 68K J 1/16W	M4E3K
R457			RK73HB1J104J	CHIP R 100K J 1/16W		R701,702			RK73GB2A331J	CHIP R 330 J 1/10W	
R458,459			RK73HB1J103J	CHIP R 10K J 1/16W		R703,704			RK73HB1J223J	CHIP R 22K J 1/16W	
R460,461			RK73HB1J334J	CHIP R 330K J 1/16W		R705,706			RK73FB2B181J	CHIP R 180 J 1/8W	
R462			RK73HB1J123J	CHIP R 12K J 1/16W		R707,708			RK73GB2A331J	CHIP R 330 J 1/10W	
R463			RK73HB1J473J	CHIP R 47K J 1/16W		R709,710			RK73HB1J223J	CHIP R 22K J 1/16W	
R505			RK73GB2A472J	CHIP R 4.7K J 1/10W		R711,712			RK73FB2B181J	CHIP R 180 J 1/8W	
R506			RK73EB2E220J	CHIP R 22 J 1/4W		R713,714			RK73GB2A331J	CHIP R 330 J 1/10W	
R507,508			RK73GB2A221J	CHIP R 220 J 1/10W		R715,716			RK73HB1J223J	CHIP R 22K J 1/16W	
R513,514			RK73GB2A684J	CHIP R 680K J 1/10W		R717,718			RK73FB2B181J	CHIP R 180 J 1/8W	
R515,516			RK73GB2A332J	CHIP R 3.3K J 1/10W		R801			RK73HB1J333J	CHIP R 33K J 1/16W	
R518			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1E2M1	R802			RK73HB1J473J	CHIP R 47K J 1/16W	
R518			RK73GB2A000J	CHIP R 0.0 J 1/10W	E3M3M4	R803			RK73HB1J331J	CHIP R 330 J 1/16W	
R518			RK73GB2A000J	CHIP R 0.0 J 1/10W	M2	R804			RK73GB2A223J	CHIP R 22K J 1/10W	
R519,520			RK73GB2A221J	CHIP R 220 J 1/10W		R805			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R528			RK73EB2E000J	CHIP R 0.0 J 1/4W	K1E1	R806			RK73GB2A100J	CHIP R 10 J 1/10W	
R528			RK73EB2E000J	CHIP R 0.0 J 1/4W	K2K3K	R807,808			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R601,602			RK73EB2E100J	CHIP R 10 J 1/4W	K1E2	R809			RK73GB2A473J	CHIP R 47K J 1/10W	
R601,602			RK73EB2E100J	CHIP R 10 J 1/4W	K2K3M3	R810			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R601,602			RK73EB2E100J	CHIP R 10 J 1/4W	M4E3K	R821			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R603			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	K1E2	R822,823			RK73HB1J101J	CHIP R 100 J 1/16W	
R603			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	K2K3M3	R901			RK73HB1J101J	CHIP R 100 J 1/16W	E2
R603			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	M4E3K	R901			RK73HB1J220J	CHIP R 22 J 1/16W	KK1E1
R605			RK73EB2E101J	CHIP R 100 J 1/4W	K1E2	R901			RK73HB1J220J	CHIP R 22 J 1/16W	M1M2

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-69xx-xx)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R902			RK73HB1J473J	CHIP R 47K J 1/16W	KK1M1	D611			RKZ6.8KG(B2)	ZENER DIODE	K2K3M
R902			RK73HB1J473J	CHIP R 47K J 1/16W	M2E1E2	D611			RKZ6.8KG(B2)	ZENER DIODE	M4E3K
R903,904			RK73GB2A473J	CHIP R 47K J 1/10W	KK1E1	D701,702			MC2846-T111	DIODE	
R903,904			RK73GB2A473J	CHIP R 47K J 1/10W	M1M2	D801			MC2846-T111	DIODE	
R905,906			RK73GB2A223J	CHIP R 22K J 1/10W	KK1E1	D921,922			RKZ4.7KG(B2)	ZENER DIODE	KK1E1
R905,906			RK73GB2A223J	CHIP R 22K J 1/10W	M1M2	D921,922			RKZ4.7KG(B2)	ZENER DIODE	M1M2
R907			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	KK1E1	IC1			BD49131-V4	ANALOGUE IC	
R907			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	M1M2	IC21			R1114N331B-TR	ANALOGUE IC	
R908,909			RK73GB2A103J	CHIP R 10K J 1/10W	KK1E1	IC51			MP2562DS-X	ANALOGUE IC	
R908,909			RK73GB2A103J	CHIP R 10K J 1/10W	M1M2	IC71			BD2224G	MOS-IC	
R913			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1E1	IC201	*		W05-1658-00	MCU	K2K3M
R913			RK73HB1J000J	CHIP R 0.0 J 1/16W	M1M2	IC201	*		W05-1658-00	MCU	M4
R913			RK73HB1J330J	CHIP R 33 J 1/16W	E2	IC201	*		W05-1659-00	MCU	E3
R914			RK73GB2A473J	CHIP R 47K J 1/10W	E2	IC201	*		W05-1660-00	MCU	E2
R915			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1E1	IC201	*		W05-1661-00	MCU	KK1M1
R915			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1M2	IC201	*		W05-1661-00	MCU	M2
R917			RK73EB2E000J	CHIP R 0.0 J 1/4W	KK1E1	IC201	*		W05-1662-00	MCU	E1
R917			RK73EB2E000J	CHIP R 0.0 J 1/4W	M1M2	IC202	*		XC6119N28AN-G	MOS-IC	
R921,922			RK73EB2E101J	CHIP R 100 J 1/4W	KK1E1	IC203			EX24016ATAS0A	ROM IC	
R921,922			RK73EB2E101J	CHIP R 100 J 1/4W	M1M2	IC261			MFI341S2162	MICROPROCESSOR IC	
R923,924			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1E1	IC301			TC7SET125FU-F	MOS-IC	
R923,924			RK73HB1J000J	CHIP R 0.0 J 1/16W	M1M2	IC401			E-TDA7415CB	ANALOGUE IC	
R951			RK73HB1J101J	CHIP R 100 J 1/16W	E2	IC451			NJM4580V-ZB	ANALOGUE IC	
R952			RK73HB1J473J	CHIP R 47K J 1/16W	E2	IC501			TEF6614TV1S3-X	ANALOGUE IC	E3E1E
R953			RK73GB2A473J	CHIP R 47K J 1/10W	E2	IC501			TEF6614TV1S4-X	ANALOGUE IC	K2K3M
R954			RK73HB1J101J	CHIP R 100 J 1/16W	E2	IC501			TEF6614TV1S4-X	ANALOGUE IC	M1M2
R955			RK73HB1J102J	CHIP R 1.0K J 1/16W	E2	IC501			TEF6614TV1S4-X	ANALOGUE IC	M4KK1
R956			RK73HB1J473J	CHIP R 47K J 1/16W	E2	IC601			TC74VHCT08AFT	MOS-IC	K1E2
S301			S70-0959-05	TACT SWITCH		IC601			TC74VHCT08AFT	MOS-IC	K2K3M
D1			S2V60-5009F46	DIODE		IC601			TC74VHCT08AFT	MOS-IC	M4E3K
D2			HZS9-E(A1)	ZENER DIODE		IC602			TC7SET08FU-F	MOS-IC	K1E2
D3			1SR154-400	DIODE		IC602			TC7SET08FU-F	MOS-IC	K2K3M
D4			HSS4148	DIODE		IC801			E-TDA7851A	ANALOGUE IC	M4E3K
D6			HSS4148	DIODE		IC802			74HCT2G08DP	MOS-IC	
D51			CMS14	DIODE		IC901			NJM4565V-ZB	ANALOGUE IC	KK1E1
D52			1SS355	DIODE		IC901			NJM4565V-ZB	ANALOGUE IC	M1M2
D91			1SR154-400	DIODE	K3K1	IC902			NJM2845DL133B	ANALOGUE IC	KK1M1
D92,93			UDZW5.6(B)	ZENER DIODE	K3K1	IC902			NJM2845DL133B	ANALOGUE IC	M2E1E
D101-104			1SR154-400	DIODE		Q1			KTA1046-P	TRANSISTOR	
D105			MC2846-T111	DIODE		Q2			2SC4081	TRANSISTOR	
D106-108			UDZW6.8(B)	ZENER DIODE		Q3			RT1N241M-T111	TRANSISTOR	
D201			RB521S-30	DIODE		Q4			RT1P241M-T111	TRANSISTOR	
D301			MC2850-T111	DIODE		Q5			RT1N436M-T111	TRANSISTOR	K2K3M
D302-304			RKZ6.8KG(B2)	ZENER DIODE		Q5			RT1N436M-T111	TRANSISTOR	M1M2
D305,306			LVS10C270S030	VARISTOR		Q5			RT1N436M-T111	TRANSISTOR	M4KK1
D307			HZM6.8ZMWA-E	ZENER DIODE		Q6			RT1P241M-T111	TRANSISTOR	K2K3M
D308			MC2850-T111	DIODE		Q6			RT1P241M-T111	TRANSISTOR	M1M2
D401-403			MC2846-T111	DIODE		Q6			RT1P241M-T111	TRANSISTOR	M4KK1
D451			MC2850-T111	DIODE		Q7			RT1N436M-T111	TRANSISTOR	
D502			MC2850-T111	DIODE		Q8			RT1P241M-T111	TRANSISTOR	
D601-605			RKZ6.8KG(B2)	ZENER DIODE	K1E2	Q9			RT1N436M-T111	TRANSISTOR	
D601-605			RKZ6.8KG(B2)	ZENER DIODE	K2K3M3	Q10			RT1P241M-T111	TRANSISTOR	
D601-605			RKZ6.8KG(B2)	ZENER DIODE	M4E3K	Q51			RT1N436M-T111	TRANSISTOR	
D611			RKZ6.8KG(B2)	ZENER DIODE	K1E2	Q91			2SC4081	TRANSISTOR	K3K1

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-69xx-xx)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
Q92			2SC5053	TRANSISTOR	K3K1	51			G01-4688-14	EXTENSION SPRING	
Q93			RT1P241M-T111	TRANSISTOR	K3K1	52	3A		G01-4692-24	TORSION COIL SPRING	
Q94			RT1N436M-T111	TRANSISTOR	K3K1	54	3A		G02-1588-04	FLAT SPRING	
Q101-104			2SC4081	TRANSISTOR		55	1B		G13-1297-04	CUSHION	
Q105			RT1N441M-T111	TRANSISTOR		56	1B		G13-1299-14	CUSHION	
Q301			RT1P237M-T111	TRANSISTOR	KK1M1	57	1A		G16-1715-04	SHEET	
Q301			RT1P237M-T111	TRANSISTOR	M2E1E2						
Q301,302			RT1P237M-T111	TRANSISTOR	K2K3M3	61	1B		J11-0675-03	CLAMPER	
Q301,302			RT1P237M-T111	TRANSISTOR	M4E3	64	2A		J19-7210-21	HOLDER	
Q451			2SC4081	TRANSISTOR		65	2B		J19-7225-04	HOLDER	
Q701-706			RT1N430M-T111	TRANSISTOR		66	1B		J22-0706-03	MOUNTING HARDWARE	
Q707,708			RT1P144M-T111	TRANSISTOR		67	1A		J22-0707-12	MOUNTING HARDWARE	
Q951			2SB1689	TRANSISTOR	E2	68	1B		J90-1166-11	GUIDE	
TH801			PRF18BE471QS2	POSITIVE RESISTOR		69	2B		J90-1168-03	RAIL	
A901			W02-5374-15	ELECTRIC CIRCUIT MODULE	KK1E1	A	1A		N09-6108-15	TAPTITE SCREW (M2X3.5)	
A901			W02-5374-15	ELECTRIC CIRCUIT MODULE	M1M2	B	2B		N09-6426-15	MACHINE SCREW	
MECHANISM ASSY (X92-6370-04) DXM-9B24W						C	2B		N09-6735-05	TAPTITE SCREW	
1	2B		A10-5450-63	CHASSIS ASSY		D	2B		N09-6737-15	MACHINE SCREW	
3	3B		A10-5452-41	CHASSIS		E	2B		N09-6738-15	TAPTITE SCREW	
4	1B		A10-5453-32	CHASSIS		F	2A		N19-2335-14	FLAT WASHER	
12	3A		D10-4993-52	LEVER		G	2B		N35-2003-48	BINDING HEAD MACHINE SCREW	
13	1B		D10-4991-22	ARM		H	2B		N39-1720-48	PAN HEAD MACHINE SCREW	
14	1B		D10-4992-13	ARM							
15	2A		D10-4994-02	SLIDER		76	2A		S68-0921-05	PUSH SWITCH	
16	2A		D10-4995-03	SLIDER		DM1	2B		X94-2090-00	SPINDLE MOTOR ASSY	
17	2B		D10-4996-02	SLIDER		DM2	2B		X94-2100-00	FEED MOTOR ASSY (LOAD/SLED)	
18	2A		D10-4997-03	LEVER		DPU1	2B		X93-2280-00	OPTICAL PICKUP ASSY	
19	1A		D10-4998-03	ARM							
20	2A		D10-4999-03	ARM							
21	2A		D10-7001-03	ARM							
22	2A		D10-7002-03	ARM							
23	2A		D10-7003-03	ARM							
24	2A		D13-2445-04	GEAR							
25	2A		D13-2446-04	GEAR							
27	2A		D13-2448-04	GEAR							
28	2A		D13-2449-04	GEAR							
29	2A		D13-2450-04	GEAR							
30	2A		D13-2451-04	GEAR							
31	2A		D13-2452-04	GEAR							
32	2A		D13-2453-04	GEAR							
33	2A		D13-2454-04	GEAR							
34	2A		D13-2455-04	GEAR							
35	2B		D13-2456-03	RACK (GEAR)							
36	2A		D14-1028-04	ROLLER							
37	3A		D21-2507-04	SHAFT							
38	2B		D21-2508-04	SHAFT							
39	3A		D23-0963-04	RETAINER							
40	3B		D39-0277-15	DAMPER							
41	3B		D39-0278-15	DAMPER							
46	1B		G01-4682-34	TORSION COIL SPRING							
47	3A		G01-4756-04	EXTENSION SPRING							
48	2A		G01-4684-04	EXTENSION SPRING							
49	2B		G01-4685-04	EXTENSION SPRING							
50	1B		G01-4686-14	EXTENSION SPRING							

K: KDC-BT848U K1: KDC-X895 K2: KDC-448U K3: KDC-X595 M1: KDC-U7049BT M2: KDC-U7049BTL

M3: KDC-U6049 M4: KDC-U6049L E1: KDC-BT51U E2: KDC-5751SD E3: KDC-5051U

⚠ indicates safety critical components.