
2. EXPLODED VIEWS AND PARTS LIST

2.1 PACKING

(DEH-P350/XM/UC, DEH-P350/XN/UC, DEH-P3500/XM/UC, DEH-P3500/XN/UC)



NOTE:

- Parts marked by "*" are generally unavailable because they are not in our Master Spare Parts List.
- Screws adjacent to ∇ mark on the product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual.
  (In the case of no amount instructions, apply as you think it appropriate.)

(1) PACKING(DEH-P350/XM/UC, DEH-P350/XN/UC, DEH-P3500/XM/UC, DEH-P3500/XN/UC) SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Cord Assy	CDE7154
	2	Accessory Assy	CEA3376
	3	Spring	CBH1650
	4	Screw Assy	CEA3445
	5	Fixing Screw	BPZ20P060FZK
	6	Screw	CBA1002
*	7	Polyethylene Bag	CEG-127
	8	Screw	CRZ50P090FTC
	9	Screw	TRZ50P080FTC
*	10	Polyethylene Bag	CEG-158
	11	Handle	CNC5395
	12	Holder	CND1249
	13	Holder	CND1250
	14	Bush	CNV3930
	15	Polyethylene Bag	CEG1173

Mark	No.	Description	Part No.
*	16	Battery	CEX1065
	17	Carton	See Contrast table(2)
	18	Contain Box	See Contrast table(2)
	19	Protector	CHP2663
	20	Protector	CHP2664
	21-1	Owner's Manual	See Contrast table(2)
	21-2	Installation Manual	See Contrast table(2)
*	21-3	Warranty Card	See Contrast table(2)
*	21-4	Card	See Contrast table(2)
*	21-5	Caution Card	See Contrast table(2)
	22	Case Assy	CXB3520
	23	Remote Control Unit	CXC1265

(2) CONTRAST TABLE

DEH-P350/XM/UC, DEH-P350/XN/UC, DEH-P3500/XM/UC and DEH-P3500/XN/UC are constructed the same except for the following:


Mark No.	Symbol and Description	Part No. DEH-P350/XM/UC	Part No. DEH-P3500/XM/UC
17	Carton	CHG4787	CHG4788
18	Contain Box	CHL4787	CHL4788
21-1	Owner's Manual	CRD3697	CRD3699
21-2	Installation Manual	CRD3698	CRD3700
* 21-3	Warranty Card	CRY1070	Not used
* 21-4	Card	Not used	ARY1048
* 21-5	Caution Card	Not used	CRP1294

Mark No.	Symbol and Description	Part No. DEH-P350/XN/UC	Part No. DEH-P3500/XN/UC
17	Carton	CHG4931	CHG4930
18	Contain Box	CHL4931	CHL4930
21-1	Owner's Manual	CRD3697	CRD3699
21-2	Installation Manual	CRD3698	CRD3700
* 21-3	Warranty Card	CRY1070	Not used
* 21-4	Card	Not used	ARY1048
* 21-5	Caution Card	Not used	CRP1294

● Owner's Manual, Installation Manual

Model	Part No.	Language
DEH-P350/XM/UC	CRD3697	English, French, Spanish
DEH-P350/XN/UC	CRD3698	
DEH-P3500/XM/UC	CRD3699	English, French, Spanish
DEH-P3500/XN/UC	CRD3700	

2.3 EXTERIOR



(1) EXTERIOR SECTION PARTS LIST

Mark No.	Description	Part No.
1	Screw	BMZ30P040FZK
2	Screw	BSZ26P060FTC
3	Screw	BSZ30P060FTC
4	Screw	BSZ30P200FTC
5	Cable	CDE7128
6	Cord Assy	See Contrast table(2)
7	Cord Assy	CDE7154
8	CD Mechanism Module(S10)	CXK5600
9	Case	CNB2793
10	Holder	CNC8915
11	Cushion	CNM4870
12	Insulator	CNM7682
13	Insulator	CNM7935
14	Insulator	CNM8174
15	Panel	See Contrast table(2)
16	•••••	
17	Tuner Amp Unit	See Contrast table(2)
18	Screw	ASZ26P060FTC
19	Screw	BPZ26P080FTC
20	Screw	BSZ26P160FTC
21	Fuse(10A)	CEK1208
22	FM/AM Tuner Unit	CWE1646
23	Holder	CND1054
24	Pin Jack(CN352)	CKB1051
25	Plug(CN901)	CKM1376
26	Plug(CN351)	See Contrast table(2)
27	Connector(CN101)	CKS3408
28	Plug(CN801)	CKS3537
29	Connector(CN651)	CKS3835
30	Antenna Jack(CN401)	CKX1056
31	Holder	See Contrast table(2)
32	Holder	CND1352
33	Insulator	CNM8245
34	Heat Sink	CNR1668
35	Holder Unit	See Contrast table(2)
36	Chassis Unit	CXB9528
37	Button(EJECT)	CAC7752
38	Screw(M2x2)	CBA1176
39	Washer	CBF1038
40	Spring	CBH2650
41	Spring	CBH2651
42	Spring	CBH2652
43	Spring	CBH2653
44	Spring	CBL1512
45	Holder	CND1254
46	Cover	CNM6854
47	Panel	CNS7245
48	Gear	CNV5997
49	Pin	CNV6486
50	Lighting Conductor	CNV6487
51	Arm	CNV7400
52	Arm	CNV7401
53	Arm	CNV7402
54	Arm	CNV7403
55	Panel Unit	CWM8758
56	Socket(CN1950)	CKS3550
57	Connector(CN1951)	CKS4462
58	Holder Unit	CXB9501
59	Holder Unit	CXB9502
60	Damper Unit	CXB9503
61	Service Panel Unit	CXX1691
62	Screw	IMS20P045FZK
63	Detach Grille Assy	See Contrast table(2)
64	Screw	BPZ20P060FTC
65	Screw	BPZ20P100FZK
66	Knob	See Contrast table(2)
67	Button(OPEN)	CAC7728
68	Button(AUDIO)	CAC7729
69	Button(DISP, 1-6, FUNC)	CAC7730
70	Button(CLK)	CAC7751
71	Button(SELECT)	See Contrast table(2)
72	Spring	CBH2654
73	Spring	CBL1470
74	Cushion	CNM8291
75	Cover	CNS7247
76	Holder	CNV7405
77	Keyboard Unit	CWM8607
78	LCD	CAW1755
79	Connector(CN1901)	CKS4524
80	Holder	CND1215
81	Sheet	CNM7921
82	Connector	CNV7365
83	Lighting Conductor	CNV7406
84	Button Unit(SRC, EQ)	CXB9924
85	Button Unit(BAND, EQ-EX)	CXB9925
86	Sub Grille Assy	See Contrast table(2)
87	Remote Control Unit	CXC1265
88	Cover	CNS7068
89	Screw	ISS26P055FTC
90	Screw	See Contrast table(2)
91	Holder	See Contrast table(2)
92	IC(IC301)	PAL007A
93	Choke Coil(L301)	CTH1280
94	Transistor(Q651, 911, 921)	2SD2396


(2) CONTRAST TABLE

DEH-P350/XM/UC, DEH-P350/XN/UC, DEH-P3500/XM/UC, DEH-P3500/XN/UC, DEH-P4550/XM/ES and DEH-P4550/XN/ES are constructed the same except for the following:

Mark No.	Symbol and Description	Part No.		
		DEH-P350/XM/UC	DEH-P3500/XM/UC	DEH-P4550/XM/ES
6	Cord Assy	CDE7129	Not used	Not used
15	Panel	CNS6935	CNS6934	CNS6935
17	Tuner Amp Unit	CWM8593	CWM8594	CWM8596
26	Plug(CN351)	CKS1238	Not used	Not used
31	Holder	CND1239	CND1477	CND1477
35	Holder Unit	CXB6681	CXB6681	CXB6681
63	Detach Grille Assy	CXB9677	CXB9678	CXB9680
66	Knob	CAA2755	CAA2753	CAA2755
71	Button(SELECT)	CAC7733	CAC7731	CAC7733
86	Sub Grille Assy	CXB9977	CXB9978	CXB9980
90	Screw	Not used	BMZ40P140FTC	Not used
91	Holder	Not used	CNV7619	Not used

Mark No.	Symbol and Description	Part No.		
		DEH-P350/XN/UC	DEH-P3500/XN/UC	DEH-P4550/XN/ES
6	Cord Assy	CDE7129	Not used	Not used
15	Panel	CNS6935	CNS6934	CNS6935
17	Tuner Amp Unit	CWM8593	CWM8594	CWM8596
26	Plug(CN351)	CKS1238	Not used	Not used
31	Holder	CND1239	CND1477	CND1477
35	Holder	CNC8659	CNC8659	CNC8659
63	Detach Grille Assy	CXB9677	CXB9678	CXB9680
66	Knob	CAA2755	CAA2753	CAA2755
71	Button(SELECT)	CAC7733	CAC7731	CAC7733
86	Sub Grille Assy	CXB9977	CXB9978	CXB9980
90	Screw	Not used	BMZ40P140FTC	Not used
91	Holder	Not used	CNV7619	Not used

2.4 CD MECHANISM MODULE



● CD MECHANISM MODULE SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	CD Core Unit(S10)	CWX2708
	2	Connector(CN101)	CKS4182
	3	Connector(CN701)	CKS4188
	4	Screw	BMZ20P035FTC
	5	Screw	BSZ20P040FTC
	6	Screw(M2x4)	CBA1362
	7	Screw(M2x3)	CBA1511
	8	Screw(M2x3)	CBA1527
	9	Washer	CBF1037
	10	Washer	CBF1038
	11	Washer	CBF1060
	12	Spring	CBH2390
	13	Spring	CBH2606
	14	Spring	CBH2607
	15	Spring	CBH2608
	16	Spring	CBH2609
	17	Spring	CBH2610
	18	Spring	CBH2611
	19	Spring	CBH2612
	20	Spring	CBH2613
	21	Spring	CBH2614
	22	Spring	CBH2615
	23	Spring	CBH2616
	24	Spring	CBH2617
	25	Spring	CBH2620
	26	Spring	CBH2621
	27	Spring	CBH2641
	28	Spring	CBH2642
	29	Spring	CBH2643
	30	Spring	CBH2659
	31	Spring	CBH2688
*	32	Spring	CBL1614
	33	Shaft	CLA3845
	34	Frame	CNC9962
	35	Frame	CNC9963
	36	Bracket	CNC9966
	37	Bracket	CNC9967
	38	Arm	CNC9968
	39	Arm	CNC9973
	40	Lever	CNC9983
	41	Lever	CNC9984
	42	Sheet	CNM8134
	43	Collar	CNV6906
	44	Guide	CNV6925
	45	Arm	CNV7198

Mark	No.	Description	Part No.
	46	Rack	CNV7199
	47	Holder	CNV7201
	48	Holder	CNV7202
	49	Arm	CNV7203
	50	Gear	CNV7207
	51	Gear	CNV7208
	52	Gear	CNV7209
	53	Gear	CNV7210
	54	Gear	CNV7211
	55	Gear	CNV7212
	56	Rack	CNV7214
	57	Arm	CNV7215
	58	Arm	CNV7216
	59	Guide	CNV7217
	60	Roller	CNV7218
	61	Gear	CNV7219
	62	Arm	CNV7221
	63	Arm	CNV7220
	64	Arm	CNV7222
	65	Damper	CNV7313
	66	Damper	CNV7314
	67	Arm	CNV7341
	68	Arm	CNV7342
	69	Guide	CNV7360
	70	Guide	CNV7361
	71	Holder	CNV7437
	72	Arm	CNV7444
	73	Gear	CNV7595
	74	Damper	CNV7618
	75	Motor Unit(M1)	CXB6007
	76	Chassis Unit	CXB8728
	77	Screw Unit	CXB8729
	78	Gear Unit	CXB8731
	79	Arm Unit	CXB8732
	80	Arm Unit	CXB8735
	81	Arm Unit	CXB8852
	82	Motor Unit(M2)	CXB8933
	83	Bracket	CNC9985
	84	Screw	JFZ20P020FTC
	85	Screw(M2x5)	EBA1028
	86	Screw	JFZ20P020FTC
	87	Screw	JGZ17P022FTC
	88	Washer	YE15FTC
	89	Washer	YE20FTC
	90	Pickup Unit(Service)(P10)	CXX1641
	91	Screw	IMS26P030FMC

5. ELECTRICAL PARTS LIST

NOTES:

- Parts whose parts numbers are omitted are subject to being not supplied.
- The part numbers shown below indicate chip components.

Chip Resistor

RS1/○S○○○J,RS1/○○S○○○J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

A Unit Number : CWM8593(DEH-P350)
CWM8594(DEH-P3500)
CWM8596(DEH-P4550)

Unit Name : Tuner Amp Unit

MISCELLANEOUS

=====Circuit Symbol and No.		===Part Name	Part No.
IC	101	IC	HA12187FP
IC	131	IC	NJM4558MD
IC	201	IC	PML009A
IC	301	IC	PAL007A
IC	401	IC	NJM2391DL1-33
IC	601	IC	PD5802A
IC	602	IC	S-80835ANUP-EDZ
IC	652	IC	TC7SET08FU
IC	653	IC	TC7SET08FU
Q	101	Transistor	2SA1037K
Q	102	Transistor	DTC114EU
Q	301	Transistor	DTC124EU
Q	351	Transistor(DEH-P350)	IMH3A
Q	352	Transistor	IMH3A
Q	353	Transistor	IMH3A
Q	651	Transistor	2SD2396
Q	652	Transistor	IMD2A
Q	803	Transistor	2SD1767
Q	804	Transistor	IMD2A
Q	805	Transistor	DTC143EU
Q	806	Transistor	IMD14
Q	807	Transistor	2SA1037K
Q	808	Transistor	DTC114EU
Q	911	Transistor	2SD2396
Q	913	Transistor	IMD2A
Q	921	Transistor	2SD2396
Q	922	Transistor	DTC114EU
Q	923	Transistor	2SB1243
Q	931	Transistor	IMX1
Q	932	Transistor	DTC114EU
Q	951	Transistor	2SA1037K
Q	981	Transistor	2SC2412K
Q	982	Transistor	IMD2A
D	131	Diode Network	DA204U
D	132	Diode Network	DA204U
D	133	Diode	DAN202U
D	134	Diode	DAP202U
D	301	Diode	S5688G
D	302	Diode	S5688G
D	303	Diode	S5688G
D	304	Diode	S5688G
D	401	Diode	S5688G
D	402	Diode	S5688G
D	403	Diode	S5688G
D	651	Diode	HZS9L(B1)
D	803	Diode Network	DA204U
D	804	Diode	DAN202U
D	805	Diode	DAP202U
D	806	Diode	DAN202U
D	807	Diode	DAP202U
D	808	Diode	HZS11L(A1)
D	911	Diode	S5688G
D	912	Diode	HZS6L(B2)
D	921	Diode	HZS9L(B3)
D	931	Diode	HZS7L(A1)
D	932	Diode	HZS7L(C3)
D	937	Diode	MA110
D	951	Diode	DAN202U
D	981	Diode	DAN202U
D	982	Diode	HZS9L(A2)
L	101	Inductor	LAU2R2K
L	201	Ferri-Inductor	LAU4R7K
L	301	Choke Coil 600µH	CTH1280
L	401	Ferri-Inductor	LAU4R7K
L	403	Inductor	LAU1R0K
L	404	Inductor	LAU1R0K
L	406	Inductor	CTF1385
L	601	Ferri-Inductor	LAU100K
L	651	Inductor	CTF1382
L	801	Inductor	LAU2R2K
L	951	Inductor	LAU2R2K
X	601	Radiator 10.00MHz	CSS1599
S	802	Switch(DSENS)	CSN1039
BZ	641	Buzzer	CPV1062
AR	401	Arrester	DSP-201M
		FM/AM Tuner Unit	CWE1646
		Fuse 10A	CEK1208

RESISTORS

R	101		RS1/16S101J
R	102		RS1/16S620J
R	103		RS1/16S101J
R	104		RS1/16S222J
R	105		RS1/16S103J
R	106		RS1/16S472J
R	107		RS1/16S223J
R	108		RS1/16S472J
R	109		RS1/16S821J
R	110		RS1/16S821J
R	111		RS1/16S223J
R	112		RS1/16S223J
R	113		RS1/16S102J
R	114		RS1/16S102J
R	133		RS1/16S563J
R	134		RS1/16S104J
R	139		RS1/16S563J
R	140		RS1/16S104J
R	147		RS1/16S474J
R	148		RS1/16S474J
R	201		RAB4C102J
R	241		RS1/16S0R0J
R	242		RS1/16S0R0J
R	247		RS1/16S101J
R	248		RS1/16S101J

=====Circuit Symbol and No.		===Part Name	Part No.
R	249		RS1/16S101J
R	250		RS1/16S101J
R	301		RS1/16S103J
R	302		RS1/16S103J
R	303		RS1/16S153J
R	304		RS1/16S331J
R	351	(DEH-P350)	RS1/16S821J
R	352	(DEH-P350)	RS1/16S821J
R	353		RS1/16S821J
R	354		RS1/16S821J
R	355		RS1/16S821J
R	356		RS1/16S821J
R	357	(DEH-P350)	RS1/16S223J
R	358	(DEH-P350)	RS1/16S223J
R	359		RS1/16S223J
R	360		RS1/16S223J
R	361		RS1/16S223J
R	362		RS1/16S223J
R	403		RS1/16S681J
R	404		RS1/16S0R0J
R	405		RS1/16S681J
R	406		RS1/16S681J
R	407		RS1/16S681J
R	408		RS1/16S681J
R	410		RS1/16S681J
R	413		RS1/16S0R0J
R	416		RS1/16S681J
R	417		RS1/16S681J
R	419		RS1/16S681J
R	421		RS1/16S681J
R	423		RD1/4PU0R0J
R	601	(DEH-P4550)	RS1/16S104J
R	602	(DEH-P350)	RS1/16S104J
		(DEH-P3500)	RS1/16S104J
R	606		RS1/16S104J
R	607		RS1/16S822J
R	615		RS1/16S0R0J
R	616		RS1/16S473J
R	617		RS1/16S102J
R	618		RS1/16S104J
R	630		RS1/16S104J
R	632		RS1/16S104J
R	641		RS1/16S102J
R	648		RS1/16S221J
R	649		RS1/16S221J
R	651		RD1/4PU221J
R	652		RD1/4PU221J
R	653		RS1/16S472J
R	654		RS1/16S222J
R	655		RS1/16S102J
R	656		RS1/16S0R0J
R	657		RS1/16S0R0J
R	658		RS1/16S102J
R	659		RS1/16S221J
R	660		RS1/16S221J
R	661		RS1/16S221J
R	662		RS1/16S221J
R	663		RS1/16S102J
R	664		RS1/16S221J
R	665		RD1/4PU0R0J
R	667		RS1/16S221J
R	668		RS1/16S222J
R	670		RS1/16S221J
R	673		RS1/16S104J
R	677		RS1/16S104J
R	682		RS1/16S221J
R	684		RS1/16S0R0J
R	689		RS1/16S0R0J
R	802		RS1/16S222J
R	803		RS1/16S472J

=====Circuit Symbol and No.		===Part Name	Part No.
R	804		RS1/16S1R0J
R	805		RS1/16S391J
R	806		RS1/16S391J
R	807		RS1/16S473J
R	808		RS1/16S473J
R	809		RS1/16S102J
R	810		RS1/16S222J
R	811		RS1/16S222J
R	812		RS1/16S222J
R	813		RS1/16S222J
R	814		RS1/16S222J
R	815		RS1/16S473J
R	816		RS1/16S104J
R	817		RD1/4PU391J
R	818		RS1/16S104J
R	819		RS1/16S222J
R	820		RS1/16S222J
R	821		RS1/16S472J
R	822		RS1/16S0R0J
R	823		RS1/16S102J
R	824		RS1/16S473J
R	825		RS1/16S102J
R	826		RS1/16S102J
R	827		RS1/16S102J
R	828		RS1/16S102J
R	903		RS1/16S223J
R	912		RS1/16S222J
R	913		RS1/16S223J
R	914		RS1/16S104J
R	915		RS1/16S104J
R	916		RS1/16S104J
R	923		RS1/16S103J
R	924		RD1/4PU122J
R	925		RS1/16S182J
R	931		RS1/16S472J
R	932		RS1/16S473J
R	933		RS1/16S103J
R	934		RS1/16S473J
R	935		RS1/16S104J
R	936		RS1/16S103J
R	938		RD1/4PU102J
R	939		RD1/4PU102J
R	951		RD1/4PU153J
R	952		RS1/16S472J
R	953		RS1/16S472J
R	954		RS1/16S102J
R	983		RS1/16S223J
R	984		RS1/16S473J
R	985		RS1/16S102J

CAPACITORS

C	101	CKSRYB104K16
C	102	CKSRYB473K25
C	131	CKSRYB104K16
C	132	CKSRYB104K16
C	141	CKSRYB104K16
C	142	CKSRYB103K50
C	143	CKSRYB474K10
C	144	CKSRYB474K10
C	145	CCSRCH101J50
C	146	CCSRCH101J50
C	147	CKSRYB104K16
C	201	CEJQ1R0M50
C	202	CEJQ1R0M50
C	203	CKSRYB104K16
C	204	CKSRYB104K16
C	205	CKSRYB104K16
C	206	CEJQ470M16
C	207	CEJQ1R0M50
C	208	CEJQ1R0M50
C	209	CEJQ1R0M50

C	210		CEJQ1R0M50
C	211		CEJQ4R7M35
C	212		CEJQ4R7M35
C	213		CEJQ4R7M35
C	214		CEJQ4R7M35
C	215		CEJQ4R7M35
C	216		CEJQ4R7M35
C	217		CEJQ4R7M35
C	218		CEJQ4R7M35
C	219		CCSRCH120J50
C	220		CCSRCH120J50
C	221		CCSRCH120J50
C	222		CCSRCH120J50
C	225		CEJQ100M16
C	301		CKSRYB104K16
C	306		CEJQ330M10
C	307	3300µF/16V	CCH1486
C	309		CKSRYB104K16
C	310		CEJQ100M16
C	311		CKSYB475K16
C	312		CKSYB475K16
C	317		CKSRYB474K10
C	318		CKSRYB474K10
C	319		CKSRYB474K10
C	320		CKSRYB474K10
C	321		CKSRYB474K10
C	322		CKSRYB474K10
C	323		CKSRYB474K10
C	324		CKSRYB474K10
C	325		CKSQYB225K10
C	326		CKSQYB225K10
C	351	(DEH-P350)	CEJQ4R7M35
C	352	(DEH-P350)	CEJQ4R7M35
C	353		CEJQ4R7M35
C	354		CEJQ4R7M35
C	355		CEJQ4R7M35
C	356		CEJQ4R7M35
C	401		CKSRYB103K50
C	402		CEJQ101M10
C	403		CKSQYB105K16
C	404		CKSYB475K10
C	406		CEJQ470M10
C	408		CKSYB475K10
C	409		CEJQ1R0M50
C	411		CCSRCH101J50
C	412		CCSRCH470J50
C	601		CEJQ4R7M35
C	602		CKSQYB105K16
C	603		CEJQ2R2M50
C	604		CCSRCH200J50
C	605		CCSRCH200J50
C	609		CCSRCH101J50
C	651		CEJQ101M10
C	652		CKSRYB473K25
C	653		CKSRYB473K25
C	656		CKSRYB473K25
C	657		CCSRCH470J50
C	755		CKSRYB104K16
C	806		CKSRYB473K25
C	807		CKSRYB473K25
C	811		CKSQYB105K16
C	854		CKSRYB473K25
C	911	470µF/16V	CCH1331
C	912		CKSRYB472K50
C	913		CKSRYB103K50
C	914		CEJQ470M10
C	921		CEJQ221M10
C	922		CKSRYB103K50
C	923		CEJQ101M16
C	931		CEJQ1R0M50

C Unit Number : CWM8607
Unit Name : Keyboard Unit

MISCELLANEOUS

IC	1900	IC	PD6294A
IC	1901	HIC Module	RS-140
Q	1910	Transistor	DTC114EU
D	1902	Diode Network	DA204U
D	1910	LED	NSSW440-9159
D	1912	LED	NSSW440-9159
D	1914	LED	NSSW440-9159
D	1930	LED	CL-195PG-CD
D	1931	LED	CL-195PG-CD
D	1932	LED	CL-195PG-CD
D	1935	LED	CL-195PG-CD
D	1942	LED	CL-195PG-CD
D	1943	LED	CL-195PG-CD
D	1946	LED	CL-195PG-CD
D	1947	LED	CL-195PG-CD
X	1900	Ceramic Resonator 5.00MHz	CSS1547
S	1901	Push Switch	CSG1112
S	1902	Push Switch	CSG1112
S	1903	Switch	CSG1107
S	1904	Switch	CSG1107
S	1905	Switch	CSG1107
S	1906	Switch	CSG1107
S	1907	Switch	CSG1107
S	1908	Switch	CSG1107
S	1909	Switch	CSG1107
S	1910	Switch	CSG1107
S	1911	Push Switch	CSG1112
S	1912	Push Switch(DEH-P350)	CSG1112
S	1912	Push Switch(DEH-P3500, P4550)	CSG1160
S	1913	Push Switch	CSG1112
S	1914	Push Switch(DEH-P350)	CSG1112
S	1914	Push Switch(DEH-P3500, P4550)	CSG1160
S	1915	Push Switch	CSG1112
S	1916	Push Switch	CSG1112
S	1917	Push Switch	CSG1111
S	1918	Push Switch	CSG1111
S	1950	Encoder	CSD1059

RESISTORS

R	1900	RS1/16S222J
R	1901	RS1/16S222J
R	1902	RS1/16S121J
R	1903	RS1/16S2R2J
R	1910	RS1/16S101J
R	1912	RS1/16S680J
R	1914	RS1/16S181J
R	1915	RS1/16S181J
R	1919	RS1/16S101J
R	1930	RS1/16S560J
R	1932	RS1/16S560J
R	1934	RS1/16S560J
R	1936	RS1/16S560J
R	1938	RS1/16S151J
R	1939	RS1/16S151J
R	1940	RS1/16S560J
R	1941	RS1/16S151J
R	1942	RS1/16S0R0J
R	1943	RS1/16S151J
R	1950	RS1/16S472J
R	1960	RS1/16S473J

=====Circuit Symbol and No.		===Part Name	Part No.
CAPACITORS			
C	1900		CKSRYB104K16
C	1901		CKSYF106Z10
C	1902		CKSRYB104K16
C	1903		CKSRYB104K16
C	1904		CKSRYB104K16
C	1910		CKSRYF104Z25
C	1911		CKSRYF104Z25
C	1913		CKSRYF104Z25

B Unit Number : CWM8758
Unit Name : Panel Unit

MISCELLANEOUS			
D	1970	LED	CL220PGC
S	1970	Push Switch(EJECT)	CSG1112
RESISTORS			
R	1970		RS1/16S101J
R	1971		RS1/16S101J
R	1972		RS1/16S0R0J
CAPACITORS			
C	1970		CKSRYB104K16

D Unit Number : CWX2708
Unit Name : CD Core Unit(S10)

MISCELLANEOUS			
IC	201	IC	UPD63712GC
IC	301	IC	BA5996FP
IC	701	IC	NJM2391DL1-33
Q	101	Transistor	2SB1132
D	101	Diode	1SS355
D	701	Diode	1SR154-400
X	201	Ceramic Resonator 16.934MHz	CSS1603
S	901	Spring Switch(HOME)	CSN1051
S	902	Spring Switch(CLAMP)	CSN1051
S	903	Spring Switch(DSCSNS)	CSN1052
S	904	Spring Switch(12EJ)	CSN1051
S	905	Spring Switch(8EJ)	CSN1051
RESISTORS			
R	101		RS1/10S1R5J
R	102		RS1/10S1R5J
R	103		RS1/10S1R5J
R	104		RS1/10S1R5J
R	105		RS1/10S1R5J
R	201		RS1/16S102J
R	202		RS1/16S1002D
R	203		RS1/16S1002D
R	204		RS1/16S1002D
R	205		RS1/16S1002D
R	206		RS1/16S1002D
R	207		RS1/16S1002D
R	208		RS1/16S1002D
R	209		RS1/16S1002D
R	214		RS1/16S103J
R	215		RS1/16S393J
R	216		RS1/16S122J
R	217		RS1/16S562J
R	218		RS1/16S472J
R	234		RS1/16S0R0J
R	235		RS1/16S103J
R	236		RS1/16S103J
R	301		RS1/16S183J
R	302		RS1/16S822J
R	303		RS1/16S183J

=====Circuit Symbol and No.		===Part Name	Part No.
R	304		RS1/16S822J
R	305		RS1/16S183J
R	306		RS1/16S183J
R	307		RS1/16S183J
R	308		RS1/16S183J
R	501		RS1/16S102J
R	503		RS1/16S102J
R	505		RS1/16S102J
R	506		RS1/16S221J
R	507		RS1/16S221J
R	508		RS1/16S221J
R	509		RS1/16S221J
R	601		RS1/16S101J
R	602		RS1/16S101J
R	603		RS1/16S0R0J
R	901		RS1/16S104J
R	902		RS1/16S473J
R	903		RS1/16S273J
CAPACITORS			
C	101		CKSRYB104K16
C	102		CKSRYB104K16
C	103	100µF/16V	CCH1504
C	104	47µF/6.3V	CCH1506
C	106		CCSRCH101J50
C	108		CKSRYB224K16
C	109		CKSRYB224K16
C	201		CKSRYB104K16
C	202		CKSRYB471K50
C	203		CKSRYB104K16
C	205	22µF/6.3V	CCH1507
C	206		CKSRYB103K25
C	207		CKSRYB104K16
C	208	100µF/6.3V	CCH1505
C	209		CKSRYB104K16
C	210		CKSRYB104K16
C	211		CKSRYB104K16
C	212		CKSRYB104K16
C	213		CKSRYB332K50
C	214		CKSRYB473K25
C	215		CKSRYB104K16
C	216		CKSRYB103K25
C	217		CCSRCH560J50
C	218		CCSRCH5R0C50
C	219		CKSRYB104K16
C	220		CKSRYB104K16
C	221		CKSRYB104K16
C	222		CKSRYB103K25
C	223		CCSRCH680J50
C	224		CCSRCH470J50
C	225		CKSRYB682K50
C	231		CKSRYB102K50
C	232		CKSRYB102K50
C	301	100µF/16V	CCH1504
C	302		CCSRCH221J50
C	303		CCSRCH221J50
C	304		CKSRYB472K50
C	305		CKSRYB103K25
C	306		CKSRYB104K16
C	501		CKSRYB103K25
C	502		CKSRYB103K25
C	702	100µF/16V	CCH1504
C	703		CKSRYB224K16
C	704		CKSRYB104K16
C	705	10µF/6.3V	CCH1470

Miscellaneous Parts List

		Pickup Unit(Service)(P10)	CXX1641
M	1	Motor Unit(SPINDLE)	CXB6007
M	2	Motor Unit(LOADING/CARRIAGE)	CXB8933