



PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

KDC-X915/X815/PS9016R/PS9080R

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
KDC-X915/X815/PS9016R/PS9080R					
201	1C		A02-1489-03	PLASTIC CABINET ASSY	
202	1C		A10-4671-02	CHASSIS ASSY	
203	1D		A10-4315-04	CHASSIS CALKING ASSY	
204	1C		A10-4317-04	CHASSIS CALKING ASSY	
205	1D		A10-4319-04	CHASSIS CALKING ASSY	
206	1D		A10-4321-04	CHASSIS CALKING ASSY	
207	1D		A10-4674-02	CHASSIS ASSY	
208	1D		A10-4676-02	CHASSIS ASSY	
209	1D		A10-4534-23	CHASSIS ASSY	
210	3C		A22-2296-43	SUB PANEL ASSY	
211	3D		A10-4666-03	CHASSIS ASSY	WO/E
211	3D		A10-4667-03	CHASSIS ASSY	E
212	2D		A46-1652-01	REAR COVER	
213	1D		A52-0742-12	TOP PLATE	
214	3C		A21-4011-03	DRESSING PANEL	
PA1	2C	*	A64-1864-02	PANEL ASSY	E
PA1	2C	*	A64-1867-02	PANEL ASSY	K
PA1	2C	*	A64-1868-02	PANEL ASSY	K1
PA1	2C	*	A64-1873-02	PANEL ASSY	M1
RM1	1C		A70-0864-05	REMOTE CONTROLLER ASSY	E
RM1	1C		A70-0883-05	REMOTE CONTROLLER ASSY	M1
RM1	1C		A70-0894-05	REMOTE CONTROLLER ASSY	KK1
RM2	1C		A70-0886-15	REMOTE CONTROLLER ASSY	M1E
221	3C		B07-2139-03	ESCUTCHEON ASSY	M1
221	3C		B07-2146-03	ESCUTCHEON ASSY	KK1E
222	1C		B07-2183-02	ESCUTCHEON	
223	2C	*	B10-3107-01	FRONT GLASS	K
223	2C	*	B10-3108-01	FRONT GLASS	K1
223	2C	*	B10-3113-01	FRONT GLASS	M1
223	2C	*	B10-3103-01	FRONT GLASS	E
-			B46-0100-50	WARRANTY CARD	
-			B46-0606-04	ID CARD	KK1
-			B46-0631-03	USER CARD	KK1
-			B46-0632-04	ID CARD	M1E
-			B58-1278-04	CAUTION CARD	
-			B58-1309-04	CAUTION CARD	M1
-			B58-1321-14	CAUTION CARD	M1
-			B64-1599-00	INSTRUCTION MANUAL E,T	M1
-			B64-1601-00	INSTRUCTION MANUAL E	KK1
-			B64-1602-00	INSTRUCTION MANUAL F,S	KK1
-			B64-1605-00	INSTRUCTION MANUAL E	E
-			B64-1606-00	INSTRUCTION MANUAL F,G,D	E
-			B64-1607-00	INSTRUCTION MANUAL I,S,P	E
224	1C		D10-4301-14	LEVER	
225	1C		D10-4302-14	LEVER	
230	1D		D10-4448-03	ARM ASSY	
231	1D		D10-4449-04	ARM ASSY	
232	2D		D13-1302-64	GEAR ASSY	
233	2D		D13-1306-24	GEAR	
234	2D		D13-1403-03	GEAR	
235	2D		D13-1404-04	GEAR	
236	2D		D13-1453-14	GEAR ASSY	
239	1D		D13-1312-34	GEAR	
240	1D		D13-1313-04	GEAR	
243	1D		D13-1456-13	GEAR ASSY	
244	1D		D13-1455-13	GEAR ASSY	
246	1D		D14-0678-04	ROLLER ASSY	
247	3D		D14-0723-04	ROLLER	
248	3D		D14-0716-14	ROLLER	
251	2D		E30-4796-05	CORD WITH PINPLUG	
252	2D		E30-4706-05	CORD WITH CONNECTOR	
DC1	1C		E30-4779-05	DC CORD	K1
DC1	1C		E30-4781-05	DC CORD	M1
DC1	1C		E30-4782-05	DC CORD	K
DC1	1C		E30-4788-05	DC CORD	E
DN1	2D		E30-4802-05	CORD WITH DIN CONNECTOR	
255	2D		F29-0049-05	INSULATING COVER	
F1	2D		F52-0004-05	FUSE(MINI BLADE TYPE)	K
F1	2D		F52-0006-05	FUSE(MINI BLADE TYPE)	K1M1
F1	2D		F52-0006-05	FUSE(MINI BLADE TYPE)	E
258	2D		G01-2984-04	EXTENSION SPRING	
259	1D		G01-2818-24	EXTENSION SPRING	
260	3C		G01-2920-14	TORSION COIL SPRING	
261	1C		G01-2924-04	TORSION COIL SPRING	
262	1D		G11-1850-04	CUSHION	
263	2D		G16-1147-04	SHEET	
-			H10-4700-02	POLYSTYRENE FOAMED FIXTURE	
-			H21-1123-04	PROTECTION SHEET	
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	
-			H25-1108-04	PROTECTION BAG (100X300X0.03)	
-		*	H54-1652-03	ITEM CARTON CASE	K
-		*	H54-1653-03	ITEM CARTON CASE	K1
-		*	H54-1658-03	ITEM CARTON CASE	M1
-		*	H54-1662-03	ITEM CARTON CASE	E
265	1C		J19-4875-04	BRACKET	WO/E
266	1C		J19-4876-04	BRACKET	WO/E
267	1C		J21-9491-03	MOUNTING HARDWARE ASSY	
271	1D		J31-1035-24	COLLAR	
272	1C		J54-0606-04	STAY	
FPC2	1D		J84-0062-23	FLEXIBLE PRINTED WIRING BOARD	
FPC3	3C		J84-0066-13	FLEXIBLE PRINTED WIRING BOARD	
280	2C		K24-3540-03	KNOB OPEN	
281	2C		K24-3541-04	KNOB SRC	
282	2C		K25-1095-03	KNOB VOL	
283	2C		K25-1096-03	KNOB 1-3	
284	2C		K25-1097-03	KNOB 4-6	
285	2C		K25-1098-03	KNOB FM/AM	
286	2C		K25-1099-03	KNOB CLK	
287	2D		K29-7010-04	KNOB ASSY LOCK	
291	1C		N99-1652-05	SCREW SET	WO/E
292	1C		N99-1683-05	SCREW SET	
A	1D		N09-4184-05	MACHINE SCREW (M2X2)	
B	1D		N09-4185-05	MACHINE SCREW (M2X2)	
C	1D		N09-4218-05	MACHINE SCREW (M2X3)	

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

⚠ indicates safety critical components.

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

KDC-X915/X815/PS9016R/PS9080R
SWITCH UNIT (X13-971X-XX)
SUB CIRCUIT (X13-978X-XX)
ELECTRIC UNIT (X25-84XX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
D	1D		N09-4340-05	MACHINE SCREW (M2X2.)	
E	1D		N09-4381-05	MACHINE SCREW (M2X2)	
F	2D		N19-2022-04	FLAT WASHER	
G	2D		N19-2058-04	FLAT WASHER	
H	1D		N19-2062-04	FLAT WASHER	
J	1D		N19-2085-04	FLAT WASHER	
K	1D		N19-2095-04	FLAT WASHER	
L	1D		N19-2103-04	FLAT WASHER	
M	3C		N35-2003-45	BINDING HEAD MACHINE SCREW	
N	3C		N38-2030-45	PAN HEAD MACHIN SCREW	
P	3C		N67-3005-46	PAN HEAD SEMS SCREW	
Q	2C		N80-2004-46	PAN HEAD TAPTITE SCREW	
R	2C		N80-2008-45	PAN HEAD TAPTITE SCREW	
S	1D		N83-3005-46	PAN HEAD TAPTITE SCREW	
PS1	1D		S68-0829-05	PUSH SWITCH	
PM1	1D		T42-0752-34	MOTOR ASSY	
295	1C		T90-0523-05	ANTENNA ADAPTOR	E
ME1	3C		X92-3710-00	MECHANISM ASSY	
SWITCH UNIT (X13-971X-XX)					
D7 ,8			B30-1562-05	LED	
C1			CK73FB1H103K	CHIP C 0.010UF K	
C2			C92-0628-05	CHIP-TAN 10UF 10WV	
C3 ,4			CK73EB1C225K	CHIP C 2.2UF K	
C5			CK73FB1H103K	CHIP C 0.010UF K	
C6			CK73EB1C225K	CHIP C 2.2UF K	
C8			CK73FB1H103K	CHIP C 0.010UF K	
CN1			E59-0833-05	RECTANGULAR PLUG	
L1			L92-0302-05	CHIP FERRITE	
L2			L40-1015-34	SMALL FIXED INDUCTOR	
L3 ,4			L33-0385-05	SMALL FIXED INDUCTOR	
X1			L78-0683-05	RESONATOR	
CP1			R90-0714-05	MULTI-COMP 10K X4	
CP2 ,3			R90-0724-05	MULTI-COMP 1K X4	
CP4			R90-1022-05	MULTI-COMP 470 X2	
R1 ,2			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R3 -5			RK73FB2A103J	CHIP R 10K J 1/10W	
R6 ,7			RK73FB2A274J	CHIP R 270K J 1/10W	
R8			RK73FB2A153J	CHIP R 15K J 1/10W	
R9			RK73FB2A101J	CHIP R 100 J 1/10W	
R10			RK73FB2A100J	CHIP R 10 J 1/10W	
R11			RK73FB2A823J	CHIP R 82K J 1/10W	
R12			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R13 ,14			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R15 ,16			RK73FB2A473J	CHIP R 47K J 1/10W	
R17			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R18			R92-1215-05	CHIP R 470 J 1/2W	
R19			R92-2023-05	CHIP R 820 J 1/2W	
R20			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R21			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R22			RK73FB2A473J	CHIP R 47K J 1/10W	

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R23			RK73EB2B330J	CHIP R 33 J 1/8W	
R24			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R25			RK73FB2A512J	CHIP R 5.1K J 1/10W	
R30			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R31			RK73FB2A103J	CHIP R 10K J 1/10W	
R33			RK73FB2A223J	CHIP R 22K J 1/10W	
R34			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R35			RK73FB2A2R2J	CHIP R 2.2 J 1/10W	
S1 -13			S70-0856-05	TACT SWITCH	
S14			S70-0857-05	TACT SWITCH	
S15 -18			S70-0860-05	TACT SWITCH	
S19 -21			S70-0851-05	TACT SWITCH	
S22			S68-0822-05	PUSH SWITCH	
S23			S70-0864-05	TACT SWITCH	
D1 ,2			DA227	DIODE	
D3			MA3056-M	ZENER DIODE	
D4 ,5			MA3062WA	ZENER DIODE	
ED1			CN1914M	FLUORESCENT INDICATOR TUBE	
IC1	2C		UPD784215GC155	MI-COM IC	
IC2			BA3830F	ANALOGUE IC	
IC3			RS-171	ANALOGUE IC	
Q1			DTA114YK	DIGITAL TRANSISTOR	
Q1			UN2114	DIGITAL TRANSISTOR	
Q2			DTA144EK	DIGITAL TRANSISTOR	
Q2			UN2113	DIGITAL TRANSISTOR	
Q3			DTC114EK	DIGITAL TRANSISTOR	
Q3			UN2211	DIGITAL TRANSISTOR	
Q5			DTC114EK	DIGITAL TRANSISTOR	
Q5			UN2211	DIGITAL TRANSISTOR	
Q6 ,7			2SC2412K	TRANSISTOR	
Q6 ,7			2SD601A	TRANSISTOR	
Q8			DTA124EK	DIGITAL TRANSISTOR	
Q8			KRA103S	TRANSISTOR	
Q8			UN2112	DIGITAL TRANSISTOR	
SUB CIRCUIT (X13-978X-XX)					
310	2C	*	B03-3056-12	DRESSING PLATE	KK1E M1
310	2C		B03-3057-02	DRESSING PLATE	
J1			E58-0895-05	RECTANGULAR RECEPTACLE	
FPC1	2C		J84-0106-02	FLEXIBLE PRINTED WIRING BOARD	
Y	2C		N38-2025-46	PAN HEAD MACHIN SCREW	
ELECTRIC UNIT (X25-84XX-XX)					
C1			C90-2822-05	ELECTRO 3900UF 16WV	K1M1E K
C1			C90-2865-05	ELECTRO 2200UF 16WV	
C2			CK73FB1H103K	CHIP C 0.010UF K	
C3			C90-2926-05	ELECTRO 220UF 16WV	
C4			CK73FB1H103K	CHIP C 0.010UF K	
C5			C90-2594-05	ELECTRO 10UF 10WV	
C6			CE04CW0J101M	ELECTRO 100UF 6.3WV	
C7			CK73EB1C105K	CHIP C 1.0UF K	
C8			CE04CW1A221M	ELECTRO 220UF 10WV	
C10			CE04CW1A101M	ELECTRO 100UF 10WV	

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

 indicates safety critical components.

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-84XX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
C12			CK73FB1H103K	CHIP C 0.010UF K	M1	C100			C90-2608-05	ELECTRO 1.0UF 50WV	K1M1E
C13			CK73FB1H223K	CHIP C 0.022UF K		C101			CE04CW1A101M	ELECTRO 100UF 10WV	K1M1E
C14			C90-2608-05	ELECTRO 1.0UF 50WV		C102			C90-2608-05	ELECTRO 1.0UF 50WV	K1M1E
C15			C90-2595-05	ELECTRO 4.7UF 16WV		C103,104			CE04CW1C220M	ELECTRO 22UF 16WV	
C16 ,17			CK73EB1C225K	CHIP C 2.2UF K		C105,106			CC73FCH1H820J	CHIP C 82PF J	K
C18			C90-2962-05	ELECTRO 100UF 16WV		C107,108			C90-2536-05	ELECTRO 10UF 16WV	K
C19 ,20			CK73EB1C225K	CHIP C 2.2UF K		C107,108			C90-2597-05	ELECTRO 10UF 16WV	K1M1E
C21			CE04CW1C220M	ELECTRO 22UF 16WV		C110			CK73FB1E473K	CHIP C 0.047UF K	
C22			CK73GB1E223K	CHIP C 0.022UF K		C111			CE04CW0J470M	ELECTRO 47UF 6.3WV	
C23			CK73FB1H103K	CHIP C 0.010UF K		C112,113			C90-2606-05	ELECTRO 0.47UF 50WV	
C24			C90-2595-05	ELECTRO 4.7UF 16WV		C115,116			CK73FB1C224K	CHIP C 0.22UF K	
C25 ,26			CK73FB1E473K	CHIP C 0.047UF K		C117			C90-2594-05	ELECTRO 10UF 10WV	
C27			C90-2598-05	ELECTRO 3.3UF 25WV		C118			CK73FB1H103K	CHIP C 0.010UF K	
C28			CK73FB1E683K	CHIP C 0.068UF K		C119			C90-2594-05	ELECTRO 10UF 10WV	
C29			C90-2602-05	ELECTRO 0.10UF 50WV		C120,121			CC73FCH1H100D	CHIP C 10PF D	
C30			CK73FB1H102K	CHIP C 1000PF K		C122			CC73FCH1H271J	CHIP C 270PF J	
C31 ,32			CK73FB1H103K	CHIP C 0.010UF K		C123-128			CC73FSL1H102J	CHIP C 1000PF J	
C33			CE04CW0J470M	ELECTRO 47UF 6.3WV		C130			C90-2594-05	ELECTRO 10UF 10WV	M1E
C34			CK73FB1H103K	CHIP C 0.010UF K		C131			CK73GB1H471K	CHIP C 470PF K	M1E
C35			CC73FCH1H240J	CHIP C 24PF J		C132			CC73FCH1H121J	CHIP C 120PF J	M1E
C36			CC73FCH1H270J	CHIP C 27PF J		C133			CC73FCH1H060D	CHIP C 6.0PF D	M1E
C37			CK73EB1C105K	CHIP C 1.0UF K		C134			CC73FSL1H122J	CHIP C 1200PF J	M1E
C38			CK73FB1H102K	CHIP C 1000PF K	M1E	C135			CK73GB1H122K	CHIP C 1200PF K	M1E
C38			CK73FB1H472K	CHIP C 4700PF K	KK1	C136			CC73FCH1H180J	CHIP C 18PF J	M1E
C39			CK73FB1H103K	CHIP C 0.010UF K		C137			CC73FCH1H471J	CHIP C 470PF J	M1E
C42 -46			C90-2595-05	ELECTRO 4.7UF 16WV		C138			CC73FCH1H820J	CHIP C 82PF J	M1E
C48 ,49			C90-2597-05	ELECTRO 10UF 16WV		C139			CC73FSL1H102J	CHIP C 1000PF J	M1E
C50			CK73FB1C104K	CHIP C 0.10UF K		C140			CK73FB1H223K	CHIP C 0.022UF K	M1E
C51			CK73FB1H103K	CHIP C 0.010UF K		C141			CC73FSL1H222J	CHIP C 2200PF J	M1E
C52 ,53			C90-2597-05	ELECTRO 10UF 16WV		C142			CK73FB1H822K	CHIP C 8200PF K	M1E
C54			CC73FCH1H121J	CHIP C 120PF J		C144			CK73FB1H103K	CHIP C 0.010UF K	
C55			CK73FB1C823K	CHIP C 0.082UF K		C145			CC73FCH1H471J	CHIP C 470PF J	M1E
C56			CK73FB1C104K	CHIP C 0.10UF K		C146			CK73FB1H103K	CHIP C 0.010UF K	
C57			CK73EB1C474K	CHIP C 0.47UF K		C147			CE04CW1A101M	ELECTRO 100UF 10WV	
C58			CK73GB1E183K	CHIP C 0.018UF K		C148			CK73FB1E273K	CHIP C 0.027UF K	
C59			CK73FB1H103K	CHIP C 0.010UF K		C149			CK73EB1C105K	CHIP C 1.0UF K	M1E
C60			CE04CW1A101M	ELECTRO 100UF 10WV	K1M1E	C150,151			CK73FB1H103K	CHIP C 0.010UF K	M1E
C60			CE04CW1A470M	ELECTRO 47UF 10WV	K	C151			CK73FB1H103K	CHIP C 0.010UF K	KK1
C61			C90-2610-05	ELECTRO 2.2UF 50WV		C153			CK73FB1H103K	CHIP C 0.010UF K	
C62			CK73FB1H103K	CHIP C 0.010UF K		C157			CK73EB1C474K	CHIP C 0.47UF K	
C63			C93-1054-05	CHIP C 0.012UF K	K1M1E	C159			CK73FB1H103K	CHIP C 0.010UF K	
C64			C90-2608-05	ELECTRO 1.0UF 50WV		C160			CK73EB1C225K	CHIP C 2.2UF K	
C65 ,66			C90-2610-05	ELECTRO 2.2UF 50WV	K1M1E	C161			C90-2608-05	ELECTRO 1.0UF 50WV	
C65 ,66			C90-5204-05	ELECTRO 0.47UF 50WV	K	CN1			E40-5066-05	PIN ASSY	
C67 ,68			CK73FB1H682K	CHIP C 6800PF K	K	CN2			E40-3299-05	PIN ASSY	
C69 -76			CK73FB1C274K	CHIP C 0.27UF K		CN3			E40-3252-05	PIN ASSY	
C77 -80			CK73FB1C104K	CHIP C 0.10UF K		CN4			E40-3261-05	PIN ASSY	
C81 ,82			CE04CW1C220M	ELECTRO 22UF 16WV		CN5			E40-9550-05	FLAT CABLE CONNECTOR	
C83 ,84			CC73FCH1H820J	CHIP C 82PF J	K	CN6			E40-9557-05	FLAT CABLE CONNECTOR	
C85 ,86			CE04CW1C220M	ELECTRO 22UF 16WV		CN7			E40-5029-05	FLAT CABLE CONNECTOR	
C87 ,88			CC73FCH1H820J	CHIP C 82PF J	K	CN8			E40-3250-05	PIN ASSY	
C89 -92			C90-2536-05	ELECTRO 10UF 16WV	K	J1			E58-0836-05	RECTANGULAR RECEPTACLE	
C89 -92			C90-2597-05	ELECTRO 10UF 16WV	K1M1E	WH1	2D		E30-4440-05	CORD WITH PLUG	
C95 -98			C90-5296-05	ELECTRO 0.22UF 50WV	K1M1E	WH1	2D		E30-4804-05	CORD WITH PLUG	
C99			C90-2935-05	ELECTRO 1.0UF 50WV	K1M1E						

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

⚠ indicates safety critical components.

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

Ref.No.	Added	Parts No.	Description	Destination
L1		L40-4795-34	SMALL FIXED INDUCTOR	
L2		L40-2205-34	SMALL FIXED INDUCTOR(22UH)	
L3 -7		L40-4795-34	SMALL FIXED INDUCTOR	
L8		L33-1039-05	LINE FILTER COIL	
L9		L39-1004-05	TRAP COIL	
L10		L40-4795-34	SMALL FIXED INDUCTOR	
L11		L92-0075-05	CHIP FERRITE	
X1		L78-0683-05	RESONATOR	
X2		L77-2738-05	CRYSTAL RESONATOR	
X3		L77-2002-05	CRYSTAL RESONATOR	
S	3D	N83-3005-46	PAN HEAD TAPTITE SCREW	K1M1
T	3D	N35-3010-46	BINDING HEAD MACHINE SCREW	
W	3D	N86-2606-46	BINDING HEAD TAPTITE SCREW	K1M1
X	3D	N83-3012-46	PAN HEAD TAPTITE SCREW	
CP2		R90-0724-05	MULTI-COMP 1K X4	
CP3		R90-1022-05	MULTI-COMP 470 X2	
CP4 -7		R90-0725-05	MULTI-COMP 1K X2	
CP9		R90-0725-05	MULTI-COMP 1K X2	
R1		RK73FB2A223J	CHIP R 22K J 1/10W	
R2		RK73FB2A101J	CHIP R 100 J 1/10W	
R3		RK73FB2A223J	CHIP R 22K J 1/10W	
R4		RK73FB2A222J	CHIP R 2.2K J 1/10W	
R5		RK73EB2B221J	CHIP R 220 J 1/8W	
R6		RK73FB2A153J	CHIP R 15K J 1/10W	
R7		R92-3032-05	CHIP R 4.3K D 1/10W	
R8 ,9		R92-3052-05	METAL GLAZE RESISTOR	
R11		RK73FB2A152J	CHIP R 1.5K J 1/10W	
R13		RK73FB2A471J	CHIP R 470 J 1/10W	
R14		RK73GB1J104J	CHIP R 100K J 1/16W	
R15		RK73EB2B752J	CHIP R 7.5K J 1/8W	M1E
R16		RK73EB2B103J	CHIP R 10K J 1/8W	
R17		RK73FB2A223J	CHIP R 22K J 1/10W	M1E
R18		RK73FB2A473J	CHIP R 47K J 1/10W	M1E
R19		RK73FB2A102J	CHIP R 1.0K J 1/10W	M1E
R20		RK73EB2B104J	CHIP R 100K J 1/8W	
R21		RK73FB2A102J	CHIP R 1.0K J 1/10W	
R22		RK73FB2A104J	CHIP R 100K J 1/10W	
R23		RK73FB2A750J	CHIP R 75 J 1/10W	
R24		RK73FB2A272J	CHIP R 2.7K J 1/10W	
R25		RK73FB2A470J	CHIP R 47 J 1/10W	
R26		RK73EB2B102J	CHIP R 1.0K J 1/8W	
R27		RK73GB1J752J	CHIP R 7.5K J 1/16W	
R28		RK73GB1J563J	CHIP R 56K J 1/16W	
R29		RK73GB1J913J	CHIP R 91K J 1/16W	
R30		RK73FB2A470J	CHIP R 47 J 1/10W	
R31		RK73FB2A103J	CHIP R 10K J 1/10W	
R32		RK73GB1J913J	CHIP R 91K J 1/16W	
R33		RK73FB2A913J	CHIP R 91K J 1/10W	
R34		RK73FB2A472J	CHIP R 4.7K J 1/10W	KK1
R35		R92-0366-05	CHIP R 560 J 1W	KK1
R36		RK73FB2A223J	CHIP R 22K J 1/10W	KK1
R37		RK73FB2A472J	CHIP R 4.7K J 1/10W	
R38		R92-0365-05	CHIP R 1.0K J 1/2W	
R39		RK73FB2A223J	CHIP R 22K J 1/10W	

ELECTRIC UNIT (X25-84XX-XX)																	
Ref.No.	A d d	N e w	Parts No.	Description						Dest inati on							
R40			R92-0365-05	CHIP R	1.0K	J	1/2W										
R41			RK73EB2B472J	CHIP R	4.7K	J	1/8W										
R42			RK73EB2B222J	CHIP R	2.2K	J	1/8W										
R43 -45			RK73EB2B470J	CHIP R	47	J	1/8W										
R46			RK73EB2B222J	CHIP R	2.2K	J	1/8W										
R47 ,48			RK73EB2B472J	CHIP R	4.7K	J	1/8W										
R50 ,51			RK73FB2A123J	CHIP R	12K	J	1/10W										
R52			RK73FB2A562J	CHIP R	5.6K	J	1/10W										
R53			RK73GB1J223J	CHIP R	22K	J	1/16W										
R54			RD14DB2H332J	SMALL-RD	3.3K	J	1/2W										
R56 ,57			RK73EB2B104J	CHIP R	100K	J	1/8W										
R58			RK73FB2A183J	CHIP R	18K	J	1/10W										
R59			RK73GB1J104J	CHIP R	100K	J	1/16W										
R60			RK73FB2A104J	CHIP R	100K	J	1/10W			K1M1							
R61			RK73FB2A104J	CHIP R	100K	J	1/10W			K							
R62			RK73FB2A104J	CHIP R	100K	J	1/10W			M1							
R63 ,64			RK73FB2A104J	CHIP R	100K	J	1/10W			KK1							
R65			RK73FB2A104J	CHIP R	100K	J	1/10W										
R66			RK73FB2A222J	CHIP R	2.2K	J	1/10W										
R67			RK73GB1J472J	CHIP R	4.7K	J	1/16W										
R70			RK73FB2A102J	CHIP R	1.0K	J	1/10W										
R71			RK73GB1J472J	CHIP R	4.7K	J	1/16W										
R72 ,73			RK73FB2A562J	CHIP R	5.6K	J	1/10W										
R74			RK73FB2A223J	CHIP R	22K	J	1/10W										
R76			RK73GB1J470J	CHIP R	47	J	1/16W										
R77			RK73FB2A104J	CHIP R	100K	J	1/10W										
R78			RK73FB2A470J	CHIP R	47	J	1/10W										
R79 ,80			RK73FB2A222J	CHIP R	2.2K	J	1/10W										
R83			RK73GB1J104J	CHIP R	100K	J	1/16W										
R84			RK73FB2A102J	CHIP R	1.0K	J	1/10W										
R86			RK73FB2A561J	CHIP R	560	J	1/10W										
R89			RK73FB2A104J	CHIP R	100K	J	1/10W										
R90			RK73GB1J222J	CHIP R	2.2K	J	1/16W										
R92			RK73GB1J102J	CHIP R	1.0K	J	1/16W										
R93			RK73FB2A222J	CHIP R	2.2K	J	1/10W			M1E							
R94			RK73GB1J223J	CHIP R	22K	J	1/16W			KK1							
R94			RK73GB1J273J	CHIP R	27K	J	1/16W			M1E							
R95 ,96			RK73GB1J472J	CHIP R	4.7K	J	1/16W										
R97			RK73FB2A102J	CHIP R	1.0K	J	1/10W			M1E							
R99			RK73GB1J102J	CHIP R	1.0K	J	1/16W										
R100			RK73FB2A102J	CHIP R	1.0K	J	1/10W										
R101			RK73GB1J104J	CHIP R	100K	J	1/16W										
R102,103			RK73FB2A470J	CHIP R	47	J	1/10W										
R104			RK73FB2A104J	CHIP R	100K	J	1/10W										
R105-107			RK73FB2A222J	CHIP R	2.2K	J	1/10W										
R108			RK73GB1J222J	CHIP R	2.2K	J	1/16W										
R112,113			RK73GB1J222J	CHIP R	2.2K	J	1/16W										
R114			RK73GB1J124J	CHIP R	120K	J	1/16W			M1E							
R114			RK73GB1J164J	CHIP R	160K	J	1/16W			KK1							
R115			RK73FB2A102J	CHIP R	1.0K	J	1/10W			M1E							
R118			RK73GB1J102J	CHIP R	1.0K	J	1/16W										
R120			RK73GB1J102J	CHIP R	1.0K	J	1/16W			M1E							
R121			RK73GB1J103J	CHIP R	10K	J	1/16W										
R122			RK73FB2A103J	CHIP R	10K	J	1/10W										
R123			RK73FB2A102J	CHIP R	1.0K	J	1/10W										

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-84XX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R124			RK73GB1J473J	CHIP R 47K J 1/16W	
R125			RK73FB2A333J	CHIP R 33K J 1/10W	
R126,127			RK73FB2A473J	CHIP R 47K J 1/10W	
R128			RK73FB2A821J	CHIP R 820 J 1/10W	
R129			RK73GB1J153J	CHIP R 15K J 1/16W	
R130			RK73FB2A473J	CHIP R 47K J 1/10W	
R131			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R132-136			RK73EB2B471J	CHIP R 470 J 1/8W	
R137-139			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R140			RK73EB2B472J	CHIP R 4.7K J 1/8W	
R141,142			RK73GB1J104J	CHIP R 100K J 1/16W	
R143,144			RK73FB2A104J	CHIP R 100K J 1/10W	
R145			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R147			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R148,149			RK73GB1J334J	CHIP R 330K J 1/16W	
R151			RK73GB1J303J	CHIP R 30K J 1/16W	K
R152			RK73GB1J222J	CHIP R 2.2K J 1/16W	K
R153,154			RK73EB2B361J	CHIP R 360 J 1/8W	
R155,156			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R157,158			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R159,160			RK73EB2B361J	CHIP R 360 J 1/8W	
R161,162			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R163,164			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R165,166			RK73FB2A335J	CHIP R 3.3M J 1/10W	K
R167,168			RK73FB2A103J	CHIP R 10K J 1/10W	
R169,170			RK73FB2A223J	CHIP R 22K J 1/10W	
R171,172			RK73FB2A820J	CHIP R 82 J 1/10W	
R173			RK73EB2B472J	CHIP R 4.7K J 1/8W	
R175,176			RK73FB2A103J	CHIP R 10K J 1/10W	
R177,178			RK73FB2A223J	CHIP R 22K J 1/10W	
R179,180			RK73FB2A820J	CHIP R 82 J 1/10W	
R181-184			RK73FB2A472J	CHIP R 4.7K J 1/10W	K1M1
R185			RK73GB1J184J	CHIP R 180K J 1/16W	K1M1
R186			RK73FB2A431J	CHIP R 430 J 1/10W	K1M1
R187			RK73FB2A751J	CHIP R 750 J 1/10W	K1M1
R188			RK73FB2A243J	CHIP R 24K J 1/10W	K1M1
R189			RK73FB2A102J	CHIP R 1.0K J 1/10W	K1M1
R190			RK73FB2A101J	CHIP R 100 J 1/10W	K1M1
R191			RK73FB2A223J	CHIP R 22K J 1/10W	K1M1
R192			RK73GB1J333J	CHIP R 33K J 1/16W	K1M1
R193,194			RK73EB2B100J	CHIP R 10 J 1/8W	
R195			RK73EB2B4R7J	CHIP R 4.7 J 1/8W	
R196			RK73EB2B104J	CHIP R 100K J 1/8W	
R198			RK73FB2A105J	CHIP R 1.0M J 1/10W	
R199			RK73GB1J104J	CHIP R 100K J 1/16W	
R200			RK73EB2B222J	CHIP R 2.2K J 1/8W	
R201,202			RK73EB2B361J	CHIP R 360 J 1/8W	
R203,204			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R205,206			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R207,208			RK73FB2A103J	CHIP R 10K J 1/10W	
R209,210			RK73FB2A223J	CHIP R 22K J 1/10W	M1E
R211,212			RK73FB2A820J	CHIP R 82 J 1/10W	M1E
R215			RK73FB2A153J	CHIP R 15K J 1/10W	M1E
R216			RK73EB2B220J	CHIP R 22 J 1/8W	M1E
R217-219			RK73GB1J103J	CHIP R 10K J 1/16W	M1E
R220			RK73FB2A103J	CHIP R 10K J 1/10W	M1E
R221			RK73FB2A823J	CHIP R 82K J 1/10W	M1E
R222			RK73FB2A272J	CHIP R 2.7K J 1/10W	M1E
R223			RK73FB2A333J	CHIP R 33K J 1/10W	M1E
R224			RK73FB2A153J	CHIP R 15K J 1/10W	M1E
R225			RK73FB2A103J	CHIP R 10K J 1/10W	M1E
R226			RK73GB1J562J	CHIP R 5.6K J 1/16W	M1E
R227			RK73GB1J103J	CHIP R 10K J 1/16W	M1E
R228			RK73FB2A104J	CHIP R 100K J 1/10W	M1E
R229			RK73FB2A103J	CHIP R 10K J 1/10W	M1E
R230			RK73FB2A222J	CHIP R 2.2K J 1/10W	M1E
R231			RK73GB1J562J	CHIP R 5.6K J 1/16W	M1E
R232			RK73FB2A272J	CHIP R 2.7K J 1/10W	
R233			RK73FB2A223J	CHIP R 22K J 1/10W	
R234			RK73EB2B102J	CHIP R 1.0K J 1/8W	
R235			RK73FB2A223J	CHIP R 22K J 1/10W	
R236			RK73EB2B102J	CHIP R 1.0K J 1/8W	
R237			RK73FB2A105J	CHIP R 1.0M J 1/10W	M1E
R241			RK73FB2A101J	CHIP R 100 J 1/10W	
R242			RK73GB1J101J	CHIP R 100 J 1/16W	
R243,244			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R245			RK73FB2A122J	CHIP R 1.2K J 1/10W	
R246			RK73FB2A473J	CHIP R 47K J 1/10W	
R247			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R248			RK73FB2A104J	CHIP R 100K J 1/10W	
VR1			R32-0229-05	SEMI FIXED VARIABLE RESISTOR	M1E
W16 -21			R92-2052-05	CHIP R 0 J 1/10W	KK1
W18 ,19			R92-2052-05	CHIP R 0 J 1/10W	M1E
W27			R92-2052-05	CHIP R 0 J 1/10W	M1
W28			R92-2052-05	CHIP R 0 J 1/10W	KK1
PH1			T95-0231-05	OPTO ISOLATOR	
D1			RM10ZLF	DIODE	
D2			AM01Z	DIODE	
D2			ERA15-01	DIODE	
D3			MA4056(N)-M	ZENER DIODE	
D4			MA4082(N)-L	ZENER DIODE	
D6			HZM4.7N(B2)	ZENER DIODE	M1E
D7			MA4110(N)-M	ZENER DIODE	
D8			MA4056(N)-M	ZENER DIODE	
D11 ,12			AM01Z	DIODE	KK1
D11 ,12			ERA15-01	DIODE	KK1
D12			AM01Z	DIODE	M1E
D12			ERA15-01	DIODE	M1E
D13			DAP202K	DIODE	
D13			KDS181	DIODE	
D13			MA152WA	DIODE	
D16			MA3062WA	ZENER DIODE	
D18			MA3062WA	ZENER DIODE	
D19			MA4056(N)-M	ZENER DIODE	
D20			MA4062(N)-M	ZENER DIODE	
D21			DAN202K	DIODE	
D21			KDS184	DIODE	
D21			MA152WK	DIODE	
D22			DA204K	DIODE	

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

⚠ indicates safety critical components.

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

Teile ohane Parts No. werden nicht geliefert.						ELECTRIC UNIT (X25-84XX-XX)					
Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
D22 D23 ,24 D27 D27 D27			KDS226 RD6.8M(B2) DAP202K KDS181 MA152WA	DIODE ZENER DIODE DIODE DIODE DIODE	K1M1E K1M1E K1M1E	Q9 Q11 Q12 Q12 Q12			UN2212 DTA123JK DTC144EK KRC104S UN2213	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	
D28 ,29 D31 D31 D31 D32			RD6.8MW DAN202K KDS184 MA152WK MA3056-M	ZENER DIODE DIODE DIODE DIODE ZENER DIODE	M1E M1E M1E	Q13 Q14 Q14 Q15 Q16			2SB1443 2SC2412K 2SD601A 2SB709A 2SC2412K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D33 D34 D34 D34 D35 -43			SA-C2012-101TB DAN202K KDS184 MA152WK 1SR154-400	SURGE ABSORBER DIODE DIODE DIODE DIODE	K1M1E K1M1E K1M1E K1M1E	Q16 Q17 Q18 Q18 Q19			2SD601A 2SB709A 2SC2412K 2SD601A 2SB709A	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D43 D47 ,48 D47 ,48 D47 ,48 D50			1SR154-400 DAP202K KDS181 MA152WA MA3220-H	DIODE DIODE DIODE DIODE ZENER DIODE	K	Q20 Q20 Q21 Q22 Q22			2SC2412K 2SD601A 2SB1277(Q,R) DTC114EK UN2211	TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	KK1 KK1 KK1
D51 D51 D55 -59 D55 -59 D60			DA204K KDS226 DA204K KDS226 MA3062WA	DIODE DIODE DIODE DIODE ZENER DIODE		Q23 Q24 Q25 Q25 Q25			2SB1277(Q,R) 2SB709A DTA124EK KRA103S UN2112	TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	
IC1 IC2 IC3 IC4 IC5			UPD784217GC104 TDA7400 M5237ML TDA7386 TDA7401	MI-COM IC ANALOGUE IC IC(VOLTAGE REGULATOR) ANALOGUE IC ANALOGUE IC	K1M1E	Q26 Q26 Q28 ,29 Q28 ,29 Q30 ,31			DTC114EK UN2211 2SC2412K 2SD601A DTA124EK	DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	
IC6 IC7 -9 IC7 -9 IC10 IC11			TC7662BE0A NJM2068MD NJM4565M-TE2 TC74HC02AF TDA7479D	ANALOGUE IC IC(OP AMP) ANALOGUE IC IC ANALOGUE IC	K K1M1E	Q30 ,31 Q30 ,31 Q32 Q32 Q33			KRA103S UN2112 2SC2412K 2SD601A DTC124EK	TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	
IC12 IC13 IC14 IC14 IC15			NJM4565M-TE2 LB1930M BR24C01AF M24C01-WMN6T S-80830ANNP	ANALOGUE IC ANALOGUE IC MEMORY IC MEMORY IC MOS-IC	M1E	Q33 Q33 Q34 -37 Q34 -37 Q38			KRC103S UN2212 2SC2412K 2SD601A DTC114YK	TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	K1M1
IC16 Q1 Q2 Q2 Q3			NJM4565M-TE2 2SB1565(E,F) 2SC2412K 2SD601A 2SB709A	ANALOGUE IC TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR		Q38 Q38 Q39 ,40 Q39 ,40 Q41			KRC107S UN2214 2SC2412K 2SD601A 2SB709A	TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	K1M1 K1M1
Q4 Q5 Q5 Q5 Q6			2SB1565(E,F) DTA124EK KRA103S UN2112 DTC124EK	TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR		Q42 Q42 Q43 Q43 Q44			2SC2412K 2SD601A DTC114TK UN2215 DTA124EK	TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	M1E M1E M1E M1E M1E
Q6 Q6 Q7 Q9 Q9			KRC103S UN2212 2SD2396F40 DTC124EK KRC103S	TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR		Q44 Q44 Q45 Q45 Q45			KRA103S UN2112 DTC124EK KRC103S UN2212	TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	M1E M1E M1E M1E M1E

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

 indicates safety critical components.

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-84XX-XX)

CD PLAYER UNIT (X32-474X-XX)

Ref.No.	Ad New	Parts No.	Description	Destination
Q48		2SB1188(Q,R)	TRANSISTOR	
Q49		DTC124EK	DIGITAL TRANSISTOR	
Q49		KRC103S	TRANSISTOR	
Q49		UN2212	DIGITAL TRANSISTOR	
Q50		2SB1188(Q,R)	TRANSISTOR	
Q51		DTC124EK	DIGITAL TRANSISTOR	
Q51		KRC103S	TRANSISTOR	
Q51		UN2212	DIGITAL TRANSISTOR	
Q52		DTC144EK	DIGITAL TRANSISTOR	
Q52		KRC104S	TRANSISTOR	
Q52		UN2213	DIGITAL TRANSISTOR	
Q53 ,54		DTA124EK	DIGITAL TRANSISTOR	
Q53 ,54		KRA103S	TRANSISTOR	
Q55		2SC2412K	TRANSISTOR	
Q55		2SD601A	TRANSISTOR	
Q56		2SB1443	TRANSISTOR	
TH1		PTH9C42BD471Q	POSITIVE RESISTOR	K1M1
A1	3D	X86-3082-70	TUNER UNIT	E
A1	3D	X86-3100-10	TUNER UNIT	KK1
A1	3D	X86-3222-70	TUNER UNIT	M1
CD PLAYER UNIT (X32-474X-XX)				
C1 ,2		CK73FB1A105K	CHIP C 1.0UF K	
C3		C92-1359-05	CHIP-TAN 10UF 16WV	
C4		C92-0566-05	CHIP-TAN 10UF 6.3WV	
C5		CC73FCH1H330J	CHIP C 33PF J	
C6		CC73FCH1H030C	CHIP C 3.0PF C	
C7		CK73FB1C104K	CHIP C 0.10UF K	
C8		CK73FB1A105K	CHIP C 1.0UF K	
C9		CC73FCH1H101J	CHIP C 100PF J	
C10		CK73FB1H472K	CHIP C 4700PF K	
C11		CK73FB1H682K	CHIP C 6800PF K	
C12		CK73FB1H222K	CHIP C 2200PF K	
C13		CK73FB1H273K	CHIP C 0.027UF K	
C14		CK73FB1H472K	CHIP C 4700PF K	
C15		CK73FB1E473K	CHIP C 0.047UF K	
C16		CC73FCH1H101J	CHIP C 100PF J	
C17		CK73FB1H472K	CHIP C 4700PF K	
C18		CK73FB1H471K	CHIP C 470PF K	
C19 ,20		CK73FB1C104K	CHIP C 0.10UF K	
C21		C92-1359-05	CHIP-TAN 10UF 16WV	
C22		CK73FB1C104K	CHIP C 0.10UF K	
C23		CK73FB1H102K	CHIP C 1000PF K	
C24		CK73FB1H223K	CHIP C 0.022UF K	
C25		CK73FB1H123K	CHIP C 0.012UF K	
C26		CK73FB1A105K	CHIP C 1.0UF K	
C28		CK73FB1A105K	CHIP C 1.0UF K	
C29		CK73FB1C104K	CHIP C 0.10UF K	
C31 ,32		CK73FB1H103K	CHIP C 0.010UF K	
C33 ,36		CK73FB1C104K	CHIP C 0.10UF K	
C37		C93-1031-05	CERAMIC 0.010UF 50WV	
C40		CK73FB1C104K	CHIP C 0.10UF K	
C41		CK73EB1C225K	CHIP C 2.2UF K	
C43		CK73FB1H123K	CHIP C 0.012UF K	
C44		CK73FB1C104K	CHIP C 0.10UF K	

Ref.No.	Ad New	Parts No.	Description	Destination
C45		CK73FB1H123K	CHIP C 0.012UF K	
C46		CK73FB1E473K	CHIP C 0.047UF K	
C51		C92-1324-05	CHIP-TAN 4.7UF 16WV	
C52		CK73FB1E473K	CHIP C 0.047UF K	
C53 ,54		C93-1084-05	CERAMIC 1200PF J	
C55		CK73FB1C104K	CHIP C 0.10UF K	
C61		CK73EB1C105K	CHIP C 1.0UF K	
C63		C92-1324-05	CHIP-TAN 4.7UF 16WV	
C65 ,66		CK73FB1A105K	CHIP C 1.0UF K	
C67 ,68		C92-1324-05	CHIP-TAN 4.7UF 16WV	
C71 -74		C93-1084-05	CERAMIC 1200PF J	
C75 -78		CC73FCH1H271J	CHIP C 270PF J	
C79 ,80		C93-1044-05	CERAMIC 2200PF K	
C81		CK73FB1H102K	CHIP C 1000PF K	
C83 ,84		CC73FCH1H100D	CHIP C 10PF D	
C85 -87		CK73FB1C104K	CHIP C 0.10UF K	
CN1		E40-9536-05	FLAT CABLE CONNECTOR	
CN2		E40-9339-05	FLAT CABLE CONNECTOR	
CP8		L92-0320-05	FERRITE CORE	
L1		L40-1001-78	SMALL FIXED INDUCTOR(10UH)	
L2		L92-0308-05	FERRITE CORE	
L3		L92-0334-05	CHIP FERRITE	
L14		L79-0938-05	LC FILTER	
L15		L92-0308-05	FERRITE CORE	
X1		L77-2081-05	CRYSTAL RESONATOR	
CP1 -3		R90-1019-05	MULTI-COMP 100 X2	
R1 ,2		RK73FB2A333J	CHIP R 33K J 1/10W	
R3		RK73FB2A823J	CHIP R 82K J 1/10W	
R5		RK73FB2A910J	CHIP R 91 J 1/10W	
R6		RK73FB2A823J	CHIP R 82K J 1/10W	
R8		RK73EB2B4R7J	CHIP R 4.7 J 1/8W	
R9		RK73EB2B100J	CHIP R 10 J 1/8W	
R10 ,11		RK73FB2A682J	CHIP R 6.8K J 1/10W	
R12		RK73FB2A432J	CHIP R 4.3K J 1/10W	
R13		RK73FB2A363J	CHIP R 36K J 1/10W	
R14 ,15		RK73FB2A824J	CHIP R 820K J 1/10W	
R16		RK73FB2A223J	CHIP R 22K J 1/10W	
R17		RK73FB2A363J	CHIP R 36K J 1/10W	
R18		RK73FB2A392J	CHIP R 3.9K J 1/10W	
R19		RK73FB2A273J	CHIP R 27K J 1/10W	
R20		RK73FB2A104J	CHIP R 100K J 1/10W	
R21		RK73FB2A224J	CHIP R 220K J 1/10W	
R22 ,23		RK73FB2A333J	CHIP R 33K J 1/10W	
R31		RK73FB2A102J	CHIP R 1.0K J 1/10W	
R32		RK73FB2A104J	CHIP R 100K J 1/10W	
R34		RK73FB2A683J	CHIP R 68K J 1/10W	
R35		RK73FB2A104J	CHIP R 100K J 1/10W	
R36		RK73FB2A151J	CHIP R 150 J 1/10W	
R37		RK73FB2A471J	CHIP R 470 J 1/10W	
R38		RK73FB2A224J	CHIP R 220K J 1/10W	
R44		RK73FB2A512J	CHIP R 5.1K J 1/10W	
R45		RK73FB2A103J	CHIP R 10K J 1/10W	
R46		RK73FB2A102J	CHIP R 1.0K J 1/10W	

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

⚠ indicates safety critical components.

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

CD PLAYER UNIT (X32-474X-XX)

DAUGHTER UNIT (X89-241X-XX)

MECHANISM ASSY (X92-37XX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R47			RK73FB2A103J	CHIP R 10K J 1/10W	
R49			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R50			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R52			RK73FB2A104J	CHIP R 100K J 1/10W	
R54			RK73FB2A104J	CHIP R 100K J 1/10W	
R71			RK73FB2A103J	CHIP R 10K J 1/10W	
R72			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R73			RK73FB2A473J	CHIP R 47K J 1/10W	
R74			RK73FB2A103J	CHIP R 10K J 1/10W	
R75			RK73FB2A333J	CHIP R 33K J 1/10W	
R76			RK73FB2A622J	CHIP R 6.2K J 1/10W	
R77			RK73FB2A563J	CHIP R 56K J 1/10W	
R78			RK73FB2A243J	CHIP R 24K J 1/10W	
R79			RK73FB2A242J	CHIP R 2.4K J 1/10W	
R80			RK73FB2A202J	CHIP R 2.0K J 1/10W	
R81			RK73FB2A333J	CHIP R 33K J 1/10W	
R82			RK73FB2A103J	CHIP R 10K J 1/10W	
R83			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R91			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R101,102			RK73FB2A241J	CHIP R 240 J 1/10W	
R103,104			RK73FB2A122J	CHIP R 1.2K J 1/10W	
R115-118			R92-2029-05	CHIP R 2.0K D 1/10W	
R119-122			R92-2044-05	CHIP R 2.7K D 1/10W	
R123-126			R92-2048-05	CHIP R 7.5K D 1/10W	
R127,128			RK73FB2A331J	CHIP R 330 J 1/10W	
R202			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R210			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R211			RK73FB2A681J	CHIP R 680 J 1/10W	
R215			RK73FB2A103J	CHIP R 10K J 1/10W	
R216,217			RK73FB2A155J	CHIP R 1.5M J 1/10W	
R218			RK73FB2A473J	CHIP R 47K J 1/10W	
R219			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R220			RK73FB2A103J	CHIP R 10K J 1/10W	
W1			R92-2053-05	CHIP R 0 J 1/8W	
W3			R92-2052-05	CHIP R 0 J 1/10W	
W8			R92-2052-05	CHIP R 0 J 1/10W	
S1 ,2			S68-0838-05	PUSH SWITCH	
S3			S68-0823-05	PUSH SWITCH	
D1 ,2			DAN202U	DIODE	
D3			DA204K	DIODE	
D4			DAN202U	DIODE	
IC1			AN8806SB	ANALOGUE IC	
IC2			MN662773KB3	MOS-IC	
IC4			BA5917AFP	ANALOGUE IC	
IC5			TA78L05F	IC(VOLTAGE REGULATOR/ +5V)	
IC6			NJM5532MD	IC(OP AMP)	
IC7			KKZ05F	CUSTOM IC	
IC8			TC7SH08F	MOS-IC	
IC9			TC7SZ04F	MOS-IC	
Q1			2SB1188	TRANSISTOR	
Q2			DTC124EUA	DIGITAL TRANSISTOR	
Q3 ,4			2SA1362(Y)	TRANSISTOR	
Q5			DTC124EUA	DIGITAL TRANSISTOR	

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
Q7			FMC5A	DIGITAL TRANSISTOR	
Q8			DTC124EUA	DIGITAL TRANSISTOR	
DAUGHTER UNIT (X89-241X-XX)					
C1			C90-2966-05	ELECTRO 100UF 16VV	
C2			CK73FB1H103K	CHIP C 0.010UF K	
C3			C90-2966-05	ELECTRO 100UF 16VV	
C4			CK73FB1H103K	CHIP C 0.010UF K	
C5			C90-2984-05	ELECTRO 47UF 50VV	
C6			CK73FB1H103K	CHIP C 0.010UF K	
C7			CK73EB1C225K	CHIP C 2.2UF K	
CN1			E40-3250-05	PIN ASSY	
L1			L33-1029-05	SMALL FIXED INDUCTOR	
R1			RK73EB2B473J	CHIP R 47K J 1/8W	
R2			RK73FB2A152J	CHIP R 1.5K J 1/10W	
R3			RK73EB2B103J	CHIP R 10K J 1/8W	
R4			R92-2104-05	CHIP R 2.2 J 1W	
D1			MA4100-L	ZENER DIODE	
D2			MA4051(N)-M	ZENER DIODE	
D3			DA204K	DIODE	
D3			KDS226	DIODE	
Q1			2SB1184	TRANSISTOR	
Q2			2SC2412K	TRANSISTOR	
Q2			2SD601A	TRANSISTOR	
A1		*	W02-3232-05	ELECTRIC CIRCUIT MODULE	
MECHANISM ASSY (X92-37XX-XX)					
401	2A		A10-4482-01	CHASSIS	
402	2A		A10-4225-33	CHASSIS CALKING ASSY	
403	2B		A11-0915-43	SUB CHASSIS CALKING ASSY	
405A	2A		D10-4038-23	ARM ASSY	
406	2A		D10-4306-04	ARM ASSY	
407	2A		D10-4305-04	ARM ASSY	
408	3A		D10-3087-44	ARM ASSY	
409	3B		D10-3092-03	SLIDER	
410	3B		D10-3093-04	SLIDER ASSY	
411	2B		D10-3095-04	SLIDER ASSY	
412	2B		D10-3096-04	SLIDER ASSY	
413	1A		D10-3099-24	SLIDER ASSY	
414	1A		D10-3100-04	SLIDER ASSY	
415	2A		D10-4123-24	LEVER ASSY	
416	1B		D10-4004-04	LEVER ASSY	
417	1B		D10-4006-04	LEVER	
418	1A		D10-4007-04	LEVER	
419	2B		D10-4008-14	LEVER	
420	2A		D10-4009-23	ARM	
421	3B		D10-4010-04	LEVER	
422	3A		D10-4011-34	LEVER ASSY	
423	3A		D10-4013-14	ARM ASSY	
424	3B		D10-4050-04	ARM	
427	3B		D13-1340-13	RACK (GEAR)	
429	3B		D13-1231-04	GEAR	

K: KDC-X915 K1: KDC-X815 M1: KDC-PS9016R E: KDC-PS9080R

⚠ indicates safety critical components.

PARTS LIST/SPECIFICATIONS

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref.No.	Adew	Parts No.	Description	Destination
430	3B	D13-1232-04	GEAR	
431	3B	D13-1233-04	GEAR	
432	3B	D13-1234-14	GEAR ASSY	
433	3A	D13-1238-03	GEAR	
434	3B	D13-1240-04	GEAR	
435	3B	D13-1241-04	GEAR	
436	3B	D13-1242-04	GEAR	
437	1B	D13-1243-04	GEAR	
438	1B	D13-1244-04	GEAR	
439	1B	D13-1245-14	GEAR	
440	2A	D13-1246-04	GEAR	
441	2B	D13-1247-04	GEAR	
443	2B	D13-1249-04	GEAR ASSY	
445	1B	D14-0668-04	ROLLER	
446	2A	D14-0670-04	ROLLER	
447	3B	D14-0674-04	ROLLER	
448	2B	D13-1341-04	GEAR ASSY	
449	3A	D21-2228-14	SHAFT	
450	1A	D21-2229-04	SHAFT	
451	1A	D23-0925-24	RETAINER	
452	2A	D32-0614-04	STOPPER	
453	1B	D39-0223-05	DAMPER	
454	2B	D39-0224-05	DAMPER	
455	3B	F09-1246-04	SHEET	
458	3B	F09-1266-14	SHEET	
460	2B	G01-2770-04	EXTENSION SPRING	
461	3A	G01-2771-04	EXTENSION SPRING	
462	3A	G01-2772-24	EXTENSION SPRING	
463	3A	G01-2773-14	EXTENSION SPRING	
464	3A	G01-2774-34	EXTENSION SPRING	
465	1B	G01-2775-04	TORSION COIL SPRING	
466	1B	G01-2776-14	TORSION COIL SPRING	
467	3B	G01-2777-24	TORSION COIL SPRING	
469	2A	G01-2844-04	EXTENSION SPRING	
470	2A	G02-1231-04	FLAT SPRING	
471	2B	G02-1232-24	FLAT SPRING	
472	2A	G02-1241-24	FLAT SPRING	
475	2A	J11-0613-13	CLAMPER	
476	3A	J19-4678-13	HOLDER	
477	2B	J19-4679-24	HOLDER	
478	3B	J21-7684-13	MOUNTING HARDWARE	
479	2B	J21-7686-13	MOUNTING HARDWARE	
480	1B	J21-7690-03	MOUNTING HARDWARE	
481	3A	J31-1032-04	COLLAR	
482	3A	J84-0107-05	FLEXIBLE PRINTED WIRING BOARD	
483	1A	J90-0757-22	GUIDE	
A	2A	N09-4249-05	MACHINE SCREW (M1.7X2.5,LOCK)	
B	1D	N09-4172-05	TAPPING SCREW (2X3.5)	
C	2B	N09-4202-05	STEPPED SCREW	
D	2A	N38-2020-46	PAN HEAD MACHIN SCREW	
F	3B	N19-2023-04	FLAT WASHER	
G	2A	N19-2058-04	FLAT WASHER	
H	3A	N19-2093-04	FLAT WASHER	
DM1	3B	T42-0764-04	DC MOTOR ASSY	
DM2	3B	T42-0763-04	DC MOTOR ASSY	
DPU1	2B	T25-0215-05	OPTICAL PICKUP HEAD	

KDC-X915/X815

FM Section

Frequency Range	87.9MHz~107.9MHz
(Frequency Step)	(200kHz)
Channel Space selection	50k/200kHz
Usable Sensitivity(S/N:30dB)	9.3dBf(0.8μV/75Ω)
Quieting Sensitivity(S/N:50dB)	15.2dBf (1.6μV/75Ω)
Frequency Response(±3.0dB)	30Hz~15kHz
S/N	70dB(MONO)
Selectivity	≥80dB(±400kHz)
Stereo Separation	40dB(1kHz)

AM Section

Frequency Range	530kHz~1700kHz
(Frequency Step)	(10kHz)
Channel Space selection	9k/10kHz
Usable Sensitivity(S/N:20dB)	28dBμ(25μV)

CD Section

Laser Diode	GaAlAs(λ=780nm)
Digital Filter(D/A)	8 Times Over Sampling
D/A Converter	1Bit
Spindle Speed	500~200(CLV)
Wow & Flutter	Below Measurable Limit
Frequency Response	10~20kHz(±1dB)
Total Harmonic Distortion	0.01%(1kHz)
S/N Ratio	105dB(1kHz)
Dynamic Range	100dB
Channel Separation	95dB

Preout Level (mV) /Load-Unbalanced 4500mV/10kΩ(CD/CD-CH)

Preout Impedance 80Ω

AMPLIFIER Section (KDC-X815 only)

Maximum Power	45W×4
Full Bandwidth Power(at less than 1%THD)	22W×4

TONE Section

Bass	100Hz±10dB
Treble	10kHz±10dB

General

Operating Voltage 14.4V
(11~16V allowable)

Current Consumption

KDC-X915 5A

KDC-X815 10A

Installation Size	KDC-X915	(W) ...	182(mm) 7-3/16(in)
		(H)	53(mm) 2-1/16(in)
		(D)	160(mm) 6-5/16(in)
	KDC-X815	(W) ...	182(mm) 7-3/16(in)
		(H)	53(mm) 2-1/16(in)
		(D)	162(mm) 6-3/8(in)

Weight

KDC-X915 4.0lbs(1.8kg)

KDC-X815 4.2lbs(1.9kg)