
2.2 EXTERIOR



(1)EXTERIOR SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Screw	BMZ26P040FMC
	2	Connector	CDE6732
	3	•••••	
	4	Screw	BMZ20P025FMC
	5	Screw	BMZ26P040FMC
	6	Screw(M2x2.5)	CBA1076
	7	Spring(Silver)	CBH2481
	8	Spring(Black)	CBH2482
	9	Connector	CDE7020
	10	Connector	CDE7035
	11	Case	CNB2705
	12	Sheet	CNM5981
	13	Damper	CNV6608
	14	Control Unit(G2T)	CWX2649
	15	Connector(CN601)	CKS1956
	16	Connector(CN101)	CKS4512
	17	Service Mechanism Unit(G2T)	CXX1658
	18	Frame	CNC9638
	19	Insulator	CNM7496
	20	Spacer	CNM8078
	21	Label	CRW1425
	22	Main Unit	See Contrast table(2)
	23	Screw	BMZ30P060FMC
	24	Screw(M3x6)	CBA1393
	25	Connector(CN801)	CKM1322
	26	Connector(CN473)	CKM1350
	27	Connector(CN472)	CKM1351
	28	Plug(CN354)	CKS-291
	29	Connector(CN353)	CKS3568
	30	Connector(CN351)	CKS3886
	31	Connector(CN804)	CKS4361
	32	Connector(CN501)	CKX1064
	33	Holder	CNC9639
	34	Holder	CNC9701
	35	FM/AM Tuner Unit	CWE1630
	36	Holder	CNC8855
	37	Terminal(CN802,CN803)	VNF1084
	38	Chassis Unit	CXB8029
	39	Chassis Unit	CXB7841
	40	Screw	BPZ20P080FMC


Mark	No.	Description	Part No.
	41	Button(EJECT)	CAC7189
	42	Button(LOAD)	CAC7190
	43	Button(1,2)	CAC7191
	44	Button(3,4)	CAC7192
	45	Button(5,6)	CAC7193
	46	Button(SCAN,TEXT)	CAC7194
	47	Button(SEEK,TRACK)	CAC7197
	48	Button(RDS,TYPE)	CAC7198
	49	Button(AM)	CAC7198
	50	Button(FM)	CAC7200
	51	Button(TAPE)	CAC7201
	52	Button(DISC)	CAC7202
	53	Lighting Conductor	CNV6895
	54	Holder	CNV6898
	55	Holder	CNV6899
	56	Holder	CNV6956
	57	Keyboard Unit	CWS1342
	58	LCD(LCD901)	CAW1700
	59	Connector(CN901)	CKS4361
	60	Holder	CNC9700
	61	Sheet	CNM7733
	62	Seal	CNM7771
	63	Rubber	CNV6892
	64	Lighting Conductor	CNV6894
	65	Connector	CNV7498
	66	Grille Unit	See Contrast table(2)
	67	Screw	BPZ20P060FZK
	68	Door	See Contrast table(2)
	69	Spring	CBH2663
	70	Door Assy	CXC1348
	71	Knob Unit	CXB8819
	72	Button Assy(EJECT)	CXB8830
	73	Button Assy(TRAF)	CXB8831
	74	Shield Unit	CXB9781
	75	Cassette Mechanism Module	EXK4295
	76	Screw	IMS26P040FMC
	77	Screw	ISS26P060FMC
	78	Transistor(Q809,811,812)	2SB1185
	79	Bracket Unit	CXB8082
	80	Label	CRW1429

(2) CONTRAST TABLE

FX-MG8527ZT/UC and FX-MG8727ZT/UC are constructed the same except for the following:

Mark	NO	Symbol and Description	FX-MG8527ZT/UC	FX-MG8727ZT/UC
	22	Main Unit	CWM8064	CWM8582
	66	Grille Unit	CXC1344	CXC1343
	68	Door	CAT2300	CAT2295


2.3 CD MECHANISM UNIT(1)



CD MECHANISM UNIT(1) SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Screw	BMZ20P020FZB
	2	Screw	BMZ20P025FMC
	3	Screw(M2x2)	CBA1556
	4	Screw(M2x2.5)	CBA1557
	5	Screw(M2x2.5)	CBA1577
	6	Screw(M2x4.5)	CBA1607
	7	Spring	CBH2460
	8	Spring	CBH2461
	9	Spring	CBH2484
	10	Spring	CBH2485
	11	Spring	CBH2486
	12	Spring	CBH2487
	13	Spring	CBH2500
	14	Connector	CDE6698
	15	Collar	CLA3994
	16	Collar	CLA4039
	17	Collar	CLA4248
	18	Gear	CNC9222
*	19	Cam Gear	CNC9223
	20	Frame	CNC9225
	21	Steer	CNC9669
	22	Arm	CNC9242
	23	Bracket	CNC9403
*	24	Bracket	CNC9408
*	25	Lever	CNC9953
	26	Gear	CNV6612
	27	Holder	CNV6648
	28	Holder	CNV6738
*	29	Chassis Unit	CXB6873
*	30	Frame Unit	CXB6875
*	31	Arm Unit	CXB6887
	32	Spring	CBH2488
	33	Holder Unit	CXB6877
	34	Holder Unit	CXB6884
	35	Tray Unit	CXB6930
	36	Lever Unit	CXB6934
*	37	Lever Unit	CXB6936
	38	Lever Unit	CXB6938
*	39	Lever Unit	CXB6939
	40	Cam Motor Assy	CXB7522
	41	Washer	CBF1064
	42	Gear	CNV6610
	43	Gear	CNV6611
	44	Motor Unit(-A)(M1)	CXB9726
	45	Screw	JFZ20P020FMC
	46	Washer	YE20FUC
	47	ELV Motor Assy	CXB7523
	48	Screw	BMZ20P025FMC
	49	Washer	CBF1064
	50	Holder	CNC9799
	51	Gear	CNV6634
	52	Gear	CNV6635
	53	PCB Unit(LED)	CWX2614
*	54	Connector(CN31)	CKS4523
	55	Motor Unit(-B)(M2)	CXB7526
	56	Screw	JFZ20P020FMC
*	57	Arm Unit	CXB7747
	58	Bracket Unit	CXB7811
*	59	Lever Unit	CXB8653
*	60	Lever Unit	CXB8724
*	61	Lever Unit	CXB8824
	62	Arm Assy	CXB8822
	63	Washer	CBF1038
	64	Spring	CBH2489
	65	Arm	CNV6735
	66	Bracket Unit	CXB7519
	67	Screw	BMZ20P025FMC
	68	Spring	CBH2459
	69	Volume(VR1)	CCW1023
	70	Bracket	CNC9226
	71	Steer	CNC9235
	72	Flexible PCB	CNP6368
	73	PCB Unit(SIDE)	CWX2613
	74	Connector(CN12)	CKS3991
*	75	Connector(CN14)	CKS4404
	76	Connector(CN13)	CKS4525
	77	Connector(CN11)	CKS4572
	78	Lever Unit	CXB6883
*	79	Lever Unit	CXB9121
*	80	Lever Unit	CXB9122
	81	Screw	JFZ20P020FMC
	82	Washer	CBF1037

2.4 CD MECHANISM UNIT(2)




①:GEM1043
②:GEM1042

CD MECHANISM UNIT(2) SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Carriage Mech. Assy(G2T)	CXB8842
	2	Screw(M2x2)	CBA1556
	3	Screw(M2x6)	CBA1582
	4	Washer	CBF1038
	5	Spring	CBH2453
	6	Spring	CBH2480
	7	Spring	CBL1521
*	8	Guide	CNC9402
	9	Flexible PCB	CNP6217
	10	Holder	CNV6624
	11	Holder	CNV6625
	12	Rack	CNV6642
	13	Arm	CNV6731
	14	Lever	CNV6736
	15	Holder	CNV6737
	16	PCB Unit	CWX2611
	17	Connector(CN41)	CKS3785
	18	Connector(CN42)	CKS4508
	19	Connector(CN1)	CKS4508
	20	Support Wheel Unit	CXB8486
	21	Screw Unit(-A)	CXB7518
	22	Carriage Motor Assy	CXB7521
	23	Washer	CBF1038
	24	Belt	CNT1088
	25	Pulley	CNV6627
	26	Gear	CNV6629
	27	Motor Unit(-A)(M3)	CXB7517
	28	Screw	JFZ14P020FMC
	29	Loading Mech. Assy	CXB7525
	30	Washer	CBF1037
*	31	Washer	CBF1075
*	32	Spring	CBH2450
	33	Spring	CBH2452
*	34	Spring	CBH2457
*	35	Spring	CBH2580
*	36	Frame	CNC9228
*	37	Arm	CNC9229
*	38	Sheet	CNM7295
	39	Roller	CNV6616
	40	Collar	CNV6617
*	41	Guide	CNV6622
*	42	Holder	CNV6636
*	43	Lever	CNV6732
*	44	Lever	CNV6733
	45	Collar	CNV6734
*	46	Holder	CNV7144
	47	Screw	JFZ12P018FMC
	48	Washer	CBF1037
*	49	Motor Unit(-C)	CXB7529
	50	Shaft Unit(-B)	CXB7528
	51	Screw	JFZ20P020FMC
	52	PU Unit(PX1)(Service)	CXX1569
*	53	Gear	CNV6620
*	54	Gear	CNV6621
	55	Switch(S1,2)	CSN1057
*	56	Connector	CDE6674

2.5 CASSETTE MECHANISM MODULE

For grease application, refer to the service manual for CX-1011 (CRT2406).



CASSETTE MECHANISM MODULE SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Screw	BSZ20P040FMC
	2	Washer	CBF1037
	3	Washer	CBG1003
	4	Screw	EBA1028
	5	Screw	CBA1037
	6	Spring	EBH1653
	7	Spring	EBH1642
	8	Spring	EBH1641
	9	Spring	EBH1626
	10	Spring	EBH1627
	11	Spring	EBH1648
	12	Cord	EDD1024
	13	Photo-reflector(Q101)	EGN1004
	14	Arm	ENC1526
	15	Lever Unit	EXA1610
	16	Lever	ENC1543
	17	Arm	ENC1532
	18	Frame	ENC1533
	19	Holder	ENC1547
	20	Gear	ENC1535
	21	Arm	ENC1550
	22	Roller	ENR1040
	23	Belt	ENT1027
	24	Collar	ENV1508
	25	Arm	ENV1539
	26	Arm	ENV1540
	27	Gear	ENV1569
	28	Gear	ENV1547
	29	Gear	ENR1044
	30	Worm Wheel	ENV1559
	31	Lever	ENV1551
	32	Flywheel	ENV1554
	33	Gathering PCB	ENX1073
	34	Switch(S101,S102,S103)	ESG1007
	35	Deck Unit	EWM1043
	36	Plug(CN251)	CKS3540
	37	Gathering PCB	ENX1076
	38	Motor Unit(M1)	EXA1618
	39	Motor	EXM1035
	40	Head Assy(HD1)	EXA1594
	41	Arm	ENC1537
	42	Screw	JGZ20P025FNI
	43	Bracket	ENC1559
	44	Chassis Unit	EXA1636
	45	Pinch Holder Unit	EXA1608
	46	Pinch Roller	ENV1518
	47	Pinch Holder Unit	EXA1607
	48	Pinch Roller	ENV1518
	49	Reel Unit	EXA1625
	50	Head Base Unit	EXA1611
	51	Lever Unit	EXA1587
	52	Gear Unit	EXA1596
	53	Motor Unit(M2)	EXA1623
	54	Washer	HBF-179
	55	Spring	EBH1537
	56	Worm Gear	ENV1564
	57	Spring	EBH1655
	58	Lever	ENC1548
	59	Washer	YE15FUC
	60	Tube	ENM1039
	61	Spring	EBH1645
	62	Spring	EBH1545
	63	Sensor Unit	EWM1041

5. ELECTRICAL PARTS LIST

NOTE:

- *Parts whose parts numbers are omitted are subject to being not supplied.*
- *The part numbers shown below indicate chip components.*

Chip Resistor

RS1/◯S◯◯◯J,RS1/◯◯S◯◯◯J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

A

Unit Number:CWM8064(FX-MG8527ZT/UC)
Unit Number:CWM8582(FX-MG8727ZT/UC)
Unit Name:Main Unit

MISCELLANEOUS

Circuit Symbol and No.	Part Name	Part No.
IC201	IC	NJM2068MD
IC202	IC	TC4052BF
IC203	IC	NJM2068MD
IC204	IC	NJM2068MD
IC252	IC	PM4009A
IC302	IC	TC4052BF
IC303	IC	NJM2068MD
IC304	IC	NJM2068MD
IC401	IC	NJM2068MD
IC501	IC	LA1061M
IC561	IC	HA12181FP
IC601	IC	PD5732A
IC602	IC	S-80735ANDZI
IC701	IC	HA12187FP
IC870	IC	S-81256SGUP-DIM
Q 201	Transistor	DTC144EU
Q 202	Transistor	DTC144EU
Q 203	Transistor	DTC144EU
Q 204	Transistor	FMG13
Q 205	Transistor	FMG13
Q 301	Transistor	DTC144EU
Q 302	Transistor	DTC144EU
Q 303	Transistor	DTC144EU
Q 304	Transistor	FMG13
Q 305	Transistor	FMG13
Q 351	Transistor	IMX1
Q 405	Transistor	DTC143TU
Q 406	Transistor	IMH3A
Q 451	Transistor	2SB1260
Q 452	Transistor	2SC2712
Q 453	Transistor	2SC2712
Q 497	Transistor	DTC114EU
Q 501	Transistor	IMX1
Q 502	Transistor	2SC2712
Q 504	Transistor	2SC2712
Q 561	Transistor	2SC2712
Q 563	Transistor	IMT2A
Q 564	Transistor	IMH1A
Q 644	Transistor	DTC114EU
Q 645	Transistor	2SA1162
Q 721	Transistor	DTA114EU
Q 722	Transistor	2SC2712
Q 801	Transistor	DTC114EU
Q 802	Transistor	IMX1
Q 805	Transistor	DTC144TUA
Q 806	Transistor	DTC144TUA
Q 807	Transistor	DTC144TUA
Q 808	Transistor	2SB1184F5
Q 809	Transistor	2SB1185
Q 811	Transistor	2SB1185
Q 812	Transistor	2SB1185
Q 813	Transistor	2SA1162
Q 814	Transistor	2SA1162
Q 815	Transistor	IMX1
Q 816	Transistor	2SC4081
Q 818	Transistor	2SB1184F5
Q 819	Transistor	2SA1162
Q 820	Transistor	IMX1
Q 822	Transistor	2SD2226K
Q 825	Transistor	2SA1162
Q 860	Transistor	2SA1162
Q 861	Transistor	DTC143EU
Q 862	Transistor	DTC144TUA
Q 863	Transistor	IMD3A
Q 864	Transistor	DTA114EU
Q 865	Transistor	DTA114EU
Q 866	Transistor	DTA114EU
Q 867	Transistor	DTA114EU
Q 870	Transistor	2SD1767
Q 882	Transistor	2SA1162
Q 884	Transistor	DTC124EU
D 203	Diode	HZU4R7(B2)
D 451	Diode	DAN202K
D 452	Diode	1SS355
D 472	Diode	MPG06G-6415G50
D 473	Diode	MPG06G-6415G50
D 474	Diode	1SS355
D 475	Diode	1SS355
D 497	Diode	UDZS20(B)
D 501	Diode	1SV241
D 502	Diode	1SV241
D 503	Diode	DAP202K
D 504	Diode	1SS355
D 703	Diode	UDZS18(B)
D 704	Diode	UDZS18(B)
D 801	Diode	1SS355
D 802	Diode	UDZS5R6(B)
D 803	Diode	RM4LFJ10
D 804	Diode	1SS355
D 805	Diode	UDZS20(B)

Circuit Symbol and No.	Part Name	Part No.
D 808	Diode	HZU8R2(B2)
D 809	Diode	HZU7R5(B3)
D 810	Diode	HZU8R2(B2)
D 811	Diode	1SS355
D 812	Diode	HZU7R5(B3)
D 813	Diode	1SS355
D 814	Diode	HZU8R2(B3)
D 860	Diode	HZU8R2(B3)
D 861	Diode	1SS355
D 862	Diode	1SS355
D 863	Diode	DAP202K
D 864	Diode	1SS355
D 870	Diode	MPG06G-6415G50
D 871	Diode	UDZS16(B)
D 882	Diode	1SS355
L 251	Inductor	LCTA101J2520
L 252	Inductor	LCTC100K3216
L 351	Inductor	LCTC2R2K1608
L 352	Inductor	LCTC2R2K1608
L 353	Inductor	LCTC2R2K1608
L 354	Inductor	LCTC2R2K1608
L 355	Inductor	CTF1578
L 356	Inductor	LCTC2R2K1608
L 357	Inductor	CTF1306
L 358	Inductor	CTF1306
L 359	Inductor	CTF1306
L 360	Inductor	CTF1306
L 361	Inductor	CTF1306
L 363	Inductor	LFEA4R7J
L 505	Ferri-Inductor	LAU4R7K
L 506	Coil	CTB1112
L 507	Inductor	LCTC6R8K3216
L 508	Inductor	LCTC6R8K3216
L 509	Inductor	LCTC6R8K3216
L 510	Inductor	LCTA561J4532
L 511	Inductor	LCTA4R7J2520
L 512	Inductor	LCTA1R0J2520
L 513	Inductor	LCTA1R0J2520
L 514	Inductor	LCTA1R0J2520
L 561	Inductor	LCTA4R7J2520
L 601	Inductor	LCTA100J3225
L 801	Coil 350µH	CTH1276
CG501	Surge Protector	DSP-201M-A21F
CG502	Surge Protector	DSP-201M-A21F
X 251	Crystal Resonator 3.648MHz	CSS1447
X 601	Radiator 10.0MHz	CSS1577
VR561	Semi-fixed 10kΩ(B)	CCP1396
FU471	Fuse 5A	CEK1216
	FM/AM Tuner Unit	CWE1630
EF352	EMI Filter	CCG1163

RESISTORS

Circuit Symbol and No.	Part No.
R 1	RS1/16S0R0J
R 2	RS1/16S0R0J
R 201	RS1/16S223J
R 202	RS1/16S223J
R 203	RS1/16S223J
R 204	RS1/16S223J
R 205	RS1/16S223J
R 206	RS1/16S223J
R 207	RS1/16S223J
R 208	RS1/16S223J
R 211	RS1/16S101J
R 212	RS1/16S101J
R 213	RS1/16S103J
R 214	RS1/16S103J
R 215	RS1/16S163J
R 216	RS1/16S163J
R 217	RS1/16S163J
R 218	RS1/16S163J
R 219	RS1/16S163J
R 220	RS1/16S163J
R 221	RS1/16S103J
R 222	RS1/16S103J
R 223	RS1/16S103J
R 224	RS1/16S103J
R 225	RS1/16S181J
R 226	RS1/16S181J
R 227	RS1/16S181J
R 228	RS1/16S181J
R 229	RS1/10S470J
R 230	RS1/10S470J
R 231	RS1/10S470J
R 232	RS1/10S470J
R 233	RS1/16S473J
R 234	RS1/16S473J
R 235	RS1/16S473J
R 237	RS1/16S473J
R 238	RS1/16S473J
R 239	RS1/16S473J
R 240	RS1/16S473J
R 241	RS1/16S222J
R 243	RS1/16S103J
R 244	RS1/16S103J
R 245	RS1/16S103J
R 246	RS1/16S103J
R 247	RS1/16S562J
R 248	RS1/16S562J
R 249	RS1/16S562J
R 250	RS1/16S562J
R 257	RS1/16S102J
R 261	RS1/16S225J
R 285	RS1/16S104J
R 286	RS1/16S104J
R 287	RS1/16S104J
R 288	RS1/16S104J
R 313	RS1/16S103J
R 314	RS1/16S103J
R 315	RS1/16S163J
R 316	RS1/16S163J
R 317	RS1/16S163J
R 318	RS1/16S163J
R 319	RS1/16S163J
R 320	RS1/16S163J
R 321	RS1/16S103J
R 322	RS1/16S103J
R 323	RS1/16S103J
R 324	RS1/16S103J
R 325	RS1/16S181J

Circuit Symbol and No.	Part Name	Part No.
R 326		RS1/16S181J
R 327		RS1/16S181J
R 328		RS1/16S181J
R 329		RS1/10S470J
R 330		RS1/10S470J
R 331		RS1/10S470J
R 332		RS1/10S470J
R 333		RS1/16S473J
R 334		RS1/16S473J
R 335		RS1/16S473J
R 337		RS1/16S473J
R 338		RS1/16S473J
R 339		RS1/16S473J
R 340		RS1/16S473J
R 351		RS1/16S103J
R 352		RS1/16S103J
R 353		RS1/16S223J
R 354		RS1/16S223J
R 355		RS1/16S273J
R 356		RS1/16S273J
R 357		RS1/16S102J
R 358		RS1/16S102J
R 359		RS1/16S100J
R 369		RS1/16S100J
R 401		RS1/16S432J
R 402		RS1/16S432J
R 407		RS1/16S102J
R 408		RS1/16S102J
R 413		RS1/16S102J
R 414		RS1/16S102J
R 417	(FX-MG8527ZT/UC)	RS1/16S623J
R 417	(FX-MG8727ZT/UC)	RS1/16S913J
R 418	(FX-MG8527ZT/UC)	RS1/16S623J
R 418	(FX-MG8727ZT/UC)	RS1/16S913J
R 427		RS1/16S203J
R 428		RS1/16S203J
R 429		RS1/16S683J
R 430		RS1/16S683J
R 431		RS1/16S473J
R 432		RS1/16S473J
R 433		RS1/16S101J
R 451		RS1/16S102J
R 452		RS1/16S223J
R 453		RS1/16S823J
R 454		RS1/16S181J
R 455		RS1/16S181J
R 456		RS1/16S181J
R 457		RS1/16S181J
R 458		RS1/16S181J
R 459		RS1/16S223J
R 460		RS1/16S223J
R 474		RS1/8S103J
R 497		RS1/8S221J
R 501		RS1/16S225J
R 502		RS1/16S225J
R 503		RS1/16S225J
R 504		RS1/16S225J
R 505		RS1/16S222J
R 506		RS1/16S104J
R 507		RS1/16S103J

Circuit Symbol and No.	Part Name	Part No.
R 508		RS1/16S103J
R 509		RS1/16S334J
R 510		RS1/16S101J
R 511		RS1/16S101J
R 512		RS1/16S104J
R 513		RS1/16S104J
R 514		RS1/16S103J
R 515		RS1/16S182J
R 516		RS1/16S683J
R 517		RS1/16S224J
R 518		RS1/16S473J
R 519		RS1/16S473J
R 520		RS1/16S102J
R 522		RS1/16S222J
R 525		RS1/16S473J
R 526		RS1/16S681J
R 527		RS1/16S681J
R 528		RS1/16S681J
R 529		RS1/16S103J
R 530		RS1/16S681J
R 531		RS1/16S473J
R 532		RS1/16S473J
R 533		RS1/16S472J
R 534		RS1/16S393J
R 535		RS1/16S473J
R 536		RS1/16S103J
R 537		RS1/16S473J
R 538		RS1/16S681J
R 539		RS1/16S681J
R 543		RS1/16S681J
R 546		RS1/16S103J
R 547		RS1/16S103J
R 548		RS1/16S221J
R 551		RS1/16S0R0J
R 552		RS1/16S0R0J
R 561		RS1/16S104J
R 562		RS1/16S123J
R 563		RS1/16S105J
R 564		RS1/16S682J
R 567		RS1/16S822J
R 568		RS1/16S222J
R 569		RS1/16S184J
R 570		RS1/16S223J
R 571		RS1/16S473J
R 582		RS1/16S332J
R 583		RS1/16S332J
R 584		RS1/16S332J
R 585		RS1/16S332J
R 601		RS1/16S102J
R 602		RS1/16S473J
R 603		RS1/16S102J
R 605		RS1/16S102J
R 606		RS1/16S0R0J
R 607		RS1/16S104J
R 608		RS1/16S102J
R 609		RS1/16S681J
R 610		RS1/16S0R0J
R 611		RS1/16S0R0J
R 612		RS1/16S102J
R 613		RS1/16S0R0J

Circuit Symbol and No.	Part Name	Part No.
R 614		RS1/16S102J
R 615		RS1/16S102J
R 616		RS1/16S102J
R 617		RS1/16S102J
R 618		RS1/16S102J
R 619		RS1/16S0R0J
R 620		RS1/16S0R0J
R 621		RS1/16S681J
R 622		RS1/16S0R0J
R 623		RS1/16S473J
R 624		RS1/16S473J
R 625		RS1/16S473J
R 626		RS1/16S473J
R 627		RS1/16S473J
R 629		RS1/16S472J
R 631		RS1/16S0R0J
R 632		RS1/16S102J
R 633		RS1/16S102J
R 634		RS1/16S102J
R 635		RS1/16S471J
R 636		RS1/16S222J
R 637		RS1/16S102J
R 638		RS1/16S102J
R 641		RS1/16S473J
R 642		RS1/16S104J
R 643		RS1/16S104J
R 644		RS1/16S473J
R 645		RS1/16S102J
R 646		RS1/16S103J
R 647		RS1/16S102J
R 648		RS1/16S102J
R 651		RS1/16S0R0J
R 654		RS1/16S102J
R 655		RS1/16S102J
R 656		RS1/16S102J
R 657		RS1/16S102J
R 658		RS1/16S223J
R 659		RS1/16S102J
R 660		RS1/16S102J
R 661		RS1/16S102J
R 662		RS1/16S102J
R 663		RS1/16S102J
R 664		RS1/16S102J
R 665		RS1/16S102J
R 666		RS1/16S681J
R 667		RS1/16S473J
R 668		RS1/16S473J
R 669		RS1/16S473J
R 670		RS1/16S473J
R 671		RS1/16S473J
R 672		RS1/16S473J
R 673		RS1/16S473J
R 674		RS1/16S473J
R 675		RS1/16S473J
R 676		RS1/16S102J
R 677		RS1/16S102J
R 678		RS1/16S102J
R 679		RS1/16S102J
R 680		RS1/16S102J
R 681		RS1/16S102J

Circuit Symbol and No.	Part Name	Part No.
R 684		RS1/16S102J
R 685		RS1/16S102J
R 687		RS1/16S473J
R 689		RS1/16S473J
R 692		RS1/16S473J
R 693		RS1/16S0R0J
R 698		RS1/16S102J
R 699		RS1/16S473J
R 701		RS1/16S473J
R 703		RS1/4S101J
R 704		RS1/4S101J
R 705		RS1PMF680J
R 711		RS1/16S473J
R 721		RS1/16S102J
R 722		RS1/16S473J
R 723		RS1/16S473J
R 801		RS1/8S222J
R 802		RS1/8S472J
R 803		RS1/8S472J
R 804		RS1/8S472J
R 805		RS1/8S472J
R 806		RS1/8S472J
R 807		RS1/8S221J
R 810		RS1/16S104J
R 811		RS1/16S104J
R 812		RS1/16S104J
R 819		RS1/16S102J
R 820		RS1/16S123J
R 821		RS1/16S103J
R 822		RS1/16S103J
R 823		RS1/16S223J
R 824		RS1/16S102J
R 825		RS1/16S331J
R 826		RS1/16S103J
R 827		RS1/16S471J
R 828		RS1/16S221J
R 829		RS1/16S223J
R 830		RS1/10S221J
R 831		RS1/16S331J
R 832		RS1/16S471J
R 833		RS1/16S221J
R 840		RS1/4S1R5J
R 841		RS1/4S1R5J
R 842		RS1/4S1R5J
R 843		RS1/4S1R5J
R 844		RS1/16S471J
R 845		RS1/16S471J
R 846		RS1/16S105J
R 847		RS1/10S361J
R 848		RS1/16S332J
R 849		RS1/16S562J
R 850		RS1/4S2R2J
R 851		RS1/16S471J
R 852		RS1/16S105J
R 853		RS1/16S102J
R 854		RS1/16S332J
R 855		RS1/16S562J
R 856		RS1/16S103J
R 857		RS1/16S103J
R 860		RS1/16S223J

Circuit Symbol and No.	Part Name	Part No.
R 861		RS1/16S103J
R 862		RS1/16S104J
R 863		RS1/16S223J
R 865		RS1/16S103J
R 866		RS1/16S103J
R 867		RS1/16S472J
R 868		RS1/16S102J
R 869		RS1/16S102J
R 870		RS1/10S102J
R 871		RS1/16S472J
R 882		RD1/4PU121J
R 884		RS1/16S223J
R 886		RS1/16S472J
R 888		RS1/16S473J

CAPACITORS

Circuit Symbol and No.	Part Name	Part No.
C 201		CEALNP4R7M16
C 202		CEALNP4R7M16
C 203		CEALNP4R7M16
C 204		CEALNP4R7M16
C 205		CCSRCH330J50
C 206		CCSRCH330J50
C 207		CCSRCH330J50
C 208		CCSRCH330J50
C 209		CKSRYB102K50
C 210		CKSRYB105K10
C 215		CEALNP4R7M16
C 216		CEALNP4R7M16
C 217		CEALNP4R7M16
C 218		CEALNP4R7M16
C 219		CCSRCH220J50
C 220		CCSRCH220J50
C 221		CCSRCH220J50
C 222		CCSRCH220J50
C 223	4.7µF/35V	CCH1016
C 224	4.7µF/35V	CCH1016
C 225	4.7µF/35V	CCH1016
C 226	4.7µF/35V	CCH1016
C 227		CCSRCH221J50
C 228		CCSRCH221J50
C 229		CCSRCH221J50
C 230		CCSRCH221J50
C 231		CKSRYB473K50
C 232		CEAL101M6R3
C 233		CKSRYB102K50
C 235	4.7µF/35V	CCH1016
C 236	4.7µF/35V	CCH1016
C 237	4.7µF/35V	CCH1016
C 238	4.7µF/35V	CCH1016
C 243		CKSQYB102K50
C 244		CKSQYB102K50
C 245		CKSQYB102K50
C 246		CKSQYB102K50
C 251		CKSRYB104K16
C 253		CEAL220M6R3
C 254		CKSRYB104K16
C 256		CCSRCH270J50
C 257		CCSRCH270J50
C 259		CKSRYB104K16

Circuit Symbol and No.	Part Name	Part No.
C 260		CCSRCH471J50
C 261		CCSRCH471J50
C 262		CEAL4R7M35
C 263		CKSRYB473K50
C 281		CKSRYB182K50
C 282		CKSRYB182K50
C 283		CKSRYB182K50
C 284		CKSRYB182K50
C 309		CKSRYB102K50
C 310		CKSRYB105K10
C 319		CCSRCH220J50
C 320		CCSRCH220J50
C 321		CCSRCH220J50
C 322		CCSRCH220J50
C 323	4.7µF/35V	CCH1016
C 324	4.7µF/35V	CCH1016
C 325	4.7µF/35V	CCH1016
C 326	4.7µF/35V	CCH1016
C 327		CCSRCH221J50
C 328		CCSRCH221J50
C 329		CCSRCH221J50
C 330		CCSRCH221J50
C 335	4.7µF/35V	CCH1016
C 336	4.7µF/35V	CCH1016
C 337	4.7µF/35V	CCH1016
C 338	4.7µF/35V	CCH1016
C 351		CEAL4R7M35
C 352		CKSRYB103K50
C 353	4.7µF/35V	CCH1016
C 354	4.7µF/35V	CCH1016
C 355		CEAL101M10
C 356		CEAL100M16
C 357		CEAL220M10
C 381		CKSRYB182K50
C 382		CKSRYB182K50
C 383		CKSRYB182K50
C 384		CKSRYB182K50
C 401		CKSRYB183K50
C 402		CKSRYB183K50
C 403	4.7µF/35V	CCH1016
C 404	4.7µF/35V	CCH1016
C 406		CKSRYB102K50
C 411		CKSRYB104K16
C 412		CKSRYB104K16
C 415		CKSRYB105K10
C 416		CKSRYB105K10
C 417		CCSRCH331J50
C 418		CCSRCH331J50
C 421		CEAL470M6R3
C 480		CKSQYB102K50
C 492		CKSRYB473K50
C 493		CCSQCH221J50
C 494		CCSQCH221J50
C 497		CCSRCH221J50
C 503		CKSQYB103K50
C 504		CKSRYB222K50
C 505		CKSRYB222K50
C 506		CKSRYB222K50
C 507		CKSRYB222K50
C 508		CKSRYB103K50

Circuit Symbol and No.	Part Name	Part No.
C 509		CKSRYB103K50
C 510		CEAL100M16
C 511		CKSRYB472K50
C 512		CEAL100M16
C 513		CKSRYB473K50
C 514		CEAL2R2M50
C 515		CKSRYB102K50
C 516		CKSRYB103K50
C 517		CKSRYB103K50
C 518		CKSRYB392K50
C 519		CKSRYB103K50
C 520		CKSRYB103K50
C 521		CEAT101M10
C 522		CKSRYB103K50
C 523		CEAL100M16
C 524		CKSRYB472K50
C 529		CKSQYB103K50
C 530		CCSRCH100D50
C 561		CEAL3R3M50
C 562		CKSRYB333K16
C 563		CEALNP1R0M50
C 564		CQMA683J50
C 565		CQMA333J50
C 566		CQMA333J50
C 567		CQMA333J50
C 568		CKSRYB105K10
C 569		CKSRYB333K16
C 570		CKSRYB103K50
C 571		CKSRYB682K50
C 572		CEAL101M10
C 573		CKSRYB392K50
C 574		CKSRYB334K10
C 575		CKSRYB102K50
C 585		CKSRYB223K50
C 586		CKSRYB223K50
C 601		CKSRYB102K50
C 602		CKSRYB103K50
C 603		CKSRYB103K50
C 604		CKSRYB104K16
C 605		CEAL220M6R3
C 645		CKSRYB103K50
C 648		CKSRYB102K50
C 671		CCSRCH101J50
C 672		CCSRCH101J50
C 673		CCSRCH101J50
C 674		CCSRCH101J50
C 675		CCSRCH101J50
C 701		CKSRYB103K50
C 703		CCSRCH221J50
C 704		CCSRCH221J50
C 801		CKSRYB102K50
C 802		CEAL1R0M50
C 803		CKSRYB102K50
C 804	2200µF/16V	CCH1186
C 805		CKSQYB473K50
C 806		CKSRYB102K50
C 807		CEAL1R0M50
C 808		CKSRYB102K50
C 814		CEAL1R0M50
C 815		CEAL1R0M50

Circuit Symbol and No.	Part Name	Part No.
C 816		CKSRYB103K50
C 817	100µF/10V	CCH1402
C 818		CKSRYB103K50
C 819	100µF/10V	CCH1402
C 820		CKSRYB103K50
C 824		CKSRYB472K50
C 825	100µF/10V	CCH1402
C 826		CKSRYB472K50
C 827	100µF/10V	CCH1402
C 829		CKSRYB103K50
C 830		CKSRYB103K50
C 831		CKSRYB103K50
C 861		CEAL101M6R3
C 866		CEAL100M16
C 867		CEAL100M16
C 870		CKSRYB103K50
C 871		CKSRYB103K50
C 872	2200µF/16V	CCH1186
C 873		CKSRYB105K10
C 875		CCSRCH101J50
C 883		CKSRYB103K50

B

Unit Number:CWS1342
Unit Name:Keyboard Unit

MISCELLANEOUS

IC901	IC	LC75804W
Q 901	Transistor	2SA1162
Q 902	Transistor	DTC143EK
Q 903	Transistor	2SA1162
Q 904	Transistor	DTC143EK
Q 905	Transistor	2SB1132
Q 907	Transistor	2SB1132
Q 908	Transistor	DTC143EK
D 901	Chip LED	HGG1105W-RR(CDE)
D 902	Chip LED	HGG1105W-RR(CDE)
D 903	Chip LED	HAA1105W-RR(CDE)
D 904	Chip LED	HAA1105W-RR(CDE)
D 905	Diode	1SS355
D 906	Diode	1SS355
D 907	Diode	1SS355
D 908	Diode	1SS355
D 909	Diode	1SS355
D 910	Diode	HZU5R6(B1)
IL 901	Lamp 8V 60mA	CEL1712
IL 902	Lamp 8V 60mA	CEL1712
IL 903	Lamp 8V 60mA	CEL1740
IL 904	Lamp 8V 60mA	CEL1740
IL 905	Lamp 8V 60mA	CEL1740
IL 906	Lamp 8V 60mA	CEL1740
IL 907	Lamp 8V 60mA	CEL1740
IL 908	Lamp 8V 60mA	CEL1740
IL 909	Lamp 8V 60mA	CEL1740
IL 910	Lamp 8V 60mA	CEL1740
IL 911	Lamp 8V 60mA	CEL1740
IL 912	Lamp 8V 60mA	CEL1740
IL 913	Lamp 8V 60mA	CEL1740

Circuit Symbol and No.	Part Name	Part No.
IL 914	Lamp 8V 60mA	CEL1740
IL 915	Lamp 8V 60mA	CEL1740
IL 916	Lamp 8V 60mA	CEL1740
VR901	Encoder(PWR•VOL)	CSD1078
VR902	Encoder(AUDIO•TUNE)	CSD1082
LCD901	LCD	CAW1700

RESISTORS

R 901	RS1/10S0R0J
R 902	RS1/10S0R0J
R 903	RS1/10S8R2J
R 904	RS1/10S8R2J
R 905	RS1/10S8R2J
R 906	RS1/10S8R2J
R 907	RS1/10S8R2J
R 908	RS1/10S8R2J
R 909	RS1/10S8R2J
R 910	RS1/10S8R2J
R 911	RS1/10S8R2J
R 912	RS1/10S8R2J
R 913	RS1/10S8R2J
R 914	RS1/10S8R2J
R 915	RS1/10S0R0J
R 916	RS1/10S0R0J
R 917	RS1/10S151J
R 918	RS1/10S151J
R 919	RS1/10S151J
R 920	RS1/10S151J
R 921	RS1/16S103J
R 922	RS1/16S332J
R 923	RS1/10S151J
R 924	RS1/10S151J
R 925	RS1/10S151J
R 926	RS1/10S151J
R 927	RS1/16S103J
R 928	RS1/16S332J
R 930	RS1/10S271J
R 931	RS1/16S103J
R 932	RS1/10S221J
R 936	RS1/16S0R0J
R 937	RS1/16S0R0J
R 938	RS1/16S0R0J
R 939	RS1/16S0R0J
R 944	RS1/16S0R0J
R 945	RS1/16S0R0J
R 946	RS1/16S0R0J
R 947	RS1/16S0R0J
R 952	RS1/16S102J
R 953	RS1/16S102J
R 954	RS1/16S102J
R 955	RS1/16S102J
R 956	RS1/16S102J
R 957	RS1/16S102J
R 958	RS1/16S102J
R 959	RS1/16S102J
R 960	RS1/16S102J
R 961	RS1/16S103J
R 962	RS1/16S102J
R 963	RS1/16S102J
R 964	RS1/16S102J
R 965	RS1/16S102J
R 966	RS1/16S681J
R 967	RS1/16S393J
R 968	RS1/16S223J
R 969	RS1/16S223J
R 971	RS1/16S471J
R 972	RS1/16S222J
R 973	RS1/16S222J
R 974	RS1/16S222J
R 975	RS1/16S0R0J
R 976	RS1/16S0R0J
R 977	RS1/16S0R0J
R 978	RS1/16S0R0J
R 991	RS1/16S0R0J

CAPACITORS

C 901	CKSRYB104K16
C 902	CKSRYB104K16
C 903	CKSRYB104K16
C 904	CKSRYB104K16
C 910	CKSRYB102K50
C 911	CKSRYB474K10
C 912	CKSRYB104K16
C 913	CKSRYB104K16
C 914	CKSRYB104K16
C 915	CKSRYB103K50
C 916	CCSRCH101J50
C 917	CCSRCH101J50
C 920	CCSRCH101J50
C 921	CCSRCH101J50
C 922	CCSRCH101J50
C 923	CCSRCH101J50

C

Unit Number:CWX2649
Unit Name:Control Unit(G2T)

MISCELLANEOUS

IC201	IC	UPD63711GC
IC301	IC	BD7962FM
IC302	IC	S-818A33AUC-BGN
IC303	IC	BA05SFP
IC501	IC	SM5903BFP
IC504	IC	TC74VHCT08AFT
IC505	IC	TC74VHC541FT
IC507	IC	MSM51V17400F6TFT
IC702	IC	PD5748C
Q 101	Transistor	2SB1132
Q 601	Transistor	DTC114EK
Q 602	Transistor	DTA123JK
Q 603	Transistor	DTC314TK
Q 604	Transistor	DTC314TK
Q 702	Transistor	UMD3N
D 101	Diode	1SS355
D 301	Diode	S1G-6904G2P
D 303	Diode	S1G-6904G2P

Circuit Symbol and No.	Part Name	Part No.
D 601	Chip Diode	MA151WA
L 601	Inductor	CTF1295
TH701	Thermistor	CCX1015
X 201	Radiator 16.93MHz	CSS1581
X 701	Radiator 10.00MHz	CSS1428

RESISTORS

R 101	RS1/8S120J
R 102	RS1/8S100J
R 103	RS1/16S222J
R 104	RS1/16S102J
R 105	RS1/16S0R0J
R 201	RS1/16S104J
R 202	RAB4CQ681J
R 203	RS1/16S0R0J
R 204	RS1/16S0R0J
R 205	RS1/16S103J
R 206	RS1/16S393J
R 207	RS1/16S0R0J
R 209	RS1/16S0R0J
R 210	RS1/16S0R0J
R 211	RS1/16S0R0J
R 212	RS1/16S562J
R 213	RS1/16S153J
R 214	RS1/16S123J
R 215	RS1/16S0R0J
R 216	RS1/16S0R0J
R 217	RS1/16S0R0J
R 220	RS1/16S471J
R 221	RS1/16S681J
R 298	RS1/16S0R0J
R 301	RS1/16S103J
R 302	RS1/16S153J
R 303	RS1/16S103J
R 304	RS1/16S103J
R 305	RS1/16S272J
R 306	RS1/16S272J
R 307	RS1/16S182J
R 308	RS1/16S272J
R 309	RS1/16S682J
R 310	RS1/16S822J
R 311	RS1/16S103J
R 312	RS1/16S681J
R 313	RS1/16S103J
R 314	RS1/16S153J
R 315	RS1/16S153J
R 316	RS1/16S153J
R 317	RS1/16S103J
R 318	RS1/16S103J
R 319	RS1/16S102J
R 320	RS1/16S392J
R 322	RS1/16S103J
R 323	RS1/16S103J
R 324	RS1/16S103J
R 325	RS1/16S103J
R 501	RS1/16S0R0J
R 504	RS1/16S331J
R 508	RS1/16S472J
R 511	RS1/16S0R0J

Circuit Symbol and No.	Part Name	Part No.
R 512		RS1/16S333J
R 513		RS1/16S473J
R 516		RS1/16S331J
R 601		RS1/16S102J
R 602		RS1/16S102J
R 603		RS1/16S223J
R 604		RS1/16S223J
R 605		RS1/16S102J
R 606		RS1/16S681J
R 607		RS1/16S681J
R 608		RS1/16S102J
R 609		RAB4CQ681J
R 701		RAB4CQ104J
R 702		RS1/16S222J
R 703		RS1/16S681J
R 704		RAB4CQ222J
R 705		RAB4CQ681J
R 706		RS1/16S473J
R 707		RS1/16S473J
R 708		RS1/16S222J
R 709		RS1/16S222J
R 711		RAB4CQ104J
R 712		RS1/16S473J
R 713		RS1/16S681J
R 714		RS1/16S473J
R 715		RAB4CQ222J
R 716		RS1/16S103J
R 718		RS1/16S473J
R 719		RS1/16S104J
R 720		RS1/16S103J
R 724		RS1/16S104J
R 727		RS1/16S0R0J
R 734		RS1/16S104J
R 736		RS1/16S681J
R 739		RS1/16S473J
R 741		RS1/16S104J
R 742		RS1/16S222J
R 743		RS1/16S681J
R 758		RS1/16S153J
R 759		RS1/16S103J
R 760		RS1/16S433J
R 767		RS1/16S154J
R 775		RAB4CQ681J

CAPACITORS

C 101	CKSRYB103K25
C 102	CKSRYB104K25
C 103	CEVL101M10
C 104	CEVL470M6R3
C 105	CKSRYB224K16
C 106	CKSRYB224K16
C 107	CKSRYB224K16
C 201	CKSRYB104K25
C 202	CEVL220M16
C 203	CKSRYB473K25
C 204	CKSRYB182K50
C 205	CKSRYB104K25
C 206	CKSRYB152K50
C 207	CKSRYB224K16
C 208	CCSRCH180J50

Circuit Symbol and No.	Part Name	Part No.
C 209		CCSRCK2R0C50
C 210		CCSRCH181J50
C 211		CCSRCH510J50
C 212		CKSRYB682K50
C 213		CKSRYB104K25
C 214		CKSRYB104K25
C 215		CKSRYB103K25
C 216		CKSRYB104K25
C 217		CKSRYB104K25
C 218		CKSRYB104K25
C 219		CKSRYB104K25
C 220		CKSRYB104K25
C 221		CEVL470M6R3
C 222		CKSRYB104K25
C 223		CKSRYB102K50
C 224		CKSRYB104K25
C 225		CKSRYB103K25
C 301		CEVL101M10
C 302		CKSRYB224K16
C 303		CKSRYB224K16
C 304	10µF/10V	CCH1349
C 305		CKSRYB224K16
C 306	10µF/10V	CCH1349
C 307		CKSRYB224K16
C 309		CKSYB475K16
C 501		CKSRYB102K50
C 502		CKSRYB104K25
C 503		CKSRYB104K25
C 505		CKSRYB104K25
C 506		CKSRYB104K25
C 508		CKSRYB104K25
C 509		CKSRYB104K25
C 601		CEVL220M6R3
C 602		CEVL220M6R3
C 701		CKSRYB104K25
C 702		CKSRYB104K25
C 703		CKSRYB103K25
C 704		CKSRYB103K25
C 705		CKSRYB104K25
C 706		CKSRYB104K25
C 707		CKSRYB103K25
C 708		CKSRYB473K25

E

Unit Number:
Unit Name:PCB Unit(Load)

Q 21	Photo-transistor	CPT231SCTU
Q 22	Photo-transistor	CPT231SCTU
L 21	Inductor	LCYBR15J1608
L 22	Inductor	LCYBR15J1608
S 21	Spring Switch(LOAD1)	CSN1051
S 22	Spring Switch(LOAD2)	CSN1052

D

Unit Number:CWX2614

Circuit Symbol and No.	Part Name	Part No.

Unit Name:PCB Unit(LED)

D 31	Chip LED	CL205IRXTU
D 32	Chip LED	CL205IRXTU
S 31	Spring Switch(CAMLOAD)	CSN1052
S 32	Spring Switch(CAMEOK)	CSN1052
R 31		RS1/16S0R0J

G

Unit Number:CWX2611
Unit Name:PCB Unit

L 1	Inductor	CTF1389
S 41	Spring Switch(LOAD3)	CSN1051

F

Unit Number:CWX2613
Unit Name:PCB Unit(Side)

MISCELLANEOUS

S 11	Spring Switch(CAMCLMP)	CSN1052
VR11	Semi-fixed 1kΩ(B)	CCP1338

RESISTORS

R 11		RS1/16S562J
R 12		RS1/16S562J
R 13		RS1/10S391J
R 14		RS1/10S391J
R 15		RS1/16S0R0J
R 16		RS1/16S0R0J

CAPACITORS

C 12		CKSRYB104K25

H

Unit Number:
Unit Name:PCB Unit(M2 Unit)

MISCELLANEOUS

IC1	IC	BA6849FS
S 1	Switch(HOME)	CSN1057
S 2	Switch(CLAMP)	CSN1057

RESISTORS

R 1		RS1/16S221J
R 2		RS1/16S221J
R 3		RS1/16S4R7J
R 4		RS1/16S1R0J

CAPACITORS

C 1		CKSRYB104K16

Circuit Symbol and No. Part NamePart No.

I

Unit Number:EWM1043
Unit Name:Deck Unit

MISCELLANEOUS

IC251	IC	HA12216F
IC351	IC	PA2020A
Q 271	Transistor	2SC4116
D 352	Diode	1SS355
VR301	Semi-fixed 33kΩ(B)	CCP1280
VR302	Semi-fixed 33kΩ(B)	CCP1280

RESISTORS

R 255	RS1/16S181J
R 256	RS1/16S181J
R 257	RS1/16S183J
R 258	RS1/16S183J
R 259	RS1/16S133J
R 260	RS1/16S133J
R 261	RS1/16S274J
R 262	RS1/16S274J
R 271	RS1/16S183J
R 272	RS1/8S0R0J
R 273	RS1/8S0R0J
R 275	RS1/16S473J
R 276	RS1/16S104J
R 277	RS1/16S224J
R 278	RS1/16S104J
R 281	RS1/8S0R0J
R 282	RS1/8S0R0J
R 283	RS1/8S0R0J
R 284	RS1/8S0R0J
R 285	RS1/8S0R0J
R 286	RS1/8S0R0J
R 287	RS1/8S0R0J
R 288	RS1/8S0R0J
R 292	RS1/8S0R0J
R 296	RS1/16S0R0J
R 321	RS1/8S0R0J
R 351	RS1/16S102J
R 352	RS1/16S102J
R 353	RS1/16S102J
R 354	RS1/16S102J
R 355	RS1/16S274J
R 362	RS1/8S301J
R 373	RS1/16S0R0J
R 374	RS1/8S0R0J
R 375	RS1/16S0R0J
R 401	RS1/16S153J
R 402	RS1/16S332J
R 403	RS1/16S911J
R 404	RS1/16S274J

CAPACITORS

C 251	CKSRYB391K50
C 252	CKSRYB391K50
C 253	CKSRYB391K50
C 254	CKSRYB391K50

Circuit Symbol and No. Part NamePart No.

C 255	CKSRYB103K50
C 256	CKSRYB103K50
C 271	CEH1R0M50
C 272	CKSRYB104K16
C 301	CKSRYB104K16
C 302	CKSRYB104K16
C 309	CKSRYB104K16
C 310	CKSRYB104K16
C 351	CKSQYB224K25
C 352	CKSRYB392K50
C 353	CKSRYB103K50
C 354	CKSRYB103K50
C 355	CKSQYB104K50
C 356	CKSRYB103K50
C 401	CKSRYB392K50
C 402	CKSRYB334K10
C 403	CKSRYB223K25
C 404	CKSRYB103K50
C 405	CKSRYB333K16

J

Unit Number:EWM1041
Unit Name:Sensor Unit

MISCELLANEOUS

L 101	Inductor	CTF1546
L 102	Inductor	CTF1546
S 101	Switch(LOAD)	ESG1007
S 102	Switch(MODE)	ESG1007
S 103	Switch(70μS)	ESG1007
Q 101	Photo-reflector	EGN1004

Miscellaneous Parts List

M 1	Motor Unit(MAIN)	EXA1618
M 2	Motor Unit(SUB)	EXA1623
HD1	Head Assy	EXA1594
M 1	Motor Unit(-A)(CAMGEAR)	CXB7527
M 2	Motor Unit(-B)(ELEVATION)	CXB7526
M 3	Motor Unit(-A)(CRG)	CXB7517
VR1	Variable Resistor 10kΩ	CCW1023
	PU Unit(Service)(PX1)	CXX1569