
2.1 PACKING


27
25
20
26
26
27
24
33
32
14
7
8
17
16
18
15
12
13
11
9
10
13
35
3
4
5
2
6
1
21
34
29
19
31
30
28
21
22
23


PACKING SECTION PARTS LIST

Mark	No.	Description	XDV-P6/UC	XDV-P6/EW5	XDV-P6/RE	XDV-P650/RC	XDV-P650/RD
	1	Cord Assy	CDE5880	CDE4167	CDE4167	CDE5880	CDE5880
	2	Cord Assy	CDE6376	CDE6376	CDE6376	CDE6376	CDE6376
	3	Cord Assy	CDE7038	CDE7038	CDE7038	CDE7038	CDE7038
	4	Cord Assy	CDE7837	CDE7638	CDE7638	CDE7837	CDE7837
	5	Cord Assy	CDE8110	CDE8110	CDE8110	CDE8110	CDE8110
	6	Cord Assy	CDE8208	CDE8208	CDE8208	CDE8208	CDE8208
*	7	Accessory Assy	CEA6152	CEA6152	CEA6152	CEA6152	CEA6152
	8	Screw Assy	CEA6150	CEA6150	CEA6150	CEA6150	CEA6150
	9	Screw	CBA1650	CBA1650	CBA1650	CBA1650	CBA1650
	10	Screw(M6 x 16)	CBA1795	CBA1795	CBA1795	CBA1795	CBA1795
*	11	Polyethylene Bag	CEG-127	CEG-127	CEG-127	CEG-127	CEG-127
	12	Screw	CMZ50P080FTB	CMZ50P080FTB	CMZ50P080FTB	CMZ50P080FTB	CMZ50P080FTB
	13	Screw	TMZ50P080FTB	TMZ50P080FTB	TMZ50P080FTB	TMZ50P080FTB	TMZ50P080FTB
*	14	Polyethylene Bag	CEG-158	CEG-158	CEG-158	CEG-158	CEG-158
	15	Handle	CNC5395	CNC5395	CNC5395	CNC5395	CNC5395
	16	Fastener(KEY SIDE)	CNM3728	CNM3728	CNM3728	CNM3728	CNM3728
	17	Fastener(CATCH SIDE)	CNM3729	CNM3729	CNM3729	CNM3729	CNM3729
	18	Bush	CNV3930	CNV3930	CNV3930	CNV3930	CNV3930
	19	Polyethylene Bag	CEG1011	CEG1011	CEG1011	CEG1011	CEG1011
	20	Polyethylene Bag	CEG1185	CEG1088	CEG1088	CEG1088	CEG1088
	21	Sub Carton	CHA3213	CHA3213	CHA3213	CHA3213	CHA3213
	22	Carton	CHG5768	CHG5895	CHG5771	CHG5769	CHG5770
	23	Contain Box	CHL5768	CHL5895	CHL5771	CHL5769	CHL5770
	24	Protector	CHP3246	CHP3246	CHP3246	CHP3246	CHP3246
	25	Protector	CHP2391	CHP2391	CHP2391	CHP2391	CHP2391
	26	Protector	CHP2446	CHP2446	CHP2446	CHP2446	CHP2446
	27	Protector	CHP3198	CHP3198	CHP3198	CHP3198	CHP3198
*	28	Spacer	CHW2047	CHW2047	CHW2047	CHW2047	CHW2047
	29	Holder	CNC8659	CNC8659	CNC8659	CNC8659	CNC8659
	30	Panel	CNS8588	CNS8588	CNS8588	CNS8589	CNS8588
	31	Air Cushioned Bag	CEG1007	CEG1007	CEG1007	CEG1007	CEG1007
	32	Remote Control Unit	CXC6319	CXC6319	CXC6319	CXC6319	CXC6319
	33	Angle Assy	CXC6808	CXC6808	CXC6808	CXC6808	CXC6808
*	34-1	Polyethylene Bag	E36-634	E36-634	E36-634	E36-634	E36-634
	34-2	Owner's Manual	CRB2222	CRB2216	CRB2228	CRB2224	CRB2224
	34-3	Owner's Manual	CRB2223	CRB2217	CRB2229	CRB2225	CRB2226
	34-4	Installation Manual	CRD4109	CRD4108	CRD4112	CRD4110	CRD4111
*	34-5	Registration Card	CRY1229	Not used	Not used	Not used	Not used
*	34-6	Warranty Card	CRY1246	CRY1157	CRY1157	Not used	Not used
	34-7	Owner's Manual	Not used	CRB2218	Not used	Not used	CRB2227
	34-8	Owner's Manual	Not used	CRB2219	Not used	Not used	Not used
	34-9	Owner's Manual	Not used	CRB2220	Not used	Not used	Not used
	34-10	Owner's Manual	Not used	CRB2221	Not used	Not used	Not used
	35	Receiver Assy	Not used	Not used	Not used	CXB7618	CXB7618

Owner's Manual,Installation Manual

Part No.	Language
CRB2222,CRB2216,CRB2224,CRB2228	English
CRB2223,CRB2219	French
CRB2217,CRB2226	Spanish
CRB2218	German
CRB2220	Italian
CRB2221	Dutch
CRB2225	Traditional Chinese
CRB2227	Portuguese(B)
CRB2229	Russian
CRD4109	English,French
CRD4108	English,Spanish,German,French,Italian,Dutch
CRD4110	English,Traditional Chinese
CRD4111	English,Spanish,Portuguese(B)
CRD4112	English,Russian

2.2 EXTERIOR


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
A
B
C
D
E
F

(1) EXTERIOR SECTION PARTS LIST


Mark	No.	Description	Part No.
	1	Cord Assy	See Contrast table(2)
	2	Cord Assy	CDE8110
⚠	3	Fuse(4 A)	CEK1001
	4	Cap	CNS1472
	5	Case	CNB3343
	6	Holder	CNC8659
	7	Insulator	CNN1358
	8	Panel	See Contrast table(2)
	9	Screw	BMZ30P040FTC
	10	Screw	BSZ26P060FTC
	11	Cord Assy	CDE8114
	12	Cord Assy	CDE8116
	13	Chassis	CNA2900
	14	Case	CNB3284
	15	Holder	CND3290
	16	Holder	CND3291
	17	Holder	CND3292
	18	Holder	CND3294
	19	Holder	CND3295
	20	Insulator	CNN1092
	21	Insulator	CNN1093
	22	Insulator	CNN1357
	23	Insulator	CNN1362
	24	Flexible PCB	CNP9273
	25	DVD Control Unit	CWN1608
	26	Connector(CN1302)	CKS1940
	27	Connector(CN1701)	CKS4450
	28	Connector(CN1301)	CKS4817
	29	Connector(CN1201)	CKS4911
	30	Connector(CN1101)	CKS5486
	31	Holder	CND3293
	32	Screw	BPZ20P080FTC
	33	Button	CAC9693
	34	Cable	CDE8115
	35	Holder	CNV9007
	36	Grille Unit	CWN1614
	37	Connector(CN2601)	CKS4911
	38	Sub Grille Assy	See Contrast table(2)
	39	Grille Unit	See Contrast table(2)
	40	Door Unit	CXC6154
	41	Label	See Contrast table(2)
	42	DVD Mechanism Module (MG4)	CXX2154
	43	Screw	IMS20P022FTC
	44	Screw	BSZ26P060FTB
	45	Cord Assy	CDE8231
	46	Chassis	CNA2902
	47	Case	See Contrast table(2)
	48	Insulator	CNN1094
	49	Audio Control Unit	See Contrast table(2)
	50	Screw	BSZ26P080FTC
	51	Pin Jack(CN301)	CKB1049
	52	Plug(CN801)	CKS-461
	53	Pin Jack(CN701)	CKS3144
	54	Connector(CN902)	CKS3410
	55	Connector(CN901)	CKS3413
	56	Connector(CN403)	CKS4590
	57	Connector(CN402)	CKS4833
	58	Connector(CN201)	CKS5518
	59	Connector(CN404)	CKS5553
	60	Connector(CN401)	CKS5554
	61	Holder	CND2645
	62	Holder	CND3296
	63	Holder	CND3297
	64	Holder	CND3303
	65	Remote Control Unit	CXC6319
	66	Cover	CZN7062
	67	Transistor (Q103)	2SB1565
	68	Transistor (Q104, Q112)	2SD2396
	69	Resistor	RS1/2PMF102J
	70	Sheet	CNN1434

(2) CONTRAST TABLE

XDV-P6/UC, XDV-P6/EW5, XDV-P6/RE, XDV-P650/RC and XDV-P650/RD are constructed the same except for the following:

Mark	No.	Description	XDV-P6/UC	XDV-P6/EW5	XDV-P6/RE	XDV-P650/RC	XDV-P650/RD
	1	Cord Assy	CDE5880	CDE4167	CDE4167	CDE5880	CDE5880
	8	Panel	CNS8588	CNS8588	CNS8588	CNS8589	CNS8588
	38	Sub Grille Assy	CXC6363	CXC6363	CXC6363	CXC6364	CXC6365
	39	Grille Unit	CXC6150	CXC6150	CXC6150	CXC6151	CXC6152
	41	Label	Not used	VRW1860	Not used	Not used	Not used
	47	Case	CNB3285	CNB3285	CNB3285	CNB3340	CNB3340
	49	Audio Control Unit	CWN1621	CWN1622	CWN1625	CWN1623	CWN1624

2.3 DVD MECHANISM MODULE



DVD MECHANISM MODULE SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	DVD Core Unit	CWX3335
	2	Terminal(CN1902)	CKF1064
	3	Connector(CN1901)	CKS3971
	4	Connector(CN1201)	CKS4840
	5	•••••	
	6	•••••	
	7	•••••	
	8	Connector(CN1101)	CKS4842
	9	Connector(CN1551)	CKS4817
	10	Mechanism Unit(Service)	CXX2155
	11	Screw	BMZ20P025FTC
	12	Screw(M2 x 2.5)	CBA1623
	13	Screw(M2 x 2.5)	CBA1823
	14	Washer	CBF1064
	15	Washer	CBF1094
	16	Spring	CBH2720
	17	Spring	CBH2731
	18	Spring	CBH2732
	19	Variable Resistor	CCW1029
*	20	Gear	CND1924
*	21	Arm	CND1926
	22	Stair	CND1930
	23	Stair	CND1931
	24	Stair	CND1932
*	25	Arm	CND1933
*	26	Gear	CND1936
*	27	Gear	CND1937
	28	Gear	CND1939
	29	Case	CND3597
	30	Plate	CND2902
	31	Sheet	CNM9680
	32	Sheet	CNM9746
	33	Arm	CNV7850
	34	Gear	CNV8944
	35	Gear	CNV7854
	36	Gear	CNV8945
	37	Holder	CNV7861
	38	Cam	CNV7866
	39	Cam	CNV8778
	40	Cam	CNV7868
	41	Arm	CNV7869
	42	Cam	CNV8779
	43	PCB Assy	CWX2986
*	44	Lever Unit	CXC2392
*	45	Lever Unit	CXC2393
*	46	Cam Gear Unit	CXC2435
	47	•••••	
	48	PCB Assy	CXC3142
*	49	Chassis Unit	CXC6900
	50	Holder Unit	CXC2418
	51	Stage Assy(Service)	CXX2133
	52	ELV Motor Assy(M2)	CXC5910
	53	Screw	JFZ20P020FTC
	54	Cam Motor Assy(M1)	CXC5908
	55	Screw	IMS26P025FTC
	56	Tray Assy	CXC6726
	57	Lower Tray Assy	CXC6787
	58	Shutter Assy	CXC5126
	59	Washer	YE15FTC
	60	Spring	CBH2950
	61	Spring	CBL1728
	62	Screw(M2 x 1.4)	CBA2025
	63	Load Arm Assy	CXC6922

5. ELECTRICAL PARTS LIST

NOTE:

- *Parts whose parts numbers are omitted are subject to being not supplied.*
- *The part numbers shown below indicate chip components.*

  Chip Resistor

  RS1/◯S◯◯◯J,RS1/◯◯S◯◯◯J

  Chip Capacitor (except for CQS.....)

  CKS....., CCS....., CSZS.....
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Meaning of the figures and others in the parentheses in the parts list.*

  Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.

  IC 301 (A, 91, 111) IC NJM2068V

Circuit Symbol and No. **Part No.**

Unit Number : CWN1608
Unit Name : DVD Control Unit
Unit Number : CWN1614
Unit Name : Grille Unit
Unit Number : CWN1621(UC)
Unit Number : CWN1622(EW5)
Unit Number : CWN1625(RE)
Unit Number : CWN1623(RC)
Unit Number : CWN1624(RD)
Unit Name : Audio Control Unit
Unit Number : CWX3335
Unit Name : DVD Core Unit
Unit Number : CWX2986
Unit Name : PCB Assy

A

Unit Number : CWN1608
Unit Name : DVD Control Unit

MISCELLANEOUS

IC 1301	(A,42,13) IC	TC7SET08FUS1
IC 1401	(A,130,38) IC	S-80827CNUA-B8M
IC 1402	(A,124,43) IC	S-818A33AUC-BGN
IC 1403	(A,53,7) IC	BA00CC0WFP
IC 1404	(B,37,11) IC	BA00DD0WHFP
IC 1501	(A,109,15) IC	SM5304AV
IC 1502	(A,137,33) IC	TC7SET08FUS1
IC 1503	(A,114,43) IC	TC7SET08FUS1
IC 1504	(A,122,31) IC	TC74VHC08FTS1
Q 1301	(A,25,6) Transistor	2SA1576
Q 1401	(A,41,7) Transistor	UMF5N
Q 1403	(A,74,14) Transistor	2SC4081
Q 1404	(A,70,6) Transistor	2SB1386
Q 1701	(A,162,22) Transistor	UMF5N
Q 1801	(A,96,26) Transistor	IMD2A
Q 1802	(A,100,19) Transistor	IMH23
D 1402	(A,136,38) Diode	MA111
D 1701	(A,166,13) Diode	UDZS5R6(B)
D 1702	(A,165,15) Diode	UDZS5R6(B)
D 1703	(A,138,29) Diode	UDZS5R6(B)
D 1704	(A,138,27) Diode	UDZS5R6(B)
D 1705	(A,138,20) Diode	UDZS12(B)
D 1706	(A,166,11) Diode	UDZS12(B)
D 1707	(A,169,6) Diode	UDZS12(B)
D 1708	(A,140,11) Diode	UDZS12(B)
D 1709	(A,167,6) Diode	UDZS12(B)
D 1710	(A,140,7) Diode	UDZS12(B)
D 1711	(A,138,18) Diode	UDZS12(B)
D 1712	(B,112,15) Diode	UDZS5R6(B)
D 1713	(B,112,18) Diode	UDZS5R6(B)
D 1714	(A,137,25) Diode	UDZS5R6(B)
D 1715	(A,139,25) Diode	UDZS5R6(B)
D 1716	(A,135,19) Diode	UDZS5R6(B)
D 1717	(A,136,23) Diode	UDZS5R6(B)
D 1801	(A,99,23) Diode	DAP202U
L 1101	(A,82,20) Inductor	CTF1473
L 1102	(A,81,23) Chip Ferrite Bead	CTF1399
L 1103	(A,102,16) Inductor	CTF1473
L 1104	(A,96,17) Inductor	CTF1473
L 1105	(B,97,18) Inductor	CTF1473
L 1301	(A,38,8) Inductor	CTF1379
L 1401	(A,131,42) Inductor	CTF1383
L 1501	(A,115,19) Inductor	CTF1473
L 1502	(A,128,33) Inductor	CTF1379
L 1503	(A,139,35) Inductor	CTF1379
L 1504	(A,114,46) Inductor	CTF1379

RESISTORS

R 1101	(A,120,26)	RS1/16S102J
R 1104	(A,103,13)	RS1/16S0R0J
R 1105	(A,105,17)	RS1/16S0R0J
R 1106	(A,90,19)	RS1/16S0R0J
R 1108	(A,92,18)	RS1/16S0R0J

Circuit Symbol and No.		Part No.
R 1109	(A,94,21)	RS1/16S0R0J
R 1110	(A,94,17)	RS1/16S102J
R 1111	(A,128,30)	RS1/16S225J
R 1113	(A,128,32)	RS1/16S102J
R 1201	(A,127,19)	RS1/16S0R0J
R 1202	(A,125,19)	RS1/16S0R0J
R 1203	(A,36,8)	RS1/16S0R0J
R 1204	(A,124,19)	RS1/16S0R0J
R 1205	(A,122,19)	RS1/16S0R0J
R 1206	(A,21,6)	RS1/16S0R0J
R 1301	(A,39,16)	RS1/16S221J
R 1302	(A,42,16)	RS1/16S621J
R 1303	(A,45,13)	RS1/16S473J
R 1304	(A,31,8)	RS1/16S331J
R 1305	(A,23,6)	RS1/16S104J
R 1306	(A,25,9)	RS1/16S104J
R 1307	(A,28,7)	RS1/16S103J
R 1401	(A,131,34)	RS1/16S102J
R 1402	(A,62,11)	RS1/16S1202D
R 1403	(A,134,38)	RS1/16S124J
R 1404	(A,60,11)	RS1/16S1501D
R 1405	(A,58,12)	RS1/16S4700D
R 1406	(A,57,13)	RS1/16S3901D
R 1407	(A,64,10)	RS1/16S102J
R 1408	(A,44,9)	RS1/16S104J
R 1409	(A,41,9)	RS1/16S103J
R 1412	(A,75,27)	RS1/16S682J
R 1413	(A,73,8)	RS1/16S103J
R 1414	(A,68,10)	RS1/4SA151J
R 1415	(A,73,11)	RS1/4SA151J
R 1416	(B,48,11)	RS1/16S102J
R 1417	(B,50,5)	RS1/16S5601D
R 1418	(B,50,7)	RS1/16S3002D
R 1503	(A,110,10)	RS1/16S332J
R 1504	(A,112,20)	RS1/16S0R0J
R 1505	(A,117,27)	RS1/16S750J
R 1506	(A,132,30)	RS1/16S471J
R 1507	(A,118,22)	RS1/16S821J
R 1508	(A,124,26)	RS1/16S102J
R 1509	(A,114,33)	RS1/16S102J
R 1510	(A,114,31)	RS1/16S102J
R 1511	(A,113,40)	RS1/16S473J
R 1512	(A,134,33)	RS1/16S473J
R 1701	(A,160,23)	RS1/16S471J
R 1702	(A,131,19)	RAB4C471J
R 1703	(A,132,24)	RAB4C471J
R 1706	(A,165,18)	RS1/16S104J
R 1707	(A,164,21)	RS1/16S103J

CAPACITORS

C 1101	(A,66,18)	CCH1709
C 1102	(A,78,28)	CKSRYB104K50
C 1103	(A,84,18)	CKSRYB104K50
C 1104	(A,77,20)	CEVW101M16
C 1301	(A,44,16)	CCSRCH150J50
C 1302	(A,41,11)	CKSRYB104K50
C 1303	(A,38,12)	CKSYB106K6R3
C 1401	(A,81,28)	CKSRYB104K50
C 1402	(A,57,19)	CEVW470M16
C 1403	(A,81,27)	CKSRYB104K50
C 1404	(A,60,13)	CKSRYB102K50
C 1405	(A,138,38)	CKSRYB105K10
C 1406	(A,119,43)	CKSQYB225K10
C 1407	(A,63,6)	CKSQYB105K16
C 1408	(A,42,5)	CKSRYB104K50
C 1409	(A,130,45)	CKSRYB105K10
C 1410	(A,132,45)	CKSRYB102K50
C 1415	(B,51,13)	CKSQYB105K16
C 1416	(A,48,20)	CEVW470M16
C 1417	(B,53,7)	CKSRYB103K50
C 1501	(A,106,13)	CKSYB106K6R3
C 1503	(A,117,19)	CKSQYB475K10
C 1505	(A,116,22)	CKSRYB104K50
C 1506	(A,112,26)	CEVLW220M6R3
C 1507	(A,125,35)	CKSRYB104K50
C 1508	(A,135,35)	CKSRYB104K50
C 1509	(A,111,45)	CKSRYB104K50
C 1510	(A,106,24)	CEVW101M16
C 1701	(A,116,44)	CKSRYB104K50

B

Unit Number : CWN1614
Unit Name : Grille Unit

MISCELLANEOUS

IC 2601	(B,139,12) IC	PE5548A
IC 2602	(A,154,20) IC	RS-140
Q 2101	(B,155,6) Transistor	2SC4081
Q 2102	(A,22,16) Transistor	2SC4081
Q 2103	(A,39,14) Transistor	2SC4081
Q 2104	(A,59,13) Transistor	2SC4081
Q 2105	(B,82,15) Transistor	2SC4081
Q 2106	(B,92,10) Transistor	2SC4081
Q 2107	(A,108,13) Transistor	2SC4081
Q 2108	(A,34,12) Transistor	2SC4081
Q 2109	(A,54,12) Transistor	2SC4081
Q 2110	(A,70,12) Transistor	2SC4081
Q 2111	(B,85,11) Transistor	2SC4081
Q 2112	(B,96,18) Transistor	2SC4081
Q 2113	(A,113,13) Transistor	2SC4081
D 2101	(A,28,8) LED	SML412BC5T(MN)
D 2102	(A,46,8) LED	SML412BC5T(MN)
D 2103	(A,64,8) LED	SML412BC5T(MN)
D 2104	(A,83,8) LED	SML412BC5T(MN)
D 2105	(A,101,8) LED	SML412BC5T(MN)
D 2106	(A,120,8) LED	SML412BC5T(MN)
D 2107	(A,139,8) LED	SML412BC5T(MN)
D 2108	(A,138,16) LED	SML412BC5T(MN)
D 2109	(A,83,23) LED	SML412BC5T(MN)
D 2110	(A,158,10) LED	CL-196HR-CD(AB)
D 2111	(A,27,16) LED	CL-196HR-CD(AB)
D 2112	(A,46,16) LED	CL-196HR-CD(AB)
D 2113	(A,64,16) LED	CL-196HR-CD(AB)
D 2114	(A,82,16) LED	CL-196HR-CD(AB)
D 2115	(A,101,16) LED	CL-196HR-CD(AB)
D 2116	(A,119,16) LED	CL-196HR-CD(AB)
D 2117	(A,29,16) LED	SML412BC5T(MN)
D 2118	(A,47,16) LED	SML412BC5T(MN)

Circuit Symbol and No.		Part No.
D 2119	(A,65,16) LED	SML412BC5T(MN)
D 2120	(A,84,16) LED	SML412BC5T(MN)
D 2121	(A,102,16) LED	SML412BC5T(MN)
D 2122	(A,121,16) LED	SML412BC5T(MN)
D 2123	(A,59,23) LED	SML412BC5T(MN)
D 2601	(B,147,8) Diode	1SS355
L 2601	(B,150,8) Inductor	CTF1379
X 2601	(B,139,20) Radiator 6.29 MHz	CSS1621
S 2001	(A,138,5) Push Switch	CSG1155
S 2002	(A,120,5) Push Switch	CSG1155
S 2003	(A,101,5) Push Switch	CSG1155
S 2004	(A,83,5) Push Switch	CSG1155
S 2005	(A,65,5) Push Switch	CSG1155
S 2006	(A,46,5) Push Switch	CSG1155
S 2007	(A,28,5) Push Switch	CSG1155
S 2601	(A,14,23) Push Switch	CSG1155
BZ2601	(A,10,9) Buzzer	CPV1063

RESISTORS

R 2001	(A,148,7)	RS1/16S472J
R 2002	(A,124,8)	RS1/16S222J
R 2003	(A,105,5)	RS1/16S272J
R 2004	(A,92,4)	RS1/16S622J
R 2005	(A,69,4)	RS1/16S472J
R 2006	(A,52,5)	RS1/16S222J
R 2007	(A,40,4)	RS1/16S272J
R 2101	(A,25,10)	RS1/16S471J
R 2102	(A,62,10)	RS1/16S471J
R 2103	(A,98,9)	RS1/16S471J
R 2104	(A,136,10)	RS1/16S471J
R 2105	(A,78,17)	RS1/16S471J
R 2106	(A,157,4)	RS1/16S152J
R 2107	(A,22,12)	RS1/16S152J
R 2108	(A,40,17)	RS1/16S152J
R 2109	(A,60,17)	RS1/16S152J
R 2110	(A,78,14)	RS1/16S152J
R 2111	(A,96,13)	RS1/16S152J
R 2112	(A,114,17)	RS1/16S152J
R 2113	(A,35,16)	RS1/16S102J
R 2114	(A,53,16)	RS1/16S102J
R 2115	(A,74,9)	RS1/16S102J
R 2116	(A,89,17)	RS1/16S102J
R 2117	(A,108,17)	RS1/16S102J
R 2119	(A,114,15)	RS1/16S102J
R 2301	(B,153,3)	RS1/16S473J
R 2601	(B,151,15)	RS1/16S103J
R 2602	(B,108,13)	RAB4C473J
R 2603	(B,147,15)	RS1/16S103J
R 2604	(B,108,17)	RAB4C473J
R 2605	(B,116,21)	RAB4C473J
R 2606	(A,18,3)	RS1/16S102J
R 2608	(B,150,18)	RS1/16S2R2J
R 2609	(B,120,6)	RAB4C471J
R 2610	(B,157,10)	RS1/16S121J

CAPACITORS

C 2101	(A,28,10)	CKSRYB104K50
C 2102	(A,46,10)	CKSRYB104K50
C 2103	(A,64,10)	CKSRYB104K50
C 2104	(A,86,9)	CKSRYB104K50
C 2105	(A,101,10)	CKSRYB104K50
C 2106	(A,121,10)	CKSRYB104K50
C 2107	(A,139,10)	CKSRYB104K50
C 2108	(A,144,16)	CKSRYB104K50
C 2109	(A,86,23)	CKSRYB104K50
C 2110	(A,33,16)	CKSRYB104K50
C 2111	(A,51,17)	CKSRYB104K50
C 2112	(A,68,11)	CKSRYB104K50
C 2113	(A,89,14)	CKSRYB104K50
C 2114	(A,107,17)	CKSRYB104K50
C 2115	(A,125,15)	CKSRYB104K50
C 2116	(A,62,23)	CKSRYB104K50
C 2601	(B,149,5)	CKSRYB103K50
C 2602	(B,151,10)	CKSRYB103K50
C 2603	(B,155,11)	CKSQYB225K10
C 2604	(B,157,16)	CKSYB475K10

Audio Control Unit
Consists of
Audio Control PCB
AVBUS PCB

C F

Unit Number : CWN1621(UC)
Unit Number : CWN1622(EW5)
Unit Number : CWN1625(RE)
Unit Number : CWN1623(RC)
Unit Number : CWN1624(RD)
Unit Name : Audio Control Unit

MISCELLANEOUS

IC 101	(A,152,52) IC	BP5451-1
IC 102	(B,15,73) IC	S-812C50AUA-C3E
IC 103	(A,153,33) IC	TC74VHC08FTS1
IC 301	(A,51,60) IC	NJM2244M
IC 302	(A,40,63) IC	NJM2136V
IC 303	(A,62,23) IC	NJM2136V
IC 304	(A,43,51) IC	NJM2244M
IC 305	(A,57,42) IC	NJM2244M
IC 401	(A,41,35) IC	TC7W53FU
IC 601	(B,111,64) IC	S-80841CNUA-B82
IC 602	(A,98,44) IC	PE5544A
IC 701	(A,89,65) IC	NJM4580V
IC 702	(A,73,62) IC	BA3131FS
IC 703	(A,80,87) IC	NJM4558V
IC 704	(A,86,79) IC	NJM4558V
IC 705	(B,74,87) IC	NJM2068MD
IC 706	(B,77,78) IC	NJM2068MD
IC 901	(A,121,52) IC	HA12241FP
Q 101	(A,77,22) Transistor	UMF5N
Q 102	(B,140,47) Transistor	2SJ529S
Q 103	(A,12,68) Transistor	2SB1565
Q 104	(A,12,56) Transistor	2SD2396
Q 105	(B,165,47) Transistor	2SJ529S
Q 106	(A,82,24) Transistor	UMF5N
Q 107	(A,25,92) Transistor	2SD1767
Q 108	(B,16,53) Transistor	UMF5N

Circuit Symbol and No.		Part No.
Q 109	(A,84,29) Transistor	UMF5N
Q 110	(B,57,87) Transistor	2SD1767
Q 112	(A,12,44) Transistor	2SD2396
Q 113	(B,45,88) Transistor	UMF5N
Q 114	(B,16,45) Transistor	IMD2A
Q 201	(A,148,24) Transistor	DTC143TU
Q 202	(A,153,21) Transistor	2SC4081
Q 301	(A,41,59) Transistor	2SC4081
Q 330	(B,64,18) Transistor	2SC4081
Q 401	(A,39,10) Transistor	UMF5N
Q 402	(B,32,61) Transistor	UMF5N
Q 403	(A,45,29) Transistor	IMD2A
Q 404	(A,38,7) Transistor	DTC124EUA
Q 601	(A,111,35) Transistor	DTA144EUA
Q 702	(B,44,82) Transistor	IMD2A
Q 703	(B,119,85) Transistor	IMH23
Q 704	(A,93,28) Transistor	IMD2A
Q 705	(B,110,17) Transistor	IMH23
Q 801	(B,56,63) Transistor	2SC4081
Q 803	(B,148,89) Transistor	IMX1
Q 804	(B,150,93) Transistor	2SC4081
Q 805	(B,141,90) Transistor	2SC4081
Q 806	(B,158,94) Transistor	DTC114EU
Q 807	(B,141,85) Transistor	2SC4081
Q 808	(B,49,23) Transistor	2SC4081
D 101	(B,148,42) Diode	RSX201L-30
D 102	(B,22,58) Diode	UDZS9R1(B)
D 103	(A,26,83) Diode	1SR154-400
D 104	(B,165,42) Diode	RSX201L-30
D 105	(A,23,97) Diode	UDZS18(B)
D 106	(B,147,60) Diode	RSX201L-30
D 107	(B,147,56) Diode	RSX201L-30
D 108	(B,58,91) Diode	HZU9R1(B1)
D 110	(B,24,48) Diode	UDZS6R2(B)
D 151	(B,148,38) Diode	RSX201L-30
D 201	(A,135,26) Diode	UDZS12(B)
D 202	(A,135,24) Diode	UDZS12(B)
D 203	(A,135,22) Diode	UDZS12(B)
D 204	(A,135,21) Diode	UDZS12(B)
D 205	(A,135,19) Diode	UDZS12(B)
D 206	(A,125,27) Diode	UDZS5R6(B)
D 207	(A,124,21) Diode	UDZS5R6(B)
D 208	(A,152,18) Diode	UDZS12(B)
D 209	(A,156,24) Diode	UDZS12(B)
D 210	(B,156,25) Diode	UDZS12(B)
D 211	(B,154,26) Diode	UDZS12(B)
D 212	(A,125,24) Diode	UDZS5R6(B)
D 213	(A,125,26) Diode	UDZS5R6(B)
D 214	(A,157,21) Diode	UDZS12(B)
D 301	(B,69,31) Diode	UDZS5R6(B)
D 302	(B,67,31) Diode	UDZS5R6(B)
D 401	(B,34,77) Diode	UDZS5R6(B)
D 402	(B,32,77) Diode	UDZS5R6(B)
D 403	(B,39,77) Diode	UDZS12(B)
D 404	(B,41,77) Diode	UDZS12(B)
D 405	(B,37,77) Diode	UDZS12(B)
D 406	(A,34,35) Diode	DAN202U
D 407	(B,42,33) Diode	DAN202U
D 408	(B,14,18) Diode	UDZS12(B)
D 409	(B,16,18) Diode	UDZS12(B)

Circuit Symbol and No.		Part No.
D 410	(B,22,18) Diode	UDZS12(B)
D 411	(A,32,8) Diode	UDZS12(B)
D 601	(B,110,70) Diode	1SS355
D 701	(A,90,24) Diode	DAN202U
D 702	(B,113,86) Diode	DAP202U
D 703	(A,96,25) Diode	DAP202U
D 705	(A,85,88) Diode	UDZS5R6(B)
D 706	(B,89,76) Diode	UDZS5R6(B)
D 707	(A,85,91) Diode	UDZS5R6(B)
D 708	(B,89,74) Diode	UDZS5R6(B)
D 709	(A,71,87) Diode	UDZS4R7(B)
D 710	(A,74,79) Diode	UDZS4R7(B)
D 711	(B,39,88) Diode	1SS355
D 712	(B,64,53) Diode	DAN202U
D 801	(B,60,73) Diode	HZU9R1(B1)
D 802	(B,155,92) Diode	UDZS6R8(B)
D 803	(B,140,77) Diode	UDZS7R5(B)
D 804	(B,165,90) Diode	1SS355
D 805	(B,164,76) Diode	1SR154-400
D 806	(B,59,78) Diode	1SS355
L 101	(A,126,42) Inductor	CTH1254
L 102	(A,170,42) Inductor	CTH1254
L 103	(A,148,27) Inductor	CTF1379
L 104	(A,130,64) Inductor	CTH1254
L 301	(A,39,60) Inductor	CTF1306
L 302	(B,47,55) Inductor	CTF1306
L 303	(B,66,21) Inductor	CTF1306
L 304	(B,38,53) Inductor	CTF1306
L 305	(B,52,36) Inductor	CTF1306
L 401	(B,44,78) Inductor	CTF1379
L 402	(B,44,76) Inductor	CTF1473
L 403	(B,44,75) Inductor	CTF1379
L 404	(B,53,76) Inductor	CTF1379
L 405	(B,41,72) Inductor	CTF1379
L 406	(A,40,71) Inductor	CTF1379
L 407	(B,57,70) Inductor	CTF1379
L 408	(A,43,32) Inductor	CTF1473
L 409	(B,30,15) Inductor	CTF1473
L 410	(A,30,8) Inductor	CTF1379
L 411	(A,24,19) Inductor	CTF1473
L 412	(A,14,13) Inductor	CTF1379
L 413	(A,13,13) Inductor	CTF1379
L 414	(A,11,13) Inductor	CTF1379
L 415	(A,10,13) Inductor	CTF1379
L 601	(B,87,41) Inductor	CTF1379
L 602	(B,89,45) Inductor	CTF1379
L 603	(A,116,37) Inductor	CTF1379
L 604	(B,109,41) Inductor	CTF1379
L 701	(B,106,14) Inductor	CTF1379
L 702	(B,115,14) Inductor	CTF1379
L 801	(A,146,76) Choke Coil 2.4 mH	CTH1101
L 901	(B,120,46) Inductor	CTF1379
L 902	(B,132,92) Inductor	CTF1473
L 905	(B,130,81) Inductor	CTF1379
L 907	(B,90,84) Inductor	CTF1379
L 908	(B,119,80) Inductor	CTF1379
L 909	(B,92,79) Inductor	CTF1379
X 601	(A,97,55) Radiator 12.58 MHz	CSS1601
S 802	(A,55,12) Switch(Mode select)	CSH1051
⚠FU101	(A,27,72) Fuse 1.25 A	CEK1281

Circuit Symbol and No.		Part No.
⚠FU102	(A,131,33) Fuse 3 A	CEK1286
⚠FU103	(A,27,50) Fuse 1.25 A	CEK1281
⚠FU104	(A,170,28) Fuse 2 A	CEK1284
⚠FU105	(A,123,71) Fuse 4 A	CEK1288
⚠FU106	(A,30,40) Fuse 1.25 A	CEK1281
⚠FU301	(A,69,21) Fuse 3 A	CEK1286
⚠FU401	(A,22,21) Fuse 3 A	CEK1286
⚠FU402	(A,28,21) Fuse 3 A	CEK1286
⚠FU701	(A,121,21) Fuse 3 A	CEK1286

RESISTORS

R 101	(B,131,50)	RS1/16S6801D
R 103	(A,74,22)	RS1/16S104J
R 104	(A,76,20)	RS1/16S103J
R 105	(B,139,54)	RS1/16S0R0J
R 106	(A,11,75)	RS1/16S471J
R 107	(B,22,90)	RS1/16S2R2J
R 108	(B,19,90)	RS1/16S2R2J
R 109	(B,22,88)	RS1/16S2R2J
R 110	(B,19,88)	RS1/16S2R2J
R 111	(B,168,54)	RS1/16S0R0J
R 113	(A,80,24)	RS1/16S104J
R 114	(A,82,22)	RS1/16S103J
R 115	(A,26,96)	RS1/16S222J
R 116	(B,172,58)	RS1/16S1002D
R 117	(A,9,60)	RS1/16S471J
R 118	(A,9,57)	RS1/16S471J
R 119	(A,9,54)	RS1/16S471J
R 120	(A,81,29)	RS1/16S104J
R 121	(A,82,27)	RS1/16S103J
R 123	(A,141,33)	RAB4C102J
R 124	(B,61,89)	RS1/16S471J
R 125	(B,62,86)	RS1/16S471J
R 126	(A,145,36)	RS1/16S102J
R 127	(B,127,53)	RS1/16S102J
R 128	(B,42,85)	RS1/16S104J
R 129	(B,41,87)	RS1/16S103J
R 130	(B,15,41)	RS1/16S472J
R 131	(B,18,56)	RS1/16S104J
R 132	(B,18,51)	RS1/16S103J
R 133	(B,144,52)	RS1/16S470J
R 134	(B,164,53)	RS1/16S470J
R 135	(B,11,51)	RS1/16S103J
R 201	(A,148,26)	RS1/16S473J
R 202	(A,148,21)	RS1/16S0R0J
R 203	(A,140,27)	RAB4C471J
R 204	(A,142,23)	RS1/16S471J
R 205	(A,152,26)	RAB4C471J
R 206	(A,155,24)	RS1/16S473J
R 301	(B,38,61)	RS1/16S272J
R 302	(B,38,58)	RS1/16S472J
R 303	(A,45,63)	RS1/16S101J
R 304	(B,61,57)	RS1/16S472J
R 305	(B,71,33)	RS1/16S750J
R 306	(B,49,57)	RS1/16S472J
R 307	(A,43,60)	RS1/16S102J
R 308	(A,51,63)	RS1/16S105J
R 309	(B,49,59)	RS1/16S105J
R 310	(B,38,65)	RS1/16S1002D
R 311	(B,42,65)	RS1/16S1002D

Circuit Symbol and No.			Part No.
R 312	(A,38,67)		RS1/16S4701D
R 313	(A,39,67)		RS1/16S4701D
R 314	(B,59,54)		RS1/16S680J
R 315	(A,37,78)		RS1/16S750J
R 316	(A,56,26)		RS1/16S101J
R 317	(B,47,52)		RS1/16S472J
R 318	(B,44,51)		RS1/16S472J
R 319	(B,45,57)		RS1/16S105J
R 320	(B,58,49)		RS1/16S105J
R 321	(A,48,45)		RS1/16S680J
R 322	(A,52,41)		RS1/16S472J
R 323	(A,61,44)		RS1/16S105J
R 324	(A,61,42)		RS1/16S472J
R 325	(A,54,43)		RS1/16S105J
R 326	(B,57,31)		RS1/16S680J
R 330	(A,61,26)		RS1/16S4701D
R 331	(A,62,26)		RS1/16S4701D
R 332	(A,59,26)		RS1/16S1002D
R 333	(A,64,26)		RS1/16S1002D
R 334	(B,63,15)		RS1/16S102J
R 335	(B,59,20)		RS1/16S272J
R 336	(B,59,17)		RS1/16S472J
R 401	(A,40,13)		RS1/16S104J
R 402	(A,36,9)		RS1/16S103J
R 403	(B,31,58)		RS1/16S473J
R 404	(B,28,61)		RS1/16S472J
R 405	(A,37,42)		RS1/16S102J
R 406	(B,20,24)		RS1/16S102J
R 408	(A,39,30)		RS1/16S102J
R 409	(A,35,7)		RS1/16S102J
R 410	(A,37,30)		RS1/16S102J
R 411	(A,38,34)		RS1/16S473J
R 601	(B,110,68)		RS1/16S104J
R 602	(B,87,43)		RS1/16S473J
R 603	(B,91,51)		RS1/16S473J
R 604	(B,90,51)		RS1/16S473J
R 605	(B,95,47)		RS1/16S473J
R 606	(B,104,29)		RS1/16S473J
R 608	(B,98,39)		RS1/16S102J
R 609	(B,102,52)		RS1/16S102J
R 611	(B,110,33)		RS1/16S473J
R 613	(A,104,30)	(UC)	RS1/16S473J
R 613	(EW5,RE)		RS1/16S273J
R 614	(A,104,28)	(EW5,RE,RC,RD)	RS1/16S473J
R 615	(A,105,33)	(RE,RC)	RS1/16S473J
R 616	(A,105,31)	(UC,EW5,RD)	RS1/16S473J
R 617	(B,98,40)		RS1/16S102J
R 619	(B,102,48)		RS1/16S473J
R 620	(B,109,45)		RS1/16S473J
R 621	(B,110,45)		RS1/16S473J
R 622	(A,116,48)		RAB4C102J
R 623	(A,120,40)		RS1/16S473J
R 624	(A,117,44)		RS1/16S473J
R 625	(B,114,42)		RS1/16S103J
R 701	(B,92,63)		RS1/16S1002D
R 702	(B,92,69)		RS1/16S1002D
R 703	(B,90,61)		RS1/16S1002D
R 704	(B,92,67)		RS1/16S1002D
R 705	(B,88,63)		RS1/16S1002D

Circuit Symbol and No.		Part No.
R 706	(B,88,69)	RS1/16S1002D
R 707	(B,86,61)	RS1/16S1002D
R 708	(A,88,70)	RS1/16S1002D
R 713	(B,82,58)	RS1/16S472J
R 714	(B,78,67)	RS1/16S472J
R 715	(B,78,60)	RS1/16S473J
R 716	(B,78,63)	RS1/16S473J
R 717	(B,76,58)	RS1/16S472J
R 718	(B,75,67)	RS1/16S472J
R 719	(B,77,61)	RS1/16S473J
R 720	(A,78,67)	RS1/16S473J
R 721	(A,78,57)	RS1/16S473J
R 722	(B,76,67)	RS1/16S473J
R 723	(A,75,57)	RS1/16S472J
R 724	(A,75,67)	RS1/16S472J
R 725	(B,74,62)	RS1/16S473J
R 726	(B,71,67)	RS1/16S473J
R 727	(B,74,58)	RS1/16S103J
R 728	(B,73,67)	RS1/16S103J
R 729	(B,71,59)	RS1/16S473J
R 730	(B,71,63)	RS1/16S473J
R 731	(B,67,59)	RS1/16S472J
R 732	(B,62,68)	RS1/16S0R0J
R 733	(B,113,89)	RS1/16S821J
R 734	(B,119,88)	RS1/16S821J
R 735	(B,124,84)	RS1/16S223J
R 736	(B,128,92)	RS1/16S223J
R 737	(B,104,22)	RS1/16S821J
R 738	(B,117,20)	RS1/16S821J
R 739	(B,103,19)	RS1/16S223J
R 740	(B,119,20)	RS1/16S223J
R 741	(B,88,84)	RS1/16S181J
R 742	(B,89,78)	RS1/16S181J
R 743	(B,83,88)	RS1/16S102J
R 744	(B,88,81)	RS1/16S102J
R 745	(B,85,87)	RS1/16S223J
R 746	(B,90,81)	RS1/16S223J
R 747	(B,80,88)	RS1/16S473J
R 748	(B,84,81)	RS1/16S473J
R 749	(B,82,88)	RS1/16S473J
R 750	(B,85,76)	RS1/16S473J
R 751	(A,77,84)	RS1/16S1002D
R 752	(A,81,78)	RS1/16S1002D
R 753	(A,78,90)	RS1/16S1002D
R 754	(A,81,80)	RS1/16S1002D
R 755	(A,75,84)	RS1/16S1002D
R 756	(A,80,76)	RS1/16S1002D
R 757	(A,74,90)	RS1/16S1002D
R 758	(A,80,82)	RS1/16S1002D
R 759	(A,69,87)	RS1/16S471J
R 760	(A,77,78)	RS1/16S471J
R 761	(A,71,91)	RS1/16S472J
R 762	(A,74,76)	RS1/16S472J
R 770	(B,37,90)	RS1/16S391J
R 771	(B,37,87)	RS1/16S391J
R 780	(A,86,70)	RS1/16S0R0J
R 781	(B,68,66)	RS1/16S472J
R 801	(B,58,76)	RS1/16S473J
R 802	(B,60,67)	RS1/16S103J
R 803	(B,59,67)	RS1/16S473J

Circuit Symbol and No.		Part No.
R 805	(B,141,94)	RS1/16S154J
R 806	(B,146,94)	RS1/16S473J
R 807	(B,141,92)	RS1/16S154J
R 808	(B,144,85)	RS1/16S104J
R 809	(B,139,82)	RS1/16S473J
R 810	(B,138,90)	RS1/16S473J
R 811	(B,152,89)	RS1/16S103J
R 812	(B,153,94)	RS1/16S473J
R 813	(B,160,81)	RS1/16S472J
R 814	(B,138,85)	RS1/16S473J
R 815	(B,164,94)	RS1/16S103J
R 816	(B,136,80)	RS1/16S473J
R 817	(B,49,26)	RS1/16S223J
R 818	(B,52,25)	RS1/16S473J
R 819	(B,52,28)	RS1/16S102J
R 820	(B,52,27)	RS1/16S104J
R 901	(B,120,53)	RS1/16S102J
R 902	(B,125,50)	RS1/16S472J
R 903	(A,122,56)	RS1/16S102J
R 904	(B,119,55)	RS1/16S102J
R 905	(A,122,57)	RS1/16S101J
R 906	(A,123,59)	RS1/16S101J

CAPACITORS

C 101	(A,81,20)	CKSRYB105K10
C 102	(A,137,42) 470 µF/16 V	CCH1704
C 103	(A,23,75)	CEJQ101M10
C 104	(B,23,72)	CKSRYB103K50
C 105	(B,23,55)	CKSRYB104K50
C 106	(A,23,53)	CEJQ101M10
C 108	(B,19,74)	CKSRYB103K50
C 109	(B,149,45)	CKSYB225K16
C 110	(A,23,61)	CEJQ101M16
C 111	(A,23,68)	CEJQ101M16
C 112	(A,85,24)	CKSRYB105K10
C 113	(A,155,42)	CEHAZL471M16
C 114	(B,23,62)	CKSRYB103K50
C 115	(B,158,48)	CKSYB225K16
C 116	(A,16,91) 1 500 µF/16 V	CCH1312
C 117	(B,172,54)	CKSRYB104K50
C 118	(A,23,95)	CKSRYB104K50
C 119	(A,168,34) 220 µF/10 V	CCH1409
C 121	(A,148,29)	CKSRYB104K50
C 122	(A,86,27)	CKSRYB104K50
C 123	(B,118,64)	CKSYB475K16
C 124	(A,114,64) 3 300 µF/16 V	CCH1150
C 125	(B,62,83)	CKSRYB103K50
C 127	(A,64,83)	CEJQ101M10
C 129	(B,23,37)	CKSRYB103K50
C 130	(A,64,90)	CEJQ101M16
C 131	(A,23,38)	CEJQ101M10
C 132	(B,62,90)	CKSRYB103K50
C 133	(A,23,46)	CEJQ101M10
C 135	(B,23,50)	CKSRYB103K50
C 201	(A,150,21)	CKSRYB104K50
C 301	(B,42,59)	CKSRYB104K50
C 302	(B,36,58)	CKSRYB102K50
C 303	(A,48,64)	CKSQYB225K10
C 304	(B,57,51)	CKSQYB225K10

Circuit Symbol and No.			Part No.
C 305	(B,71,29)		CKSRYB471K50
C 306	(A,45,60)		CKSRYB104K50
C 307	(A,61,30)	10 µF	CCG1220
C 308	(A,65,30)	10 µF	CCG1220
C 309	(A,59,30)	10 µF	CCG1220
C 310	(A,63,30)	10 µF	CCG1220
C 311	(B,38,67)		CCSRCK2R0C50
C 312	(B,42,67)		CCSRCK2R0C50
C 313	(B,53,59)		CKSRYB104K50
C 314	(B,52,55)		CKSRYB103K50
C 315	(A,59,54)	680 µF/16 V	CCH1415
C 316	(A,52,53)		CEJQ470M6R3
C 317	(A,39,76)	10 µF	CCG1220
C 318	(A,34,76)	10 µF	CCG1220
C 319	(A,38,76)	10 µF	CCG1220
C 320	(A,36,76)	10 µF	CCG1220
C 321	(B,63,22)		CKSRYB104K50
C 323	(A,44,56)		CKSQYB225K10
C 324	(A,59,49)		CKSQYB225K10
C 325	(B,39,50)		CKSRYB104K50
C 326	(B,38,49)		CKSRYB103K50
C 327	(A,43,42)	680 µF/16 V	CCH1415
C 328	(A,34,49)		CEJQ470M6R3
C 330	(A,59,47)		CKSQYB225K10
C 331	(A,62,44)		CKSRYB104K50
C 332	(A,54,40)		CKSRYB104K50
C 333	(B,59,33)		CKSRYB103K50
C 334	(A,53,32)	680 µF/16 V	CCH1415
C 335	(A,59,34)		CEJQ470M6R3
C 337	(B,94,10)		CKSRYB102K50
C 339	(A,58,26)		CCSRCK2R0C50
C 340	(A,65,26)		CCSRCK2R0C50
C 341	(B,63,14)		CKSRYB104K50
C 342	(B,59,18)		CKSRYB102K50
C 401	(B,51,79)		CKSRYB104K50
C 402	(A,43,35)		CKSRYB104K50
C 404	(A,38,36)		CKSRYB104K50
C 601	(B,110,60)		CKSQYB225K10
C 602	(A,104,27)		CKSRYB103K50
C 603	(B,88,50)	10 µF	CCG1220
C 604	(B,85,47)		CCSRCH101J50
C 605	(B,98,48)		CKSRYB105K10
C 606	(B,103,55)		CKSRYB103K50
C 607	(A,111,33)		CCSRCH101J50
C 608	(B,117,46)		CKSRYB104K50
C 701	(A,94,62)		CEJQ100M16
C 702	(A,94,68)		CEJQ100M16
C 703	(A,102,61)		CEJQ100M16
C 704	(A,98,64)		CEJQ100M16
C 705	(B,88,65)		CCSRCH820J50
C 706	(B,88,71)		CCSRCH820J50
C 707	(A,86,61)		CCSRCH820J50
C 708	(A,88,72)		CCSRCH820J50
C 709	(A,86,65)	10 µF	CCG1203
C 710	(A,90,59)		CKSRYB104K50
C 713	(A,82,62)		CEJQNP4R7M16
C 714	(A,82,68)		CEJQNP4R7M16
C 715	(A,69,79)		CEJQNP100M10
C 716	(A,75,72)		CEJQNP100M10
C 717	(A,75,55)		CCSRCH220J50

Circuit Symbol and No.			Part No.
C 718	(A,75,69)		CCSRCH220J50
C 719	(A,64,59)		CEJQ101M6R3
C 720	(A,59,61)		CEJQ220M6R3
C 721	(A,64,66)		CEJQ101M10
C 722	(B,66,66)		CKSRYB103K50
C 723	(A,64,73)		CEJQ4R7M25
C 724	(A,69,73)		CEJQ4R7M25
C 727	(A,107,21)		CEJQ4R7M25
C 728	(A,115,21)		CEJQ4R7M25
C 731	(B,124,9)		CKSRYB102K50
C 733	(B,83,85)		CKSRYB471K50
C 734	(B,86,84)		CKSRYB471K50
C 735	(A,84,85)		CKSRYB105K10
C 736	(B,86,78)		CKSRYB105K10
C 737	(A,80,90)		CKSRYB105K10
C 738	(B,86,80)		CKSRYB105K10
C 739	(A,75,86)		CCSRCH820J50
C 740	(A,79,76)		CCSRCH820J50
C 741	(A,73,90)		CCSRCH820J50
C 742	(A,79,82)		CCSRCH820J50
C 743	(A,72,87)	10 µF	CCG1203
C 744	(A,75,82)	10 µF	CCG1203
C 745	(A,80,91)		CKSRYB104K50
C 746	(A,88,74)		CKSRYB104K50
C 750	(A,37,83)		CEJQ101M16
C 801	(B,157,91)		CKSRYB105K10
C 802	(B,160,83)		CKSRYB104K50
C 803	(B,161,87)		CKSRYB104K50
C 804	(A,166,66)	2 200 µF/16 V	CCH1383
C 805	(B,62,60)		CKSRYB104K50
C 901	(A,121,49)		CKSRYB104K50
C 904	(B,107,91)		CKSRYB104K50

D

Unit Number : CWX3335
Unit Name : DVD Core Unit

MISCELLANEOUS

IC 1001	(A,7,9) IC	S-L2980A50MC-C7J
IC 1003	(A,83,36) IC	LTC3411EMS
IC 1201	(A,23,73) IC	AN8471SAT1
IC 1240	(A,49,74) IC	BD7962FM
IC 1501	(A,86,79) IC	MN35104UB
IC 1570	(B,68,87) IC	EDS1232AATA-75
IC 1601	(B,108,57) IC	PD6555B
IC 1602	(B,120,62) IC	TC7SH86FUS1
IC 1651	(B,108,27) IC	M5M5V216ATP-70HI
IC 1652	(B,98,36) IC	TC7SZ126FU
IC 1671	(B,108,43) IC	TC74LCX16373AFT
IC 1672	(B,98,40) IC	TC7SZ08FU
IC 1801	(B,33,92) IC	SM8707LV
IC 1802	(B,33,81) IC	TC7WH157FU
IC 1851	(B,16,87) IC	PCM1742KE
IC 1852	(B,17,79) IC	NJM2100V
IC 1853	(B,17,74) IC	NJM2100V
IC 1901	(A,23,56) IC	BA033SFP
IC 2001	(A,108,39) IC	PE5555A
IC 2002	(A,98,28) IC	BR93L56RFVM-W
IC 2003	(A,98,23) IC	TC74HC4053AFT

Circuit Symbol and No.		Part No.
IC 2006	(B,122,25) IC	NJM2904V
Q 1002	(A,76,37) Transistor	DTC114EU
Q 1101	(A,53,91) Transistor	2SB1260
Q 1102	(A,53,97) Transistor	2SB1260
Q 1103	(A,58,102) Transistor	DTC114EU
Q 1104	(A,55,102) Transistor	2SA1576
Q 1105	(A,50,102) Transistor	2SC4081
Q 1106	(A,63,93) Transistor	2SC4081
Q 1107	(A,63,99) Transistor	2SC4081
Q 1551	(A,107,98) Transistor	2SA1576
Q 2001	(A,123,42) Transistor	2SA2018
D 1001	(A,12,7) Diode	1SR154-400
D 1101	(A,49,91) Diode	1SS355
D 1102	(A,49,96) Diode	1SS355
D 2001	(B,94,36) Diode	DAN202U
L 1001	(A,77,30) Inductor	CTF1623
L 1002	(A,86,26) Inductor	CTF1624
L 1022	(A,9,5) Inductor	CTF1558
L 1101	(A,19,99) Inductor	CTF1305
L 1501	(A,118,69) Inductor	CTF1378
L 1502	(A,121,61) Inductor	CTF1487
L 1503	(B,75,71) Inductor	CTF1488
L 1554	(A,89,98) Inductor	CTF1473
L 1555	(A,90,100) Inductor	CTF1473
L 1556	(A,96,103) Inductor	CTF1400
L 1557	(A,103,102) Inductor	CTF1395
L 1558	(A,106,84) Inductor	CTF1473
L 1559	(A,73,101) Inductor	CTF1387
L 1561	(A,112,97) Inductor	CTF1473
L 1601	(B,112,68) Inductor	CTF1464
L 1651	(B,120,35) Inductor	CTF1464
L 1671	(B,120,39) Inductor	CTF1473
L 1801	(B,27,93) Inductor	CTF1558
L 1802	(B,27,90) Inductor	CTF1558
L 1803	(B,30,76) Inductor	CTF1464
L 1804	(B,35,76) Inductor	CTF1385
L 1805	(B,35,87) Inductor	CTF1385
L 1851	(B,25,89) Inductor	CTF1379
L 1852	(B,25,83) Inductor	CTF1473
L 1901	(B,17,15) Inductor	CTF1487
L 1902	(A,14,20) Inductor	CTF1558
L 1903	(A,16,22) Inductor	CTF1558
L 1904	(B,23,24) Inductor	CTF1468
L 1907	(B,23,22) Inductor	CTF1558
X 1801	(B,34,99) Resonator 27.000 MHz	CSS1661
X 2001	(A,109,50) Resonator 9.830 MHz	CSS1684
VR1551	(A,86,103) Semi-fixed 10 kΩ(B)	CCP1448
EF1570	(B,75,74) EMI Filter	DTF1106
EF1801	(B,27,87) EMI Filter	DTL1106
EF1802	(B,30,79) EMI Filter	DTL1106
EF1803	(B,27,96) EMI Filter	DTL1106
EF1901	(A,11,20) EMI Filter	DTL1106
EF1902	(A,13,22) EMI Filter	DTL1106
EF1903	(B,21,24) EMI Filter	DTL1106
EF1905	(B,13,15) EMI Filter	DTF1106
EF1907	(B,21,22) EMI Filter	DTL1106

RESISTORS

R 1003	(A,85,41)	RS1/16SS1003D
R 1005	(A,83,41)	RS1/16SS1501D
R 1006	(A,85,42)	RS1/16SS8202D
R 1007	(A,83,42)	RS1/16SS1502D
R 1008	(A,81,42)	RS1/16SS101J
R 1010	(A,88,37)	RS1/16SS105J
R 1011	(A,79,37)	RS1/16SS105J
R 1013	(A,85,39)	RS1/16SS103J
R 1014	(A,79,39)	RS1/16SS1203D
R 1015	(A,78,39)	RS1/16SS2402D
R 1016	(A,77,39)	RS1/16SS0R0J
R 1017	(A,75,39)	RS1/16SS0R0J
R 1018	(A,89,37)	RS1/16SS105J
R 1021	(A,83,39)	RS1/16SS122J
R 1101	(A,61,90)	RS1/16S6R8J
R 1102	(A,57,91)	RS1/16SS3R9J
R 1103	(A,57,89)	RS1/16SS3R9J
R 1104	(A,56,89)	RS1/16SS3R9J
R 1105	(A,56,91)	RS1/16SS3R9J
R 1106	(A,61,97)	RS1/16S6R8J
R 1107	(A,57,98)	RS1/16SS3R9J
R 1108	(A,57,96)	RS1/16SS3R9J
R 1109	(A,56,96)	RS1/16SS3R9J
R 1110	(A,56,98)	RS1/16SS3R9J
R 1111	(A,54,104)	RS1/16SS272J
R 1112	(A,57,104)	RS1/16SS472J
R 1113	(A,50,104)	RS1/16SS102J
R 1114	(A,56,94)	RS1/16SS221J
R 1115	(A,57,100)	RS1/16SS221J
R 1116	(A,63,95)	RS1/16SS331J
R 1117	(A,63,101)	RS1/16SS221J
R 1120	(A,57,93)	RS1/16SS0R0J
R 1201	(A,18,96)	RS1/16SS181J
R 1202	(A,14,95)	RS1/16SS181J
R 1203	(A,16,74)	RS1/16SS513J
R 1204	(A,16,71)	RS1/16SS221J
R 1206	(A,29,70)	RS1/16SS513J
R 1209	(A,19,88)	RS1/10S391J
R 1210	(A,15,88)	RS1/10S391J
R 1211	(A,29,76)	RS1/16SS1R0J
R 1212	(A,29,75)	RS1/16SS1R0J
R 1213	(A,29,74)	RS1/16SS1R0J
R 1214	(A,29,73)	RS1/16SS1R0J
R 1215	(A,29,72)	RS1/16SS1R0J
R 1216	(A,29,71)	RS1/16SS1R0J
R 1217	(A,15,75)	RS1/16SS102J
R 1251	(A,54,84)	RS1/16SS102J
R 1252	(A,51,85)	RS1/16SS472J
R 1253	(A,52,82)	RS1/16SS823J
R 1254	(A,52,84)	RS1/16SS122J
R 1255	(A,51,84)	RS1/16SS122J
R 1256	(A,51,82)	RS1/16SS682J
R 1257	(A,54,82)	RAB4CQ103J
R 1258	(A,47,84)	RS1/16SS223J
R 1259	(A,45,84)	RS1/16SS223J
R 1260	(A,46,82)	RS1/16SS393J
R 1261	(A,45,82)	RS1/16SS393J
R 1262	(A,54,67)	RS1/16SS273J
R 1263	(A,53,67)	RS1/16SS153J
R 1264	(A,52,67)	RS1/16SS102J
R 1265	(A,48,67)	RS1/16SS183J

Circuit Symbol and No.		Part No.
R 1266	(A,47,67)	RS1/16SS333J
R 1272	(A,47,85)	RS1/16SS102J
R 1273	(A,45,85)	RS1/16SS102J
R 1274	(A,56,83)	RS1/10S0R0J
R 1501	(A,89,58)	RS1/16SS0R0J
R 1502	(A,80,63)	RS1/16SS0R0J
R 1503	(A,81,60)	RAB4CQ101J
R 1504	(A,82,58)	RS1/16SS0R0J
R 1505	(A,83,58)	RS1/16SS0R0J
R 1506	(A,84,60)	RAB4CQ101J
R 1507	(A,86,63)	RS1/16SS0R0J
R 1508	(A,87,60)	RAB4CQ101J
R 1509	(A,87,58)	RS1/16SS0R0J
R 1511	(A,90,60)	RAB4CQ101J
R 1512	(A,90,58)	RS1/16SS0R0J
R 1513	(A,92,59)	RS1/16SS473J
R 1514	(A,93,61)	RS1/16SS104J
R 1515	(A,105,66)	RS1/16SS222J
R 1521	(A,96,57)	RS1/16SS0R0J
R 1522	(A,103,68)	RS1/16SS103J
R 1523	(A,94,61)	RS1/16SS104J
R 1525	(A,95,59)	RS1/16SS102J
R 1526	(A,94,57)	RS1/16SS0R0J
R 1529	(A,95,57)	RS1/16SS0R0J
R 1530	(A,97,63)	RS1/16SS104J
R 1531	(A,99,60)	RS1/16S221J
R 1532	(A,100,60)	RS1/16SS104J
R 1536	(A,99,63)	RS1/16SS104J
R 1537	(A,100,63)	RS1/16SS104J
R 1539	(A,103,75)	RS1/16SS104J
R 1540	(A,103,70)	RS1/16SS221J
R 1541	(A,104,71)	RS1/16SS473J
R 1543	(A,103,72)	RS1/16SS104J
R 1544	(A,103,74)	RS1/16SS102J
R 1545	(A,104,74)	RS1/16SS102J
R 1546	(A,105,64)	RS1/16SS104J
R 1547	(A,104,75)	RS1/16SS330J
R 1548	(A,95,61)	RS1/16SS104J
R 1555	(A,79,98)	RS1/16S101J
R 1556	(A,80,101)	RS1/16S101J
R 1558	(A,85,96)	RS1/16SS750J
R 1561	(A,88,96)	RS1/16SS153J
R 1562	(A,109,96)	RS1/16SS471J
R 1563	(A,110,96)	RS1/16SS471J
R 1565	(A,112,95)	RS1/16S68R0D
R 1566	(A,114,95)	RS1/16S4R7J
R 1567	(A,83,102)	RS1/16SS273J
R 1568	(A,83,104)	RS1/16SS183J
R 1569	(A,84,98)	RS1/16SS153J
R 1570	(A,81,101)	RS1/16SS222J
R 1571	(A,73,99)	RAB4CQ101J
R 1572	(A,73,96)	RAB4CQ101J
R 1573	(A,67,91)	RAB4CQ101J
R 1574	(A,67,88)	RAB4CQ101J
R 1575	(A,67,86)	RS1/16SS560J
R 1576	(A,67,85)	RS1/16SS560J
R 1577	(A,67,83)	RAB4CQ560J
R 1578	(A,67,81)	RAB4CQ560J
R 1579	(A,69,79)	RS1/16SS220J
R 1580	(A,67,78)	RAB4CQ560J

Circuit Symbol and No.		Part No.
R 1581	(A,67,76)	RS1/16SS560J
R 1582	(A,67,75)	RS1/16SS560J
R 1583	(A,67,74)	RS1/16SS560J
R 1584	(A,67,72)	RAB4CQ560J
R 1585	(A,67,70)	RS1/16SS560J
R 1586	(A,67,69)	RS1/16SS560J
R 1587	(A,67,67)	RAB4CQ101J
R 1588	(A,67,64)	RAB4CQ101J
R 1589	(A,74,60)	RAB4CQ101J
R 1590	(A,77,60)	RAB4CQ101J
R 1593	(B,61,86)	RS1/16SS104J
R 1595	(A,78,101)	RS1/16SS101J
R 1599	(A,71,101)	RS1/16S221J
R 1604	(B,120,60)	RS1/16SS0R0J
R 1608	(B,94,52)	RS1/16SS104J
R 1613	(B,96,64)	RS1/16SS0R0J
R 1621	(B,119,57)	RS1/16SS0R0J
R 1652	(B,103,35)	RS1/16SS104J
R 1653	(B,101,35)	RS1/16SS510J
R 1671	(B,103,49)	RAB4CQ101J
R 1672	(B,107,50)	RAB4CQ101J
R 1673	(B,109,50)	RAB4CQ101J
R 1674	(B,113,49)	RAB4CQ101J
R 1675	(B,101,41)	RS1/16SS331J
R 1701	(A,103,69)	RS1/16SS103J
R 1702	(A,105,68)	RS1/16SS103J
R 1705	(A,90,98)	RN1/16SE1002D
R 1709	(A,93,100)	RS1/16S1502D
R 1710	(A,95,98)	RS1/16SS102J
R 1711	(A,97,99)	RS1/16SS683J
R 1712	(A,98,96)	RS1/16SS103J
R 1713	(A,99,96)	RS1/16SS103J
R 1714	(A,101,96)	RS1/16SS0R0J
R 1715	(A,104,94)	RS1/16SS0R0J
R 1716	(A,104,93)	RS1/16SS0R0J
R 1717	(A,104,92)	RS1/16SS0R0J
R 1718	(A,103,91)	RS1/16SS103J
R 1719	(A,104,91)	RS1/16SS103J
R 1720	(A,103,90)	RS1/16SS103J
R 1721	(A,104,90)	RS1/16SS103J
R 1723	(A,106,87)	RN1/16SE3901D
R 1729	(A,105,81)	RAB4CQ220J
R 1730	(A,105,78)	RAB4CQ220J
R 1733	(B,92,87)	RS1/16SS104J
R 1734	(B,91,87)	RS1/16SS104J
R 1801	(B,31,87)	RS1/16S0R0J
R 1802	(B,29,94)	RS1/16S151J
R 1803	(B,29,87)	RS1/16S151J
R 1804	(B,32,87)	RS1/16S221J
R 1805	(B,37,87)	RS1/16S271J
R 1806	(B,33,86)	RS1/16SS104J
R 1809	(B,33,77)	RS1/16SS0R0J
R 1821	(B,37,81)	RS1/16SS222J
R 1823	(B,36,96)	RS1/16SS101J
R 1825	(B,35,79)	RS1/16SS101J
R 1851	(B,11,91)	RS1/16SS0R0J
R 1856	(B,14,77)	RS1/16SS102J
R 1857	(B,14,82)	RS1/16SS102J
R 1858	(B,11,77)	RS1/16SS222J
R 1859	(B,11,82)	RS1/16SS222J

Circuit Symbol and No.		Part No.
R 1860	(B,12,77)	RS1/16SS472J
R 1861	(B,12,82)	RS1/16SS472J
R 1862	(B,12,75)	RS1/16SS472J
R 1863	(B,12,80)	RS1/16SS472J
R 1864	(B,10,73)	RS1/16SS103J
R 1865	(B,10,78)	RS1/16SS103J
R 1866	(B,12,73)	RS1/16SS472J
R 1867	(B,12,78)	RS1/16SS472J
R 1868	(B,19,71)	RS1/16SS821J
R 1869	(B,12,71)	RS1/16SS821J
R 1870	(B,18,66)	RS1/16SS104J
R 1871	(B,12,66)	RS1/16SS104J
R 1875	(B,16,91)	RS1/16SS0R0J
R 1897	(B,37,84)	RS1/16SS101J
R 1901	(A,18,24)	RS1/16SS221J
R 1903	(A,20,26)	RS1/16SS221J
R 1905	(A,18,50)	RS1/16SS102J
R 1922	(A,16,30)	RS1/16SS0R0J
R 1923	(A,117,82)	RS1/16SS221J
R 1924	(B,26,33)	RS1/16S221J
R 1927	(A,15,30)	RS1/16SS0R0J
R 1931	(B,25,26)	RS1/16SS0R0J
R 1933	(B,25,27)	RS1/16SS0R0J
R 1938	(A,16,36)	RS1/16SS0R0J
R 1945	(B,24,36)	RS1/16SS0R0J
R 1947	(A,115,77)	RS1/16SS221J
R 1954	(A,16,26)	RS1/16SS221J
R 1955	(A,18,27)	RS1/16SS221J
R 2000	(A,118,32)	RS1/16SS104J
R 2001	(A,120,32)	RS1/16SS104J
R 2002	(A,118,34)	RS1/16SS472J
R 2003	(A,118,35)	RS1/16SS104J
R 2006	(A,118,37)	RS1/16SS104J
R 2007	(A,120,37)	RS1/16SS104J
R 2008	(A,118,38)	RS1/16SS104J
R 2009	(A,120,38)	RS1/16SS103J
R 2010	(A,105,27)	RS1/16SS473J
R 2011	(A,118,40)	RS1/16SS103J
R 2012	(A,120,41)	RS1/16SS103J
R 2013	(A,120,42)	RS1/16SS223J
R 2016	(A,120,45)	RS1/16SS184J
R 2021	(A,104,52)	RS1/16SS104J
R 2022	(A,99,49)	RS1/16S221J
R 2023	(A,95,46)	RS1/16S221J
R 2037	(A,98,34)	RS1/16SS104J
R 2038	(A,96,32)	RS1/16SS104J
R 2040	(A,103,29)	RS1/16SS104J
R 2041	(A,104,27)	RS1/16SS221J
R 2042	(A,104,29)	RS1/16SS104J
R 2043	(A,106,29)	RS1/16SS104J
R 2044	(A,106,27)	RS1/16SS104J
R 2045	(A,107,29)	RS1/16SS104J
R 2046	(A,107,27)	RS1/16SS104J
R 2047	(A,108,29)	RS1/16SS104J
R 2048	(A,108,27)	RS1/16SS104J
R 2049	(A,109,29)	RS1/16SS104J
R 2050	(A,109,24)	RS1/16SS104J
R 2051	(A,112,24)	RS1/16SS104J
R 2054	(A,110,29)	RS1/16SS104J
R 2055	(A,112,29)	RS1/16SS104J

Circuit Symbol and No.		Part No.
R 2057	(A,113,27)	RS1/16SS104J
R 2059	(A,120,34)	RS1/16SS104J
R 2060	(A,118,46)	RS1/16SS473J
R 2061	(A,118,45)	RS1/16SS682J
R 2062	(A,112,51)	RS1/16SS473J
R 2063	(A,106,54)	RS1/16SS104J
R 2064	(A,105,54)	RS1/16SS222J
R 2065	(A,106,52)	RS1/16SS473J
R 2067	(A,105,52)	RS1/16SS473J
R 2068	(A,104,49)	RS1/16SS104J
R 2073	(A,96,31)	RS1/16SS473J
R 2074	(A,98,31)	RS1/16SS472J
R 2075	(A,102,29)	RS1/16SS473J
R 2076	(B,92,42)	RS1/16SS0R0J
R 2077	(A,122,39)	RS1/16SS272J
R 2078	(A,123,39)	RS1/16SS103J
R 2080	(A,103,23)	RS1/16SS272J
R 2081	(A,103,22)	RS1/16SS243J
R 2082	(A,104,50)	RS1/16SS221J
R 2083	(B,92,44)	RS1/16SS221J
R 2084	(A,97,35)	RS1/16SS221J
R 2086	(A,98,33)	RS1/16SS0R0J
R 2087	(A,83,51)	RS1/16S0R0J
R 2092	(A,105,25)	RS1/16SS103J
R 2093	(A,106,25)	RS1/16SS103J
R 2094	(A,120,28)	RS1/16S0R0J
R 2096	(A,98,48)	RS1/16SS104J
R 2097	(A,102,27)	RS1/16SS104J
R 2098	(A,115,29)	RS1/16SS104J
R 2109	(A,108,48)	RS1/16SS105J
R 2110	(A,75,55)	RS1/16SS392J
R 2111	(A,74,57)	RS1/16SS123J

CAPACITORS

C 1001	(A,6,6)	CKSRYB224K10
C 1004	(A,9,9)	CKSRYB102K50
C 1005	(A,4,9)	CKSRYB105K10
C 1006	(A,76,23)	CKSRYB104K25
C 1007	(A,79,26) 22 µF	CCG1178
C 1008	(A,84,32) 22 µF	CCG1178
C 1009	(A,83,40)	CCSSCH220J50
C 1010	(A,81,39)	CKSSYB102K50
C 1012	(A,79,24) 22 µF	CCG1178
C 1013	(A,84,30) 22 µF	CCG1178
C 1017	(A,30,64)	CKSRYB105K10
C 1101	(A,29,83)	CSZSR220M16
C 1102	(A,59,91)	CSZSR101M6R3
C 1103	(A,56,93)	CKSSYB104K10
C 1104	(A,49,93)	CKSSYB103K16
C 1105	(A,59,97)	CSZSR101M6R3
C 1106	(A,56,100)	CKSSYB104K10
C 1107	(A,49,98)	CKSSYB103K16
C 1108	(A,52,103)	CKSRYB104K25
C 1109	(A,56,104)	CKSSYB473K10
C 1110	(A,47,104)	CKSSYB473K10
C 1111	(A,41,88)	CKSSYB103K16
C 1112	(A,41,104)	CKSRYB105K10
C 1113	(A,40,104)	CKSRYB105K10
C 1114	(A,40,99)	CKSSYB103K16
C 1115	(A,35,83)	CSZSR220M16

Circuit Symbol and No.		Part No.
C 1201	(A,33,79) 10 µF	CCG1138
C 1202	(A,29,78)	CKSRYB104K25
C 1203	(A,21,64)	CSZSR220M16
C 1204	(A,29,68)	CKSRYB104K25
C 1205	(A,16,67)	CKSRYB104K25
C 1206	(A,17,67)	CKSRYB104K25
C 1207	(A,24,64)	CSZSR220M16
C 1208	(A,17,80)	CKSRYB104K25
C 1240	(A,46,81)	CCSSCH470J50
C 1241	(A,45,81)	CCSSCH5R0C50
C 1243	(A,38,73) 10 µF	CCG1138
C 1244	(A,54,68)	CKSSYB472K25
C 1245	(A,47,68)	CKSSYB103K16
C 1501	(A,115,69)	CSZSR470M10
C 1502	(A,118,61)	CSZSR101M6R3
C 1503	(A,114,61)	CSZSR101M6R3
C 1504	(A,74,63)	CKSSYB104K10
C 1505	(A,76,63)	CKSSYB104K10
C 1506	(A,79,62)	CKSSYB104K10
C 1507	(A,79,63)	CKSSYB104K10
C 1508	(A,82,63)	CKSSYB104K10
C 1509	(A,85,63)	CKSSYB104K10
C 1510	(A,90,63)	CKSSYB104K10
C 1511	(A,96,63)	CKSSYB104K10
C 1512	(A,102,68)	CKSSYB104K10
C 1513	(A,103,73)	CKSSYB104K10
C 1514	(A,103,78)	CKSSYB104K10
C 1515	(A,103,80)	CKSSYB104K10
C 1516	(A,82,96)	CKSSYB104K10
C 1517	(A,78,96)	CKSSYB104K10
C 1518	(A,76,96)	CKSSYB104K10
C 1519	(A,76,97)	CKSSYB104K10
C 1520	(A,70,91)	CKSSYB104K10
C 1521	(A,70,89)	CKSSYB104K10
C 1522	(A,70,86)	CKSSYB104K10
C 1523	(A,70,85)	CKSSYB104K10
C 1524	(A,70,83)	CKSSYB104K10
C 1525	(A,70,81)	CKSSYB104K10
C 1526	(A,70,78)	CKSSYB104K10
C 1527	(A,70,75)	CKSSYB104K10
C 1528	(A,70,73)	CKSSYB104K10
C 1529	(A,70,71)	CKSSYB104K10
C 1530	(A,70,69)	CKSSYB104K10
C 1531	(A,98,63)	CKSSYB471K50
C 1532	(A,105,67)	CKSSYB103K16
C 1533	(A,105,65)	CKSSYB103K16
C 1552	(A,83,96)	CKSSYB104K10
C 1553	(A,90,102)	CKSRYB104K25
C 1554	(A,87,96)	CKSSYB104K10
C 1555	(A,87,98)	CKSRYB105K10
C 1556	(A,100,101)	CSZSR470M10
C 1557	(A,89,96)	CKSSYB104K10
C 1558	(A,111,98)	CSZS4R7M16
C 1559	(A,84,100)	CKSRYB105K10
C 1570	(B,67,73)	CSZSR470M10
C 1571	(B,76,77)	CKSRYB474K10
C 1572	(B,76,85)	CKSRYB474K10
C 1573	(B,61,80)	CKSRYB474K10
C 1574	(B,61,83)	CKSRYB474K10
C 1575	(B,61,91)	CKSRYB474K10
C 1576	(B,61,94)	CKSRYB474K10
C 1577	(B,61,97)	CKSRYB474K10
C 1578	(B,76,98)	CKSRYB474K10
C 1579	(B,76,79)	CKSRYB474K10
C 1580	(B,76,82)	CKSRYB474K10
C 1581	(B,76,92)	CKSRYB474K10
C 1582	(B,76,95)	CKSRYB474K10
C 1583	(B,71,73)	CSZSR470M10
C 1601	(B,110,65)	CSZSR470M10
C 1603	(B,96,51)	CKSSYB104K10
C 1651	(B,121,33)	CSZSR470M10
C 1653	(B,108,20)	CKSSYB104K10
C 1654	(B,98,34)	CKSRYB104K25
C 1655	(B,108,34)	CKSSYB104K10
C 1671	(B,106,48)	CKSSYB104K10
C 1672	(B,110,48)	CKSSYB104K10
C 1673	(B,110,37)	CKSSYB104K10
C 1674	(B,106,37)	CKSSYB104K10
C 1675	(B,98,42)	CKSRYB104K25
C 1676	(B,118,39)	CKSYB106K6R3
C 1701	(A,106,67)	CKSRYB104K25
C 1702	(A,105,69)	CKSRYB104K25
C 1703	(A,90,96)	CKSSYB104K10
C 1704	(A,91,96)	CKSSYB103K16
C 1706	(A,92,96)	CKSSYB104K10
C 1707	(A,96,100)	CKSSYB104K10
C 1708	(A,95,100)	CKSSYB103K16
C 1709	(A,92,98)	CCSRCH221J50
C 1710	(A,97,98)	CKSSYB152K50
C 1711	(A,94,97)	CKSRYB105K10
C 1712	(A,96,97)	CKSRYB105K10
C 1713	(A,97,97)	CKSRYB105K10
C 1715	(A,104,89)	CKSSYB104K10
C 1716	(A,103,88)	CKSSYB104K10
C 1717	(A,104,88)	CKSSYB104K10
C 1718	(A,103,87)	CKSSYB104K10
C 1719	(A,104,87)	CKSSYB562K25
C 1720	(A,103,86)	CCSSCH101J50
C 1721	(A,104,86)	CCSSCH470J50
C 1722	(A,103,85)	CKSSYB103K16
C 1723	(A,104,85)	CKSSYB104K10
C 1724	(A,103,84)	CKSSYB104K10
C 1725	(A,104,84)	CKSSYB104K10
C 1726	(A,103,83)	CCSSCH330J50
C 1727	(A,104,83)	CKSSYB333K16
C 1728	(A,103,82)	CKSSYB104K10
C 1801	(B,31,96)	CKSSYB104K10
C 1802	(B,33,96)	CKSSYB104K10
C 1804	(B,34,87)	CKSSYB104K10
C 1809	(B,32,101)	CCSSCJ3R0C50
C 1810	(B,36,101)	CCSSCK2R0C50
C 1811	(B,35,81)	CKSSYB104K10
C 1851	(B,21,87)	CKSSYB104K10
C 1852	(B,12,85)	CKSSYB104K10
C 1853	(B,10,85)	CKSYB106K6R3
C 1854	(B,23,84)	CKSYB106K6R3
C 1855	(B,21,84)	CKSRYB104K25
C 1856	(B,17,82)	CKSQYB225K10
C 1857	(B,10,80)	CCSRCH471J50
C 1858	(B,10,74)	CCSRCH471J50

Circuit Symbol and No.		Part No.
C 1859	(B,10,81)	CCSRCH471J50
C 1860	(B,10,76)	CCSRCH471J50
C 1861	(B,17,77)	CKSQYB225K10
C 1862	(B,19,69)	CKSSYB471K50
C 1863	(B,11,71)	CKSSYB471K50
C 1864	(B,17,69)	CKSYB475K10
C 1865	(B,14,69)	CKSYB475K10
C 1870	(B,23,92)	CKSSYB102K50
C 1901	(A,19,46)	CKSRYB474K10
C 1902	(A,29,54) 22 µF/6.3 V	CCH1300
C 1903	(A,28,48)	CSZSC101M10
C 1910	(B,10,15)	CKSRYB102K50
C 2001	(A,120,30)	CKSYB106K6R3
C 2002	(A,114,48)	CKSRYB105K10
C 2003	(A,112,49)	CKSSYB103K16
C 2004	(A,110,48)	CKSSYB103K16
C 2005	(A,109,54)	CKSQYB475K10
C 2006	(A,103,54)	CKSSYB103K16
C 2007	(A,96,41)	CKSSYB104K10
C 2008	(A,111,29)	CKSSYB104K10
C 2009	(A,120,43)	CKSSYB473K10
C 2010	(A,118,43)	CKSSYB103K16
C 2011	(A,123,47)	CKSRYB105K10
C 2015	(A,120,44)	CKSSYB473K10
C 2016	(A,118,44)	CKSSYB103K16
C 2017	(A,103,55)	CKSSYB103K16
C 2018	(A,98,20)	CKSRYB104K25
C 2020	(A,105,50)	CKSSYB471K50
C 2021	(A,119,48)	CKSRYB104K25
C 2022	(B,122,30)	CKSRYB104K16

E

Unit Number : CWX2986
Unit Name : PCB Assy

MISCELLANEOUS

VR11	(A,8,10) Semi-fixed 1 kΩ(B)	CCP1442
VR12	(A,9,23) Semi-fixed 1 kΩ(B)	CCP1442
R 11	(A,8,15)	RS1/16S562J
R 12	(A,10,15)	RS1/16S472J
R 13	(A,8,18)	RS1/16S562J
R 14	(A,9,6)	RS1/16S562J

Miscellaneous Parts List

	Stage Assy(Service)	CXX2133
M 1	Cam Motor Assy(CAM)	CXC5908
M 2	ELV Motor Assy(E/L Motor)	CXC5910
VR13	Variable Resistor	CCW1029