
Packing Assembly Parts List

Symbol No.	Part No.	Description
#1 101	68-00493Z08	OWNER'S MANUAL
$1 101	68-00493Z09	OWNER'S MANUAL
102	01T55561W37	ASSY,DIN(AINET/5500)

Symbol No.	Part No.	Description
103	03E36299S01	SCR,M4X14 TPG1.BLK(CR FREE)
104	75E26094S01	PAD,MAGIC TAPE
105	01E34618S01	ASSY,KIT WIRE 6P5557-06

NOTE : #1 : For North American Model Only, $1 : For General Foreign Model Only, Others : Common.

Packing Method View



TO CONTENTS

Electrical Parts List (Only Difference)

NOTE : For the parts not mentioned, refer to the Service Manual for PXA-H700 (Part No. 68E35821S01).

Model	PXA-H700		PXA-H701	
Symbol No.	Part No.	Description	Part No.	Description
MAIN P.W.Board				
Transistor			Transistor	
Q203	48E22877S01	TR,2SC3693 M,L,K	48E36297S01	TR,2SC4551
DSP P.W.Board				
IC			IC	
IC506	51T65804Y01	IC,UPD70F3030BYGC	51T65804Y06	IC,UPD70F3030BYGC

TO CONTENTS