


MC-90

Exploded View



× New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Parts List

Ref. No.	Address	New Parts	Parts No.	Description	Desti- nation	Re- marks
参照番号	位置	新	部品番号	部品名 / 規格	仕向	備考
MC-90						
4	2A	*	A62-0187-08	PANEL		
8	2B		E06-0854-08	CYLINDRICAL RECEPTACLE(8P)		
9	1B, 2B		E07-0852-05	8P PLUG(MIC CABLE)		
10	1B		E30-1692-08	MICROPHONE CABLE(8P-8P)		
11	1B	*	E37-0293-08	CONNECTING WIRE(CANNON)		
12	3B	*	E37-0294-08	CONNECTING WIRE(2P-2P)		
13	2B	*	E37-0295-08	CONNECTING WIRE(6P)		
15	3B	*	E37-0297-08	CONNECTING WIRE(CANNON)		
18	2A	*	G13-1378-08	FORMED PLATE(LOCK)		
20	3A, 3B	*	J02-0466-08	FOOT		
21	1A		J19-1355-08	HOLDER		
25	2A	*	K24-2001-08	KNOB(UP-DOWN)		
26	2A	*	K24-2002-08	KNOB(LOCK)		
27	2A	*	K24-2003-08	KNOB(PTT)		
A	2B		N08-0510-08	DRESSED SCREW(A)		
B	2A		N08-0511-08	DRESSED SCREW(B)		
C	2B		N19-0626-08	SPRING WASHER		
D	2B		N19-0627-08	WASHER		
E	3B	*	N19-0653-08	FLAT WASHER		
F	3A		N30-2004-41	PAN HEAD MACHIN SCREW		
G	3B		N30-3005-41	PAN HEAD MACHIN SCREW		
H	3A		N30-3008-41	PAN HEAD MACHIN SCREW		
I	3B	*	N30-4015-41	PAN HEAD MACHIN SCREW		
J	2A		N87-2008-46	BRAZIER HEAD TAPTITE SCREW		
S1	-		S40-2429-05	PUSH SWITCH(LOCK)		
S2	-		S40-2430-05	PUSH SWITCH(PTT)		
S3	-		S42-2405-08	PUSH SWITCH(UP-DWN)		
S5	3A	*	S62-0424-08	SLIDE SWITCH(M.V1.V2)		
41	1A	*	W02-1737-08	MICROPHONE UNIT		
C1	-		CS15E1CR47M	TANTAL. 0.47UF 16WV		
C2	-		CS15E1CR22M	TANTAL. 0.22UF 16WV		
R1	-		RD14BB2B122J	RD 1.2K J 1/8W		