
EXPLODED VIEW



Parts with the exploded numbers larger than 700 are not supplied.

KAC-PS621/X621

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KAC-PS621/X621					
1	1B	✻	A21-4363-02	DRESSING PANEL	KM1
1	1B	✻	A21-4364-02	DRESSING PANEL	E1
3	3A	✻	A64-3298-02	PANEL	
4	1A	✻	B07-3102-03	ESCUTCHEON	
5	1B	✻	B07-3103-02	ESCUTCHEON	
6	1B	✻	B07-3104-02	ESCUTCHEON	
7	1A	✻	B10-4544-03	FRONT GLASS	
8	1B	✻	B19-2257-03	LIGHTING BOARD	
10	1B	✻	B43-1521-04	BADGE	KM1
10	1B	✻	B43-1522-04	BADGE	E1
-			B46-0100-50	WARRANTY CARD	
-			B46-0648-13	USER CARD	K
-		✻	B64-2795-00	INSTRUCT.MANUAL (ENG.FRE.SPA.)	KE1
-		✻	B64-2796-00	INST.MANUAL (GER.DUT.ITA.POR.)	E1
-		✻	B64-2798-00	INSTRUCTION MANUAL(ENG.T-CHI.)	M1
FC1	3B	✻	E39-0642-05	FLAT CABLE	
13	1B	✻	F01-1752-01	HEAT SINK	
14	1B	✻	F07-1140-12	COVER	KM1
14	1B	✻	F07-1141-12	COVER	E1
16	1B		F09-1846-05	FAN	
17	1A	✻	F09-1885-05	FAN	
⚠ F1-3	3A		F52-0014-05	FUSE (BLADE TYPE) 25A	
-		✻	H10-4894-13	POLYSTYRENE FOAMED FIXTURE	
-		✻	H13-2056-04	CARTON BOARD	
-		✻	H25-1199-04	PROTECTION BAG	
-		✻	H25-1200-04	PROTECTION BAG (250X350X0.03)	
-		✻	H54-3136-03	ITEM CARTON CASE	K
-		✻	H54-3137-03	ITEM CARTON CASE	E1
-		✻	H54-3138-03	ITEM CARTON CASE	M1
24	2B	✻	K24-4146-03	KNOB (VR CAP)	
26	1A		N99-1577-15	SCREW SET	
27	1A	✻	N99-1752-05	SCREW SET	
A	2A	✻	N09-6216-05	TAPTITE SCREW	
B	3A	✻	N09-6218-05	TAPTITE SCREW	
C	2B	✻	N09-6220-05	MACHINE SCREW	
D	3A	✻	N15-1040-48	FLAT WASHER (4)	
E	3A	✻	N80-2008-43	PAN HEAD TAPTITE SCREW	
F	3A		N80-3010-43	PAN HEAD TAPTITE SCREW	
G	1A		N82-2006-48	BINDING HEAD TAPTITE SCREW	
H	2A	✻	N84-2606-48	PAN HEAD TAPTITE SCREW	
J	3A		N89-3006-43	BINDING HEAD TAPTITE SCREW	
K	3A	✻	N89-3008-43	BINDING HEAD TAPTITE SCREW	
L	2A		N89-3008-48	BINDING HEAD TAPTITE SCREW	
M	2A	✻	N89-3016-48	BINDING HEAD TAPTITE SCREW	
P	2B	✻	N80-2008-48	PAN HEAD TAPTITE SCREW	
Q	2B	✻	N83-3012-48	PAN HEAD TAPTITE SCREW	
28	1A		W01-1606-05	ACCESSORY	

Ref. No.	Add	New	Parts No.	Description	Destination
PREAMPLIFIER UNIT (X08-4150-10)					
40	2B	✻	B11-1446-04	REFLECTION SHEET	
41	2A	✻	B11-1447-04	OPTICAL DIFFUSER	
42	2B	✻	B19-2258-12	LIGHTING BOARD	
D2		✻	B30-1694-05	LED	
ED1		✻	B38-1150-05	LCD DISPLAY ASSY	
C3-6			CK73FB1C224K	CHIP C 0.22UF K	
C9,10			CD04AS1H010M	ELECTRO 1UF 50WV	
C11-13			CK73GB1H103K	CHIP C 0.010UF K	
C15-20			CD04AS1C100M	ELECTRO 10UF 16WV	
C21,22			CK73GB1C104K	CHIP C 0.10UF K	
C23,24			CK73FB1C224K	CHIP C 0.22UF K	
C25,26			CD04AS1C100M	ELECTRO 10UF 16WV	
C27,28			CK73GB1H103K	CHIP C 0.010UF K	
C29,30			CK73GB1H102K	CHIP C 1000PF K	
C31,32			CD04AS1C100M	ELECTRO 10UF 16WV	
C33			CK73GB1C104K	CHIP C 0.10UF K	
C34			CK73FB1C154K	CHIP C 0.15UF K	
C35			CK73GB1E223K	CHIP C 0.022UF K	
C37,38			CK73GB1H103K	CHIP C 0.010UF K	
C39			CD04AS1C100M	ELECTRO 10UF 16WV	
C40-45			CK73GB1H103K	CHIP C 0.010UF K	
C48,49			CK73GB1H103K	CHIP C 0.010UF K	
C61			CD04AS1C100M	ELECTRO 10UF 16WV	
C63-66			CK73FB1C224K	CHIP C 0.22UF K	
C67,68			CD04AS1C100M	ELECTRO 10UF 16WV	
C73			CK73GB1C104K	CHIP C 0.10UF K	
C74			CK73FB1C154K	CHIP C 0.15UF K	
C75			CK73GB1E333K	CHIP C 0.033UF K	
C101			CK73GB1H821K	CHIP C 820PF K	
C102,103			CK73GB1H473K	CHIP C 0.047UF K	
C104			CK73GB1H103K	CHIP C 0.010UF K	
C105			CD04AS1C100M	ELECTRO 10UF 16WV	
C107			CK73GB1H102K	CHIP C 1000PF K	
CN1		✻	E41-2178-05	FLAT CABLE CONNECTOR	
CN2			E41-0941-05	PIN ASSY	
WH2		✻	E39-0655-05	WIRING HARNESS	
R1,2			RK73GB2A473J	CHIP R 47K J 1/10W	
R3,4			RK73GB2A134J	CHIP R 130K J 1/10W	
R5,6			RK73GB2A223J	CHIP R 22K J 1/10W	
R7-12			RK73GB2A473J	CHIP R 47K J 1/10W	
R13			RD14BB2C391J	RD 390 J 1/6W	
R14-16			RK73GB2A101J	CHIP R 100 J 1/10W	
R17-20			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R21,22			RK73GB2A103J	CHIP R 10K J 1/10W	
R23,24			RK73GB2A473J	CHIP R 47K J 1/10W	
R25,26			RK73GB2A563J	CHIP R 56K J 1/10W	
R27,28			RK73GB2A912J	CHIP R 9.1K J 1/10W	
R29,30			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R31-33			RK73GB2A473J	CHIP R 47K J 1/10W	
R34			RK73GB2A103J	CHIP R 10K J 1/10W	
R38			RK73GB2A203J	CHIP R 20K J 1/10W	
R39,40			RK73GB2A471J	CHIP R 470 J 1/10W	

E1 : KAC-PS621 **K** : KAC-X621 **M1** : KAC-X621
(**E** : Europe **K** : North America **M** : Other Areas)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description				Destination
R41,42			RK73GB2A153J	CHIP R	15K	J	1/10W	
R43			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R44			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R45			RK73GB2A153J	CHIP R	15K	J	1/10W	
R46			RK73GB2A473J	CHIP R	47K	J	1/10W	
R52			RK73GB2A473J	CHIP R	47K	J	1/10W	
R55,56			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R63,64			RK73GB2A563J	CHIP R	56K	J	1/10W	
R65,66			RK73GB2A393J	CHIP R	39K	J	1/10W	
R69,70			RK73GB2A103J	CHIP R	10K	J	1/10W	
R72			RK73GB2A752J	CHIP R	7.5K	J	1/10W	
R73			RK73GB2A103J	CHIP R	10K	J	1/10W	
R74			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R76			RK73GB2A224J	CHIP R	220K	J	1/10W	
R77			RK73GB2A123J	CHIP R	12K	J	1/10W	
R78			RK73GB2A101J	CHIP R	100	J	1/10W	
R79			RK73GB2A103J	CHIP R	10K	J	1/10W	
R101-104			RK73GB2A471J	CHIP R	470	J	1/10W	
R105			RK73GB2A683J	CHIP R	68K	J	1/10W	
R106			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R107,108			RK73GB2A471J	CHIP R	470	J	1/10W	
R109-111			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R112			RK73GB2A104J	CHIP R	100K	J	1/10W	
R114,115			RK73GB2A103J	CHIP R	10K	J	1/10W	
R116			RD14BB2C391J	RD	390	J	1/6W	
R117			RD14BB2C6R8J	RD	6.8	J	1/6W	
VR1			R31-0225-05	VARIABLE RESISTOR				
VR2		✻	R31-0238-05	VARIABLE RESISTOR				
VR3			R31-0225-05	VARIABLE RESISTOR				
S1-3		✻	S62-0873-05	SLIDE SWITCH				
S4		✻	S62-0874-05	SLIDE SWITCH				
S7-9		✻	S70-0922-05	TACT SWITCH				
D1			MA3082-M	ZENER DIODE				
IC1		✻	NJM2058M-ZB	ANALOGUE IC				
IC3		✻	E-TDA7409DTR	ANALOGUE IC				
IC4		✻	NJM4565MD-ZB	ANALOGUE IC				
IC5		✻	NJM2058M-ZB	ANALOGUE IC				
IC6		✻	NJM4565MD-ZB	ANALOGUE IC				
IC7		✻	LC75853NE-E	MOS-IC				

AUDIO UNIT (X09-5770-10)

Ref. No.	Add	New	Parts No.	Description				Destination
D13			B30-1601-05	LED				
C1,2			CK73GB1H471K	CHIP C	470PF	K		
C3,4		✻	C90-5592-05	ELECTRO	10UF	35WV		
C5,6			CC73GCH1H150J	CHIP C	15PF	J		
C11-14			CC73GCH1H150J	CHIP C	15PF	J		
C15,16		✻	C90-5586-05	ELECTRO	22UF	25WV		
C17,18		✻	C90-5592-05	ELECTRO	10UF	35WV		
C19			CF92FV1H102J	MF-C	1000PF	J		
C21			CK73FB1H104K	CHIP C	0.10UF	K		
C51		✻	C90-5557-05	ELECTRO	10UF	25WV		
C52		✻	C90-5588-05	ELECTRO	47UF	25WV		
C53			CK73GB1H102K	CHIP C	1000PF	K		
C54		✻	C90-5588-05	ELECTRO	47UF	25WV		

PREAMPLIFIER UNIT (X08-4150-10)

Ref. No.	Add	New	Parts No.	Description				Destination
C55,56		✻	CD04BC1C392M	ELECTRO	3900UF	16WV		
C61		✻	C90-5592-05	ELECTRO	10UF	35WV		
C62			CK73GB1H103K	CHIP C	0.010UF	K		
C63,64		✻	C90-5588-05	ELECTRO	47UF	25WV		
C65,66			CK73GB1H103K	CHIP C	0.010UF	K		
C67,68		✻	C90-5592-05	ELECTRO	10UF	35WV		
C69			C90-5601-05	ELECTRO	1UF	50WV		
C70		✻	C90-5588-05	ELECTRO	47UF	25WV		
C71			CK73GB1C104K	CHIP C	0.10UF	K		
C72			CF92FV1H332J	MF-C	3300PF	J		
C73			CF92FV1H182J	MF-C	1800PF	J		
C74		✻	C90-5590-05	ELECTRO	220UF	25WV		
C76		✻	C90-5592-05	ELECTRO	10UF	35WV		
C89			CF92FV1H332J	MF-C	3300PF	J		
C90,91		✻	C90-5689-05	ELECTRO	4700UF	63WV		
C101,102		✻	C90-5586-05	ELECTRO	22UF	25WV		
C103,104			CC45FSL1H471J	CERAMIC	470PF	J		
C105,106			CK73GB1H472K	CHIP C	4700PF	K		
C107,108			C90-5601-05	ELECTRO	1UF	50WV		
C109		✻	C90-5592-05	ELECTRO	10UF	35WV		
C111,112		✻	C90-5588-05	ELECTRO	47UF	25WV		
C115,116			CC45FSL1H331J	CERAMIC	330PF	J		
C117-120			CC45FSL1H220J	CERAMIC	22PF	J		
C121,122			CK45FB1H102K	CERAMIC	1000PF	K		
C123,124			CC45FSL1H220J	CERAMIC	22PF	J		
C125-128			CK73GB1H471K	CHIP C	470PF	K		
C129-136			CK45FB1H471K	CERAMIC	470PF	K		
C137		✻	C90-5695-05	ELECTRO	100UF	63WV		
C138			C90-5602-05	ELECTRO	2.2UF	50WV		
C139		✻	C90-5570-05	ELECTRO	33UF	10WV		
C140		✻	C90-5588-05	ELECTRO	47UF	25WV		
C141			C90-5566-05	ELECTRO	100UF	6.3WV		
C142			CK73GB1H103K	CHIP C	0.010UF	K		
C143			C90-5566-05	ELECTRO	100UF	6.3WV		
C145,146			CF92FV1H473J	MF-C	0.047UF	J		
C147		✻	C90-5695-05	ELECTRO	100UF	63WV		
C151,152			CC73GCH1H220J	CHIP C	22PF	J		
C153,154			CC73GCH1H221J	CHIP C	220PF	J		
C251,252			CK73GB1H103K	CHIP C	0.010UF	K		
C257			C90-5602-05	ELECTRO	2.2UF	50WV		
C260		✻	C90-5570-05	ELECTRO	33UF	10WV		
C301		✻	C90-5557-05	ELECTRO	10UF	25WV		
C302-305			CK73FB1H104K	CHIP C	0.10UF	K		
C307			CK73GB1H103K	CHIP C	0.010UF	K		
C308		✻	C90-5592-05	ELECTRO	10UF	35WV		
C309,310			CK73GB1H103K	CHIP C	0.010UF	K		
C311,312			CC73GCH1H101J	CHIP C	100PF	J		
C313			CK73GB1H103K	CHIP C	0.010UF	K		
C314			CK73FB1H104K	CHIP C	0.10UF	K		
C343			CK73GB1H103K	CHIP C	0.010UF	K		
C349,350		✻	C90-5592-05	ELECTRO	10UF	35WV		
C351		✻	C90-5588-05	ELECTRO	47UF	25WV		
C352		✻	C90-5592-05	ELECTRO	10UF	35WV		
C353,354			CK73GB1H103K	CHIP C	0.010UF	K		
C358		✻	C90-5592-05	ELECTRO	10UF	35WV		

E1 : KAC-PS621 **K** : KAC-X621 **M1** : KAC-X621
(**E** : Europe **K** : North America **M** : Other Areas)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5770-10)

Ref. No.	Add	New	Parts No.	Description				Destination
C401			C90-5572-05	ELECTRO	100UF		10WV	
C402			CK73GB1H103K	CHIP C	0.010UF		K	
C403			C90-5602-05	ELECTRO	2.2UF		50WV	
C404,405			CC73GCH1H270J	CHIP C	27PF		J	
C406			CK73GB1H103K	CHIP C	0.010UF		K	
C451-453			CC73GCH1H101J	CHIP C	100PF		J	
C454			CK73GB1H103K	CHIP C	0.010UF		K	
C456,457			CK73GB1H103K	CHIP C	0.010UF		K	
C601		✻	CD04BC1C392M	ELECTRO	3900UF		16WV	
C602,603			CK73GB1H102K	CHIP C	1000PF		K	
CN1			E41-0928-05	PIN ASSY				
CN2,3			E41-0927-05	PIN ASSY				
CN10		✻	E41-2202-05	FLAT CABLE CONNECTOR				
J1		✻	E63-0901-05	PIN JACK				
J2			E70-0838-05	SCREW TERMINAL BOARD				
J3		✻	E56-0856-05	CYLINDRICAL RECEPTACLE				
J4		✻	E56-0853-05	CYLINDRICAL RECEPTACLE				
⚠ CN9			J13-0602-05	FUSE HOLDER				
⚠ CN61			J13-0602-05	FUSE HOLDER				
L1		✻	L33-1972-05	CHOKE COIL				
L4		✻	L19-0754-05	TRANSFORMER FOR CONVERTER				
L5		✻	L19-0758-05	TRANSFORMER FOR CONVERTER				
L6		✻	L19-0754-05	TRANSFORMER FOR CONVERTER				
L9			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)				
X1			L77-2844-05	CRYSTAL RESONATOR (12.288MHZ)				
F	3A		N80-3010-43	PAN HEAD TAPTITE SCREW				
K	3A	✻	N89-3008-43	BINDING HEAD TAPTITE SCREW				
N	2B	✻	N09-6217-05	TAPTITE SCREW				
R1,2			RD14BB2C102J	RD	1.0K	J	1/6W	
R3,4			RK73GB2A103J	CHIP R	10K	J	1/10W	
R5,6			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R7-10			RK73GB2A103J	CHIP R	10K	J	1/10W	
R11-18			RN73GH1J103D	CHIP R	10K	D	1/16W	
R19,20			RK73GB2A223J	CHIP R	22K	J	1/10W	
R21-23			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R51			RK73GB2A154J	CHIP R	150K	J	1/10W	
R52			RK73GB2A333J	CHIP R	33K	J	1/10W	
R53			RK73GB2A682J	CHIP R	6.8K	J	1/10W	
R54			RK73GB2A183J	CHIP R	18K	J	1/10W	
R55,56			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R57,58			RK73GB2A560J	CHIP R	56	J	1/10W	
R59,60			RK73GB2A100J	CHIP R	10	J	1/10W	
R61,62			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R67			RK73GB2A821J	CHIP R	820	J	1/10W	
R69			RK73GB2A153J	CHIP R	15K	J	1/10W	
R70			RK73GB2A101J	CHIP R	100	J	1/10W	
R71			RK73GB2A103J	CHIP R	10K	J	1/10W	
R72			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R73			RD14DB2H100J	SMALL-RD	10	J	1/2W	
R74			RK73GB2A104J	CHIP R	100K	J	1/10W	
R76			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R77			RK73GB2A511J	CHIP R	510	J	1/10W	
R79			RK73GB2A103J	CHIP R	10K	J	1/10W	

Ref. No.	Add	New	Parts No.	Description				Destination
R80			RK73GB2A473J	CHIP R	47K	J	1/10W	
R81			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R82			RK73GB2A392J	CHIP R	3.9K	J	1/10W	
R83			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R84			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R85			RK73GB2A392J	CHIP R	3.9K	J	1/10W	
R86			RK73GB2A103J	CHIP R	10K	J	1/10W	
R88,89			RD14DB2H100J	SMALL-RD	10	J	1/2W	
R90,91			RD14BB2C563J	RD	56K	J	1/6W	
R92			RK73GB2A103J	CHIP R	10K	J	1/10W	
R93			RK73GB2A113J	CHIP R	11K	J	1/10W	
R101,102			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R103,104			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R105,106			RD14BB2C333J	RD	33K	J	1/6W	
R107-110			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R111,112			RK73GB2A101J	CHIP R	100	J	1/10W	
R113,114			RK73GB2A473J	CHIP R	47K	J	1/10W	
R115,116			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R117,118			RK73GB2A242J	CHIP R	2.4K	J	1/10W	
R119,120			RD14BB2C222J	RD	2.2K	J	1/6W	
R121-124			RD14BB2C221J	RD	220	J	1/6W	
R125-128			RD14BB2C682J	RD	6.8K	J	1/6W	
R129,130			RD14BB2C151J	RD	150	J	1/6W	
R131,132			RD14BB2C333J	RD	33K	J	1/6W	
R133,134			RD14BB2C182J	RD	1.8K	J	1/6W	
R135,136			RD14BB2C561J	RD	560	J	1/6W	
R137,138			RD14BB2C330J	RD	33	J	1/6W	
R139-142			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R143,144			RK73GB2A112J	CHIP R	1.1K	J	1/10W	
R145,146			RD14NB2E471J	RD	470	J	1/4W	
R147,148			RK73GB2A112J	CHIP R	1.1K	J	1/10W	
R151-154			RD14NB2E101J	RD	100	J	1/4W	
R155,156			RD14NB2E471J	RD	470	J	1/4W	
R157-164			RD14NB2E4R7J	RD	4.7	J	1/4W	
R165-172			R92-0205-05	METAL-PLATE	0.1	K	2W	
R173			RD14DB2H100J	SMALL-RD	10	J	1/2W	
R174			RK73GB2A333J	CHIP R	33K	J	1/10W	
R175			RK73GB2A153J	CHIP R	15K	J	1/10W	
R176			RK73GB2A331J	CHIP R	330	J	1/10W	
R177			RK73GB2A223J	CHIP R	22K	J	1/10W	
R178,179			RK73GB2A470J	CHIP R	47	J	1/10W	
R180,181			RK73GB2A682J	CHIP R	6.8K	J	1/10W	
R182,183			RK73GB2A103J	CHIP R	10K	J	1/10W	
R184-186			RK73GB2A473J	CHIP R	47K	J	1/10W	
R187,188			RK73GB2A103J	CHIP R	10K	J	1/10W	
R189			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R190			RK73GB2A103J	CHIP R	10K	J	1/10W	
R191			RK73GB2A562J	CHIP R	5.6K	J	1/10W	
R192			RK73GB2A153J	CHIP R	15K	J	1/10W	
R193			RK73GB2A223J	CHIP R	22K	J	1/10W	
R194			RK73GB2A822J	CHIP R	8.2K	J	1/10W	
R195			RK73GB2A103J	CHIP R	10K	J	1/10W	
R196			RK73GB2A104J	CHIP R	100K	J	1/10W	
R197,198			RK73GB2A473J	CHIP R	47K	J	1/10W	
R199			RK73GB2A562J	CHIP R	5.6K	J	1/10W	

E1 : KAC-PS621 **K** : KAC-X621 **M1** : KAC-X621
(**E** : Europe **K** : North America **M** : Other Areas)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5770-10)

Ref. No.	Add	New	Parts No.	Description	Destination
R200			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R201,202			RD14DB2H100J	SMALL-RD 10 J 1/2W	
R203			RK73GB2A273J	CHIP R 27K J 1/10W	
R211,212			RK73GB2A1R0J	CHIP R 1.0 J 1/10W	
R221,222			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R223,224			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R241			RK73GB2A512J	CHIP R 5.1K J 1/10W	
R249,250			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R263			RK73GB2A333J	CHIP R 33K J 1/10W	
R266			RK73GB2A153J	CHIP R 15K J 1/10W	
R269			RK73GB2A331J	CHIP R 330 J 1/10W	
R272			RK73GB2A223J	CHIP R 22K J 1/10W	
R277,278			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R301,302			RD14BB2C271J	RD 270 J 1/6W	
R303,304			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R306,307			RN73GH1J103D	CHIP R 10K D 1/16W	
R308,309			RK73GB2A470J	CHIP R 47 J 1/10W	
R310			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R311			RK73GB2A113J	CHIP R 11K J 1/10W	
R312,313			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R314			RK73GB2A113J	CHIP R 11K J 1/10W	
R315			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R316,317			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R318			RD14BB2C153J	RD 15K J 1/6W	
R319			RD14BB2C104J	RD 100K J 1/6W	
R320			RD14BB2C153J	RD 15K J 1/6W	
R321,322			RD14BB2C102J	RD 1.0K J 1/6W	
R323			RK73GB2A392J	CHIP R 3.9K J 1/10W	
R324			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R325,326			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R328,329			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R330,331			RK73GB2A470J	CHIP R 47 J 1/10W	
R332			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R333			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R334,335			RD14BB2C470J	RD 47 J 1/6W	
R336			RK73GB2A104J	CHIP R 100K J 1/10W	
R337-339			RK73GB2A103J	CHIP R 10K J 1/10W	
R341,342			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R344			RK73GB2A473J	CHIP R 47K J 1/10W	
R345			RD14BB2C473J	RD 47K J 1/6W	
R347			RK73GB2A104J	CHIP R 100K J 1/10W	
R348,349			RK73GB2A182J	CHIP R 1.8K J 1/10W	
R350,351			RK73GB2A103J	CHIP R 10K J 1/10W	
R352			RK73GB2A302J	CHIP R 3.0K J 1/10W	
R353			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R354-357			RK73GB2A100J	CHIP R 10 J 1/10W	
R360			RK73GB2A103J	CHIP R 10K J 1/10W	
R401			RK73GB2A103J	CHIP R 10K J 1/10W	
R402			RK73GB2A473J	CHIP R 47K J 1/10W	
R421,422			RK73GB2A101J	CHIP R 100 J 1/10W	
R423,424			RK73GB2A103J	CHIP R 10K J 1/10W	
R425,426			RK73GB2A181J	CHIP R 180 J 1/10W	
R427-429			RK73GB2A103J	CHIP R 10K J 1/10W	
R430			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R431			RK73GB2A473J	CHIP R 47K J 1/10W	
R432,433			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R434			RK73GB2A103J	CHIP R 10K J 1/10W	
R438			RK73GB2A153J	CHIP R 15K J 1/10W	
R439			RK73GB2A181J	CHIP R 180 J 1/10W	
R440			RK73GB2A103J	CHIP R 10K J 1/10W	
R441			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R442			RK73GB2A182J	CHIP R 1.8K J 1/10W	
R443,444			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R450-453			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R454,455			RK73GB2A101J	CHIP R 100 J 1/10W	
R458-460			RK73GB2A101J	CHIP R 100 J 1/10W	
R475,476			RK73GB2A133J	CHIP R 13K J 1/10W	
R477,478			RK73GB2A113J	CHIP R 11K J 1/10W	
R479,480			RK73GB2A103J	CHIP R 10K J 1/10W	
R481,482			RK73GB2A104J	CHIP R 100K J 1/10W	
R483			RK73GB2A103J	CHIP R 10K J 1/10W	
VR1,2			R12-0092-05	TRIMMING POT. (220)	
W301-319			R92-1252-05	CHIP R 0 OHM J 1/16W	
W321-324			R92-1252-05	CHIP R 0 OHM J 1/16W	
W327			R92-1252-05	CHIP R 0 OHM J 1/16W	
W329-332			R92-1252-05	CHIP R 0 OHM J 1/16W	
W334-366			R92-1252-05	CHIP R 0 OHM J 1/16W	
W368-377			R92-1252-05	CHIP R 0 OHM J 1/16W	
W379-396			R92-1252-05	CHIP R 0 OHM J 1/16W	
W398-405			R92-1252-05	CHIP R 0 OHM J 1/16W	
S1			S68-0806-05	PUSH SWITCH	
S2		✻	S79-0843-05	DIP SWITCHES	
D1			UMZ6.8N	ZENER DIODE	
D2		✻	LM1MA142WK-G	DIODE	
D3			LM1MA142WA-G	DIODE	
D51-53		✻	RM4ZLF-J1NF	DIODE	
D55			UDZS4.7B	ZENER DIODE	
D59		✻	S5566B-Q	DIODE	
D60		✻	RD16JS-AZ(B)	ZENER DIODE	
D68		✻	FCH20A20	DIODE	
D69		✻	FRH20A20	DIODE	
D70			UDZS6.8B	ZENER DIODE	
D71			RD15JS-AZ(B)	ZENER DIODE	
D81		✻	LM1MA142WK-G	DIODE	
D103			LM1MA142WA-G	DIODE	
D105,106			RD5.1JS-AZ(B2)	ZENER DIODE	
D107			1SS133	DIODE	
D108			RD5.1JS-AZ(B2)	ZENER DIODE	
D109-118			1SS133	DIODE	
D127-130			1SS133	DIODE	
D131-133			1SS355	DIODE	
D251			1SS133	DIODE	
D257			LM1MA142WA-G	DIODE	
D260			1SS355	DIODE	
D301			LM1MA142WA-G	DIODE	
D302		✻	LM1MA142WK-G	DIODE	
D303			UMZ6.8N	ZENER DIODE	
D304,305			1SS355	DIODE	
D306-308			UMZ6.8N	ZENER DIODE	

E1 : KAC-PS621 **K** : KAC-X621 **M1** : KAC-X621
(**E** : Europe **K** : North America **M** : Other Areas)

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5770-10)

Ref. No.	Add	New	Parts No.	Description	Destination
D309			DA204U	DIODE	
D310			UDZS5.1B	ZENER DIODE	
D311			UMZ6.8N	ZENER DIODE	
D312		✻	UDZS16B	ZENER DIODE	
D313,314			UMZ6.8N	ZENER DIODE	
D315		✻	LM1MA142WK-G	DIODE	
D316			1SS355	DIODE	
D317			DA204U	DIODE	
D341-344			1SS355	DIODE	
D351			UDZS5.1B	ZENER DIODE	
D352			UDZS10B	ZENER DIODE	
D353		✻	UDZS3.3B	ZENER DIODE	
D354			UDZS5.1B	ZENER DIODE	
IC1			BA4560F	IC	
IC2			UPC494GS	ANALOGUE IC	
IC3		✻	P82B96PN	ANALOGUE IC	
IC5			BA10393F	ANALOGUE IC	
IC6		✻	784224YGC117	MICROCONTROLLER IC	
IC7			PST3436UL-E	MOS-IC	
IC9,10			BA4560F	IC	
Q50			2SC4081	TRANSISTOR	
Q51,52			2SC4097	TRANSISTOR	
Q53,54			2SA1577	TRANSISTOR	
Q55-60			IRFIZ48N	FET	
Q61		✻	2SC4883ANF	TRANSISTOR	
Q62		✻	2SA1859ANF	TRANSISTOR	
Q63			2SA1576A	TRANSISTOR	
Q64			2SB1241	TRANSISTOR	
Q65			DTC114EUA	DIGITAL TRANSISTOR	
Q66			2SB1238	TRANSISTOR	
Q68			2SC4081	TRANSISTOR	
Q69			2SA1576A	TRANSISTOR	
Q70,71			2SC4081	TRANSISTOR	
Q81		✻	2SK246(BL)-F	FET	
Q91,92			DTA114EUA	DIGITAL TRANSISTOR	
Q97			2SC4081	TRANSISTOR	
Q101,102			2SC4081	TRANSISTOR	
Q103-110		✻	2SA992-A(F,E)	TRANSISTOR	
Q111,112			2SA1576A	TRANSISTOR	
Q113-116		✻	2SC3478AA(L,K)	TRANSISTOR	
Q117,118		✻	2SA1376AA(L,K)	TRANSISTOR	
Q119,120			2SC3419(Y)	TRANSISTOR	
Q121,122		✻	2SC1845-A(F,E)	TRANSISTOR	
Q123,124		✻	2SA992-A(F,E)	TRANSISTOR	
Q125-128		✻	2SC2235-F	TRANSISTOR	
Q129-132		✻	2SA965-F	TRANSISTOR	
Q133-136		✻	2SC3856NF	TRANSISTOR	
Q137-140		✻	2SA1492NF	TRANSISTOR	
Q141			DTA124EUA	DIGITAL TRANSISTOR	
Q142		✻	2SA992-A(F,E)	TRANSISTOR	
Q143		✻	2SC1845-A(F,E)	TRANSISTOR	
Q144			2SC4081	TRANSISTOR	
Q145			2SA1576A	TRANSISTOR	
Q146		✻	2SC1845-A(F,E)	TRANSISTOR	
Q147			2SA1576A	TRANSISTOR	

Ref. No.	Add	New	Parts No.	Description	Destination
Q148,149			2SC4081	TRANSISTOR	
Q249,250			2SC4081	TRANSISTOR	
Q263			DTA124EUA	DIGITAL TRANSISTOR	
Q301			2SC4081	TRANSISTOR	
Q302,303			2SA1576A	TRANSISTOR	
Q304			2SC4081	TRANSISTOR	
Q305,306			2SA1576A	TRANSISTOR	
Q307			DTC114EUA	DIGITAL TRANSISTOR	
Q310			DTA114EUA	DIGITAL TRANSISTOR	
Q313			DTC114EUA	DIGITAL TRANSISTOR	
Q341-344			2SC4081	TRANSISTOR	
Q346			DTC114EUA	DIGITAL TRANSISTOR	
Q347			DTA114EUA	DIGITAL TRANSISTOR	
Q348			DTC114EUA	DIGITAL TRANSISTOR	
Q349			DTA114EUA	DIGITAL TRANSISTOR	
Q351			DTA114EUA	DIGITAL TRANSISTOR	
Q352,353			DTC114EUA	DIGITAL TRANSISTOR	
Q354			DTA114EUA	DIGITAL TRANSISTOR	
Q355			DTC114EUA	DIGITAL TRANSISTOR	
Q356			2SD1863	TRANSISTOR	
Q357			2SC4081	TRANSISTOR	
Q358			2SD1863	TRANSISTOR	
Q403,404		✻	2SC945AA(Q,P)	TRANSISTOR	
Q601,602			IRFIZ48N	FET	
TH1		✻	NT732ATTD103J	THERMISTOR	
TH3,4		✻	NT732ATTD103J	THERMISTOR	

E1 : KAC-PS621 **K** : KAC-X621 **M1** : KAC-X621
(**E** : Europe **K** : North America **M** : Other Areas)

⚠ Indicates safety critical components.