# TK-5820

## PARTS LIST

✻ New Parts. ⚠indicates safety critical components.
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

**L** : Scandinavia **K** : USA **P** : Canada
**Y** : PX (Far East, Hawaii) **T** : England **E** : Europe
**C** : China **X** : Australia **M** : Other Areas

**TK-5820**
**DISPLAY UNIT (X54-3680-10)**

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| | | | **TK-5820** | | |
| 1 | 1B | | A01-2194-11 | METALLIC CABINET | |
| 2 | 3A | | A62-1154-02 | PANEL ASSY | |
| 4 | 2A | | B09-0681-03 | CAP | |
| 5 | 3B | | B11-1850-04 | FILTER | |
| 6 | 3B | | B38-0922-05 | LCD ASSY | |
| 7 | 3A | ✻ | B43-1635-04 | BADGE (P25) | |
| 8 | 1D | ✻ | B62-2206-00 | INSTRUCTION MANUAL | |
| 10 | 2B | | E04-0167-15 | RF COAXIAL RECEPTACLE (M) | |
| 11 | 2B | | E30-7520-25 | DC CORD | |
| 12 | 2C | | E30-7523-55 | DC CORD ASSY ACCESSORY | |
| 13 | 1A | | E37-1118-05 | LEAD WIRE WITH CONNECTOR (SHORT CABLE) | |
| 14 | 3B | | E37-1124-05 | LEAD WIRE WITH CONNECTOR (2P/SP) | |
| 15 | 2A | | E37-1448-05 | FLAT CABLE (30P/D-SUB) | |
| 16 | 2A | | E37-1449-05 | FLAT CABLE (30P/PANEL) | |
| 18 | 2B | | F10-2488-12 | SHIELDING PLATE (CHASSIS) | |
| 19 | 1A | | F10-2489-13 | SHIELDING CASE (FINAL) | K |
| 20 | 1A | | F10-2490-13 | SHIELDING CASE (VCO) | |
| 19 | 1A | | F10-3032-14 | SHIELDING CASE (FINAL) | K2 |
| 21 | 2C | | F52-0024-05 | FUSE (BLADE TYPE) 15A/32V ACCESSORY | |
| 24 | 3B | | G10-1342-04 | FIBROUS SHEET (BIRITSUKI) | |
| 25 | 3B | | G10-1802-04 | FIBROUS SHEET (LCD) | |
| 26 | 1B | | G11-4343-04 | SHEET (STEP) | |
| 27 | 1A | | G13-2018-04 | CUSHION (FINAL) | |
| 28 | 2B | | G13-2047-04 | CUSHION (DC SCREW) | |
| 29 | 2B | | G13-2279-04 | CUSHION (PLATE-FFC) | |
| 30 | 1B | | G53-1613-11 | PACKING (SHIELD PLATE) | |
| 31 | 1A | | G53-1616-03 | PACKING (PHONE JACK) | |
| 32 | 2B | | G53-1626-03 | PACKING (D-SUB OUTER) | |
| 33 | 2B | | G53-1643-04 | PACKING (DC CORD) | |
| 34 | 2A | | G53-1645-03 | PACKING (D-SUB INNER) | |
| 35 | 2A | | G53-1662-04 | PACKING (ANT) | |
| 36 | 3A | | G53-1676-03 | PACKING | |
| 38 | 3C | ✻ | H02-0624-13 | INNER CARTON CASE | |
| 39 | 2D | ✻ | H12-4274-03 | PACKING FIXTURE (UPPER) | |
| 40 | 2D | ✻ | H12-4275-02 | PACKING FIXTURE (LOWER) | |
| 41 | 3D | ✻ | H52-2200-02 | ITEM CARTON CASE | |
| 44 | 2C | | J19-1584-15 | HOLDER (MIC) ACCESSORY | |
| 45 | 3B | | J19-5464-13 | HOLDER (SP) | |
| 46 | 3B | | J19-5485-12 | HOLDER (PANEL) | |
| 47 | 3B | | J19-5502-03 | HOLDER (LCD) | |
| 48 | 2B | | J21-8479-02 | MOUNTING HARDWARE (D-SUB) | |
| 49 | 3B | | J21-8481-03 | MOUNTING HARDWARE (SP) | |
| 50 | 3B | | J21-8569-03 | MOUNTING HARDWARE (LCD) | |
| 51 | 2C | | J29-0726-03 | BRACKET ACCESSORY | |
| 52 | 3B | | J30-1289-04 | SPACER (SP SHEET) | |
| 54 | 3A | | K29-9401-03 | KEY TOP | |
| A | 2B | | N09-2292-05 | HEXAGON HEAD SCREW | |
| B | 1A,2A | | N67-3008-48 | PAN HEAD SEMS SCREW | |
| C | 1A,2B | | N87-2606-43 | BRAZIER HEAD TAPTITE SCREW | |
| D | 1A,2A,2B | | N87-2608-48 | BRAZIER HEAD TAPTITE SCREW | |
| 56 | 2C | | N99-2039-05 | SCREW SET ACCESSORY | |

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| 58 | 3B | | T07-0757-15 | SPEAKER | |
| 59 | 1C | | T91-0639-55 | MICROPHONE ACCESSORY | |
| | | | **DISPLAY UNIT (X54-3680-10)** | | |
| D914 | | | B30-2304-05 | LED (RED/GREEN) | |
| D915-926 | | | B30-2281-05 | LED (Y) | |
| D927-936 | | | B30-2282-05 | LED (Y) | |
| C903 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C905 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C906 | | | CK73HB1H222K | CHIP C 2200PF K | |
| C907-909 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C910-912 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C913 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C914 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C915 | | | CK73FB1E475K | CHIP C 4.7UF K | |
| C916 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C917,918 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C919 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C920 | | | CC73HCH1H121J | CHIP C 120PF J | |
| C921 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C922-925 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C926-929 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C930 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C931,932 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C933 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C934 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C935 | | | CS77BA1E4R7M | CHIP TNTL 4.7UF 25WV | |
| C936 | | | CC73HCH1H100D | CHIP C 10PF D | |
| C938 | | | CC73HCH1H100D | CHIP C 10PF D | |
| C939 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| C940 | | | CK73FB1A106K | CHIP C 10UF K | |
| C941,942 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C943,944 | | | CS77BA1E4R7M | CHIP TNTL 4.7UF 25WV | |
| C945 | | | CK73GB1H103K | CHIP C 0.010UF K | |
| C946 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C947 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C948 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C949-954 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C955 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C956,957 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C958 | | | CK73HB1H102K | CHIP C 1000PF K | |
| C959,960 | | | CK73HB1E103K | CHIP C 0.010UF K | |
| C961 | | | CK73HB0J105K | CHIP C 1.0UF K | |
| C962 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C963 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C964 | | | CK73GB1E105K | CHIP C 1.0UF K | |
| C965 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C966,967 | | | CK73HB1H102K | CHIP C 1000PF K | |
| CN901 | | | E40-6559-05 | FLAT CABLE CONNECTOR | |
| CN902 | | | E41-2671-05 | PIN ASSY | |
| CN905 | | | E40-6557-05 | FLAT CABLE CONNECTOR | |
| J901 | | | E58-0522-05 | MODULAR JACK | |

# PARTS LIST

**DISPLAY UNIT (X54-3680-10)**
**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| - | | | J31-0551-05 | COLLAR | |
| L901,902 | | | L41-1095-39 | SMALL FIXED INDUCTOR (1.0UH) | |
| L903-905 | | | L92-0140-05 | CHIP FERRITE | |
| L906 | | | L92-0163-05 | BEADS CORE | |
| L907 | | | L92-0140-05 | CHIP FERRITE | |
| L908 | | | L92-0163-05 | BEADS CORE | |
| X901 | | | L77-1950-05 | CRYSTAL RESONATOR (11.0592MHZ) | |
| CP907,908 | | | RK75HA1JR00J | CHIP-COM 0.00 J 1/16W | |
| CP909 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | |
| CP910 | | | RK74HA1J101J | CHIP-COM 100 J 1/16W | |
| CP912 | | | RK74HA1J101J | CHIP-COM 100 J 1/16W | |
| CP917 | | | RK74HA1J104J | CHIP-COM 100K J 1/16W | |
| R900 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R901 | | | RK73GB2A000J | CHIP R 0.0 J 1/10W | |
| R902 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R904 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R905 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R906 | | | RK73HB1J331J | CHIP R 330 J 1/16W | |
| R907 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R908 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R909 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R911 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R912 | | | RK73HB1J333J | CHIP R 33K J 1/16W | |
| R913 | | | RK73HB1J823J | CHIP R 82K J 1/16W | |
| R914 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R915 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R916,917 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R918 | | | RK73GB2A100J | CHIP R 10 J 1/10W | |
| R919 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R920,921 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R922-925 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R926 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R927 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R928 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R929 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R930 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R931 | | | RK73FB2B561J | CHIP R 560 J 1/8W | |
| R932 | | | RK73FB2B471J | CHIP R 470 J 1/8W | |
| R933 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R934-937 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R938,939 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R940 | | | RK73HB1J274J | CHIP R 270K J 1/16W | |
| R941 | | | RK73HB1J124J | CHIP R 120K J 1/16W | |
| R942 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R943 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R944 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R945,946 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R947 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R948 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R949 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R950 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R952 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R953 | | | RK73GB2A271J | CHIP R 270 J 1/10W | |
| R954 | | | RK73GB2A470J | CHIP R 47 J 1/10W | |
| R955 | | | RK73GB2A271J | CHIP R 270 J 1/10W | |
| R956 | | | RK73GB2A101J | CHIP R 100 J 1/10W | |
| R957,958 | | | RK73GB2A271J | CHIP R 270 J 1/10W | |
| R960 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R962 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R963,964 | | | RK73GB2A391J | CHIP R 390 J 1/10W | |
| R965,966 | | | RK73GB2A821J | CHIP R 820 J 1/10W | |
| R967-974 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R976 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R977-979 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R981,982 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R986 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R988 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R989 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R990 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R991 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R992 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R996 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R997 | | | RK73GB2A000J | CHIP R 0.0 J 1/10W | |
| R998 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R999 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| D901,902 | | | AVRM16080MAAB | VARISTOR | |
| D903 | | | 02DZ18F-X | ZENER DIODE | |
| D904 | | | AVRM16080MAAB | VARISTOR | |
| D906 | | | MINISMDC020F | VARISTOR | |
| D907 | | | 02DZ18F-X | ZENER DIODE | |
| D908 | | | HSC119 | DIODE | |
| D910 | | | 1SS416 | DIODE | |
| D911,912 | | | HSC119 | DIODE | |
| D913 | | | DA204U | DIODE | |
| D937 | | | 1SS416 | DIODE | |
| IC901 | | | TC7W66FK-F | MOS-IC | |
| IC902 | | | TC75S51FE(F) | MOS-IC | |
| IC903 | | | XC6209B502PR | MOS-IC | |
| IC904 | | | XC6204B332M | MOS-IC | |
| IC905 | | | TC7SH126FU-F | MOS-IC | |
| IC906 | | | LM2682MMX | MOS-IC | |
| IC907 | | | TC7WH126FU-F | MOS-IC | |
| IC908 | | | TC7SH08FU-F | MOS-IC | |
| IC909 | | | LMC7101BIM5 | MOS-IC | |
| IC910 | | | TC74LCX245FK | MOS-IC | |
| IC911 | | | 30620SPGPU3C | MICROPROCESSOR IC | |
| IC912 | | | TC7WZ245FK-F | MOS-IC | |
| IC913 | | | 29AL16D7KCCB | ROM IC | |
| Q901 | | | SSM3K15TE(F) | FET | |
| Q902 | | | DTC144EE | DIGITAL TRANSISTOR | |
| Q904 | | | DTC144EE | DIGITAL TRANSISTOR | |
| Q905,906 | | | DTC114EE | DIGITAL TRANSISTOR | |
| Q908,909 | | | DTC114EE | DIGITAL TRANSISTOR | |
| Q910 | | | 12A02CH | TRANSISTOR | |
| Q911 | | | SSM3K15TE(F) | FET | |
| Q913 | | | UPA672T-A | FET | |
| TH901 | | | ERTJ0EV104H | THERMISTOR | |

## TX-RX UNIT (X57-7910-XX) -10 : K -11 : K2

| | | | | | |
|---|---|---|---|---|---|
| C1 | | | CK73HB0J105K | CHIP C 1.0UF K | |
| C2 | | | CC73HCH1H101J | CHIP C 100PF J | |
| C3 | | | CK73HB1H471K | CHIP C 470PF K | |
| C4 | | | CK73HB1A104K | CHIP C 0.10UF K | |
| C5 | | | CK73HB1E103K | CHIP C 0.010UF K | |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C6 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C7 | | | CC73HCH1H180J | CHIP C | 18PF | J | |
| C8 | | | CC73HCH1H080B | CHIP C | 8.0PF | B | K |
| C8 | | | CC73HCH1H100B | CHIP C | 10PF | B | K2 |
| C9 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C10 | | | CC73HCH1H390J | CHIP C | 39PF | J | |
| C11 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C12 | | | CC73HCH1H080B | CHIP C | 8.0PF | B | K |
| C12 | | | CC73HCH1H120G | CHIP C | 12PF | G | K2 |
| C13 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C14 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C15 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C16,17 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C18-23 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C24 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C25,26 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C27 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C28,29 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C31 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C32 | | | CS77CA1VR15M | CHIP TNTL | 0.15UF | 35WV | |
| C33 | | | CC73HCH1H330J | CHIP C | 33PF | J | |
| C34 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C35 | | | CS77BA1D100M | CHIP TNTL | 10UF | 20WV | |
| C36 | | | CC73HCH1H050B | CHIP C | 5.0PF | B | K |
| C36 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | K2 |
| C37 | | | C92-0863-05 | CHIP TNTL | 0.047UF | 35WV | |
| C38 | | | C93-0787-05 | CERAMIC | 0.1UF | 50WV | |
| C39 | | | CC73HCH1H030B | CHIP C | 3.0PF | B | |
| C41 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C43 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C44,45 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C46 | | | CC73HCH1H050B | CHIP C | 5.0PF | B | K |
| C46 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | K2 |
| C47 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C48 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C49 | | | CC73HCH1H100B | CHIP C | 10PF | B | K |
| C49 | | | CC73HCH1H150G | CHIP C | 15PF | G | K2 |
| C50,51 | | | CC73HCH1H151J | CHIP C | 150PF | J | |
| C52,53 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C54 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C55 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C56 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C58 | | | CC73HCH1H120G | CHIP C | 12PF | G | K |
| C58 | | | CC73HCH1H180G | CHIP C | 18PF | G | K2 |
| C59 | | | CC73HCH1H150G | CHIP C | 15PF | G | K |
| C59 | | | CC73HCH1H200G | CHIP C | 20PF | G | K2 |
| C60 | | | CC73HCH1HR75B | CHIP C | 0.75PF | B | K |
| C61 | | | CC73HCH1H0R5B | CHIP C | 0.5PF | B | K |
| C63 | | | CC73HCH1HR75B | CHIP C | 0.75PF | B | |
| C64 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | |
| C65 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C66 | | | CC73HCH1H060B | CHIP C | 6.0PF | B | K2 |
| C66,67 | | | CC73HCH1H060B | CHIP C | 6.0PF | B | K |
| C67-69 | | | CC73HCH1H050B | CHIP C | 5.0PF | B | K2 |
| C68 | | | CC73HCH1H040B | CHIP C | 4.0PF | B | K |
| C69 | | | CC73HCH1H050B | CHIP C | 5.0PF | B | K |
| C70 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C71 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C72 | | | CC73HCH1H030B | CHIP C | 3.0PF | B | K |
| C72 | | | CC73HCH1H040B | CHIP C | 4.0PF | B | K2 |

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C73 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C74 | | | CC73HCH1H0R5B | CHIP C | 0.5PF | B | |
| C75 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C76 | | | CC73HCH1H0R5B | CHIP C | 0.5PF | B | |
| C77,78 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C79 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | |
| C80 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C81 | | | CC73HCH1H100B | CHIP C | 10PF | B | |
| C82 | | | CC73HCH1H330J | CHIP C | 33PF | J | |
| C83,84 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C85 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C86 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | |
| C88 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C90-92 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C98 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C101 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C102 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C103 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C104-107 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C108 | | | CK73FB1E475K | CHIP C | 4.7UF | K | |
| C109 | | | CC73HCH1H060D | CHIP C | 6.0PF | D | |
| C110-112 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C115-117 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C118 | | | CC73HCH1H060D | CHIP C | 6.0PF | D | |
| C120 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C123 | | | CC73HCH1H220J | CHIP C | 22PF | J | |
| C125 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C127 | | | CK73HB1H471K | CHIP C | 470PF | K | K |
| C128 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C131 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C132 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C133 | | | CC73HCH1H220J | CHIP C | 22PF | J | |
| C134 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C135 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C136 | | | CK73FB1H471K | CHIP C | 470PF | K | |
| C138 | | | CS77CA1A6R8M | CHIP TNTL | 6.8UF | 10WV | |
| C141 | | | CC73HCH1H220J | CHIP C | 22PF | J | |
| C142 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C145 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C147 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C150 | | | C92-0875-05 | ELECTRO | 47UF | 25WV | |
| C152,153 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C155,156 | | | CC73HCH1H220J | CHIP C | 22PF | J | |
| C157 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C158 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C162 | | | CC73FCH1H020C | CHIP C | 2.0PF | C | K |
| C162 | | | CC73FCH1H050B | CHIP C | 5.0PF | B | K2 |
| C164 | | | CC73GCH1H0R5B | CHIP C | 0.5PF | B | |
| C165 | | | CC73GCH1H030B | CHIP C | 3.0PF | B | |
| C166 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C169 | | | CC73HCH1H101J | CHIP C | 100PF | J | K2 |
| C170 | | | CC73GCH1H0R5B | CHIP C | 0.5PF | B | |
| C171 | | | CC73GCH1H020B | CHIP C | 2.0PF | B | K |
| C171 | | | CC73GCH1H030B | CHIP C | 3.0PF | B | K2 |
| C172 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C174 | | | C93-0552-05 | CHIP C | 2.0PF | C | K |
| C174 | | | C93-0553-05 | CHIP C | 3.0PF | C | K2 |
| C175 | | | CC73HCH1H101J | CHIP C | 100PF | J | K2 |
| C178 | | | CC73GCH1H0R5B | CHIP C | 0.5PF | B | |
| C179 | | | CC73GCH1H010B | CHIP C | 1.0PF | B | K2 |

# PARTS LIST

TX-RX UNIT (X57-7910-XX)

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C179 | | | CC73GCH1H020B | CHIP C | 2.0PF | B | K |
| C180 | | | CC73HCH1H101J | CHIP C | 100PF | J | K |
| C180,181 | | | CC73HCH1H101J | CHIP C | 100PF | J | K2 |
| C185 | | | CM73F2H040C | CHIP C | 4.0PF | C | K |
| C185 | | | CM73F2H060D | CHIP C | 6.0PF | D | K2 |
| C186 | | | CM73F2H121J | CHIP C | 120PF | J | |
| C187 | | | CM73F2H040C | CHIP C | 4.0PF | C | K2 |
| C187 | | | CM73F2H050C | CHIP C | 5.0PF | C | K |
| C188 | | | CM73F2H080D | CHIP C | 8.0PF | D | K |
| C188 | | | CM73F2H090D | CHIP C | 9.0PF | D | K2 |
| C189 | | | CM73F2H090D | CHIP C | 9.0PF | D | K |
| C189 | | | CM73F2H120J | CHIP C | 12PF | J | K2 |
| C190 | | | CM73F2H030C | CHIP C | 3.0PF | C | K |
| C190 | | | CM73F2H060D | CHIP C | 6.0PF | D | K2 |
| C193,194 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C201 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C202-205 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C206 | | | CC73HCH1H100B | CHIP C | 10PF | B | |
| C207,208 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C210 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C211 | | | CC73HCH1H100B | CHIP C | 10PF | B | |
| C212,213 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C214 | | | CC73HCH1H680J | CHIP C | 68PF | J | |
| C215 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C216 | | | CC73HCH1H680J | CHIP C | 68PF | J | |
| C217 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C218,219 | | | CK73GB0J475K | CHIP C | 4.7UF | K | |
| C220 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C221 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C222-224 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C225 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C226 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C227 | | | CC73HCH1H820J | CHIP C | 82PF | J | |
| C228-230 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C231 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C232 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C233 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C234 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C236 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C237 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C238-240 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C242 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C243 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C244 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C245 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C246 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C247 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C252 | | | CC73HCH1H010B | CHIP C | 1.0PF | B | |
| C256 | | | CC73HCH1H010B | CHIP C | 1.0PF | B | |
| C257 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C260 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C261 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C262 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C263,264 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C265 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C266 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C267 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | |
| C268 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C269,270 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C271 | | | CC73HCH1H100B | CHIP C | 10PF | B | |
| C272 | | | CC73HCH1H020B | CHIP C | 2.0PF | B | |
| C273 | | | CC73HCH1H120G | CHIP C | 12PF | G | |
| C275 | | | CC73HCH1H010B | CHIP C | 1.0PF | B | K |
| C275 | | | CC73HCH1H020B | CHIP C | 2.0PF | B | K2 |
| C276 | | | CC73HCH1H060B | CHIP C | 6.0PF | B | |
| C278-281 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C283 | | | CC73HCH1H080B | CHIP C | 8.0PF | B | K |
| C283 | | | CC73HCH1H090B | CHIP C | 9.0PF | B | K2 |
| C284 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C285 | | | CC73HCH1H220G | CHIP C | 22PF | G | K |
| C285 | | | CC73HCH1H330G | CHIP C | 33PF | G | K2 |
| C286 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | |
| C287 | | | CC73HCH1H050B | CHIP C | 5.0PF | B | |
| C288 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C289 | | | CK73GB1H104K | CHIP C | 0.10UF | K | |
| C290 | | | CC73HCH1H180G | CHIP C | 18PF | G | K |
| C290 | | | CC73HCH1H330G | CHIP C | 33PF | G | K2 |
| C291 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | K |
| C291 | | | CC73HCH1H100B | CHIP C | 10PF | B | K2 |
| C292 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C293 | | | CC73HCH1H100B | CHIP C | 10PF | B | |
| C294 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C295 | | | CC73HCH1H180G | CHIP C | 18PF | G | K |
| C295 | | | CC73HCH1H330G | CHIP C | 33PF | G | K2 |
| C296 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | K2 |
| C296,297 | | | CC73HCH1H070B | CHIP C | 7.0PF | B | K |
| C297 | | | CC73HCH1H090B | CHIP C | 9.0PF | B | K2 |
| C298 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C299 | | | CC73HCH1H220G | CHIP C | 22PF | G | K |
| C299 | | | CC73HCH1H330G | CHIP C | 33PF | G | K2 |
| C301 | | | CC73HCH1H060B | CHIP C | 6.0PF | B | K2 |
| C301 | | | CC73HCH1H100B | CHIP C | 10PF | B | K |
| C302 | | | CK73GB1H104K | CHIP C | 0.10UF | K | |
| C307,308 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C310 | | | CC73HCH1H330G | CHIP C | 33PF | G | |
| C315 | | | CC73HCH1H050B | CHIP C | 5.0PF | B | K |
| C315 | | | CC73HCH1H100B | CHIP C | 10PF | B | K2 |
| C316 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C317 | | | CC73HCH1H100B | CHIP C | 10PF | B | K |
| C317 | | | CC73HCH1H220G | CHIP C | 22PF | G | K2 |
| C318 | | | CC73HCH1H040B | CHIP C | 4.0PF | B | K2 |
| C318,319 | | | CC73HCH1H020B | CHIP C | 2.0PF | B | K |
| C319 | | | CC73HCH1H030B | CHIP C | 3.0PF | B | K2 |
| C320 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C321 | | | CC73HCH1H040B | CHIP C | 4.0PF | B | |
| C322 | | | CC73HCH1H080B | CHIP C | 8.0PF | B | K |
| C322 | | | CC73HCH1H180G | CHIP C | 18PF | G | K2 |
| C323 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C324 | | | CC73HCH1H120G | CHIP C | 12PF | G | K |
| C324 | | | CC73HCH1H150G | CHIP C | 15PF | G | K2 |
| C325 | | | CC73HCH1H040B | CHIP C | 4.0PF | B | |
| C327 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C330-334 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C335 | | | CC73HCH1H120G | CHIP C | 12PF | G | |
| C336 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C337,338 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C339 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C341 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C342 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C343 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C344 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C347 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C348 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C358 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C361 | | | CC73HCH1H101J | CHIP C | 100PF | J | K2 |
| C364-366 | | | CK73HB1H102K | CHIP C | 1000PF | K | K2 |
| C401 | | | C92-0777-05 | ELECTRO | 1000UF | 25WV | |
| C403 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C405 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C406 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C409 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C410 | | | CK73GB1H103K | CHIP C | 0.010UF | K | |
| C411 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C413 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C415 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C417 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C419 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C420 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C421 | | | CK73GB1H473K | CHIP C | 0.047UF | K | |
| C422 | | | CK73FB1E475K | CHIP C | 4.7UF | K | |
| C424 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C425 | | | CK73GB1H104K | CHIP C | 0.10UF | K | |
| C426 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C427 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C428 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C429 | | | CK73GB1H104K | CHIP C | 0.10UF | K | |
| C430,431 | | | CK73FB1E475K | CHIP C | 4.7UF | K | |
| C432 | | | C92-0875-05 | ELECTRO | 47UF | 25WV | |
| C433 | | | CK73GB1H104K | CHIP C | 0.10UF | K | |
| C434 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C435 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C436 | | | CS77BA1A100M | CHIP TNTL | 10UF | 10WV | |
| C437 | | | CK73HB1A224K | CHIP C | 0.22UF | K | |
| C438 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C439 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C440 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C441,442 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C443,444 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C445 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C446 | | | C92-0765-05 | CHIP TNTL | 4.7UF | 16WV | |
| C447 | | | CK73HB1A224K | CHIP C | 0.22UF | K | |
| C448 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C449 | | | CK73GB1C225K | CHIP C | 2.2UF | K | |
| C450 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C451 | | | CK73GB1C225K | CHIP C | 2.2UF | K | |
| C452 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C453 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C454 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C455,456 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C457,458 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C459 | | | C92-0765-05 | CHIP TNTL | 4.7UF | 16WV | |
| C460 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C461 | | | CC73HCH1H181J | CHIP C | 180PF | J | |
| C462 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C463 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C464 | | | CC73HCH1H220J | CHIP C | 22PF | J | |
| C465-467 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C468 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C471 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C473 | | | CS77BA1E4R7M | CHIP TNTL | 4.7UF | 25WV | |

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C474 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C475 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C476 | | | CK73HB1H102K | CHIP C | 1000PF | K | K2 |
| C477 | | | CC73HCH1H101J | CHIP C | 100PF | J | K2 |
| C478-483 | | | CK73HB1H102K | CHIP C | 1000PF | K | K2 |
| C501,502 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C503-507 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C508 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C509 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C511-514 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C515 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C516,517 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C518 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C520-523 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C527 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C528 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C529,530 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C531 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C532 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C533 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C534 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C535 | | | CS77CP0J100M | CHIP TNTL | 10UF | 6.3WV | |
| C536 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C537,538 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C539 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C540 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C541 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C542 | | | CS77CP0J100M | CHIP TNTL | 10UF | 6.3WV | |
| C543-546 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C547-550 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C551 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C552 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C553 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C554-558 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C559 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C560 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C561-563 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C565,566 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C567 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C568-578 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C579 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C580 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C581-583 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C584,585 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C586 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C587-589 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C590,591 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C592,593 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C594,595 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C596 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C597-607 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C608 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C609 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C610 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C611 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C612 | | | CK73GB1H103K | CHIP C | 0.010UF | K | |
| C613-616 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C618 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C620,621 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C622 | | | CK73HB1H102K | CHIP C | 1000PF | K | K2 |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C623-629 | | | CK73HB1E103K | CHIP C | 0.010UF | K | K2 |
| C630 | | | CK73GB1H104K | CHIP C | 0.10UF | K | |
| C701 | | | CK73GB0J335K | CHIP C | 3.3UF | K | |
| C702 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C705 | | | CK73HB1H122K | CHIP C | 1200PF | K | |
| C706 | | | CK73HB1H331K | CHIP C | 330PF | K | |
| C707 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C708 | | | CK73HB1H122K | CHIP C | 1200PF | K | |
| C709 | | | CC73HCH1H221J | CHIP C | 220PF | J | |
| C710 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C711 | | | CC73HCH1H181J | CHIP C | 180PF | J | |
| C712 | | | CC73HCH1H680J | CHIP C | 68PF | J | |
| C714 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C715 | | | CK73HB1H122K | CHIP C | 1200PF | K | |
| C716 | | | CC73HCH1H221J | CHIP C | 220PF | J | |
| C717 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C718 | | | CC73HCH1H221J | CHIP C | 220PF | J | |
| C719,720 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C721 | | | CC73HCH1H221J | CHIP C | 220PF | J | |
| C722 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C723,724 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C725 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C726 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C727 | | | CC73HCH1H820J | CHIP C | 82PF | J | |
| C729 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C730 | | | CK73HB1H561K | CHIP C | 560PF | K | |
| C731 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C732 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C734 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C735 | | | CK73FB1E475K | CHIP C | 4.7UF | K | |
| C736 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C737 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C738 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C740 | | | CK73HB1H472K | CHIP C | 4700PF | K | |
| C741 | | | CK73HB1A154K | CHIP C | 0.15UF | K | |
| C742 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C743 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C744 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C745-747 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C748-751 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C752,753 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C754 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C757 | | | CC73HCH1H150J | CHIP C | 15PF | J | |
| C761 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C762,763 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C764 | | | CC73HCH1H220J | CHIP C | 22PF | J | |
| C765,766 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C767 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C768,769 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C770 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C773 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C774 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C775 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C776 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C777 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C778 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C779 | | | CC73HCH1H680J | CHIP C | 68PF | J | |
| C782-786 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C787 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C788 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |

| Ref. No. | Address | New parts | Parts No. | Description | | | Destination |
|---|---|---|---|---|---|---|---|
| C789 | | | CK73FB1E475K | CHIP C | 4.7UF | K | |
| C790 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C791 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C792 | | | CC73HCH1H470J | CHIP C | 47PF | J | |
| C793 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C794,795 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C796-799 | | | CK73HB1A104K | CHIP C | 0.10UF | K | |
| C801,802 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C803-805 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C806 | | | C92-0906-05 | ELECTRO | 330UF | 16WV | |
| C807 | | | C92-0875-05 | ELECTRO | 47UF | 25WV | |
| C809 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C810 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C811 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C813 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C814 | | | CK73HB1H471K | CHIP C | 470PF | K | |
| C815,816 | | | CK73FB1A106K | CHIP C | 10UF | K | |
| C817 | | | CK73HB1E103K | CHIP C | 0.010UF | K | |
| C818 | | | CK73HB0J105K | CHIP C | 1.0UF | K | |
| C820 | | | CK73GB1E105K | CHIP C | 1.0UF | K | |
| C821 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C824 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C825 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C826 | | | CK73HB1H102K | CHIP C | 1000PF | K | K2 |
| C828 | | | CC73HCH1H101J | CHIP C | 100PF | J | K2 |
| C901 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C902 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C903-906 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C907 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| C908-921 | | | CC73HCH1H101J | CHIP C | 100PF | J | |
| C922,923 | | | CK73HB1H102K | CHIP C | 1000PF | K | |
| CN401,402 | | | E23-1260-04 | TERMINAL | | | |
| CN403 | | | E41-1682-05 | PIN ASSY | | | |
| CN502-513 | | | E23-1278-05 | TERMINAL | | | |
| CN516,517 | | | E23-1278-05 | TERMINAL | | | |
| CN520 | | | E23-1278-05 | TERMINAL | | | |
| CN527 | | | E23-1278-05 | TERMINAL | | | |
| CN540 | | | E23-1278-05 | TERMINAL | | | |
| CN542,543 | | | E23-1278-05 | TERMINAL | | | |
| CN549 | | | E40-6720-05 | SOCKET FOR PIN ASSY | | | |
| CN595 | | | E40-6361-05 | PIN ASSY | | | |
| CN597 | | | E40-6558-05 | FLAT CABLE CONNECTOR | | | |
| CN600 | | | E40-6560-05 | FLAT CABLE CONNECTOR | | | |
| CN611,612 | | | E23-1278-05 | TERMINAL | | | |
| CN614 | | | E23-1278-05 | TERMINAL | | | |
| CN705 | | | E40-6582-05 | PIN ASSY | | | |
| CN901 | | | E40-6560-05 | FLAT CABLE CONNECTOR | | | |
| J701 | | | E11-0425-05 | 3.5D PHONE JACK (3P) | | | |
| J901 | | | E58-0521-05 | SUB SOCKET (D) | | | |
| F401 | | | F53-0328-05 | FUSE (5A) | | | |
| F501 | | | F53-0352-05 | FUSE (2A) | | | |
| CN405 | | | J19-5386-05 | HOLDER | | | |
| CD201 | | | L79-1850-05 | TUNING COIL (450KHZ) | | | |
| CF201 | | | L72-1017-05 | CERAMIC FILTER (450KHZ) | | | |
| CF202 | | | L72-1021-05 | CERAMIC FILTER (450KHZ) | | | |
| CF203 | | | L72-1020-05 | CERAMIC FILTER (450KHZ) | | | |
| L1 | | | L41-4795-39 | SMALL FIXED INDUCTOR (4.7U) | | | |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| L3 | | | L92-0163-05 | BEADS CORE | |
| L4 | | | L40-1275-92 | SMALL FIXED INDUCTOR (12NH) | |
| L6,7 | | | L40-1001-86 | SMALL FIXED INDUCTOR (10UH) | |
| L10 | | | L40-1878-92 | SMALL FIXED INDUCTOR (18NH) | |
| L11 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | K |
| L11-16 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | K2 |
| L12 | | | L40-1885-92 | SMALL FIXED INDUCTOR (180NH) | K |
| L13 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | K |
| L14 | | | L40-1885-92 | SMALL FIXED INDUCTOR (180NH) | K |
| L15 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | K |
| L16 | | | L40-1885-92 | SMALL FIXED INDUCTOR (180NH) | K |
| L17 | | | L34-4607-15 | AIR-CORE COIL | K |
| L17 | | | L34-4608-15 | AIR-CORE COIL | K2 |
| L18 | | | L34-4608-15 | AIR-CORE COIL | K |
| L18 | | | L34-4609-15 | AIR-CORE COIL | K2 |
| L19 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | |
| L20 | | | L92-0446-05 | BEADS CORE | |
| L21 | | | L40-1885-92 | SMALL FIXED INDUCTOR (180NH) | K |
| L21-23 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | K2 |
| L22 | | | L40-2285-92 | SMALL FIXED INDUCTOR (220NH) | K |
| L23 | | | L40-1885-92 | SMALL FIXED INDUCTOR (180NH) | K |
| L25 | | | L40-2775-71 | SMALL FIXED INDUCTOR (27NH) | |
| L26 | | | L40-2275-92 | SMALL FIXED INDUCTOR (22NH) | K |
| L26 | | | L40-3375-92 | SMALL FIXED INDUCTOR (33NH) | K2 |
| L31-36 | | | L92-0163-05 | BEADS CORE | |
| L40,41 | | | L92-0163-05 | BEADS CORE | |
| L101 | | | L40-1875-92 | SMALL FIXED INDUCTOR (18NH) | |
| L102 | | | L92-0140-05 | CHIP FERRITE | |
| L103 | | | L40-2275-92 | SMALL FIXED INDUCTOR (22NH) | |
| L106 | | | L92-0140-05 | CHIP FERRITE | |
| L107-109 | | | L92-0179-05 | CHIP FERRITE | |
| L110 | | | L34-4638-05 | AIR-CORE COIL | |
| L111 | | | L34-4758-05 | AIR-CORE COIL | |
| L112-114 | | | L34-4743-05 | AIR-CORE COIL | |
| L115 | | | L34-4848-05 | AIR-CORE COIL | |
| L201 | | | L40-1085-71 | SMALL FIXED INDUCTOR (100NH) | |
| L202 | | | L40-5681-86 | SMALL FIXED INDUCTOR (0.56UH) | |
| L204 | | | L41-4778-45 | SMALL FIXED INDUCTOR (47NH) | |
| L205 | | | L40-5681-86 | SMALL FIXED INDUCTOR (0.56UH) | |
| L206 | | | L92-0138-05 | CHIP FERRITE | |
| L207 | | | L40-5681-86 | SMALL FIXED INDUCTOR (0.56UH) | |
| L208 | | | L92-0138-05 | CHIP FERRITE | |
| L209 | | | L40-2275-92 | SMALL FIXED INDUCTOR (22NH) | K |
| L209 | | | L40-3375-92 | SMALL FIXED INDUCTOR (33NH) | K2 |
| L210 | | | L39-1498-05 | TOROIDAL COIL | |
| L211 | | | L92-0138-05 | CHIP FERRITE | |
| L212 | | | L39-1498-05 | TOROIDAL COIL | |
| L213 | | | L40-1575-92 | SMALL FIXED INDUCTOR (15NH) | K |
| L213,214 | | | L40-2275-92 | SMALL FIXED INDUCTOR (22NH) | K2 |
| L214 | | | L40-1875-92 | SMALL FIXED INDUCTOR (18NH) | K |
| L215 | | | L39-1498-05 | TOROIDAL COIL | |
| L216-219 | | | L34-4565-05 | AIR-CORE COIL | |
| L221 | | | L41-1278-14 | SMALL FIXED INDUCTOR (12NH) | K2 |
| L221 | | | L41-1878-14 | SMALL FIXED INDUCTOR (18NH) | K |
| L222 | | | L41-6878-14 | SMALL FIXED INDUCTOR (68N) | |
| L223,224 | | | L34-4568-05 | AIR-CORE COIL | |
| L225 | | | L41-6878-14 | SMALL FIXED INDUCTOR (68N) | |
| L228 | | | L40-2763-92 | SMALL FIXED INDUCTOR (2.7NH) | |
| L230 | | | L92-0138-05 | CHIP FERRITE | |
| L401-403 | | | L92-0179-05 | CHIP FERRITE | |

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| L404 | | | L92-0639-05 | CHIP FERRITE | |
| L405 | | | L33-1496-05 | SMALL FIXED INDUCTOR (22UH) | |
| L406 | | | L33-1462-05 | SMALL FIXED INDUCTOR (68UH) | |
| L501-503 | | | L92-0138-05 | CHIP FERRITE | |
| L506-511 | | | L92-0138-05 | CHIP FERRITE | |
| L512 | | | L92-0140-05 | CHIP FERRITE | |
| L517,518 | | | L92-0138-05 | CHIP FERRITE | |
| L521-523 | | | L92-0162-05 | BEADS CORE | |
| L901,902 | | | L92-0140-05 | CHIP FERRITE | |
| L903-905 | | | L92-0162-05 | BEADS CORE | |
| X1 | | | L77-3016-05 | TCXO (19.2M) | |
| X501 | | | L77-1802-05 | CRYSTAL RESONATOR (32768HZ) | |
| X502 | | | L77-3015-05 | TCXO (18.432M) | |
| XF202 | | | L71-0649-05 | MCF (58.05MHZ) | |
| R1,2 | | | RK73HH1J223D | CHIP R 22K D 1/16W | |
| R3 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| R4 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R5 | | | RK73HB1J224J | CHIP R 220K J 1/16W | |
| R6 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R7 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R8 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R10 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R12 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R13 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R15-19 | | | RK73HB1J100J | CHIP R 10 J 1/16W | |
| R21 | | | RK73HB1J100J | CHIP R 10 J 1/16W | |
| R22,23 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R25 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R26 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R27 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R28 | | | RK73HB1J683J | CHIP R 68K J 1/16W | |
| R29 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R30 | | | RK73HB1J184J | CHIP R 180K J 1/16W | |
| R31 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R32 | | | RK73HB1J151J | CHIP R 150 J 1/16W | |
| R34 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R35 | | | RK73HH1J391D | CHIP R 390 D 1/16W | |
| R36 | | | RK73HB1J106J | CHIP R 10M J 1/16W | |
| R37 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R40,41 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R42 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R43 | | | RK73HB1J100J | CHIP R 10 J 1/16W | |
| R44 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R45 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R46 | | | RK73HB1J271J | CHIP R 270 J 1/16W | |
| R47 | | | RK73HB1J154J | CHIP R 150K J 1/16W | |
| R49 | | | RK73HB1J683J | CHIP R 68K J 1/16W | |
| R53,54 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R55 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R56 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R57 | | | RK73HH1J181D | CHIP R 180 D 1/16W | |
| R58 | | | RK73HB1J181J | CHIP R 180 J 1/16W | |
| R59 | | | RK73HH1J181D | CHIP R 180 D 1/16W | |
| R60 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R61 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R62 | | | RK73HB1J154J | CHIP R 150K J 1/16W | |
| R63 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R64 | | | RK73HB1J682J | CHIP R 6.8K J 1/16W | |
| R65 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | | | | Destination |
|---|---|---|---|---|---|---|---|---|
| R66 | | | RK73HB1J331J | CHIP R | 330 | J | 1/16W | |
| R67 | | | RK73HB1J222J | CHIP R | 2.2K | J | 1/16W | |
| R68 | | | RK73HB1J470J | CHIP R | 47 | J | 1/16W | |
| R69 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R70 | | | RK73HB1J472J | CHIP R | 4.7K | J | 1/16W | |
| R71 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R72 | | | RK73HB1J183J | CHIP R | 18K | J | 1/16W | |
| R74 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R75 | | | RK73HB1J221J | CHIP R | 220 | J | 1/16W | |
| R76 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R77 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R79-83 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R84,85 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R86 | | | RK73GB2A272J | CHIP R | 2.7K | J | 1/10W | |
| R101 | | | RK73HB1J332J | CHIP R | 3.3K | J | 1/16W | |
| R102 | | | RK73HB1J821J | CHIP R | 820 | J | 1/16W | |
| R103 | | | RK73HB1J5R6J | CHIP R | 5.6 | J | 1/16W | |
| R104 | | | RK73HB1J821J | CHIP R | 820 | J | 1/16W | |
| R105 | | | RK73HB1J333J | CHIP R | 33K | J | 1/16W | |
| R106 | | | RK73HB1J221J | CHIP R | 220 | J | 1/16W | |
| R107 | | | RK73HB1J682J | CHIP R | 6.8K | J | 1/16W | |
| R108 | | | RK73GB2A100J | CHIP R | 10 | J | 1/10W | |
| R109 | | | RK73HB1J471J | CHIP R | 470 | J | 1/16W | |
| R110 | | | RK73GB2A220J | CHIP R | 22 | J | 1/10W | |
| R111 | | | RK73HB1J561J | CHIP R | 560 | J | 1/16W | |
| R112 | | | RK73HB1J272J | CHIP R | 2.7K | J | 1/16W | |
| R113 | | | RK73GB2A100J | CHIP R | 10 | J | 1/10W | |
| R114 | | | RK73HB1J331J | CHIP R | 330 | J | 1/16W | |
| R115 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R116 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R117 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R119 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R120 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R121 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R122 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R123 | | | RK73HB1J273J | CHIP R | 27K | J | 1/16W | |
| R124 | | | RK73HB1J332J | CHIP R | 3.3K | J | 1/16W | |
| R125 | | | RK73FB2B271J | CHIP R | 270 | J | 1/8W | |
| R126,127 | | | RK73FB2B390J | CHIP R | 39 | J | 1/8W | |
| R129 | | | RK73FB2B271J | CHIP R | 270 | J | 1/8W | |
| R131 | | | RK73HB1J331J | CHIP R | 330 | J | 1/16W | |
| R132,133 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R134 | | | RK73HB1J224J | CHIP R | 220K | J | 1/16W | K |
| R134 | | | RK73HB1J274J | CHIP R | 270K | J | 1/16W | K2 |
| R136 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R137 | | | RK73HB1J334J | CHIP R | 330K | J | 1/16W | |
| R138 | | | RK73EB2E301J | CHIP R | 300 | J | 1/4W | |
| R140 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R141 | | | RK73HB1J124J | CHIP R | 120K | J | 1/16W | |
| R142 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R143 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R144 | | | RK73HB1J824J | CHIP R | 820K | J | 1/16W | |
| R145 | | | RK73HB1J333J | CHIP R | 33K | J | 1/16W | K2 |
| R145 | | | RK73HB1J393J | CHIP R | 39K | J | 1/16W | K |
| R146,147 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R148 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R149 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | K |
| R149,150 | | | RK73HB1J823J | CHIP R | 82K | J | 1/16W | K2 |
| R150 | | | RK73HB1J823J | CHIP R | 82K | J | 1/16W | K |
| R151 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | K |

| Ref. No. | Address | New parts | Parts No. | Description | | | | Destination |
|---|---|---|---|---|---|---|---|---|
| R151 | | | RK73HB1J124J | CHIP R | 120K | J | 1/16W | K2 |
| R152 | | | R92-1061-05 | JUMPER REST | | | 0Ω | |
| R153 | | | RK73HB1J121J | CHIP R | 120 | J | 1/16W | K |
| R153 | | | RK73HB1J151J | CHIP R | 150 | J | 1/16W | K2 |
| R154 | | | RK73EB2E301J | CHIP R | 300 | J | 1/4W | |
| R156 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R158 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R160 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R161 | | | RK73HB1J332J | CHIP R | 3.3K | J | 1/16W | |
| R201 | | | RK73HB1J153J | CHIP R | 15K | J | 1/16W | |
| R202,203 | | | RK73HB1J223J | CHIP R | 22K | J | 1/16W | |
| R204 | | | RK73HB1J470J | CHIP R | 47 | J | 1/16W | |
| R205,206 | | | RK73HB1J223J | CHIP R | 22K | J | 1/16W | |
| R207 | | | RK73HB1J334J | CHIP R | 330K | J | 1/16W | |
| R208 | | | RK73HB1J153J | CHIP R | 15K | J | 1/16W | |
| R209,210 | | | RK73HB1J100J | CHIP R | 10 | J | 1/16W | |
| R211 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R212 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R213 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R215 | | | RK73HB1J122J | CHIP R | 1.2K | J | 1/16W | K2 |
| R215 | | | RK73HB1J272J | CHIP R | 2.7K | J | 1/16W | K |
| R216 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R218,219 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R220 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R221 | | | RK73HB1J183J | CHIP R | 18K | J | 1/16W | |
| R222 | | | RK73HB1J222J | CHIP R | 2.2K | J | 1/16W | |
| R223 | | | RK73HB1J274J | CHIP R | 270K | J | 1/16W | |
| R224 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R225 | | | RK73HB1J153J | CHIP R | 15K | J | 1/16W | |
| R226 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R227 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R228 | | | RK73HB1J223J | CHIP R | 22K | J | 1/16W | |
| R229 | | | RK73HB1J222J | CHIP R | 2.2K | J | 1/16W | |
| R230 | | | RK73HB1J223J | CHIP R | 22K | J | 1/16W | |
| R231 | | | RK73HB1J221J | CHIP R | 220 | J | 1/16W | |
| R232 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R234 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R235 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R237 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R238 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R239 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R242 | | | RK73HB1J221J | CHIP R | 220 | J | 1/16W | |
| R243 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R244 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R245,246 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R248 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R250 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R256 | | | RK73HB1J181J | CHIP R | 180 | J | 1/16W | |
| R257 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R261 | | | RK73HB1J472J | CHIP R | 4.7K | J | 1/16W | |
| R262 | | | RK73HB1J682J | CHIP R | 6.8K | J | 1/16W | |
| R263 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R265 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R266 | | | RK73HB1J222J | CHIP R | 2.2K | J | 1/16W | |
| R267 | | | RK73HB1J271J | CHIP R | 270 | J | 1/16W | |
| R268,269 | | | RK73HB1J470J | CHIP R | 47 | J | 1/16W | |
| R270 | | | RK73HB1J680J | CHIP R | 68 | J | 1/16W | |
| R271 | | | RK73HB1J222J | CHIP R | 2.2K | J | 1/16W | |
| R272 | | | RK73HB1J271J | CHIP R | 270 | J | 1/16W | |
| R273 | | | RK73HB1J180J | CHIP R | 18 | J | 1/16W | |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | | | | Destination |
|---|---|---|---|---|---|---|---|---|
| R274 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R275 | | | RK73HB1J271J | CHIP R | 270 | J | 1/16W | |
| R276 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R277 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R278 | | | RK73HB1J271J | CHIP R | 270 | J | 1/16W | K2 |
| R279 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K |
| R279 | | | RK73HB1J180J | CHIP R | 18 | J | 1/16W | K2 |
| R280 | | | RK73HB1J271J | CHIP R | 270 | J | 1/16W | K2 |
| R282 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R283,284 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R285 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R286,287 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R288 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R289 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R290 | | | RK73HB1J274J | CHIP R | 270K | J | 1/16W | |
| R291 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R294 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R296 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R297 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K |
| R297,298 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K2 |
| R299 | | | RK73HB1J221J | CHIP R | 220 | J | 1/16W | |
| R300 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K2 |
| R301 | | | RK73HB1J564J | CHIP R | 560K | J | 1/16W | |
| R302,303 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R306,307 | | | RK73HB1J183J | CHIP R | 18K | J | 1/16W | |
| R310 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R313 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R314 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R315,316 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R317 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R320,321 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R324,325 | | | RK73HB1J182J | CHIP R | 1.8K | J | 1/16W | |
| R327 | | | RK73HB1J332J | CHIP R | 3.3K | J | 1/16W | |
| R328 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R329 | | | RK73HB1J562J | CHIP R | 5.6K | J | 1/16W | |
| R330 | | | RK73GB2A100J | CHIP R | 10 | J | 1/10W | |
| R331 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R332 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R333 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R334 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R338 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R339 | | | RK73HB1J470J | CHIP R | 47 | J | 1/16W | |
| R340,341 | | | RK73HB1J121J | CHIP R | 120 | J | 1/16W | |
| R342,343 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R344 | | | RK73HB1J152J | CHIP R | 1.5K | J | 1/16W | |
| R345 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R346 | | | RK73HB1J223J | CHIP R | 22K | J | 1/16W | |
| R352,353 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R401 | | | RK73HH1J105D | CHIP R | 1.0M | D | 1/16W | |
| R402 | | | RK73HB1J471J | CHIP R | 470 | J | 1/16W | |
| R403 | | | RK73HH1J104D | CHIP R | 100K | D | 1/16W | |
| R404 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R405 | | | RK73HH1J274D | CHIP R | 270K | D | 1/16W | |
| R406 | | | RK73HH1J104D | CHIP R | 100K | D | 1/16W | |
| R407 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R408 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R409 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R410 | | | RK73HB1J684J | CHIP R | 680K | J | 1/16W | |
| R411 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R413 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |

| Ref. No. | Address | New parts | Parts No. | Description | | | | Destination |
|---|---|---|---|---|---|---|---|---|
| R415 | | | RK73HB1J332J | CHIP R | 3.3K | J | 1/16W | |
| R417 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R418,419 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R420 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R421 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R422 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R423-425 | | | RK73GB2A472J | CHIP R | 4.7K | J | 1/10W | |
| R426 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R428,429 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R430 | | | RK73HH1J124D | CHIP R | 120K | D | 1/16W | |
| R431 | | | RK73HH1J183D | CHIP R | 18K | D | 1/16W | |
| R432 | | | RK73HH1J223D | CHIP R | 22K | D | 1/16W | |
| R433 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R434 | | | RK73HB1J330J | CHIP R | 33 | J | 1/16W | |
| R435 | | | RK73GB2A100J | CHIP R | 10 | J | 1/10W | |
| R436 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R437 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R438 | | | RK73HB1J154J | CHIP R | 150K | J | 1/16W | |
| R440 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R441 | | | RK73HB1J123J | CHIP R | 12K | J | 1/16W | |
| R442 | | | RK73HH1J334D | CHIP R | 330K | D | 1/16W | |
| R443 | | | RK73HH1J223D | CHIP R | 22K | D | 1/16W | |
| R444 | | | RK73HB1J272J | CHIP R | 2.7K | J | 1/16W | |
| R445 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R446 | | | RK73GB2A100J | CHIP R | 10 | J | 1/10W | |
| R447 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R448 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R449 | | | RK73GB2A220J | CHIP R | 22 | J | 1/10W | |
| R450 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R501 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R503 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R504 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R506 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R507 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R509 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R510 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R511 | | | RK73HB1J220J | CHIP R | 22 | J | 1/16W | |
| R512 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R514 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R515,516 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R520,521 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R522 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R523 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R524 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R525 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R527 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R528,529 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R531 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R532 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R533,534 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R536,537 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R538 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R539 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R540,541 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R542 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R543 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R544 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R545 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R548 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R550 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |

# PARTS LIST

TX-RX UNIT (X57-7910-XX)

| Ref. No. | Address | New parts | Parts No. | Description | | | | Destination |
|---|---|---|---|---|---|---|---|---|
| R551 | | | RK73HB1J101J | CHIP R | 100 | J | 1/16W | |
| R552-554 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R556-558 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R560 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R561 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R562 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R565 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R567 | | | RK73HB1J151J | CHIP R | 150 | J | 1/16W | |
| R568 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R569 | | | RK73HB1J220J | CHIP R | 22 | J | 1/16W | |
| R572 | | | RK73HB1J220J | CHIP R | 22 | J | 1/16W | |
| R574 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R575 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R576 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R577 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R578-580 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R581 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R582-586 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R587 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R588-590 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R591 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R592,593 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R594 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R595 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R596 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R597 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R598-601 | | | RK73FB2B102J | CHIP R | 1.0K | J | 1/8W | |
| R602 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R603,604 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R605 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R606 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R607,608 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R610 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R611,612 | | | RK73HB1J105J | CHIP R | 1.0M | J | 1/16W | |
| R614 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R615,616 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R617-620 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R621 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K2 |
| R621,622 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K |
| R622 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | K2 |
| R623-625 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R627,628 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R629 | | | RK73HB1J105J | CHIP R | 1.0M | J | 1/16W | |
| R630 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R632 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R633 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R634 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R636 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R637 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R638 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R639 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R640 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R641,642 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R644 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R646 | | | RK73HB1J682J | CHIP R | 6.8K | J | 1/16W | |
| R648 | | | RK73HB1J682J | CHIP R | 6.8K | J | 1/16W | |
| R650 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R651 | | | RK73FB2B102J | CHIP R | 1.0K | J | 1/8W | |
| R652 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R654 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |

| Ref. No. | Address | New parts | Parts No. | Description | | | | Destination |
|---|---|---|---|---|---|---|---|---|
| R656 | | | RK73HB1J471J | CHIP R | 470 | J | 1/16W | |
| R658 | | | RK73GB2A000J | CHIP R | 0.0 | J | 1/10W | |
| R659-661 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R662,663 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R664-674 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R676 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R677 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R678 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R680-683 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | K |
| R680-683 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | K2 |
| R684-686 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R687,688 | | | RK73HB1J472J | CHIP R | 4.7K | J | 1/16W | |
| R689,690 | | | RK73HB1J474J | CHIP R | 470K | J | 1/16W | |
| R691-696 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R697,698 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R701 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R703 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R704 | | | RK73HB1J563J | CHIP R | 56K | J | 1/16W | |
| R705 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R706 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R707 | | | RK73HB1J153J | CHIP R | 15K | J | 1/16W | |
| R708 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R709 | | | RK73HB1J822J | CHIP R | 8.2K | J | 1/16W | |
| R710 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R712 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R713 | | | RK73HB1J563J | CHIP R | 56K | J | 1/16W | |
| R714 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R715 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R716 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R717 | | | RK73HB1J393J | CHIP R | 39K | J | 1/16W | K2 |
| R717 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | K |
| R718 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R720 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R721 | | | RK73HB1J222J | CHIP R | 2.2K | J | 1/16W | |
| R722 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R724 | | | RK73HB1J563J | CHIP R | 56K | J | 1/16W | |
| R725 | | | RK73HB1J683J | CHIP R | 68K | J | 1/16W | |
| R726 | | | RK73HB1J100J | CHIP R | 10 | J | 1/16W | |
| R727 | | | RK73HB1J274J | CHIP R | 270K | J | 1/16W | |
| R728 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R729 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R730 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R731 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R732 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R733 | | | RK73HB1J333J | CHIP R | 33K | J | 1/16W | |
| R734 | | | RK73HB1J223J | CHIP R | 22K | J | 1/16W | |
| R737 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R738 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R739 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R740,741 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R744 | | | RK73HB1J473J | CHIP R | 47K | J | 1/16W | |
| R745 | | | RK73HB1J104J | CHIP R | 100K | J | 1/16W | |
| R746 | | | RK73HB1J103J | CHIP R | 10K | J | 1/16W | |
| R747 | | | RK73HB1J334J | CHIP R | 330K | J | 1/16W | |
| R748 | | | RK73HB1J000J | CHIP R | 0.0 | J | 1/16W | |
| R749 | | | RK73HB1J823J | CHIP R | 82K | J | 1/16W | |
| R750 | | | RK73HB1J332J | CHIP R | 3.3K | J | 1/16W | |
| R751 | | | RK73HB1J271J | CHIP R | 270 | J | 1/16W | |
| R752 | | | RK73HB1J102J | CHIP R | 1.0K | J | 1/16W | |
| R753 | | | RK73HB1J563J | CHIP R | 56K | J | 1/16W | |

# PARTS LIST

**TX-RX UNIT (X57-7910-XX)**

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| R755 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R756 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R758 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R759 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R760 | | | RK73HB1J152J | CHIP R 1.5K J 1/16W | |
| R761 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R762 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R763 | | | RK73HB1J183J | CHIP R 18K J 1/16W | |
| R764 | | | RK73HB1J124J | CHIP R 120K J 1/16W | |
| R765 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R766 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R767,768 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R769 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R770 | | | RK73HB1J563J | CHIP R 56K J 1/16W | |
| R771 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R772 | | | RK73HB1J123J | CHIP R 12K J 1/16W | |
| R773 | | | RK73HB1J684J | CHIP R 680K J 1/16W | |
| R774 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R775 | | | RK73HB1J823J | CHIP R 82K J 1/16W | |
| R776 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| R777 | | | RK73HB1J154J | CHIP R 150K J 1/16W | |
| R778 | | | RK73HB1J394J | CHIP R 390K J 1/16W | |
| R779 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R780,781 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R782 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R783 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R784 | | | RK73HB1J154J | CHIP R 150K J 1/16W | |
| R785 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R786 | | | RK73HB1J393J | CHIP R 39K J 1/16W | |
| R787 | | | RK73HB1J274J | CHIP R 270K J 1/16W | |
| R788 | | | RK73HB1J223J | CHIP R 22K J 1/16W | |
| R789 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R790 | | | RK73HB1J224J | CHIP R 220K J 1/16W | |
| R791 | | | RK73HB1J564J | CHIP R 560K J 1/16W | |
| R792 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R793,794 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R795 | | | RK73HB1J224J | CHIP R 220K J 1/16W | |
| R796 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R797 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| R798 | | | RK73HB1J684J | CHIP R 680K J 1/16W | |
| R799 | | | RK73HB1J563J | CHIP R 56K J 1/16W | |
| R800 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R801 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R802 | | | RK73HB1J273J | CHIP R 27K J 1/16W | |
| R803 | | | RK73HB1J153J | CHIP R 15K J 1/16W | |
| R804 | | | RK73HB1J681J | CHIP R 680 J 1/16W | |
| R805 | | | RK73HB1J823J | CHIP R 82K J 1/16W | |
| R806 | | | RK73HB1J562J | CHIP R 5.6K J 1/16W | |
| R807,808 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R809 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R810 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R812,813 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R814-816 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R817 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R818 | | | RK73HB1J333J | CHIP R 33K J 1/16W | |
| R819 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R820 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R821 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R822 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R823 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| R825,826 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R827 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | |
| R828 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R831 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R833-835 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R836 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R837 | | | RK73HB1J472J | CHIP R 4.7K J 1/16W | |
| R838 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R841 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R842 | | | RK73FB2B102J | CHIP R 1.0K J 1/8W | |
| R843 | | | RK73HB1J471J | CHIP R 470 J 1/16W | |
| R845 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R846 | | | RK73HB1J332J | CHIP R 3.3K J 1/16W | |
| R901 | | | RK73GB2A471J | CHIP R 470 J 1/10W | |
| R902,903 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R904-913 | | | RK73HB1J471J | CHIP R 470 J 1/16W | |
| R914 | | | RK73GB2A471J | CHIP R 470 J 1/10W | |
| R915-917 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| R918,919 | | | RK73HB1J101J | CHIP R 100 J 1/16W | |
| R920 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | K2 |
| R921 | | | RK73HB1J474J | CHIP R 470K J 1/16W | |
| R922 | | | RK73HB1J000J | CHIP R 0.0 J 1/16W | |
| D2 | | | DA221 | DIODE | |
| D3,4 | | | 1SV325F | VARIABLE CAPACITANCE DIODE | |
| D7-12 | | | 1SV282-F | VARIABLE CAPACITANCE DIODE | |
| D14 | | | 1SV278F | VARIABLE CAPACITANCE DIODE | |
| D21 | | | HVC131 | DIODE | |
| D101 | | | HVC131 | DIODE | |
| D102 | | | 02DZ5.6F-X,Y | ZENER DIODE | |
| D103,104 | | | L407CDB | DIODE (50V/1W) | |
| D106 | | | L7091CER | DIODE | |
| D108-110 | | | HSM88AS-E | DIODE | |
| D201,202 | | | DAN235E | DIODE | |
| D205 | | | HVC131 | DIODE | |
| D207-210 | | | 1SV286F | VARIABLE CAPACITANCE DIODE | |
| D212,213 | | | 1SV286F | VARIABLE CAPACITANCE DIODE | |
| D216 | | | HVC131 | DIODE | |
| D401 | | | 02DZ18F-X | ZENER DIODE | |
| D403 | | | 1SS416 | DIODE | |
| D404 | | | 22ZR-10D | SURGE ABSORBER | |
| D405 | | | DSA3A1 | DIODE | |
| D406 | | | HSC119 | DIODE | |
| D407 | | | CRS02-Q | DIODE | |
| D408 | | | 1SS301F | DIODE | |
| D409-412 | | | 1SS388F | DIODE | |
| D501,502 | | | 1SS388F | DIODE | |
| D503,504 | | | 1SS416 | DIODE | |
| D506,507 | | | 1SS416 | DIODE | |
| D508 | | | DA204U | DIODE | |
| D509,510 | | | 1SS416 | DIODE | |
| D511,512 | | | DA204U | DIODE | |
| D702 | | | HSC119 | DIODE | |
| D703-705 | | | RB706F-40 | DIODE | |
| D706,707 | | | EMZ6.8N | ZENER DIODE | |
| D901-904 | | | DA204U | DIODE | |
| D905,906 | | | 02DZ18F-X | ZENER DIODE | |
| D907,908 | | | DA204U | DIODE | |
| D909 | | | 1SS355 | DIODE | |
| D910 | | | 02DZ18F-X | ZENER DIODE | |
| D911,912 | | | DA204U | DIODE | |

# PARTS LIST

TX-RX UNIT (X57-7910-XX)

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| D913 | | | 1SS355 | DIODE | |
| D914 | | | 02DZ18F-X | ZENER DIODE | |
| IC1 | | | LM73CIMKX-0 | MOS-IC | |
| IC2 | | | LMC7101BIM5 | MOS-IC | |
| IC3 | | | **Note 1** | MOS-IC | |
| IC4 | | | LMC7101BIM5 | MOS-IC | |
| IC5 | | | TC75W51FK(F) | MOS-IC | |
| IC101 | | | NJM2904V-ZB | MOS-IC | K |
| IC101 | | | TA75W01FUF | MOS-IC | K2 |
| IC102 | 2A | | RA55H4047A123 | MOS-IC | K2 |
| IC102 | 2A | | RA55H4452M123 | MOS-IC | K |
| IC103 | | | NJM2904V-ZB | MOS-IC | K |
| IC103 | | | TA75W01FUF | MOS-IC | K2 |
| IC201 | | | MCP6021-E/OT | MOS-IC | |
| IC202 | | | TK10931VTL-G | ANALOGUE IC | |
| IC203 | | | TC75W51FK(F) | MOS-IC | |
| IC204 | | | SPM5001 | MOS-IC | |
| IC205,206 | | | LMC7101BIM5 | MOS-IC | |
| IC401 | | | XC6108C23CMN | MOS-IC | |
| IC402 | | | XC6204B332P1 | ANALOGUE IC | |
| IC403 | 2A | | NJM78M08FA-ZB | ANALOGUE IC | |
| IC404 | | | TA7805FQ | MOS-IC | |
| IC405 | | | LT1616ES6-PBF | ANALOGUE IC | |
| IC406 | | | TK71733S | BI-POLAR IC | |
| IC407,408 | | | XC6204B332M | MOS-IC | |
| IC409 | | | XC6205B152PRN | ANALOGUE IC | |
| IC410 | | | XC9101D09AKR | ANALOGUE IC | |
| IC501 | | | **Note 1 (BGA)** | ROM IC | |
| IC502 | | | **Note 1 (BGA)** | MCU | |
| IC503 | | | **Note 1 (BGA)** | SRAM IC | |
| IC504 | | | RV5C386A | MOS-IC | |
| IC505 | | | TC7SH08FU-F | MOS-IC | |
| IC506 | | | XC6109C29ANN | ANALOGUE IC | |
| IC507 | | | TC7SH126FU-F | MOS-IC | |
| IC508 | | | SM5023CNDH-G | MOS-IC | |
| IC509 | | | TC7WT125FUF | MOS-IC | |
| IC510 | | | **Note 1 (BGA)** | MOS-IC | |
| IC511 | | | TC7SH08FU-F | MOS-IC | |
| IC512,513 | | | TC7SET08FU-F | MOS-IC | |
| IC514 | | | TC7WBD125AFK | MOS-IC | |
| IC515 | | | TC7WT126FU-F | MOS-IC | |
| IC516 | | | TC7WH126FU-F | MOS-IC | |
| IC517 | | | **Note 1** | MOS-IC | |
| IC518 | | | ADM202EARNZ | MOS-IC | |
| IC701 | | | TC75S51FE(F) | MOS-IC | |
| IC702,703 | | | TC75W51FK(F) | MOS-IC | |
| IC704 | | | MCP6021-E/OT | MOS-IC | |
| IC705,706 | | | TC75W51FK(F) | MOS-IC | |
| IC707,708 | | | TC7W53FK(F) | MOS-IC | |
| IC709 | | | TC75W51FK(F) | MOS-IC | |
| IC710 | | | TC7W53FK(F) | MOS-IC | |
| IC711 | | | TC75W51FK(F) | MOS-IC | |
| IC712 | | | M62364FP-F | MOS-IC | |
| IC713 | | | TC7W53FK(F) | MOS-IC | |
| IC714 | | | TC75S51FE(F) | MOS-IC | |
| IC715 | 2A | | LA4425A | MOS-IC | |
| Q1 | | | 2SC5383-T111 | TRANSISTOR | |
| Q3 | | | 2SC5636 | TRANSISTOR | |
| Q4 | | | 2SC5383-T111 | TRANSISTOR | |
| Q5,6 | | | 2SK508NV(K52) | FET | |

| Ref. No. | Address | New parts | Parts No. | Description | Destination |
|---|---|---|---|---|---|
| Q7 | | | SSM6L05FU-F | FET | |
| Q8 | | | SSM3J05FU-F | FET | K2 |
| Q8 | | | 2SJ347F | FET | K |
| Q9,10 | | | 2SC5636 | TRANSISTOR | |
| Q11 | | | 2SK1215-E(E) | FET | |
| Q101 | | | 2SC5108(Y)F | TRANSISTOR | |
| Q102 | | | 2SC5455-A | TRANSISTOR | |
| Q105 | | | DTC114EEB | DIGITAL TRANSISTOR | |
| Q106 | | | 2SK1830F | FET | |
| Q201 | | ✻ | DTA114EEB | DIGITAL TRANSISTOR | |
| Q202 | | ✻ | DTC144EEB | DIGITAL TRANSISTOR | |
| Q203 | | | 2SC5636 | TRANSISTOR | |
| Q204,205 | | | 2SC3356(R23) | TRANSISTOR | |
| Q208 | | | 2SC5636 | TRANSISTOR | |
| Q210 | | | 2SC3357-A | TRANSISTOR | |
| Q212 | | | EMD9 | TRANSISTOR | |
| Q401,402 | | | DTC114EEB | DIGITAL TRANSISTOR | |
| Q403 | | ✻ | DTC114TEB | DIGITAL TRANSISTOR | |
| Q404 | | | 2SJ645 | FET | |
| Q405 | | | 2SA1955A-F | TRANSISTOR | |
| Q406 | | | UPA672T-A | FET | |
| Q407-409 | | | 12A02CH | TRANSISTOR | |
| Q410 | | | SSM3K15TE(F) | FET | |
| Q411,412 | | | 2SA1955A-F | TRANSISTOR | |
| Q413-415 | | | DTC114EEB | DIGITAL TRANSISTOR | |
| Q416 | | | SSM6L05FU-F | FET | |
| Q417 | | | SSM5H01TU-F | FET | |
| Q501 | | | UPA672T-A | FET | |
| Q701 | | | SSM3K15TE(F) | FET | |
| Q702 | | | 2SC4617(Q) | TRANSISTOR | |
| Q703 | | | SSM3K15TE(F) | FET | |
| Q704 | | | 2SC4738(GR)F | TRANSISTOR | |
| Q705 | | | 2SA1832(GR)F | TRANSISTOR | |
| Q706,707 | | | 2SJ243-A | FET | |
| Q708 | | | 2SA1832(GR)F | TRANSISTOR | |
| Q709 | | | DTC114EEB | DIGITAL TRANSISTOR | |
| Q710 | | | DTC363EU | DIGITAL TRANSISTOR | |
| Q901,902 | | | QSX6 | TRANSISTOR | |
| TH101,102 | | | ERTJ0EV104H | THERMISTOR | |
| TH701 | | | ERTJ0EV104H | THERMISTOR | |
| 101 | 2A | | W09-0971-05 | LITHIUM CELL | |
| - | | ✻ | X57-7910-12 | SERVICE TX-RX UNIT | K |
| - | | ✻ | X57-7910-13 | SERVICE TX-RX UNIT | K2 |

**If a part reference number is listed in a shaded box, that part does not come with the PCB.**
**Note 1 : This part cannot be replaced. Therefore, this part is not supplied as a service part.**

# EXPLODED VIEW






**Parts with the exploded numbers larger than 700 are not supplied.**
**If a part reference number is listed in a box on the exploded view of the PCB (for example, IC123), that part does not come with the PCB. These parts must be ordered separately.**

# PACKING




**Parts with the exploded numbers larger than 700 are not supplied.**