Pioneer

Service Manual

ORDER NO.
CRT4543

FLASH MEMORY MULTIMEDIA AV NAVIGATION RECEIVER

AVIC-Z120BT /XNUC

NAVIGATION AV SYSTEM

AVIC-F20BT /XNAU

DVD is a trademark of DVD Format/Logo Licensing Corporation.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Pioneer Corporation is under license. Other trademarks and trade names are those of their respective owners.

This service manual should be used together with the following manual(s) listed below. For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
AVIC-Z110BT/XN/UC	CRT4399		
CX-3250	CRT4300	LS1	DVD Mech.Module:Circuit Descriptions, Mech. Descriptions, Disassembly

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
ⓒ**PIONEER CORPORATION 2010**
K-ZZZ. MAR. 2010 Printed in Japan

SAFETY INFORMATION

WARNING

This product may contain a chemical known to the State of California to cause cancer, or birth defects or other reproductive harm.
Health & Safety Code Section 25249.6 - Proposition 65

EXPLODED VIEWS AND PARTS LIST

PACKING(Page 170)

PACKING SECTION PARTS LIST

*:Non spare part

Mark	No.	Description	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
	1	Polyethylene Bag	CEG1359	CEG1359 (Cover)	CEG1356 (Cover)
	2	Unit Box	CHG6940	CHG7325	CHG7326
	3	Contain Box	CHL6940	CHL7325	CHL7326
	5	Sub Unit Box Assy	CHX2124	*CHX2202	*CHX2199
	6	Cord	CDE6825	Not used	Not used
	7	Cord	CDP1157	Not used	Not used
	8	Cord Assy	CDP1194	CDP1335	CDP1335
	16	Connector	CKX1049	Not used	Not used
	17	IM CD-ROM	Not used	CPJ1318	CPJ1318
	21	RDS-TMC Tuner	Not used	Not used	CXE2176
	26-1	Owner's Manual	CRB3035	Not used	Not used
	26-2	Owner's Manual	CRB3036	Not used	Not used
	26-3	Quick Start Guide	CRB3037	CRB3219	CRB3238
	26-4	Quick Start Guide	CRB3038	CRB3220	Not used
	26-5	Important Information	Not used	CRD4459	CRB3239
	26-6	Installation Manual	CRD4418	CRD4460	CRB3240
*	26-8	Warranty Card	CRY1246	CRY1246	Not used
*	26-9	Registration Card	CRY1271	CRY1271	Not used
	27	Cord Assy	CDP1095	CDP1307	CDP1307

Owner's Manual,Installation Manual

Part No.	Language	Model
CRB3219	English	UC
CRB3220	French	
CRD4459	English, French	
CRD4460	English, French	
CRB3238	English	AU
CRB3239	English	
CRB3240	English	

CONTENTS OF CD-ROM (Operation Manual), CPJ1318

Part No.	Language	Model
* CRB3201	English	UC
* CRB3202	French	
* CRB3237	English	AU

All operation manuals are supplied in PDF files by the CD-ROM.
Regarding the availability of paper manual, contact Pioneer Service representative in your region.

EXTERIOR(1)(Page 172)

EXTERIOR(1) SECTION PARTS LIST

Mark	No.	Description	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
	7	Shield	CND4940	Not used	CND4940
	13	Sheet	CNN3148	Not used	Not used
	14	Sheet	CNN3149	Not used	CNN3149
	16	Navi Unit	CWN3985	CWN5264	CWN5264
	20	Service CC Assy	CXX2854	CXX2845	CXX2846
	24	DVD Mechanism Module(LS1)	CXK6802	CXK6803	CXK6803

EXTERIOR(2)(Page 174)

EXTERIOR(2) SECTION PARTS LIST

Mark	No.	Description	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
	5	Cord	CDE6825	Not used	Not used
	6	Cap	CNS1472	Not used	Not used
	8	Cord Assy	CDP1194	CDP1335	CDP1335
	9	Cap	CNW1490(x 13)	CNW1490(x 11)	CNW1490(x 11)
	10	Audio Unit	CWN4335	CWN5269	CWN5270
	11	Screw	BMZ26P060FTB	BMZ26P060FTC	BMZ26P060FTC
	12	Shield	CND4926	Not used	Not used
	18	Cord Assy	CDP1095	CDP1307	CDP1307

EXTERIOR(3)(Page 176)

EXTERIOR(3) SECTION PARTS LIST

Mark	No.	Description	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
	14	Screw(M2 x 2)	CBA1771	JJZ20P020FTC	JJZ20P020FTC
	17	Monitor Unit	CWN3935	CWN5271	CWN5271
	19	Bluetooth Module	CWX3851	CWX3931	CWX3931
	26	Grille Unit	CXE2206	CXE3317	CXE3316
	30	Plate	CNS9899	CNU1299	CNU1298
	32	Panel Unit	CXE1991	CXE1991	CXE1992

EXTERIOR(4)(Page 178)

EXTERIOR(4) SECTION PARTS LIST

Mark	No.	Description	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
	5	Bracket	CND4917	CND5724	CND5724

DVD MECHANISM MODULE(Page 180)

DVD MECHANISM MODULE SECTION PARTS LIST

Mark	No.	Description	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
	72	DVD Core Unit	YWX5014	YWX5015	YWX5015

ELECTRICAL PARTS LIST (Page 310)

For the information of the parts that are added to this model, please refer to the following manual CRT4399).

TUNER IF UNIT

Circuit Symbol and No.	Part Name	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
R410		RS1/16SS681J	RS1/16SS681J	Not used
R411		RS1/16SS681J	RS1/16SS681J	Not used
R412		RS1/16SS681J	RS1/16SS681J	Not used
R426		RS1/16SS104J	RS1/16SS104J	Not used
R427		RS1/16SS104J	RS1/16SS104J	Not used
R520		RS1/16SS472J	RS1/16SS472J	Not used
R522		Not used	Not used	RS1/16SS223J
C431		CKSSYB122K50	CKSSYB122K50	Not used
C432		CKSSYB122K50	CKSSYB122K50	Not used

SERVICE CC ASSY

Circuit Symbol and No.	Part Name	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
IC4403	IC	PEH224B8	CXX2678	CXX2678
R4285		Not used	RS1/16SS0R0J	RS1/16SS0R0J
R4288		RS1/16SS0R0J	Not used	Not used
R4289		Not used	RS1/16SS0R0J	RS1/16SS0R0J
R4290		RS1/16SS0R0J	Not used	RS1/16SS0R0J
C4004		CKSRYB104K10	CKSRYB104K16	CKSRYB104K16
C4613		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4621		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4622		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4623		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4624		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4625		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4626		CKSSYB473K10	CKSSYB473K16	CKSSYB473K16
C4925		CKSSYB333K10	CKSSYB333K16	CKSSYB333K16

DVD CORE UNIT

Circuit Symbol and No.	Part Name	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
*IC1401	Flash ROM Unit	CWW2489	CWW2491	CWW2491
*IC1402	Flash ROM Unit	CWW2490	CWW2492	CWW2492

NAVI UNIT

Circuit Symbol and No.	Part Name	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
Q5003	Chip Transistor	DTC114EUA	LTC114EUB	LTC114EUB
Q5102	Transistor	2SA1576A	Not used	Not used
Q5103	Transistor	2SC4081	Not used	Not used
Q5105	Transistor	UMF23N	Not used	Not used
Q5106	Transistor	2SB1184F5	Not used	Not used
Q5107	Digital Transistor	DTC143EUA	Not used	Not used
Q5108	Transistor	2SA1587	2SA1579	2SA1579
Q5109	Chip Transistor	DTC114EUA	LTC114EUB	LTC114EUB
Q5110	Transistor	IMX1	Not used	Not used
Q5111	Digital Transistor	DTC143EUA	LTC143EUB	LTC143EUB
Q5113	Transistor	2SA1576A	LSA1576UB	LSA1576UB
Q5114	Chip Transistor	DTC114EUA	LTC114EUB	LTC114EUB
Q5116	Chip Transistor	DTC114EUA	LTC114EUB	LTC114EUB
Q5201	Transistor	2SA1576A	LSA1576UB	LSA1576UB
Q5202	Chip Transistor	DTC114EUA	LTC114EUB	LTC114EUB
Q5304	Transistor	2SA1576A	LSA1576UB	LSA1576UB
D5003	Diode	RB551V-30	Not used	Not used
D5203	Diode	UDZS18(B)	Not used	Not used
D5204	Diode	EDZ5R6(B)	Not used	Not used
D5205	Diode	EDZ5R6(B)	Not used	Not used
D5251	Diode	MALS180X	Not used	Not used
D5253	Diode	MALS180X	Not used	Not used
D5254	Diode	MALS180X	Not used	Not used
D5502	Diode	UDZS5R6(B)	Not used	Not used
L5310	Inductor	CTF1736	Not used	Not used
F5251	EMI Filter	CCG1067	CCG1289	CCG1289
F5252	EMI Filter	CCG1067	CCG1289	CCG1289
F5253	EMI Filter	CCG1060	CCG1290	CCG1290
VA5201	Varistor	AVR-M1608C270KT2AB	Not used	Not used
VA5202	Varistor	AVR-M1608C270KT2AB	Not used	Not used
VA5203	Varistor	AVR-M1608C270KT2AB	Not used	Not used
VA5204	Varistor	AVR-M1608C270KT2AB	Not used	Not used
R5104		RS1/10SR682J	Not used	Not used
R5105		RS1/10SR153J	Not used	Not used
R5107		RS1/10SR103J	Not used	Not used
R5108		Not used	RS1/10SR330J	RS1/10SR330J
R5109		RS1/10SR330J	Not used	Not used
R5110		RS1/16SS223J	Not used	Not used
R5111		RS1/8SQ472J	Not used	Not used
R5112		Not used	RS1/4SA0R0J	RS1/4SA0R0J

NAVI UNIT

Circuit Symbol and No.	Part Name	AVIC-Z110BT/XN/UC	AVIC-Z120BT/XNUC	AVIC-F20BT/XNAU
R5113		RS1/10SR153J	Not used	Not used
R5114		RS1/4SA331J	Not used	Not used
R5115		RS1/4SA331J	Not used	Not used
R5118		RS1/16SS224J	Not used	Not used
R5119		RS1/16SS472J	Not used	Not used
R5120		RS1/8SQ102J	Not used	Not used
R5122		RS1/10SR102J	Not used	Not used
R5134		Not used	RS1/10SR0R0J	RS1/10SR0R0J
R5136		RS1/10SR102J	RS1/10SR271J	RS1/10SR271J
R5150		RS1/4SA682J	Not used	Not used
R5151		RS1/10SR6800D	Not used	Not used
R5152		RS1/10SR6800D	Not used	Not used
R5153		RS1/16SS473J	Not used	Not used
R5154		RS1/16SS393J	Not used	Not used
R5519		RS1/10SR3900D	RS1/10SR101J	RS1/10SR101J
C5106		CKSQYB103K50	Not used	Not used
C5111		CEVW101M16	Not used	Not used
C5112		CKSQYB104K50	Not used	Not used
C5115		CKSRYB472K50	Not used	Not used
C5116		CKSRYB104K16	Not used	Not used
C5118		CEVW470M16	Not used	Not used
C5139		CKSQYB106K6R3	DCH1201	DCH1201
C5149		CKSRYB105K10	Not used	Not used
C5434	22 uF	CCG1178	CCG1254	CCG1254
C5504	10 uF	CKSQYB106K6R3	DCH1201	DCH1201
C5518	10 uF	CKSQYB106K6R3	DCH1201	DCH1201
C5521	10 uF	CKSQYB106K6R3	DCH1201	DCH1201
C5523	10 uF	CKSQYB106K6R3	DCH1201	DCH1201

ELECTRICAL PARTS LIST

NOTE:

- *Parts whose parts numbers are omitted are subject to being not supplied.*
- *The part numbers shown below indicate chip components.*

Chip Resistor

RS1/◯S◯◯◯J,RS1/◯◯S◯◯◯J

Chip Capacitor (except for CQS.....)

CKS....., CCS....., CSZS.....

- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Meaning of the figures and others in the parentheses in the parts list.*

Example) IC 301 is on the point (face A, 91 of x-axis, and 111 of y-axis) of the corresponding PC board.

IC 301 (A, 91, 111) IC NJM2068V

- *The expression of the unit in this manual is shown by u instead of μ. Please do not make a mistake.*

AF

Unit Number:CWN5269(UC)
Unit Number:CWN5270(AU)
Unit Name:Audio Unit

MISCELLANEOUS

Circuit Symbol and No.			Part No.
IC	2051	(B,62,83) IC	BD3931FP
IC	2056	(B,68,79) IC	S-1200B33-M5
IC	2121	(A,12,100) IC	NJM2388F84
IC	2131	(A,12,78) IC	NJM2388F84
IC	2151	(A,94,16) IC	LT3505EDD
IC	2161	(A,86,44) Regulator IC	BD9781HFP
IC	2181	(A,99,32) IC	LT3461AES6
IC	2182	(A,114,40) IC	S-812C56AUA-C3K
IC	2190	(B,138,34) IC	S-812C56AUA-C3K
IC	2300	(A,88,136) IC	PA2030A
IC	2302	(A,43,37) IC	S-93C56BD0I-I8
IC	2303	(B,55,51) IC(UC)	PEG677A8
		(B,55,51) IC(AU)	PEG678A8
IC	2304	(A,60,53) IC	BD5229FVE
IC	2491	(A,10,43) IC	NJM2904M
IC	2511	(A,23,112) IC	TC7WH126FU
IC	2512	(A,24,120) IC	TPD1018F
IC	2513	(B,21,119) L-MOS And Gate(UC)	TC7SET08FUS1
IC	2530	(A,38,46) IC	TC74VHCT541AFTS1
IC	2531	(A,52,50) Logic IC	TC74VHCT32AFT
IC	2621	(A,106,71) IC	NJM2125F
IC	2625	(B,96,64) IC	BA4558RFVM
IC	2641	(B,136,89) IC	NJM2060V
IC	2661	(B,129,53) IC	AN15887A
IC	2771	(B,112,81) IC	PML017B
IC	2889	(A,139,18) IC	NJM4580V
Q	2031	(B,37,85) Transistor	LSC4081UB
Q	2032	(B,40,87) Transistor	LSC4081UB
Q	2041	(A,48,118) Transistor	2SC4116
Q	2046	(B,11,128) Transistor	LTC114EUB
Q	2066	(B,13,34) Transistor	LSA1576UB
Q	2067	(B,13,29) Transistor	LTC114EUB
Q	2071	(A,30,37) Transistor	LSA1576UB
Q	2072	(A,33,37) Transistor	LTC114EUB
Q	2101	(B,120,29) Chip Transistor	UMF21N
Q	2181	(B,91,37) Transistor	UMD3N
Q	2182	(B,91,30) Transistor	2SD1767
Q	2226	(A,27,48) Transistor	2SC4116
Q	2231	(B,70,33) Transistor	LSA1576UB
Q	2242	(A,75,96) Transistor	UMD3N
Q	2276	(A,37,69) Transistor	LTC114EUB
Q	2303	(A,38,31) Transistor	LSA1576UB
Q	2491	(A,13,36) Transistor	DTC114WK
Q	2492	(A,16,44) Transistor	LTC114EUB
Q	2505	(A,75,58) Transistor(UC)	UMH1N
Q	2506	(A,77,62) Transistor(UC)	UMH1N
Q	2512	(B,24,127) Transistor	LSA1576UB
Q	2513	(B,25,119) Digital Transistor	DTC144EUA
Q	2514	(B,24,122) Digital Transistor	DTC144EUA
Q	2515	(B,23,117) Transistor(UC)	LTC114EUB
Q	2531	(A,63,91) Transistor	LSC4081UB
Q	2551	(A,143,8) Transistor	IMH23
Q	2552	(A,134,8) Transistor	UMD3N
Q	2642	(B,144,81) Transistor	UMD3N
Q	2644	(B,140,81) Transistor	DTC323TU
Q	2731	(A,124,70) Transistor	LSC4081UB
Q	2732	(A,123,66) Transistor	LSA1576UB
Q	2761	(B,143,70) Transistor	FMG12
Q	2762	(A,137,60) Transistor	UMD3N
Q	2831	(B,118,101) Transistor	FMG12
Q	2841	(A,123,96) Transistor	FMG12
Q	2842	(A,110,99) Transistor	FMG12
D	2001	(A,35,109) Diode	ST70-27F
D	2026	(B,75,91) Diode	KS926S2
D	2027	(B,80,85) Diode	RB160M-30
D	2028	(B,70,90) Diode	1SR154-400
D	2029	(B,49,79) Diode	RB500V-40
D	2031	(B,43,82) Diode	RB500V-40
D	2032	(B,42,82) Diode	HZU7R5(B3)
D	2033	(B,50,79) Diode	RB500V-40
D	2034	(B,46,80) Diode	EDZ20(B)

Circuit Symbol and No.			Part No.
D	2041	(A,53,122) Diode	1SR154-400
D	2042	(A,54,117) Diode	HZU8R2(B1)
D	2046	(B,19,129) Diode	1SR154-400
D	2151	(A,95,21) Diode	RB160M-40
D	2152	(A,97,14) Diode	1SS352
D	2160	(A,66,22) Diode	RB051LA-40
D	2162	(A,95,49) Diode	RB050L-40
D	2181	(B,91,35) Diode	HZU9R1(B2)
D	2216	(B,31,110) Diode	1SR154-400
D	2217	(B,28,110) Diode	1SR154-400
D	2227	(B,61,140) Diode	UDZS18(B)
D	2228	(A,22,48) Diode	UDZS5R6(B)
D	2229	(A,29,47) Diode	RB715W
D	2231	(A,62,117) Diode	PTZ18A
D	2232	(B,67,31) Diode	1SS352
D	2236	(B,68,119) Diode	1SR154-400
D	2237	(B,67,115) Diode	MALS180X
D	2239	(B,121,116) Diode	PTZ27(B)
D	2240	(B,112,109) Diode	1SS355
D	2241	(A,69,100) Diode	1SS352
D	2432	(A,57,57) Diode	RB501V-40
D	2433	(A,54,60) Diode	RB751S-40
D	2491	(A,14,50) Diode	1SS352
D	2519	(B,32,127) Diode	UDZS18(B)
D	2520	(B,35,127) Diode	UDZS18(B)
D	2521	(A,24,131) Diode	1SR154-400
D	2522	(A,19,130) Diode	1SR154-400
D	2527	(B,28,122) Diode	UDZS18(B)
D	2531	(A,64,100) Diode	UDZS8R2(B)
D	2552	(A,138,8) Diode	DAP202U
D	2621	(A,100,62) Diode	EDZ4R3(B)
D	2622	(A,104,68) Diode	1SS352
D	2641	(B,146,89) Diode	HZU6R8(B1)
D	2644	(B,146,75) Diode	RB715Z
D	2761	(A,144,68) Diode	DAP202U
D	2762	(A,141,61) Diode	DAP202U
D	2841	(B,110,103) Diode	DAP202U
D	2862	(A,135,117) Diode	MALS180X
D	2865	(A,138,117) Diode	MALS180X
D	2870	(B,106,120) Diode	UDZS18(B)
D	2871	(B,118,140) Diode	UDZS18(B)
D	2872	(B,111,116) Diode	1SS352
D	2873	(B,118,116) Diode	PTZ27(B)
D	2874	(B,123,140) Diode	UDZS18(B)
D	2880	(B,9,126) Diode	MALS180X
D	2881	(B,8,126) Diode	MALS180X
L	2001	(A,54,109) Choke Coil 600 uH	CTH1347
L	2151	(A,91,22) Inductor	CTF1744
L	2152	(A,101,18) Inductor	BTH1112
L	2161	(A,85,18) Inductor	CTH1257
L	2162	(A,100,39) Inductor	CTH1254
L	2181	(A,90,28) Inductor	CTF1473
L	2182	(A,91,33) Choke Coil 22 uH	CTH1426
L	2183	(A,105,33) Inductor	CTF1389
L	2226	(B,55,137) Inductor	CTF1410

Circuit Symbol and No.			Part No.
L	2236	(B,62,137) Inductor	CTF1410
L	2239	(B,115,112) Inductor	CTF1556
L	2302	(A,47,70) Inductor	LCTAW2R2J2520
L	2303	(A,43,32) Inductor	CTF1306
L	2311	(A,67,56) Inductor	CTF1305
L	2331	(A,70,47) Inductor	CTF1305
L	2351	(A,66,38) Inductor	CTF1305
L	2371	(A,57,36) Inductor	CTF1305
L	2411	(A,45,59) Inductor	CTF1305
L	2421	(A,43,59) Inductor	CTF1305
L	2461	(A,65,70) Inductor	CTF1305
L	2491	(A,17,38) Inductor	CTF1334
L	2492	(A,16,41) Inductor	CTF1334
L	2511	(A,19,115) Inductor	CTF1410
L	2530	(A,39,38) Inductor	CTF1410
L	2531	(A,56,47) Inductor	CTF1410
L	2553	(B,112,16) Inductor	CTF1488
L	2554	(B,114,21) Inductor	CTF1410
L	2571	(B,19,36) Inductor	CTF1306
L	2622	(A,96,64) Inductor	CTF1410
L	2641	(A,145,100) Inductor	CTF1410
L	2661	(A,135,52) Chip Coil	LCTAW100J2520
L	2662	(A,120,44) Chip Coil	LCTAW100J2520
L	2731	(A,129,62) Inductor	CTF1473
L	2771	(A,110,80) Inductor	LCTAW2R2J2520
L	2861	(B,112,116) Inductor	LCTC2R2K1608
L	2880	(A,7,121) Inductor	CTF1334
L	2881	(A,12,123) Inductor	CTF1334
L	2889	(A,136,20) Inductor	CTF1410
X	2301	(B,59,68) Oscillator 15 000 kHz	CSS1781
F	2161	(A,72,19) EMI Filter	CCG1267
F	2861	(B,134,115) EMI Filter	CCG1082
F	2868	(B,128,115) EMI Filter	CCG1082
VR	2731	(A,116,69) Semi-fixed 1 kohm(B)	CCP1442
⚠P	2107	(A,38,24) Fuse 250 mA	CEK1276
⚠P	2151	(A,10,66) Fuse 1 A	CEK1254
⚠P	2161	(A,41,92) Fuse 3.15 A	CEK1259
⚠P	2162	(A,120,24) Fuse 1.5 A	CEK1282
⚠P	2176	(A,112,27) Fuse 0.5 A	CEK1278
⚠P	2861	(B,125,134) Poly Switch	MINISMDC075F/24
⚠P	2862	(B,141,140) Poly Switch	MINISMDC075F/24
⚠P	2863	(B,131,137) Poly Switch	MINISMDC075F/24
⚠P	2864	(B,135,137) Poly Switch	MINISMDC075F/24
⚠P	2880	(A,19,136) Poly Switch	MINISMDC075F/24
VA	2861	(B,128,133) Varistor	AVR-M1608C270KT2AB
VA	2862	(B,130,133) Varistor	AVR-M1608C270KT2AB
VA	2863	(B,125,116) Varistor	AVR-M1608C270KT2AB
VA	2864	(B,126,116) Varistor	AVR-M1608C270KT2AB
CN	2101	(A,135,35) Connector	CKS5546
CN	2512	(A,32,143) Connector	CKS6155
CN	2551	(B,129,8) Connector	VKN1620
CN	2571	(B,27,53) Connector	CKS6124
CN	2861	(A,130,139) Plug	CKM1567
JA	2001	(A,56,136) Plug	CKM1550
JA	2880	(A,12,132) Jack	CKN1042
U	2511	(A,8,58) Remote IC(AU)	RS-750
		FM/AM Tuner Unit(UC)	CWE2097
		FM/AM Tuner Unit(AU)	CWE2128

RESISTORS

Circuit Symbol and No.			Part No.
R	2021	(B,64,96)	RS1/4S4R7J
R	2022	(B,61,96)	RS1/4S4R7J
R	2023	(B,66,91)	RS1/10SR473J
R	2026	(B,80,89)	RS1/4S4R7J
R	2027	(B,80,95)	RS1/4S4R7J
R	2028	(B,75,85)	RS1/10SR473J
R	2031	(B,39,84)	RS1/10SR473J
R	2032	(B,37,82)	RS1/10SR473J
R	2033	(B,43,80)	RS1/10SR103J
R	2034	(B,41,89)	RS1/10SR103J
R	2041	(B,48,139) 4.7 kohm	CCN1180
R	2042	(B,48,142) 1 kohm	CCN1179
R	2043	(A,51,118)	RS1/10SR473J
R	2044	(A,50,118)	RS1/10SR473J
R	2046	(B,52,140) 1 kohm	CCN1179
R	2047	(B,18,126) 4.7 kohm	CCN1180
R	2048	(B,14,129)	RS1/10SR103J
R	2056	(B,70,82)	RS1/16SS472J
R	2066	(B,13,31)	RS1/16SS472J
R	2067	(B,11,29)	RS1/16SS472J
R	2068	(B,11,35)	RS1/16SS104J
R	2071	(A,30,39)	RS1/16SS222J
R	2072	(A,31,36)	RS1/16SS222J
R	2073	(A,33,34)	RS1/16SS473J
R	2074	(A,22,35)	RS1/10SR0R0J
R	2075	(A,138,10)	RS1/16SS0R0J
R	2083	(A,139,111)	RS1/10SR0R0J
R	2084	(A,136,27)	RS1/10SR0R0J
R	2085	(B,34,31)	RS1/16SS0R0J
R	2101	(A,127,29)	RS1/16SS102J
R	2102	(A,115,50)	RS1/16SS102J
R	2105	(B,123,29)	RS1/16SS473J
R	2106	(B,122,28)	RS1/16SS102J
R	2121	(B,19,108)	RS1/16SS473J
R	2128	(B,19,111)	RS1/16SS332J
R	2131	(B,17,90)	RS1/16SS473J
R	2136	(B,17,92)	RS1/16SS332J
R	2151	(B,98,14)	RS1/16SS223J
R	2152	(B,93,14)	RS1/16SS2002D
R	2153	(B,98,15)	RS1/16SS0R0J
R	2154	(B,96,15)	RS1/10SR1303D
R	2155	(B,94,15)	RS1/16SS2402D
R	2161	(B,90,43)	RS1/10SR1003D
R	2162	(B,90,44)	RS1/10SR1002D
R	2163	(B,96,45)	RS1/10SR333J
R	2164	(B,98,46)	RS1/10SR0R0J
R	2165	(B,98,48)	RS1/10SR6802D
R	2166	(B,95,48)	RS1/10SR3001D
R	2167	(B,93,47)	RS1/10SR1002D
R	2181	(B,89,32)	RS1/16SS122J
R	2182	(B,99,33)	RS1/16SS1003D
R	2183	(B,98,33)	RS1/16SS1603D
R	2185	(B,97,32)	RS1/16SS1202D
R	2186	(B,96,31)	RS1/16SS1102D
R	2187	(B,101,31)	RS1/10SR473J
R	2188	(A,110,43)	RS1/16SS5601D
R	2189	(A,110,42)	RS1/16SS6801D
R	2190	(B,140,31)	RS1/16SS5601D
R	2191	(B,140,30)	RS1/10SR6201D
R	2193	(B,137,30)	RS1/10SR1801D
R	2211	(B,34,112)	RS1/10SR0R0J
R	2226	(B,58,137) 1 kohm	CCN1179
R	2227	(B,57,140)	RS1/10SR472J
R	2228	(B,57,141)	RS1/10SR102J
R	2229	(A,25,48)	RS1/16SS104J
R	2230	(A,25,47)	RS1/16SS473J
R	2231	(A,60,122) 10 kohm	CCN1191
R	2232	(B,71,35)	RS1/16SS153J
R	2233	(B,69,36)	RS1/16SS103J
R	2234	(B,68,35)	RS1/16SS102J
R	2239	(B,114,108)	RS1/8SQ103J
R	2241	(A,72,98)	RS1/16SS391J
R	2242	(A,72,97)	RS1/16SS391J
R	2243	(A,73,95)	RS1/16SS102J
R	2251	(B,90,51)	RS1/10SR102J
R	2276	(A,39,72)	RS1/16SS103J
R	2277	(A,39,70)	RS1/16SS103J
R	2301	(A,59,53)	RS1/16SS104J
R	2302	(A,62,50)	RS1/16SS0R0J
R	2304	(A,45,39)	RS1/16SS473J
R	2305	(A,41,37)	RS1/16SS473J
R	2310	(B,55,67)	RS1/16SS102J
R	2311	(A,69,51)	RS1/16SS104J
R	2312	(B,72,51)	RS1/16SS472J
R	2313	(B,72,52)	RS1/16SS472J
R	2314	(A,70,56)	RS1/16SS473J
R	2315	(B,67,61)	RS1/16SS471J
R	2316	(B,68,60)	RS1/16SS471J
R	2317	(B,73,59)	RS1/16SS681J
R	2327	(B,71,53)	RS1/16SS471J
R	2328	(B,68,53)	RS1/16SS681J
R	2329	(B,68,52)	RS1/16SS101J
R	2331	(B,70,51)	RS1/16SS221J
R	2332	(A,64,49)	RS1/16SS102J
R	2336	(B,71,46)	RS1/16SS102J
R	2337	(B,68,45)	RS1/16SS102J
R	2341	(B,68,43)	RS1/16SS681J
R	2344	(B,68,40)	RS1/16SS471J
R	2348	(B,70,38)	RS1/16SS473J
R	2351	(B,62,35)	RS1/16SS104J
R	2353	(B,67,37)	RS1/16SS0R0J
R	2355	(B,63,35)	RS1/16SS102J
R	2356	(B,62,38)	RS1/16SS102J
R	2357	(A,60,40)	RS1/16SS221J
R	2359	(A,36,36)	RS1/10SR472J
R	2360	(A,36,31)	RS1/10SR473J
R	2365	(B,58,36)	RS1/16SS473J
R	2366	(B,57,36)	RS1/16SS473J
R	2367	(A,55,39)	RS1/16SS104J
R	2368	(B,55,34)	RS1/16SS221J

Circuit Symbol and No.	Part No.
R 2369 (B,56,36)	RS1/16SS104J
R 2372 (B,54,34)	RS1/16SS221J
R 2375 (B,52,36)	RS1/16SS681J
R 2376 (A,54,41)	RS1/16SS681J
R 2377 (A,52,36)	RS1/16SS681J
R 2378 (A,49,37)	RS1/16SS681J
R 2379 (A,48,43)	RS1/16SS102J
R 2381 (B,44,33)	RS1/16SS151J
R 2382 (B,44,34)	RS1/16SS151J
R 2384 (B,48,37)	RS1/16SS221J
R 2385 (B,47,37)	RS1/16SS221J
R 2386 (A,48,37)	RS1/16SS681J
R 2387 (B,42,37)	RS1/16SS102J
R 2388 (B,37,36)	RS1/16SS221J
R 2390 (B,40,36)	RS1/16SS104J
R 2391 (B,47,35)	RS1/16SS104J
R 2392 (B,46,36)	RS1/16SS104J
R 2394 (B,42,39)	RS1/16SS102J
R 2395 (B,42,41)	RS1/16SS102J
R 2396 (B,41,41)	RS1/16SS102J
R 2397 (B,41,42)	RS1/16SS102J
R 2398 (B,42,43)	RS1/16SS471J
R 2401 (B,40,46)	RS1/16SS681J
R 2403 (B,36,42)	RS1/16SS681J
R 2404 (B,38,49)	RS1/16SS104J
R 2405 (B,37,50)	RS1/10SR104J
R 2406 (B,38,51)	RS1/16SS104J
R 2407 (B,36,51)	RS1/16SS221J
R 2410 (B,42,54)	RS1/16SS0R0J
R 2411 (B,42,52)	RS1/16SS681J
R 2413 (A,45,55)	RS1/16SS681J
R 2414 (A,44,53)	RS1/16SS681J
R 2415 (A,48,51)	RS1/16SS104J
R 2417 (A,60,60)	RS1/16SS102J
R 2419 (A,52,59)	RS1/16SS102J
R 2420 (B,40,63)	RS1/16SS681J
R 2421 (B,39,63)	RS1/16SS681J
R 2423 (B,40,61)	RS1/16SS470J
R 2424 (B,39,46)	RS1/16SS473J
R 2427 (A,40,63)	RS1/10SR392J
R 2428 (A,39,63)	RS1/10SR392J
R 2429 (A,45,56)	RS1/16SS104J
R 2431 (B,37,62)	RS1/16SS182J
R 2432 (A,54,57)	RS1/16SS103J
R 2433 (A,53,57)	RS1/16SS103J
R 2435 (B,37,64)	RS1/16SS182J
R 2436 (B,41,63)	RS1/16SS470J
R 2437 (B,44,61)	RS1/16SS473J
R 2439 (B,45,64) (AU)	RS1/16SS102J
R 2444 (A,42,62)	RS1/16SS473J
R 2446 (B,50,64)	RS1/16SS471J
R 2451 (B,45,67)	RS1/16SS104J
R 2452 (B,46,70)	RS1/16SS472J
R 2453 (B,54,64)	RS1/16SS102J
R 2458 (A,54,63)	RS1/16SS473J
R 2460 (B,57,65)	RS1/16SS561J

Circuit Symbol and No.	Part No.
R 2461 (B,64,66)	RS1/16SS473J
R 2463 (A,31,48)	RS1/16SS104J
R 2473 (B,64,63)	RS1/16SS561J
R 2477 (A,46,37)	RS1/16SS104J
R 2491 (A,9,38)	RS1/16SS104J
R 2492 (A,11,38)	RS1/16SS473J
R 2493 (A,13,38)	RS1/16SS563J
R 2494 (A,7,44)	RS1/16SS513J
R 2495 (A,10,49)	RS1/16SS104J
R 2496 (A,11,49)	RS1/16SS513J
R 2497 (A,12,48)	RS1/16SS513J
R 2498 (A,12,51)	RS1/16SS102J
R 2499 (A,10,50)	RS1/16SS102J
R 2500 (A,13,49)	RS1/16SS564J
R 2501 (A,16,49)	RS1/16SS202J
R 2502 (A,17,49)	RS1/16SS822J
R 2503 (A,16,48)	RS1/16SS203J
R 2504 (A,18,48)	RS1/16SS333J
R 2507 (A,72,59) (UC)	RS1/10SR223J
R 2508 (A,75,60) (UC)	RS1/16SS223J
R 2509 (A,73,62) (UC)	RS1/10SR223J
R 2511 (A,19,109)	RS1/10SR105J
R 2513 (B,27,127)	RS1/10SR473J
R 2514 (B,26,129)	RS1/10SR473J
R 2520 (A,31,132)	RS1/8SQ102J
R 2521 (A,33,132)	RS1/8SQ102J
R 2522 (A,35,132)	RS1/8SQ102J
R 2524 (A,7,50) (AU)	RS1/10SR470J
R 2527 (A,29,132)	RS1/8SQ102J
R 2529 (A,43,48)	RS1/16SS104J
R 2530 (B,72,46)	RS1/16SS104J
R 2531 (A,57,46)	RS1/16SS104J
R 2532 (A,60,44)	RS1/16SS104J
R 2533 (A,61,94)	RS1/10SR473J
R 2534 (A,62,42)	RS1/16SS104J
R 2535 (A,63,45)	RS1/16SS104J
R 2536 (A,57,52)	RS1/16SS104J
R 2537 (B,39,43)	RS1/16SS104J
R 2538 (A,66,94)	RS1/10SR104J
R 2539 (A,43,43)	RS1/16SS104J
R 2540 (A,19,118) (UC)	RS1/10SR0R0J
R 2541 (A,19,119) (AU)	RS1/10SR0R0J
R 2543 (B,18,115) (UC)	RS1/10SR104J
R 2551 (B,142,18)	RS1/10SR182J
R 2552 (B,144,20)	RS1/10SR104J
R 2553 (B,144,17)	RS1/10SR104J
R 2554 (B,142,20)	RS1/10SR182J
R 2555 (A,125,16)	RS1/10SR0R0J
R 2557 (B,120,20)	RS1/16SS471J
R 2558 (B,123,20)	RS1/16SS471J
R 2559 (A,122,12)	RS1/16SS471J
R 2560 (B,119,20)	RS1/16SS102J
R 2561 (B,121,20)	RS1/16SS221J
R 2562 (B,122,20)	RS1/16SS221J
R 2569 (A,28,66)	RS1/16SS0R0J
R 2570 (A,30,93)	RS1/16SS0R0J
R 2577 (B,36,55)	RS1/16SS221J

Circuit Symbol and No.	Part No.	Circuit Symbol and No.	Part No.
R 2621 (A,98,63)	RS1/16SS102J	R 2721 (B,114,64)	RS1/16SS101J
R 2623 (A,101,75)	RS1/16SS0R0J	R 2722 (B,114,69)	RS1/16SS101J
R 2624 (B,97,78)	RS1/16SS0R0J	R 2723 (B,135,63)	RS1/16SS221J
R 2628 (B,89,63)	RS1/10SR332J	R 2724 (B,135,64)	RS1/16SS221J
R 2629 (B,91,67)	RS1/10SR332J	R 2733 (A,127,67)	RS1/16SS223J
R 2630 (B,91,63)	RS1/10SR103J	R 2734 (A,127,69)	RS1/16SS303J
R 2631 (B,91,66)	RS1/10SR103J	R 2735 (A,122,70)	RS1/10SR681J
R 2632 (B,105,60)	RS1/10SR102J	R 2736 (A,120,70)	RS1/10SR102J
R 2633 (B,100,61)	RS1/10SR104J	R 2737 (A,120,67)	RS1/10SR821J
R 2634 (B,104,66)	RS1/10SR104J	R 2738 (A,123,62)	RS1/10SR681J
R 2635 (B,104,63)	RS1/10SR683J	R 2740 (A,129,64)	RS1/10SR0R0J
R 2636 (B,102,64)	RS1/10SR473J	R 2750 (A,145,77)	RS1/10SR75R0D
R 2641 (B,132,84)	RS1/10SR473J	R 2761 (B,141,68)	RS1/16SS821J
R 2642 (B,139,84)	RS1/10SR473J	R 2762 (B,146,67)	RS1/16SS821J
R 2643 (B,133,84)	RS1/10SR683J	R 2763 (B,141,69)	RS1/16SS223J
R 2644 (B,138,84)	RS1/10SR683J	R 2764 (B,146,69)	RS1/16SS223J
R 2645 (B,133,86)	RS1/10SR473J	R 2772 (A,91,82)	RS1/10SR0R0J
R 2646 (B,139,86)	RS1/10SR473J	R 2773 (B,112,71)	RS1/10SR102J
R 2647 (B,130,92)	RS1/10SR473J	R 2774 (B,112,91)	RS1/10SR102J
R 2648 (B,142,92)	RS1/10SR473J	R 2777 (A,124,86)	RS1/10SR472J
R 2649 (B,130,87)	RS1/10SR473J	R 2778 (A,124,87)	RS1/10SR472J
R 2650 (B,142,87)	RS1/10SR473J	R 2779 (A,118,85)	RS1/10SR472J
R 2652 (B,144,84)	RS1/10SR0R0J	R 2780 (A,118,86)	RS1/10SR472J
R 2653 (B,147,94)	RS1/10SR302J	R 2781 (A,118,84)	RS1/10SR472J
R 2654 (B,146,94)	RS1/10SR302J	R 2782 (A,124,90)	RS1/10SR472J
R 2656 (A,145,97)	RS1/10SR0R0J	R 2788 (A,110,76)	RS1/10SR0R0J
R 2658 (B,136,75)	RS1/10SR821J	R 2811 (B,133,95)	RS1/10SR272J
R 2660 (B,141,79)	RS1/16SS104J	R 2812 (B,141,95)	RS1/10SR272J
R 2664 (B,134,76)	RS1/16SS0R0J	R 2813 (B,132,95)	RS1/10SR272J
R 2673 (B,144,63)	RS1/10SR101J	R 2814 (B,139,95)	RS1/10SR272J
R 2683 (B,143,50)	RS1/16SS101J	R 2815 (B,126,84)	RS1/10SR272J
R 2684 (B,143,49)	RS1/16SS101J	R 2816 (B,126,86)	RS1/10SR272J
R 2685 (B,145,47)	RS1/16SS750J	R 2817 (B,126,82)	RS1/10SR272J
R 2688 (B,142,44)	RS1/16SS101J	R 2818 (B,126,88)	RS1/10SR272J
R 2694 (B,144,24)	RS1/8SQ0R0J	R 2831 (B,121,98)	RS1/10SR390J
R 2695 (B,119,36)	RS1/16SS472J	R 2832 (B,115,98)	RS1/10SR390J
R 2696 (B,116,40)	RS1/16SS472J	R 2835 (B,121,99)	RS1/10SR223J
R 2697 (B,121,36)	RS1/16SS472J	R 2836 (B,115,99)	RS1/10SR223J
R 2698 (B,116,37)	RS1/16SS472J	R 2841 (A,127,95)	RS1/10SR390J
R 2699 (B,121,34)	RS1/16SS101J	R 2842 (A,120,95)	RS1/10SR390J
R 2700 (B,115,37)	RS1/16SS101J	R 2843 (A,114,97)	RS1/10SR390J
R 2701 (B,122,34)	RS1/16SS101J	R 2844 (A,107,97)	RS1/10SR390J
R 2702 (B,113,37)	RS1/16SS101J	R 2849 (A,127,96)	RS1/10SR223J
R 2703 (B,121,35)	RS1/16SS123J	R 2850 (A,120,96)	RS1/10SR223J
R 2704 (B,115,36)	RS1/16SS123J	R 2851 (A,114,99)	RS1/10SR223J
R 2705 (B,114,46)	RS1/16SS102J	R 2852 (A,107,99)	RS1/10SR223J
R 2706 (B,113,44)	RS1/16SS102J	R 2867 (B,110,119)	RS1/8SQ102J
R 2707 (B,114,45)	RS1/16SS102J	R 2868 (B,120,136)	RS1/8SQ102J
R 2708 (B,113,43)	RS1/16SS102J	R 2869 (B,114,115)	RS1/8SQ153J
R 2709 (B,117,46)	RS1/16SS473J	R 2870 (A,133,105)	RS1/16SS750J
R 2710 (B,117,43)	RS1/16SS473J	R 2871 (A,129,105)	RS1/16SS750J
R 2717 (B,113,61)	RS1/16SS101J	R 2873 (A,110,115)	RS1/10SR0R0J
R 2718 (B,114,67)	RS1/16SS101J	R 2874 (B,122,136)	RS1/8SQ102J
R 2719 (B,113,62)	RS1/16SS223J	R 2875 (B,132,115)	RS1/8SQ0R0J
R 2720 (B,113,66)	RS1/16SS223J	R 2876 (B,130,115)	RS1/8SQ0R0J

Circuit Symbol and No.			Part No.
R	2880	(B,139,115)	RS1/8SQ0R0J
R	2881	(A,98,100)	RS1/10SR0R0J
R	2889	(A,141,10)	RS1/10SR473J
R	2890	(A,141,25)	RS1/10SR473J
R	2891	(A,136,13)	RS1/10SR473J
R	2892	(A,138,25)	RS1/10SR473J
R	2893	(A,141,11)	RS1/10SR363J
R	2894	(A,141,24)	RS1/10SR363J
R	2895	(A,135,15)	RS1/10SR363J
R	2896	(A,138,24)	RS1/10SR363J
R	2993	(A,8,26) (AU)	RS1/16SS332J
R	2995	(A,8,23) (UC)	RS1/16SS333J
R	2997	(A,8,20)	RS1/16SS0R0J

CAPACITORS

C	2001	(A,75,106) 3 300 uF/16 V	CCH1928(P35)
C	2007	(B,50,122)	CKSRYB392K50
C	2027	(A,86,93) 10 000 uF/16 V	CCH1849(P35)
C	2028	(A,52,92)	CEAT472M16(P35)
C	2029	(B,75,84)	CKSRYB104K50
C	2041	(A,54,120)	CKSRYB104K50
C	2042	(A,55,119)	CKSSYB102K50
C	2046	(B,18,125)	CKSRYB102K50
C	2047	(B,14,126)	CKSQYB105K16
C	2051	(B,62,91)	CKSYB105K35
C	2052	(B,67,84)	CKSSYB103K16
C	2053	(A,70,80)	CEVW101M16
C	2056	(B,67,82)	CKSRYB105K16
C	2057	(B,66,76)	CKSRYB105K16
C	2058	(A,61,81)	CEVW101M16
C	2101	(A,145,29)	CKSSYB103K16
C	2121	(B,19,103)	CKSRYB104K50
C	2122	(B,18,108)	CKSSYB223K16
C	2123	(A,21,103) 100 uF/16 V	CCH1565
C	2124	(A,17,104)	CKSSYB102K50
C	2131	(B,18,86)	CKSRYB104K50
C	2132	(B,16,90)	CKSSYB223K16
C	2133	(A,17,84)	CKSSYB102K50
C	2134	(A,20,90) 100 uF/16 V	CCH1565
C	2151	(A,93,22)	CKSYB225K25
C	2153	(B,100,14)	CCSRCH151J50
C	2154	(A,97,18)	CKSRYB104K16
C	2155	(B,95,14)	CCSSCH221J50
C	2156	(A,103,23) 22 uF	CCG1183
C	2161	(A,85,27) 100 uF/16 V	CCH1565
C	2162	(A,84,32) 10 uF	CCG1223
C	2163	(A,84,35) 10 uF	CCG1223
C	2167	(B,92,43)	CKSSYB104K16
C	2169	(B,95,43)	CKSRYB104K50
C	2170	(A,101,48) 100 uF/16 V	CCH1565
C	2172	(B,101,53) 10 uF	CCG1223
C	2173	(A,124,26)	CKSYB475K16
C	2181	(B,88,27)	CKSYB475K25
C	2182	(B,91,33)	CKSRYB104K16
C	2183	(A,92,28)	CKSRYB104K16

Circuit Symbol and No.			Part No.
C	2184	(A,93,29)	CKSYB475K16
C	2185	(B,98,31)	CCSRCH220J50
C	2186	(A,100,29)	CKSSYB473K10
C	2187	(A,102,31)	CKSQYB105K25
C	2188	(A,110,41)	CKSSYB103K25
C	2189	(A,109,43)	CKSSYB103K25
C	2191	(B,133,33)	CKSQYB105K25
C	2192	(B,138,31)	CKSSYB103K25
C	2193	(B,142,35)	CKSSYB103K25
C	2194	(B,104,33)	CKSSYB103K25
C	2195	(B,109,31)	CKSSYB103K25
C	2216	(B,34,110)	CKSRYB102K50
C	2226	(B,55,140)	CKSRYB102K50
C	2227	(B,59,141)	CKSSYB102K50
C	2232	(A,62,120)	CKSRYB103K50
C	2238	(B,115,111)	CKSRYB103K50
C	2241	(A,72,90) Capacitor	CEVW470M16
C	2276	(A,43,77) Capacitor	CEHVW330M10
C	2281	(A,96,127)	CKSRYB105K16
C	2282	(A,90,127)	CKSRYB105K16
C	2283	(A,80,126)	CKSRYB105K16
C	2284	(A,86,126)	CKSRYB105K16
C	2285	(A,95,124)	CKSQYB105K16
C	2286	(A,90,124)	CKSQYB105K16
C	2287	(A,81,124)	CKSQYB105K16
C	2288	(A,86,124)	CKSQYB105K16
C	2289	(B,97,121)	CKSRYB104K50
C	2290	(B,97,123)	CKSRYB104K50
C	2292	(A,103,126)	CKSQYB475K10
C	2293	(A,100,124)	CKSYB475K16
C	2294	(A,104,119) Capacitor	CEHVW100M16
C	2302	(A,52,71)	CEVW100M16
C	2303	(A,49,70)	CKSRYB102K50
C	2304	(A,43,34)	CKSRYB104K16
C	2306	(A,60,50)	CKSRYB153K50
C	2307	(A,60,55)	CKSRYB104K16
C	2311	(B,71,61)	CCSSCH101J50
C	2321	(B,68,58)	CKSRYB103K50
C	2331	(B,68,48)	CKSRYB103K50
C	2351	(B,65,38)	CKSRYB103K50
C	2352	(B,61,35)	CCSSCH101J50
C	2355	(A,61,38)	CKSSYB103K16
C	2374	(B,54,37)	CKSRYB103K50
C	2411	(B,43,53)	CKSRYB103K50
C	2412	(A,44,51)	CKSSYB103K16
C	2413	(B,53,37)	CKSSYB104K16
C	2414	(A,48,53)	CKSSYB103K16
C	2415	(A,45,52)	CKSSYB103K16
C	2416	(A,52,55)	CKSSYB103K16
C	2417	(A,47,57)	CKSSYB103K16
C	2418	(B,41,56)	CKSSYB103K16
C	2419	(A,49,59)	CKSSYB103K16
C	2420	(B,42,57)	CKSRYB105K10
C	2424	(B,42,59)	CKSRYB103K50
C	2430	(B,36,60)	CCSSCH470J50

Circuit Symbol and No.			Part No.
C	2431	(A,58,56)	CKSSYB104K16
C	2432	(A,52,57)	CKSSYB104K16
C	2434	(B,46,67)	CCSSCH331J50
C	2435	(B,41,65)	CCSSCH470J50
C	2436	(A,44,67)	CCSSCH151J50
C	2437	(B,44,66)	CCSSCH471J16
C	2438	(A,50,67)	CKSSYB103K16
C	2450	(B,49,68)	CKSQYB475K10
C	2459	(B,55,70)	CKSRYB104K16
C	2460	(B,59,65)	CCSSCH100D50
C	2461	(B,61,65)	CCSSCH100D50
C	2462	(B,58,64)	CKSRYB103K50
C	2464	(A,59,61)	CKSRYB105K10
C	2491	(A,14,41)	CKSRYB104K16
C	2492	(A,10,48)	CKSSYB102K50
C	2493	(A,14,47)	CKSRYB104K16
C	2494	(A,16,47)	CKSRYB103K50
C	2495	(A,14,44)	CKSRYB823K16
C	2510	(A,23,128)	CKSRYB102K50
C	2511	(A,19,112)	CKSRYB104K16
C	2512	(A,23,127)	CKSSYB103K25
C	2513	(B,30,127)	CKSRYB103K50
C	2516	(A,7,52) (AU)	CKSRYB104K50
C	2517	(B,22,121) (UC)	CKSSYB104K10
C	2518	(A,20,122)	CKSRYB104K50
C	2527	(B,27,124)	CKSRYB103K50
C	2530	(A,38,41)	CKSRYB104K16
C	2531	(A,56,50)	CKSRYB104K16
C	2551	(B,146,17)	CCSRCH101J50
C	2552	(B,146,20)	CCSRCH101J50
C	2557	(B,116,14)	CKSRYB104K16
C	2558	(B,120,14)	CKSRYB104K16
C	2559	(B,120,16)	CKSQYB475K10
C	2561	(B,116,20)	CKSRYB104K16
C	2563	(B,116,18) 10 uF	CCG1236
C	2564	(B,116,21) 10 uF	DCH1201
C	2565	(A,115,18) Capacitor	CEVW220M16
C	2572	(B,18,36)	CKSRYB104K16
C	2590	(B,18,46)	CCSSCH101J50
C	2621	(A,90,62)	CEVW101M16
C	2622	(A,101,63)	CKSSYB103K16
C	2623	(A,104,64)	CEVW100M16
C	2624	(A,104,71)	CKSSYB104K16
C	2625	(B,98,71) 10 uF	DCH1201
C	2626	(B,94,71) 10 uF	DCH1201
C	2627	(B,91,65)	CCSRCH221J50
C	2628	(B,92,63)	CCSRCH221J50
C	2629	(B,97,62)	CKSSYB104K16
C	2630	(B,104,60)	CKSRYB103K50
C	2631	(B,104,64)	CKSRYB104K16
C	2632	(B,102,66)	CCSRCH151J50
C	2633	(B,101,63)	CCSRCH151J50
C	2641	(B,130,81)	CKSQYB475K10
C	2642	(B,135,80)	CKSQYB475K10
C	2643	(B,132,81)	CKSRYB105K10
C	2644	(B,134,81)	CKSRYB105K10

Circuit Symbol and No.			Part No.
C	2645	(B,131,86)	CCSSCH220J50
C	2646	(B,141,87)	CCSSCH220J50
C	2647	(B,131,92)	CCSSCH220J50
C	2648	(B,141,92)	CCSSCH220J50
C	2649	(B,136,93)	CKSRYB104K50
C	2651	(B,146,84) 10 uF	CCG1236
C	2652	(B,148,89)	CKSRYB103K50
C	2653	(B,107,64)	CKSQYB225K10
C	2661	(A,139,46) Capacitor	CEVW470M16
C	2662	(B,135,43)	CKSRYB104K16
C	2663	(B,133,42)	CKSYB226K6R3
C	2664	(B,132,45)	CKSSYB104K16
C	2665	(B,139,59)	CKSSYB104K16
C	2666	(B,140,59)	CKSSYB104K16
C	2667	(B,141,59)	CKSRYB105K10
C	2668	(B,141,56)	CKSRYB105K10
C	2671	(B,141,52)	CKSRYB105K10
C	2672	(B,141,50)	CKSRYB105K10
C	2673	(B,141,49)	CKSRYB105K10
C	2674	(B,141,48)	CKSRYB105K10
C	2675	(B,140,44)	CKSRYB105K10
C	2676	(B,140,43)	CKSRYB105K10
C	2679	(B,138,53)	CKSSYB104K16
C	2680	(B,138,55)	CKSSYB104K16
C	2685	(B,127,36)	CKSQYB475K10
C	2686	(B,114,40)	CKSQYB475K10
C	2687	(B,125,36)	CKSQYB475K10
C	2688	(B,113,40)	CKSQYB475K10
C	2689	(B,116,48)	CKSQYB475K10
C	2690	(B,118,51)	CKSQYB475K10
C	2691	(B,118,50)	CKSQYB475K10
C	2692	(B,114,51)	CKSQYB475K10
C	2693	(B,112,55)	CKSQYB475K10
C	2694	(B,114,55)	CKSQYB475K10
C	2695	(B,118,54)	CKSQYB475K10
C	2696	(B,118,56)	CKSQYB475K10
C	2697	(B,117,62)	CKSQYB475K10
C	2698	(B,117,67)	CKSQYB475K10
C	2699	(B,117,64)	CKSQYB475K10
C	2700	(B,117,69)	CKSQYB475K10
C	2701	(A,127,46) Capacitor	CEVW470M16
C	2702	(B,125,44)	CKSRYB104K16
C	2703	(B,121,41)	CKSYB226K6R3
C	2705	(B,131,43)	CKSSYB104K16
C	2706	(B,129,43)	CKSSYB104K16
C	2707	(B,130,43)	CKSSYB104K16
C	2708	(B,128,43)	CKSSYB104K16
C	2713	(B,117,33)	CKSRYB102K50
C	2714	(B,118,39)	CKSRYB102K50
C	2715	(B,123,35)	CKSRYB102K50
C	2716	(B,115,34)	CKSRYB102K50
C	2725	(B,104,73)	CKSQYB475K10
C	2726	(B,104,90)	CKSQYB475K10
C	2733	(A,129,72) Capacitor	CEVW101M4
C	2734	(A,126,63)	CKSRYB105K16

Circuit Symbol and No.			Part No.
C	2743	(A,137,74)	CEVW101M16
C	2744	(A,137,67)	CEVQW221M6R3
C	2761	(B,138,72)	CKSQYB475K10
C	2762	(B,136,72)	CKSQYB475K10
C	2771	(A,106,83) Capacitor	CEVW470M16
C	2772	(B,104,83)	CKSSYB104K16
C	2774	(B,104,86)	CKSSYB104K16
C	2775	(A,114,88)	CEVW100M16
C	2779	(B,108,72)	CKSRYB105K10
C	2780	(B,108,91)	CKSRYB105K10
C	2781	(B,109,72)	CKSSYB104K16
C	2782	(B,109,90)	CKSSYB104K16
C	2785	(B,112,72)	CKSRYB105K10
C	2786	(B,114,91)	CKSRYB105K10
C	2787	(B,116,72)	CKSQYB475K10
C	2788	(B,115,91)	CKSQYB475K10
C	2789	(B,119,73)	CKSQYB475K10
C	2790	(B,118,91)	CKSQYB475K10
C	2791	(B,122,73)	CKSQYB475K10
C	2792	(B,120,91)	CKSQYB475K10
C	2799	(A,116,80)	CEVW100M16
C	2800	(B,121,79)	CKSSYB104K16
C	2801	(A,125,80) Capacitor	CEVW470M16
C	2831	(B,121,96) 10 uF	CCG1182
C	2832	(B,115,96) 10 uF	CCG1182
C	2841	(A,128,93) 10 uF	CCG1182
C	2842	(A,119,93) 10 uF	CCG1182
C	2843	(A,114,95) 10 uF	CCG1182
C	2844	(A,107,95) 10 uF	CCG1182
C	2864	(B,116,116)	CKSRYB102K50
C	2865	(B,121,140)	CKSRYB103K50
C	2874	(A,139,117)	CKSRYB392K50
C	2880	(A,15,123)	CKSSYB102K50
C	2881	(A,8,123)	CKSSYB102K50
C	2889	(A,145,18)	CKSQYB225K10
C	2890	(A,144,22)	CKSQYB225K10
C	2891	(A,145,15)	CKSQYB225K10
C	2892	(A,145,24)	CKSQYB225K10
C	2893	(A,142,13)	CCSRCH330J50
C	2894	(A,141,23)	CCSRCH330J50
C	2895	(A,136,15)	CCSRCH330J50
C	2896	(A,138,23)	CCSRCH330J50
C	2897	(A,137,19)	CKSSYB104K16
C	2965	(A,117,63) Capacitor	CEVW101M4

GF

Unit Number:CWN5271
Unit Name:Monitor Unit

MISCELLANEOUS

IC	3001	(B,109,29) IC	BD6171KV
IC	3102	(A,118,65) IC	BD8113EFV
IC	3150	(A,42,49) IC	DS90C124QVS
IC	3151	(A,32,49) IC	TC7SZ08FU
IC	3201	(A,31,61) IC	TC7S66FU
IC	3202	(A,25,55) IC	NJM082BV
IC	3203	(A,34,63) IC	TC7WT240FU
IC	3204	(B,61,39) Logic IC	TC74VHCT04AFTS1
IC	3300	(A,73,31) IC	BH2227AFV
IC	3360	(B,87,54) IC	AK4388VT
IC	3362	(B,83,36) IC	TC7SH08FUS1
Q	3001	(B,118,38) FET	RSQ035P03
Q	3002	(B,105,43) FET	RSQ035P03
Q	3003	(B,96,23) Transistor	2SA1577
Q	3004	(B,98,20) Transistor	2SC4097
Q	3005	(B,96,33) Transistor	DTC114EE
Q	3102	(B,104,67) Transistor	2SC4617
Q	3103	(B,100,70) Transistor	2SC4617
Q	3106	(A,132,64) FET	SP8K22
Q	3200	(A,20,47) Transistor	2SC4617
Q	3201	(A,27,50) Transistor	2SA1774
Q	3202	(A,28,46) Transistor	2SC4617
Q	3203	(A,23,50) Transistor	2SA1774
Q	3204	(A,26,69) Transistor	2SC4617
Q	3300	(A,76,19) Transistor	UMZ1N
Q	3301	(A,76,21) Transistor	UMZ1N
Q	3302	(A,67,17) Transistor	UMZ1N
Q	3303	(A,67,20) Transistor	UMZ1N
Q	3304	(A,67,26) Transistor	UMZ1N
Q	3305	(A,67,23) Transistor	UMZ1N
Q	3360	(B,86,33) Transistor	DTC114EE
D	3001	(B,121,39) Diode	RB160M-30
D	3002	(B,103,21) Diode	RB500V-40
D	3003	(B,107,21) Diode	RB500V-40
D	3004	(B,105,21) Diode	RB500V-40
D	3005	(B,110,19) Diode	RB500V-40
D	3006	(B,108,43) Diode	RB160M-30
D	3007	(B,102,37) Diode	1SS352
D	3008	(B,98,42) Diode	RB548W
D	3009	(B,100,42) Diode	RB548W
D	3010	(B,89,18) Diode	RB548W
D	3011	(B,92,18) Diode	RB548W
D	3012	(B,94,18) Diode	RB548W
D	3100	(B,95,68) Diode	UDZS6R8(B)
D	3105	(A,140,51) Diode	RB160VA-40
L	3002	(B,127,27) Inductor	CTF1635
L	3003	(B,126,39) Choke Coil 68 uH	CTH1318
L	3004	(B,112,46) Choke Coil 68 uH	CTH1318
L	3005	(B,113,50) Inductor	CTF1635
L	3006	(B,96,46) Inductor	DTL1096
L	3007	(B,97,16) Inductor	CTF1635
L	3101	(A,138,56) Choke Coil 56 uH	CTH1394
L	3150	(A,55,49) Inductor	CTF1731
L	3151	(A,49,54) Inductor	CTF1306
L	3152	(A,48,42) Inductor	CTF1306
L	3153	(A,45,38) Inductor	CTF1748
L	3154	(A,44,38) Inductor	CTF1748
L	3155	(A,44,60) Inductor	CTF1734
L	3156	(A,43,37) Inductor	CTF1748
L	3157	(A,43,60) Inductor	CTF1734

Circuit Symbol and No.			Part No.
L	3158	(A,41,38) Inductor	CTF1748
L	3159	(A,42,60) Inductor	CTF1734
L	3160	(A,40,39) Inductor	CTF1748
L	3161	(A,39,59) Inductor	CTF1734
L	3162	(A,39,38) Inductor	CTF1748
L	3163	(A,38,59) Inductor	CTF1734
L	3164	(A,38,39) Inductor	CTF1748
L	3165	(A,37,59) Inductor	CTF1748
L	3166	(A,37,38) Inductor	CTF1748
L	3167	(A,32,56) Inductor	CTF1734
L	3168	(A,41,59) Inductor	CTF1306
L	3169	(A,41,63) Inductor	CTF1736
L	3170	(A,36,41) Inductor	CTF1748
L	3171	(A,35,41) Inductor	CTF1748
L	3172	(A,34,41) Inductor	CTF1748
L	3173	(A,33,41) Inductor	CTF1748
L	3174	(A,31,44) Inductor	CTF1734
L	3175	(A,32,52) Inductor	CTF1734
L	3176	(A,31,53) Inductor	CTF1734
L	3177	(A,32,54) Inductor	CTF1734
L	3178	(A,32,55) Inductor	CTF1734
L	3179	(A,50,44) Inductor	CTF1306
L	3180	(A,35,48) Inductor	CTF1306
L	3200	(A,31,65) Inductor	CTF1306
L	3201	(A,25,69) Inductor	CTF1306
L	3202	(A,27,58) Inductor	LCTAW101J2520
L	3203	(A,20,51) Inductor	LCTAW101J2520
L	3205	(A,32,68) Inductor	CTF1306
L	3206	(B,63,47) Chip Ferrite Bead	BTX1042
L	3207	(B,56,35) Inductor	CTF1306
L	3208	(B,63,35) Inductor	CTF1306
L	3300	(A,128,17) Ferrite Bead	CTF1528
L	3301	(A,129,17) Ferrite Bead	CTF1528
L	3302	(A,112,19) Ferrite Bead	CTF1528
L	3303	(A,113,17) Ferrite Bead	CTF1528
L	3304	(A,87,57) Inductor	CTF1488
L	3310	(A,65,58) Chip Ferrite Bead	BTX1042
L	3360	(B,95,59) Inductor	LCTAW2R7J2520
L	3361	(A,81,33) Inductor	CTF1394
L	3362	(B,80,34) Inductor	CTF1306
L	3401	(A,22,40) Inductor	DTL1096
L	3402	(A,13,36) Inductor	DTL1096
L	3403	(A,23,44) Inductor	CTF1635
L	3404	(A,15,43) Chip Ferrite Bead	BTX1042
L	3407	(B,126,50) Chip Ferrite Bead	BTX1042
TH	3350	(A,66,6) Thermistor	CCX1084
VA	3300	(A,126,21) Varistor	AVR-M1608C120MT6AB
VA	3301	(A,129,21) Varistor	AVR-M1608C120MT6AB
VA	3302	(A,114,20) Varistor	AVR-M1608C120MT6AB
VA	3303	(A,115,17) Varistor	AVR-M1608C120MT6AB
VA	3305	(A,89,20) Varistor	AVR-M1608C120MT6AB
VA	3307	(A,91,20) Varistor	AVR-M1608C120MT6AB
VA	3310	(A,85,19) Varistor	AVR-M1608C120MT6AB
CN	3100	(A,137,39) Connector	CKS5715
CN	3300	(A,121,16) Connector	CKS5105

Circuit Symbol and No.			Part No.
CN	3301	(A,69,70) Connector	CKS6118
CN	3302	(A,89,13) Connector	CKS5501
CN	3360	(A,89,36) Connector	CKS6117
CN	3361	(A,107,9) Connector	CKS5749
CN	3362	(A,107,15) Connector	CKS5749
CN	3401	(A,34,31) Connector	CKS5773

RESISTORS

R	3001	(B,132,30)	RS1/10SR0R0J
R	3002	(B,130,29)	RS1/10SR6801D
R	3003	(B,126,30)	RS1/10SR2000D
R	3004	(B,126,29)	RS1/10SR1001D
R	3005	(B,131,37)	RS1/10SR0R0J
R	3006	(B,130,33)	RS1/10SR1001D
R	3007	(B,129,32)	RS1/10SR82R0D
R	3008	(B,124,32)	RS1/10SR3300D
R	3009	(B,127,35)	RS1/10SR102J
R	3010	(B,123,31)	RS1/10SR102J
R	3011	(B,119,30)	RS1/10SR104J
R	3012	(B,123,34)	RS1/10SR333J
R	3013	(B,119,31)	RS1/16SS331J
R	3014	(B,118,26)	RS1/10SR2001D
R	3015	(B,119,26)	RS1/10SR3900D
R	3016	(B,121,26)	RS1/10SR1000D
R	3017	(B,113,41)	RS1/10SR273J
R	3018	(B,115,38)	RS1/10SR150J
R	3019	(B,104,38)	RS1/10SR150J
R	3020	(B,109,37)	RS1/10SR563J
R	3021	(B,101,16)	RS1/10SR1002D
R	3022	(B,102,32)	RS1/10SR6202D
R	3023	(B,100,18)	RS1/10SR1802D
R	3024	(B,97,17)	RS1/10SR2202D
R	3025	(B,99,36)	RS1/10SR1802D
R	3026	(B,98,34)	RS1/10SR8200D
R	3027	(B,100,25)	RS1/16SS470J
R	3028	(B,100,24)	RS1/16SS470J
R	3030	(B,97,39)	RS1/10SR3303D
R	3031	(B,97,51)	RS1/10SR203J
R	3034	(B,96,36)	RS1/10SR2703D
R	3101	(B,101,62)	RS1/16SS562J
R	3102	(B,101,56)	RS1/16SS562J
R	3104	(A,109,63)	RS1/16SS473J
R	3107	(B,106,66)	RS1/16SS473J
R	3108	(B,106,67)	RS1/16SS473J
R	3110	(A,109,64)	RS1/16SS473J
R	3112	(B,103,70)	RS1/16SS223J
R	3113	(A,112,64)	RS1/16SS470J
R	3114	(A,112,63)	RS1/16SS470J
R	3117	(B,102,68)	RS1/16SS101J
R	3122	(B,115,62)	RS1/16SS0R0J
R	3123	(B,118,67)	RS1/10SR225J
R	3124	(A,110,66)	RS1/10SR1003D
R	3125	(B,114,70)	RS1/10SR392J
R	3126	(B,127,63)	RS1/10SR1203D
R	3128	(A,125,66)	RS1/10SR150J
R	3129	(B,127,61)	RS1/10SR0R0J
R	3130	(A,120,74)	RS1/4S1R0J
R	3131	(A,116,74)	RS1/4S1R0J

Circuit Symbol and No.			Part No.
R	3133	(A,114,72)	RS1/16SS0R0J
R	3134	(B,124,59)	RS1/10SR3602D
R	3135	(B,123,60)	RS1/10SR1801D
R	3136	(A,127,73)	RS1/8SQ0R0J
R	3137	(B,125,67)	RS1/10SR0R0J
R	3138	(B,107,56)	RS1/16SS0R0J
R	3139	(B,107,62)	RS1/16SS0R0J
R	3140	(A,113,67)	RS1/16SS0R0J
R	3141	(B,114,65)	RS1/16SS222J
R	3142	(A,97,73)	RS1/8SQ0R0J
R	3150	(A,48,49)	RS1/16SS1000D
R	3151	(A,46,56)	RS1/16SS103J
R	3152	(A,45,58)	RS1/16SS103J
R	3153	(A,51,53)	RS1/16SS103J
R	3154	(A,44,56)	RS1/16SS103J
R	3157	(A,45,40)	RS1/16SS181J
R	3158	(A,44,40)	RS1/16SS151J
R	3159	(A,44,58)	RS1/16SS151J
R	3160	(A,43,39)	RS1/16SS151J
R	3161	(A,43,58)	RS1/16SS151J
R	3162	(A,41,40)	RS1/16SS151J
R	3163	(A,42,58)	RS1/16SS151J
R	3166	(A,40,41)	RS1/16SS151J
R	3167	(A,39,57)	RS1/16SS151J
R	3168	(A,39,40)	RS1/16SS151J
R	3169	(A,38,57)	RS1/16SS151J
R	3170	(A,38,41)	RS1/16SS151J
R	3171	(A,37,57)	RS1/16SS151J
R	3172	(A,37,40)	RS1/16SS151J
R	3173	(A,34,56)	RS1/16SS101J
R	3175	(A,36,43)	RS1/16SS151J
R	3176	(A,35,43)	RS1/16SS151J
R	3177	(A,34,43)	RS1/16SS151J
R	3178	(A,33,43)	RS1/16SS151J
R	3179	(A,34,50)	RS1/16SS820J
R	3180	(A,33,52)	RS1/16SS101J
R	3181	(A,33,53)	RS1/16SS101J
R	3182	(A,34,54)	RS1/16SS101J
R	3183	(A,34,55)	RS1/16SS101J
R	3185	(A,31,46)	RS1/16SS470J
R	3186	(A,43,77)	RS1/10SR0R0J
R	3200	(A,26,71)	RS1/10SR1801D
R	3201	(A,29,71)	RS1/10SR9101D
R	3203	(A,29,70)	RS1/16SS471J
R	3207	(A,28,62)	RS1/16SS101J
R	3209	(A,22,61)	RS1/16SS223J
R	3210	(A,30,59)	RS1/16SS472J
R	3211	(A,22,60)	RS1/16SS101J
R	3212	(A,23,58)	RS1/10SR5602D
R	3213	(A,20,55)	RS1/10SR4703D
R	3214	(A,24,52)	RS1/10SR3302D
R	3215	(A,26,60)	RS1/16SS101J
R	3217	(A,29,49)	RS1/16SS153J
R	3218	(A,22,50)	RS1/16SS153J
R	3221	(A,26,46)	RS1/10SR100J

Circuit Symbol and No.			Part No.
R	3222	(A,25,49)	RS1/10SR100J
R	3321	(A,79,18)	RS1/10SR2000D
R	3322	(A,81,18)	RS1/10SR2400D
R	3323	(A,79,21)	RS1/10SR2000D
R	3324	(A,80,23)	RS1/10SR2400D
R	3325	(A,76,24)	RS1/10SR333J
R	3326	(A,70,17)	RS1/10SR2200D
R	3327	(A,72,17)	RS1/10SR1500D
R	3328	(A,70,20)	RS1/10SR2200D
R	3329	(A,72,20)	RS1/10SR1500D
R	3330	(A,71,25)	RS1/10SR333J
R	3331	(A,64,26)	RS1/10SR1000D
R	3332	(A,63,26)	RS1/10SR2000D
R	3333	(A,64,23)	RS1/10SR1000D
R	3334	(A,63,23)	RS1/10SR2000D
R	3335	(A,69,29)	RS1/10SR333J
R	3339	(A,76,35)	RS1/16SS0R0J
R	3350	(A,69,7)	RS1/16SS183J
R	3360	(B,84,65)	RS1/16SS221J
R	3361	(B,87,66)	RS1/16SS221J
R	3362	(B,85,64)	RS1/16SS223J
R	3363	(B,87,64)	RS1/16SS223J
R	3364	(B,84,48)	RS1/16SS103J
R	3365	(B,84,52)	RS1/16SS103J
R	3366	(A,84,43)	RS1/16SS470J
R	3367	(B,84,53)	RS1/16SS103J
R	3368	(A,85,44)	RS1/16SS470J
R	3369	(A,83,42)	RS1/16SS470J
R	3371	(B,94,41)	RS1/16SS470J
R	3372	(B,93,39)	RS1/16SS473J
R	3373	(B,86,48)	RS1/16SS470J
R	3374	(B,85,48)	RS1/16SS103J
R	3375	(B,93,38)	RS1/16SS470J
R	3376	(B,83,41)	RS1/16SS470J
R	3380	(A,84,38)	RS1/16SS223J
R	3401	(B,53,35)	RS1/10SR10R0D
R	3402	(B,53,37)	RS1/10SR22R0D
R	3403	(B,53,38)	RS1/10SR1200D
R	3404	(B,55,41)	RS1/10SR82R0D
R	3405	(B,54,41)	RS1/10SR91R0D
R	3406	(B,52,41)	RS1/10SR30R0D
R	3407	(B,55,44)	RS1/10SR39R0D
R	3408	(B,57,44)	RS1/10SR39R0D
R	3409	(B,58,44)	RS1/10SR27R0D
R	3410	(B,57,48)	RS1/10SR1000D
R	3411	(B,58,48)	RS1/10SR75R0D
R	3412	(B,60,48)	RS1/10SR1200D
R	3416	(B,31,36)	RS1/16SS473J
R	3422	(B,23,38)	RS1/16SS473J
R	3423	(B,106,14)	RS1/16SS104J
R	3424	(B,107,14)	RS1/16SS333J
R	3434	(A,59,31)	RS1/16SS0R0J

CAPACITORS

Circuit Symbol and No.			Part No.
C	3001	(B,125,55) 10 uF	CCG1236
C	3002	(B,129,30)	CKSRYB103K50
C	3003	(B,125,52)	CKSQYB104K50
C	3004	(B,130,35)	CCSRCH681J50
C	3005	(B,125,46) 68 uF/10 V	CCH1635
C	3006	(B,127,33)	CCSRCH331J50
C	3007	(B,123,29)	CKSRYB104K50
C	3008	(B,127,25)	CKSRYB104K50
C	3009	(B,124,44)	CKSRYB104K50
C	3010	(B,120,35)	CKSRYB103K50
C	3011	(B,124,26) 10 uF	DCH1201
C	3012	(B,119,33)	CKSRYB393K16
C	3013	(B,121,30)	CKSRYB472K50
C	3015	(B,118,28)	CKSRYB393K16
C	3016	(B,122,26)	CKSRYB104K50
C	3017	(B,114,19)	CKSRYB393K16
C	3018	(B,113,40)	CKSRYB104K50
C	3020	(B,118,41)	CKSRYB103K50
C	3021	(B,119,43) 10 uF	CCG1236
C	3022	(B,119,45) 10 uF	CCG1236
C	3023	(B,113,38)	CKSRYB105K10
C	3024	(B,111,38)	CCSRCH102J50
C	3025	(B,105,47) 10 uF	CCG1236
C	3026	(B,109,38)	CKSRYB104K50
C	3027	(B,104,46)	CKSRYB103K50
C	3028	(B,109,22)	CCSRCH102J50
C	3029	(B,107,38)	CKSRYB105K10
C	3030	(B,105,38)	CKSRYB103K50
C	3032	(B,103,18)	CKSRYB105K10
C	3033	(B,102,29)	CKSRYB103K50
C	3034	(B,100,29)	CKSYB475K25
C	3035	(B,103,26)	CKSRYB104K16
C	3036	(B,100,34)	CCSRCH181J50
C	3037	(B,109,50)	CKSRYB104K50
C	3038	(B,106,53) 33 uF/10 V	CCH1968
C	3039	(B,96,39)	CCSRCH181J50
C	3040	(B,100,39)	CKSRYB472K50
C	3041	(B,99,39)	CKSRYB472K50
C	3042	(B,88,21)	CKSRYB474K16
C	3043	(B,90,21)	CKSRYB474K16
C	3044	(B,117,50)	CKSQYB105K16
C	3045	(B,91,21)	CKSRYB474K16
C	3046	(B,98,46)	CKSQYB105K25
C	3047	(B,102,45)	CKSRYB104K50
C	3048	(B,92,14)	CKSQYB225K16
C	3049	(B,94,14)	CKSQYB225K16
C	3050	(B,100,47)	CKSQYB105K25
C	3051	(B,97,49)	CKSQYB105K25
C	3052	(B,88,14)	CKSQYB105K16
C	3053	(B,90,14)	CKSQYB105K16
C	3054	(B,93,22)	CKSQYB105K16
C	3055	(B,97,13)	CKSQYB105K16
C	3106	(B,114,68)	CKSSYB473K16
C	3107	(B,116,66)	CKSRYB104K50
C	3108	(A,124,71)	CKSQYB225K10

Circuit Symbol and No.			Part No.
C	3111	(A,139,45) 10 uF	CCG1223
C	3112	(A,139,48) 10 uF	CCG1223
C	3113	(B,137,44)	CKSSYB102K50
C	3116	(A,125,61)	CKSSYB102K50
C	3150	(A,50,48)	CKSSYB104K16
C	3151	(A,50,49)	CKSSYB104K16
C	3152	(A,50,46)	CKSSYB104K10
C	3153	(A,49,45)	CKSSYB104K10
C	3154	(A,49,46)	CKSSYB103K16
C	3155	(B,49,50)	CKSSYB104K10
C	3156	(B,49,54)	CKSSYB104K10
C	3157	(A,49,44)	CKSSYB103K16
C	3158	(B,49,49)	CKSSYB103K16
C	3159	(B,49,53)	CKSSYB103K16
C	3160	(A,47,45)	CKSSYB104K10
C	3161	(A,47,44)	CKSSYB103K16
C	3162	(B,40,48)	CKSSYB104K10
C	3163	(B,41,48)	CKSSYB103K16
C	3164	(B,40,52)	CKSSYB104K10
C	3165	(B,41,52)	CKSSYB103K16
C	3166	(B,40,50)	CKSSYB104K10
C	3167	(B,39,50)	CKSSYB103K16
C	3168	(B,42,64) 33 uF/10 V	CCH1586
C	3200	(A,29,73)	CKSSYB104K10
C	3203	(A,29,64)	CKSRYB105K10
C	3204	(A,20,57)	CKSSYB104K10
C	3205	(A,31,63)	CKSSYB104K10
C	3206	(A,27,52)	CKSRYB105K10
C	3207	(B,25,55)	CKSRYB104K50
C	3208	(B,21,50)	CKSRYB104K50
C	3209	(B,22,55) 10 uF	CCG1236
C	3210	(B,23,50) 4.7 uF	CCG1222
C	3213	(A,33,67)	CKSSYB104K10
C	3215	(B,62,43)	CKSSYB104K10
C	3300	(A,109,71) 10 uF	CCG1236
C	3303	(A,77,25)	CKSQYB475K6R3
C	3304	(A,72,23)	CKSQYB475K6R3
C	3305	(A,67,29)	CKSQYB475K6R3
C	3309	(A,77,33) 10 uF	DCH1201
C	3310	(A,65,53)	CKSSYB104K10
C	3350	(A,66,7)	CKSSYB104K10
C	3360	(B,85,65)	CKSSYB222K50
C	3361	(B,86,66)	CKSSYB222K50
C	3362	(B,85,61) 10 uF	DCH1201
C	3363	(B,87,62) 10 uF	DCH1201
C	3364	(B,89,61) 10 uF	DCH1201
C	3365	(B,89,64)	CKSSYB102K50
C	3366	(B,91,60) 10 uF	DCH1201
C	3367	(B,89,59)	CKSSYB102K50
C	3368	(A,81,36) 10 uF	DCH1201
C	3369	(A,83,36) 10 uF	DCH1201
C	3370	(B,92,35)	CKSSYB104K10
C	3371	(B,93,35)	CKSSYB104K10
C	3372	(B,95,35)	CKSSYB104K10
C	3373	(A,85,30)	CKSSYB104K10

Circuit Symbol and No.			Part No.
C	3374	(B,81,35)	CKSSYB104K10
C	3407	(A,26,43) 10 uF	DCH1201
C	3408	(A,18,39)	CKSQYB334K50
C	3409	(A,16,38) 10 uF	CCG1236
C	3410	(A,26,39) 10 uF	DCH1201
C	3411	(A,28,41) 10 uF	DCH1201
C	3414	(A,30,39) 10 uF	DCH1201
C	3423	(A,33,48)	CKSSYB103K16