Pioneer

Service Manual

ORDER NO.
RRV4157

MULTI PLAYER

CDJ-350-W

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
CDJ-350-W	SYXJ8	AC 220 V to 240 V	
CDJ-350-W	UXJCB	AC 120 V	
CDJ-350-W	FLXJ	AC 110 V to 240 V	
CDJ-350-W	AXJ5	AC 220 V to 240 V	
CDJ-350-W	KXJ5	AC 220 V	

This service manual should be used together with the following manual(s):

Model	Order No.	Remarks
CDJ-350/SYXJ8	RRV4069	

Descriptions to be written in the Service Manual for the CDJ-350-W
This product is the same as the CDJ-350, except for the colors. The major changes are as shown below.
Exterior panels (control panel and chassis): Changed to white
LED colors: Green changed to blue
Amber (except for CUE) changed to blue
When replacing the above-mentioned parts, be sure to use the parts described in this manual.

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
ⓒ**PIONEER CORPORATION 2010**

K-ZZZ DEC 2010 Printerd in Japan

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES:
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)*
- *Nos. indicate the pages and Nos. in the service manual for the base model.*
- *When ordering resistors, first convert resistance values into code form as shown in the following examples.*

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560Ω → 56 x 10^1 → 561 ····· RD1/4PU[5][6][1]J
47kΩ → 47 x 10^3 → 473 ····· RD1/4PU[4][7][3]J
0.5Ω → R50 ····· RN2H[R][5][0]K
1Ω → 1R0 ····· RS1P[1][R][0]K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ → 562 x 10^1 → 5621 ····· RN1/4PC[5][6][2][1]F

1.1 CONTRAST TABLE

(1) All models are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-350/ SYXJ8, CUXJ, FLXJ, AXJ5, KXJ5	CDJ-350-W/ SYXJ8, UXJCB, FLXJ, AXJ5, KXJ5	Remarks
		PCB ASSEMBLIES			
NSP		1..PANL ASSY	DWM2380	DWM2435	
	P53-1	2..PNLB ASSY	DWX3106	DWX3253	
		CONTROL PANEL SECTION			
	P53-7	Loop Button	DAC2575	DAC2714	
	P53-8	Search Button	DAC2576	DAC2717	
	P53-9	Vinyl Tempo Button	DAC2577	DAC2718	
	P53-10	Beat Loop Button	DAC2578	DAC2719	
	P53-12	Play Button	DAC2580	DAC2689	
	P53-13	Slide Knob	DAC2594	DAC2724	
	P53-14	Jog Plate	DAH2775	DAH2848	
	P53-15	Display Panel	DAH2789	DAH2854	
⚠	P53-34	Control Panel	DNK5549	DNK5891	
	P53-37	Jog Dial B	DNK5571	DNK5894	
	P53-38	Jog Dial A	DNK5574	DNK5911	
	P53-39	USB Cover	DNK5657	DNK5912	
	P53-40	Sourse Select B Assy	DXB2063	DXB2099	
	P53-43	USB Stop Button Assy	DXB2064	DXB2102	
	P53-46	Standby Button Assy	DXB2065	DXB2105	

(2) CDJ-350/SYXJ8 and CDJ-350-W/SYXJ8 are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-350/SYXJ8	CDJ-350-W/SYXJ8	Remarks
		PACKING SECTION			
	P49-20	Packing Case	DHG2957	DHG2988	
		EXTERIOR SECTION			
⚠NSP	P51-15	Chassis	DNK5576	DNK5896	

(3) CDJ-350/CUXJ andCDJ-350-W/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-350/CUXJ	CDJ-350-W/UXJCB	Remarks
		PACKING SECTION			
	P49-20	Packing Case	DHG2958	DHG2989	
		EXTERIOR SECTION			
⚠NSP	P51-15	Chassis	DNK5780	DNK5923	

(4) CDJ-350/FLXJ andCDJ-350-W/FLXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-350/FLXJ	CDJ-350-W/FLXJ	Remarks
		PACKING SECTION			
	P49-20	Packing Case	DHG2960	DHG2990	
		EXTERIOR SECTION			
⚠NSP	P51-15	Chassis	DNK5781	DNK5975	

(5) CDJ-350/AXJ5 and CDJ-350-W/AXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-350/AXJ5	CDJ-350-W/AXJ5	Remarks
		PACKING SECTION			
	P49-20	Packing Case	DHG2961	DHG2991	
		EXTERIOR SECTION			
⚠NSP	P51-15	Chassis	DNK5782	DNK5926	

(6) CDJ-350/KXJ5 and CDJ-350-W/KXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-350/KXJ5	CDJ-350-W/KXJ5	Remarks
		PACKING SECTION			
	P49-20	Packing Case	DHG2962	DHG3011	
		EXTERIOR SECTION			
⚠NSP	P51-15	Chassis	DNK5784	DNK5925	

1.2 CCONTRAST OF PCB ASSEMBLIES

EF PNLB ASSY

DWX3106 and DWX3253 are constructed the same except for the following:

Mark	Symbol and Description	DWX3106	DWX3253	Remarks
	D504	SLI-343M8C(FGHJ)	SLR343BC4T(JK)	
	D505	SLI-343Y8C(KLMN)	SLI-343Y8C(LMN)	
	D506	SLI-343Y8C(KLMN)	SLR343BC4T(JK)	
	D507	SLI-343Y8C(KLMN)	SLR343BC4T(JK)	
	D508	SLI-343Y8C(KLMN)	SLR343BC4T(JK)	
	D509	SLR-343MC(NPQ)	SLR343BC4T(JK)	
	D510	SLR-343MC(NPQ)	SLR343BC4T(JK)	
	D511	SLR-343MC(NPQ)	SLR343BC4T(JK)	
	D514	SLR-343MC(NPQ)	SLR343BC4T(JK)	
	D515	SLI-343Y8C(KLMN)	SLR343BC4T(JK)	
	D516	SLR343BC4T(JKLM)	SLR343BC4T(JK)	
	R584	RS1/10SR391J	RS1/10SR3901F	
	R585	RS1/10SR272J	RS1/10SR392J	
	R586	RS1/10SR152J	RS1/10SR3601F	
	R587	RS1/10SR152J	RS1/10SR3601F	
	R588	RS1/10SR272J	RS1/10SR4701F	
	R589	RS1/10SR271J	RS1/10SR3601F	
	R590	RS1/10SR271J	RS1/10SR3601F	
	R591	RS1/10SR271J	RS1/10SR3601F	
	R592	RS1/10SR361J	RS1/10SR102J	
	R594	RS1/10SR271J	RS1/10SR3601F	
	R595	RS1/10SR272J	RS1/10SR4701F	
	R596	RS1/10SR562J	RS1/10SR4701F	
	R597	RS1/10SR361J	RS1/10SR152J	
	R641	RS1/10SR681J	RS1/10SR391J	