PARTS LIST

✻ New Parts. ⚠indicates safety critical components.
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia **K** : USA **P** : Canada
Y : PX (Far East, Hawaii) **T** : England **E** : Europe
C : China **X** : Australia **M** : Other Areas

TK-2312/2317
TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description	Destination
TK-2312/2317					
1	1A	✻	A02-4095-23	PLASTIC CABINET ASSY	
3	2C,2E		B09-0725-03	CAP ACCESSORY	
4	1B		B43-1622-04	BADGE (FRONT)	
5	1B		B43-1623-04	BADGE (REAR)	
6	1E	✻	B62-2237-00	INSTRUCTION MANUAL ACCESSORY	M
7	1C	✻	B62-2238-00	INSTRUCTION MANUAL ACCESSORY	P1,K1,M1
9	1A		D10-0649-03	LEVER	
10	1A		D21-0863-04	SHAFT (LEVER)	
11	1A		D32-0441-13	STOPPER (LEVER)	
13	2A		E04-0477-15	RF COAXIAL RECEPTACLE (SMA)	
14	3A		E23-1253-04	TERMINAL (GND)	
15	2A		E23-1254-04	TERMINAL (+VE)	
16	1B		E37-1165-15	PROCESSED LEAD WIRE (SP/RED)	
17	1B	✻	E37-1514-05	PROCESSED LEAD WIRE (SP/BLK)	
19	3A		F20-3353-14	INSULATING SHEET (+VE)	
21	2A		G01-4542-04	COIL SPRING	
22	2A		G01-4543-14	COIL SPRING	
23	2B		G10-1330-04	FIBROUS SHEET (IC)	
24	2A		G11-4465-04	RUBBER SHEET (FET)	
25	3A		G13-2009-04	CUSHION (CHASSIS)	
27	3A		G13-2033-04	CUSHION (-VE)	
28	3A		G13-2034-14	CUSHION (CHASSIS)	
29	2B		G13-2038-34	CUSHION (X57)	
30	2B		G13-2088-04	CUSHION (IC820)	
31	2A	✻	G13-2340-14	CUSHION (CF401,CF402)	
34	2B	✻	G13-2346-04	CUSHION (X57)	
35	3A		G53-1604-03	PACKING (CHASSIS)	
36	2A		G53-1605-03	PACKING	
37	2A		G53-1802-04	PACKING (SMA)	
39	2B	✻	G53-1845-03	PACKING (VOL/SEL)	
40	1B	✻	G53-1846-03	PACKING (SPK)	
41	1B	✻	G53-1847-03	PACKING (SP/MIC)	
43	2D		H12-4251-05	PACKING FIXTURE	K1
44	3D		H52-2300-13	ITEM CARTON CASE	K1
46	2A		J19-5463-03	HOLDER (+VE)	
47	2A		J19-5473-03	HOLDER ASSY (+VE)	
48	2C,2E	✻	J19-5549-03	HOLDER (SP/MIC) ACCESSORY	
49	2B	✻	J19-5545-14	HOLDER ASSY (SPK)	
50	2C,1E		J29-0734-05	BELT CLIP ACCESSORY	
52	2A	✻	J82-0127-05	FPC	
54	1B		K29-9309-13	KNOB (VOL)	
55	1A	✻	K29-9425-03	BUTTON KNOB (PTT)	
56	1A	✻	K29-9426-03	BUTTON KNOB (SIDE1,2)	
57	1B	✻	K29-9427-03	KNOB (SELECTOR)	
58	1A	✻	K29-9463-02	KEY TOP (7KEY)	
A	2A		N14-0848-05	CIRCULAR NUT (SELECTOR)	
B	2B		N14-0849-05	CIRCULAR NUT (VOL)	
C	2A		N30-2604-48	PAN HEAD MACHINE SCREW (SMA)	
D	3A		N30-2606-48	PAN HEAD MACHINE SCREW	
E	2B,3A		N83-2005-48	PAN HEAD TAPTITE SCREW	
60	2C,2E		N99-2046-05	SCREW SET ACCESSORY	
VR1	2A	✻	R31-0676-05	VARIABLE RESISTOR	
62	1B		T07-0787-05	SPEAKER	
63	2D		T90-1036-15	HELICAL ANTENNA ACCESSORY	P1,K1,M1
64	1B	✻	T91-0672-05	MIC ELEMENT (WITH LEAD WIRE)	
W1	2A	✻	W02-3748-05	ENCODER (SELECTOR)	
66	1D		W08-0988-05	CHARGER (KSC-35) ACCESSORY	K1,M1
67	1D		W08-0989-25	AC ADAPTER (KSC-35) ACCESSORY	K1
68	1D		W08-0992-05	AC ADAPTER (KSC-35) ACCESSORY	M1
69	1D		W08-1097-05	CHARGER (KSC-31) ACCESSORY	P1
71	1D		W08-1205-05	AC ADAPTER (KSC-31) ACCESSORY	P1
TX-RX UNIT (X57-7880-20)					
101	2B	✻	B11-1876-03	ILLUMINATION GUIDE (LCD)	
102	2B	✻	B11-1877-14	FILTER (LCD)	
103	2B	✻	B38-0935-05	LCD	
D801			B30-1790-05	LED (BLUE)	
D804			B30-2314-05	LED (GREEN)	
D805			B30-2315-05	LED (RED)	
D818-821		✻	B30-2337-05	LED (YELLOW)	
D824		✻	B30-2337-05	LED (YELLOW)	
C1			CC73HCH1H101J	CHIP C 100PF J	
C3			CC73HCH1H100B	CHIP C 10PF B	
C4			CK73HB1H102K	CHIP C 1000PF K	
C5			CC73HCH1H101J	CHIP C 100PF J	
C7			CC73HCH1H100B	CHIP C 10PF B	
C8			CC73HCH1H101J	CHIP C 100PF J	
C9			CK73HB1E103K	CHIP C 0.010UF K	
C10			CC73HCH1H101J	CHIP C 100PF J	
C11			CK73HB1E103K	CHIP C 0.010UF K	
C12			CC73HCH1H101J	CHIP C 100PF J	
C14			CK73HB1A473K	CHIP C 0.047UF K	
C15			CK73HB1A224K	CHIP C 0.22UF K	
C16,17			CC73HCH1H101J	CHIP C 100PF J	
C18			CK73HB1E103K	CHIP C 0.010UF K	
C19			CC73HCH1H101J	CHIP C 100PF J	
C20			CK73HB1H471K	CHIP C 470PF K	
C21			CK73HB1E103K	CHIP C 0.010UF K	
C23			CS77CA1VR15M	CHIP TNTL 0.15UF 35WV	
C24			C92-0588-05	CHIP TNTL 1.5UF 16WV	
C25			C92-0872-05	CHIP TNTL 0.22UF 10WV	
C27			CK73HB1A224K	CHIP C 0.22UF K	
C28			CK73HB1H471K	CHIP C 470PF K	
C29,30			CC73HCH1H150J	CHIP C 15PF J	
C33			CC73HCH1H470J	CHIP C 47PF J	
C34			CK73HB1H471K	CHIP C 470PF K	
C35			CK73HB1E103K	CHIP C 0.010UF K	
C37,38			CK73HB1A104K	CHIP C 0.10UF K	

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

PARTS LIST

TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description	Destination
C39			CK73HB1H471K	CHIP C 470PF K	
C41			CC73HCH1H101J	CHIP C 100PF J	
C43			CC73HCH1H101J	CHIP C 100PF J	
C44			CK73HB1H102K	CHIP C 1000PF K	
C45			CK73HB1H471K	CHIP C 470PF K	
C47			CC73HCH1H820J	CHIP C 82PF J	
C48			CC73HCH1H070B	CHIP C 7.0PF B	
C49			CK73HB1H102K	CHIP C 1000PF K	
C50			CK73HB1A104K	CHIP C 0.10UF K	
C51			CC73HCH1H470J	CHIP C 47PF J	
C52			CC73HCH1H030B	CHIP C 3.0PF B	
C53			CC73HCH1H070B	CHIP C 7.0PF B	
C55			CK73FB0J106K	CHIP C 10UF K	
C57			CC73HCH1H0R3B	CHIP C 0.3PF B	
C58			CC73HCH1H130G	CHIP C 13PF G	
C59			CC73HCH1H150G	CHIP C 15PF G	
C60,61			CC73HCH1H060B	CHIP C 6.0PF B	
C62,63			CK73HB1E103K	CHIP C 0.010UF K	
C66,67			CC73HCH1H0R5B	CHIP C 0.5PF B	
C70			CK73HB1H102K	CHIP C 1000PF K	
C71			CC73HCH1H330J	CHIP C 33PF J	
C72			CC73HCH1H050B	CHIP C 5.0PF B	
C73			CC73HCH1H150J	CHIP C 15PF J	
C74,75			CK73HB1H102K	CHIP C 1000PF K	
C76			CK73HB1A104K	CHIP C 0.10UF K	
C77			CC73HCH1H180J	CHIP C 18PF J	
C78			CK73HB1A105K	CHIP C 1.0UF K	
C85,86			CC73HCH1H220J	CHIP C 22PF J	
C87			CK73HB1H102K	CHIP C 1000PF K	
C88			CC73HCH1H220J	CHIP C 22PF J	
C89			CK73HB1H471K	CHIP C 470PF K	
C98			CK73HB1H102K	CHIP C 1000PF K	
C201			CK73HB1H102K	CHIP C 1000PF K	
C203			CK73HB1H102K	CHIP C 1000PF K	
C204			CK73HB1A104K	CHIP C 0.10UF K	
C205			CK73HB1H102K	CHIP C 1000PF K	
C209			CC73HCH1H300J	CHIP C 30PF J	
C210			CK73GB1A224K	CHIP C 0.22UF K	
C211-213			CK73HB1H102K	CHIP C 1000PF K	
C214			CK73HB1A104K	CHIP C 0.10UF K	
C215			CC73HCH1H220J	CHIP C 22PF J	
C216			CK73HB1H102K	CHIP C 1000PF K	
C217			CC73HCH1H300J	CHIP C 30PF J	
C218			CC73HCH1H180J	CHIP C 18PF J	
C219			CK73HB1H102K	CHIP C 1000PF K	
C221			CK73HB1H102K	CHIP C 1000PF K	
C222			CC73HCH1H820J	CHIP C 82PF J	
C223-225			CK73HB1H102K	CHIP C 1000PF K	
C227			CC73GCH1H270J	CHIP C 27PF J	
C228			CC73GCH1H130J	CHIP C 13PF J	
C229,230			CC73HCH1H151J	CHIP C 150PF J	
C233			CK73GB1C104K	CHIP C 0.10UF K	
C234			CK73GB1A105K	CHIP C 1.0UF K	
C235			CK73HB1H102K	CHIP C 1000PF K	
C236			CC73GCH1H390J	CHIP C 39PF J	
C237			CC73GCH1H470J	CHIP C 47PF J	
C238			CC73GCH1H120J	CHIP C 12PF J	
C239			CC73GCH1H220J	CHIP C 22PF J	
C240			CK73GB1H102K	CHIP C 1000PF K	
C241			CC73GCH1H1R5B	CHIP C 1.5PF B	

Ref. No.	Address	New parts	Parts No.	Description	Destination
C243			CK73GB1H102K	CHIP C 1000PF K	
C244			CK73HB1H471K	CHIP C 470PF K	
C245			CC73HCH1H180J	CHIP C 18PF J	
C246			CC73GCH1H110J	CHIP C 11PF J	
C247			CK73GB1H102K	CHIP C 1000PF K	
C248			CC73GCH1H100C	CHIP C 10PF C	
C249			CC73GCH1H150J	CHIP C 15PF J	
C250			CC73GCH1H200J	CHIP C 20PF J	
C253			CC73GCH1H060B	CHIP C 6.0PF B	
C255			CC73GCH1H220J	CHIP C 22PF J	
C256			CC73GCH1H070B	CHIP C 7.0PF B	
C257			CC73GCH1H080B	CHIP C 8.0PF B	
C264			CC73HCH1H470J	CHIP C 47PF J	
C265			CC73HCH1H330J	CHIP C 33PF J	
C271			CC73GCH1H030B	CHIP C 3.0PF B	
C301			CK73HB1A104K	CHIP C 0.10UF K	
C302			CK73HB1H471K	CHIP C 470PF K	
C303			CK73FB1E225K	CHIP C 2.2UF K	
C304			CK73HB1H471K	CHIP C 470PF K	
C305			CC73HCH1H101J	CHIP C 100PF J	
C307			CC73HCH1H470J	CHIP C 47PF J	
C308			CC73HCH1H100B	CHIP C 10PF B	
C309			CK73HB1H471K	CHIP C 470PF K	
C311			CK73HB1H471K	CHIP C 470PF K	
C314			CK73HB1H471K	CHIP C 470PF K	
C315			CK73HB1H102K	CHIP C 1000PF K	
C402-407			CK73HB1A104K	CHIP C 0.10UF K	
C408			CC73HCH1H330J	CHIP C 33PF J	
C409			CK73HB1E103K	CHIP C 0.010UF K	
C410			CC73HCH1H220J	CHIP C 22PF J	
C411			CC73HCH1H820J	CHIP C 82PF J	
C412			CK73HB1H471K	CHIP C 470PF K	
C414			CK73HB1A104K	CHIP C 0.10UF K	
C415			CC73HCH1H390J	CHIP C 39PF J	
C416			CC73HCH1H820J	CHIP C 82PF J	
C417			CK73HB1H471K	CHIP C 470PF K	
C418			CK73HB1A104K	CHIP C 0.10UF K	
C419			CC73HCH1H390J	CHIP C 39PF J	
C420			CK73HB1H182K	CHIP C 1800PF K	
C421			CK73HB1H471K	CHIP C 470PF K	
C422,423			CK73GB0J106K	CHIP C 10UF K	
C424			CC73HCH1H560J	CHIP C 56PF J	
C425			CK73HB1E103K	CHIP C 0.010UF K	
C426			CK73HB1H102K	CHIP C 1000PF K	
C427			CK73HB1A104K	CHIP C 0.10UF K	
C428			CK73HB1A333K	CHIP C 0.033UF K	
C429			CC73HCH1H330J	CHIP C 33PF J	
C431			CK73HB1A224K	CHIP C 0.22UF K	
C433			CK73HB1E103K	CHIP C 0.010UF K	
C435			CK73HB1E103K	CHIP C 0.010UF K	
C436			CC73HCH1H020B	CHIP C 2.0PF B	
C437			CC73HCH1H160J	CHIP C 16PF J	
C438			CC73HCH1H020B	CHIP C 2.0PF B	
C439			CK73HB1E103K	CHIP C 0.010UF K	
C440,441			CK73HB1H102K	CHIP C 1000PF K	
C442			CC73HCH1H100B	CHIP C 10PF B	
C443			CK73HB1E103K	CHIP C 0.010UF K	
C444			CC73HCH1H020B	CHIP C 2.0PF B	
C445,446			CC73HCH1H130J	CHIP C 13PF J	
C447,448			CC73HCH1H030B	CHIP C 3.0PF B	

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

PARTS LIST

TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description	Destination
C449			CK73HB1E103K	CHIP C 0.010UF K	
C450			CC73HCH1H010B	CHIP C 1.0PF B	
C451,452			CK73HB1H102K	CHIP C 1000PF K	
C453			CC73HCH1H2R5B	CHIP C 2.5PF B	
C454,455			CK73HB1H102K	CHIP C 1000PF K	
C456			CC73HCH1H080B	CHIP C 8.0PF B	
C459			CK73HB1H102K	CHIP C 1000PF K	
C461,462			CK73HB1H102K	CHIP C 1000PF K	
C463			CC73HCH1H2R5B	CHIP C 2.5PF B	
C464			CC73HCH1H390J	CHIP C 39PF J	
C465			CK73HB1H102K	CHIP C 1000PF K	
C466,467			CC73HCH1H060B	CHIP C 6.0PF B	
C468			CC73HCH1H270J	CHIP C 27PF J	
C469			CC73HCH1H050B	CHIP C 5.0PF B	
C470			CK73HB1H102K	CHIP C 1000PF K	
C474,475			CK73HB1H102K	CHIP C 1000PF K	
C477,478			CK73HB1H102K	CHIP C 1000PF K	
C479			CC73HCH1H2R5B	CHIP C 2.5PF B	
C480			CC73HCH1H240J	CHIP C 24PF J	
C481			CC73HCH1H470J	CHIP C 47PF J	
C482			CC73HCH1H060B	CHIP C 6.0PF B	
C484			CC73HCH1H060B	CHIP C 6.0PF B	
C485			CC73HCH1H200J	CHIP C 20PF J	
C486			CC73HCH1H020B	CHIP C 2.0PF B	
C487			CC73HCH1H100B	CHIP C 10PF B	
C488			CC73HCH1H030B	CHIP C 3.0PF B	
C489			CC73HCH1H330J	CHIP C 33PF J	
C490			CC73HCH1H240J	CHIP C 24PF J	
C491			CC73HCH1H390J	CHIP C 39PF J	
C495			CK73HB1H471K	CHIP C 470PF K	
C496			CK73HB1A104K	CHIP C 0.10UF K	
C803,804			CK73HB1H102K	CHIP C 1000PF K	
C806,807			CK73HB1H102K	CHIP C 1000PF K	
C808,809			CK73GB1A105K	CHIP C 1.0UF K	
C810,811			CK73HB1H102K	CHIP C 1000PF K	
C812-816			CK73GB1A105K	CHIP C 1.0UF K	
C818,819			CK73HB1H102K	CHIP C 1000PF K	
C821			CK73HB1H102K	CHIP C 1000PF K	
C823			CK73GB1A105K	CHIP C 1.0UF K	
C825			CK73HB1A105K	CHIP C 1.0UF K	
C826			CK73HB1A104K	CHIP C 0.10UF K	
C828			CK73GB1A105K	CHIP C 1.0UF K	
C829			CK73HB1E103K	CHIP C 0.010UF K	
C831			CK73GB0J106K	CHIP C 10UF K	
C832,833			CK73HB1A104K	CHIP C 0.10UF K	
C834			CK73HB1H102K	CHIP C 1000PF K	
C837			CK73HB1H102K	CHIP C 1000PF K	
C840			CK73HB1H332K	CHIP C 3300PF K	
C842			CK73HB1H392K	CHIP C 3900PF K	
C843			CK73HB1H102K	CHIP C 1000PF K	
C844			CK73HB1A104K	CHIP C 0.10UF K	
C846			CC73HCH1H050B	CHIP C 5PF B	
C848			CK73HB1H271K	CHIP C 270PF K	
C849			CK73HB1A104K	CHIP C 0.10UF K	
C850			CK73HB1H102K	CHIP C 1000PF K	
C852			CK73HB1A104K	CHIP C 0.10UF K	
C857			CK73HB1H332K	CHIP C 3300PF K	
C858			CK73HB1E682K	CHIP C 6800PF K	
C859			CK73HB1A105K	CHIP C 1.0UF K	
C861			CK73HB1H102K	CHIP C 1000PF K	

Ref. No.	Address	New parts	Parts No.	Description	Destination
C863			CK73HB1E103K	CHIP C 0.010UF K	
C865			CK73HB1H471K	CHIP C 470PF K	
C866			CK73GB0J106K	CHIP C 10UF K	
C869			CK73GB0J106K	CHIP C 10UF K	
C872			CK73HB1H102K	CHIP C 1000PF K	
C873			CK73HB1E103K	CHIP C 0.010UF K	
C874			CK73HB1A104K	CHIP C 0.10UF K	
C876			CK73GB0J106K	CHIP C 10UF K	
C877			CK73HB1H102K	CHIP C 1000PF K	
C878			CK73HB1E103K	CHIP C 0.010UF K	
C879			CK73GB0J106K	CHIP C 10UF K	
C881			CK73HB1A104K	CHIP C 0.10UF K	
C882			CK73HB1H102K	CHIP C 1000PF K	
C883			CK73HB1H152K	CHIP C 1500PF K	
C884			CK73HB1A105K	CHIP C 1.0UF K	
C885			CC73HCH1H181J	CHIP C 180PF J	
C886			CC73HCH1H221J	CHIP C 220PF J	
C887			CC73HCH1H121J	CHIP C 120PF J	
C890,891			CK73HB1H391K	CHIP C 390PF K	
C892			CK73HB1A105K	CHIP C 1.0UF K	
C893			CK73HB0J475M	CHIP C 4.7UF M	
C894			CK73HB1A105K	CHIP C 1.0UF K	
C896			CK73HB1A104K	CHIP C 0.10UF K	
C897,898			CK73HB1A474K	CHIP C 0.47UF K	
C899,900			CK73HB1H471K	CHIP C 470PF K	
C901			CK73HB1A474K	CHIP C 0.47UF K	
C902,903			CK73GB0J225K	CHIP C 2.2UF K	
C904			CK73HB1A474K	CHIP C 0.47UF K	
C905,906			CK73HB1H471K	CHIP C 470PF K	
C907			CC73HCH1H470J	CHIP C 47PF J	
C909			CK73HB1A104K	CHIP C 0.10UF K	
C910			CK73HB1A683K	CHIP C 0.068UF K	
C911			CK73GB0J106K	CHIP C 10UF K	
C912			CK73HB1H102K	CHIP C 1000PF K	
C913			CK73HB1H332K	CHIP C 3300PF K	
C914,915			CK73HB1A105K	CHIP C 1.0UF K	
C916-919			CK73HB1H102K	CHIP C 1000PF K	
C920			CK73GB1A105K	CHIP C 1.0UF K	
C921			CC73HCH1H101J	CHIP C 100PF J	
C922			CK73HB1A104K	CHIP C 0.10UF K	
C923			CK73FB0J106K	CHIP C 10UF K	
C924			CC73HCH1H101J	CHIP C 100PF J	
C925			CK73HB1A473J	CHIP C 0.047UF J	
C926			CS77CC0J101M	CHIP TNTL 100UF 6.3WV	
C930			CK73HB1H102K	CHIP C 1000PF K	
C936			CK73HB1H102K	CHIP C 1000PF K	
C945			CK73HB1A104K	CHIP C 0.10UF K	
C946			CK73HB1A105K	CHIP C 1.0UF K	
C947			CK73HB1H471K	CHIP C 470PF K	
C948,949			CK73HB1H102K	CHIP C 1000PF K	
C950			CK73HB0J105K	CHIP C 1.0UF K	
C951			CK73HB1H102K	CHIP C 1000PF K	
C964,965			CK73GB1C225K	CHIP C 2.2UF K	
105	2B		E29-1229-05	INTER CONNECTOR (LCD)	
CN801			E40-6827-05	FLAT CABLE CONNECTOR	
J802			E11-0703-05	PHONE JACK (EXT-SP/MIC)	
F801			F53-0324-15	FUSE (2.5A)	
F802			F53-0319-15	FUSE (1.0A)	

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

PARTS LIST

TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
107	2B	✻	G11-4525-04	SHEET (LCD)	
109	1B	✻	J21-8619-03	MOUNTING HARDWARE (LCD)	
CD401			L79-1866-05	TUNING COIL	
CF401			L72-1045-05	CERAMIC FILTER (450KHz/NAR)	
CF402			L72-1010-05	CERAMIC FILTER (450KHz/WID)	
L1			L41-4795-39	SMALL FIXED INDUCTOR (4.7UH)	
L2			L40-1575-57	SMALL FIXED INDUCTOR (15.0NH)	
L4			L92-0163-05	BEADS CORE	
L5			L40-1001-86	SMALL FIXED INDUCTOR (10UH)	
L7			L40-1001-86	SMALL FIXED INDUCTOR (10UH)	
L8			L40-2702-86	SMALL FIXED INDUCTOR (27UH)	
L10			L40-3391-86	SMALL FIXED INDUCTOR (3.3UH)	
L11			L40-1502-86	SMALL FIXED INDUCTOR (15UH)	
L14			L40-3391-86	SMALL FIXED INDUCTOR (3.3UH)	
L15			L41-3978-14	SMALL FIXED INDUCTOR (39NH)	
L16			L92-0163-05	BEADS CORE	
L17			L41-2278-14	SMALL FIXED INDUCTOR (22NH)	
L18,19			L40-1001-86	SMALL FIXED INDUCTOR (10UH)	
L20			L40-1085-71	SMALL FIXED INDUCTOR (100NH)	
L21			L40-1085-57	SMALL FIXED INDUCTOR (100NH)	
L25			L40-1575-71	SMALL FIXED INDUCTOR (15NH)	
L27			L40-1085-57	SMALL FIXED INDUCTOR (100NH)	
L202			L40-1085-71	SMALL FIXED INDUCTOR (100NH)	
L203			L40-4775-71	SMALL FIXED INDUCTOR (47NH)	
L204			L40-1085-71	SMALL FIXED INDUCTOR (100NH)	
L205			L92-0162-05	BEADS CORE	
L206			L40-3975-71	SMALL FIXED INDUCTOR (39NH)	
L207			L34-4577-05	AIR-CORE COIL	
L208			L92-0149-05	CHIP FERRITE	
L210			L92-0149-05	CHIP FERRITE	
L211			L34-4569-05	AIR-CORE COIL	
L212			L34-4563-05	AIR-CORE COIL	
L213			L34-4565-05	AIR-CORE COIL	
L214			L34-4566-05	AIR-CORE COIL	
L216			L41-2295-39	SMALL FIXED INDUCTOR (2.2UH)	
L217			L34-4577-05	AIR-CORE COIL	
L219			L34-4566-05	AIR-CORE COIL	
L220			L34-4569-05	AIR-CORE COIL	
L221			L34-4568-05	AIR-CORE COIL	
L222			L40-4775-57	SMALL FIXED INDUCTOR (47.0NH)	
L302			L92-0138-05	CHIP FERRITE	
L401			L41-1885-53	SMALL FIXED INDUCTOR (0.18UH)	
L402			L40-1085-57	SMALL FIXED INDUCTOR (100NH)	
L403			L40-1591-86	SMALL FIXED INDUCTOR (1.5UH)	
L406			L92-0138-05	CHIP FERRITE	
L407			L41-5685-39	SMALL FIXED INDUCTOR (0.56UH)	
L408			L40-5675-57	SMALL FIXED INDUCTOR (56.0NH)	
L409		✻	L41-2285-53	SMALL FIXED INDUCTOR (0.22UH)	
L410			L40-5675-57	SMALL FIXED INDUCTOR (56.0NH)	
L411			L41-1585-53	SMALL FIXED INDUCTOR (0.15UH)	
L412			L41-2785-53	SMALL FIXED INDUCTOR (0.27UH)	
L414			L41-6878-14	SMALL FIXED INDUCTOR (68NH)	
L415			L92-0138-05	CHIP FERRITE	
L416			L41-6878-14	SMALL FIXED INDUCTOR (68NH)	
L418			L41-6878-14	SMALL FIXED INDUCTOR (68NH)	
L419			L41-5678-14	SMALL FIXED INDUCTOR (56NH)	
L420			L40-4775-57	SMALL FIXED INDUCTOR (47.0NH)	
L801			L92-0472-05	CHIP FERRITE	
L802,803			L92-0161-05	BEADS CORE	
X1			L77-3050-05	TCXO (16.8MHZ).	
X802		✻	L78-1434-05	RESONATOR (19.2MHZ)	
XF401			L71-0655-05	MCF (49.95MHZ)	
CP1			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP802			RK75HA1J102J	CHIP-COM 1.0K J 1/16W	
CP812			RK75HA1J102J	CHIP-COM 1.0K J 1/16W	
CP814			RK75HA1J474J	CHIP-COM 470K J 1/16W	
CP817			RK75HA1J473J	CHIP-COM 47K J 1/16W	
CP818-821			RK74HB1J103J	CHIP-COM 10K J 1/16W	
CP823			RK74HB1J103J	CHIP-COM 10K J 1/16W	
CP826			RK74HB1J103J	CHIP-COM 10K J 1/16W	
CP827,828			RK75HA1J473J	CHIP-COM 47K J 1/16W	
CP836,837			RK75HA1J102J	CHIP-COM 1.0K J 1/16W	
CP840-844			RK75HA1J103J	CHIP-COM 10K J 1/16W	
CP845,846			RK75HA1J472J	CHIP-COM 4.7K J 1/16W	
CP847			RK75HA1J473J	CHIP-COM 47K J 1/16W	
R1,2			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R5			RK73HB1J103J	CHIP R 10K J 1/16W	
R6			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R7			RK73HB1J103J	CHIP R 10K J 1/16W	
R8			RK73HB1J331J	CHIP R 330 J 1/16W	
R9			RK73HB1J101J	CHIP R 100 J 1/16W	
R10			RK73HB1J122J	CHIP R 1.2K J 1/16W	
R11			RK73HB1J103J	CHIP R 10K J 1/16W	
R13			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R14			RK73HB1J223J	CHIP R 22K J 1/16W	
R15,16			RK73HB1J100J	CHIP R 10 J 1/16W	
R17			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R18			RK73HB1J391J	CHIP R 390 J 1/16W	
R19			RK73HB1J471J	CHIP R 470 J 1/16W	
R20			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R21			RK73HB1J471J	CHIP R 470 J 1/16W	
R22			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R26			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R27			RK73HB1J103J	CHIP R 10K J 1/16W	
R28			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R29			RK73HB1J474J	CHIP R 470K J 1/16W	
R30			RK73HB1J821J	CHIP R 820 J 1/16W	
R31			RK73HB1J106J	CHIP R 10M J 1/16W	
R33			RK73HB1J470J	CHIP R 47 J 1/16W	
R37			RK73HB1J152J	CHIP R 1.5K J 1/16W	
R39			RK73GB2A563J	CHIP R 56K J 1/10W	
R40			RK73HB1J104J	CHIP R 100K J 1/16W	
R41,42			RK73HB1J271J	CHIP R 270 J 1/16W	
R43			RK73HB1J104J	CHIP R 100K J 1/16W	
R44			RK73GB2A220J	CHIP R 22 J 1/10W	
R45			RK73HB1J220J	CHIP R 22 J 1/16W	
R46			RK73HB1J154J	CHIP R 150K J 1/16W	
R47			RK73HB1J101J	CHIP R 100 J 1/16W	
R49			RK73HB1J103J	CHIP R 10K J 1/16W	
R50			RK73HB1J470J	CHIP R 47 J 1/16W	
R51			RK73HB1J471J	CHIP R 470 J 1/16W	
R52			RK73HB1J103J	CHIP R 10K J 1/16W	
R53			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R56,57			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R58			RK73GB2A224J	CHIP R 220K J 1/10W	
R60			RK73HB1J471J	CHIP R 470 J 1/16W	
R62			RK73HB1J683J	CHIP R 68K J 1/16W	

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

PARTS LIST

TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description				Destination
R63			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R67			RK73HB1J103J	CHIP R	10K	J	1/16W	
R68			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R98			RK73HB1J183J	CHIP R	18K	J	1/16W	
R99			RK73HB1J183J	CHIP R	18K	J	1/16W	
R104,105			RK73HB1J103J	CHIP R	10K	J	1/16W	
R201			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R202			RK73HB1J182J	CHIP R	1.8K	J	1/16W	
R203			RK73HB1J100J	CHIP R	10	J	1/16W	
R205			RK73HB1J101J	CHIP R	100	J	1/16W	
R206			RK73HB1J222J	CHIP R	2.2K	J	1/16W	
R207			RK73HB1J101J	CHIP R	100	J	1/16W	
R209			RK73HB1J181J	CHIP R	180	J	1/16W	
R211			RK73HB1J100J	CHIP R	10	J	1/16W	
R212			RK73HB1J681J	CHIP R	680	J	1/16W	
R213			RK73HB1J122J	CHIP R	1.2K	J	1/16W	
R214			RK73HB1J270J	CHIP R	27	J	1/16W	
R215			RK73HB1J331J	CHIP R	330	J	1/16W	
R216			RK73HB1J471J	CHIP R	470	J	1/16W	
R217			RK73HB1J120J	CHIP R	12	J	1/16W	
R218			RK73HB1J471J	CHIP R	470	J	1/16W	
R219			RK73HB1J823J	CHIP R	82K	J	1/16W	
R220			RK73HB1J470J	CHIP R	47	J	1/16W	
R221			RK73HB1J563J	CHIP R	56K	J	1/16W	
R222			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R223			RK73HB1J151J	CHIP R	150	J	1/16W	
R224			RK73HB1J683J	CHIP R	68K	J	1/16W	
R225			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R226			RK73HB1J120J	CHIP R	12	J	1/16W	
R227			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R228			RK73HB1J333J	CHIP R	33K	J	1/16W	
R229,230			RK73GB2A4R7J	CHIP R	4.7	J	1/10W	
R231			RK73FB2B000J	CHIP R	0.0	J	1/8W	
R232,233			RK73HB1J271J	CHIP R	270	J	1/16W	
R235			RK73GB2A823J	CHIP R	82K	J	1/10W	
R237			RK73HB1J120J	CHIP R	12	J	1/16W	
R240			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R301			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R303			RK73HB1J561J	CHIP R	560	J	1/16W	
R304			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R305			RK73HB1J333J	CHIP R	33K	J	1/16W	
R306			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R307			RK73EB2ER39K	CHIP R	0.39	K	1/4W	
R308			RK73HB1J182J	CHIP R	1.8K	J	1/16W	
R309,310			RK73EB2ER39K	CHIP R	0.39	K	1/4W	
R311,312			RK73HH1J154D	CHIP R	150K	D	1/16W	
R313,314			RK73HH1J474D	CHIP R	470K	D	1/16W	
R315			RK73HB1J103J	CHIP R	10K	J	1/16W	
R316			RK73HB1J563J	CHIP R	56K	J	1/16W	
R317			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R318			RK73HB1J474J	CHIP R	470K	J	1/16W	
R319			RK73HB1J224J	CHIP R	220K	J	1/16W	
R320			RK73HB1J105J	CHIP R	1.0M	J	1/16W	
R406			RK73HB1J182J	CHIP R	1.8K	J	1/16W	
R408			RK73HB1J103J	CHIP R	10K	J	1/16W	
R409			RK73HB1J153J	CHIP R	15K	J	1/16W	
R410			RK73HB1J334J	CHIP R	330K	J	1/16W	
R411			RK73HB1J103J	CHIP R	10K	J	1/16W	
R414			RK73HB1J101J	CHIP R	100	J	1/16W	
R415			RK73HB1J182J	CHIP R	1.8K	J	1/16W	

Ref. No.	Address	New parts	Parts No.	Description				Destination
R416			RK73HB1J122J	CHIP R	1.2K	J	1/16W	
R417			RK73HB1J154J	CHIP R	150K	J	1/16W	
R419			RK73HB1J823J	CHIP R	82K	J	1/16W	
R421,422			RK73HB1J332J	CHIP R	3.3K	J	1/16W	
R423			RK73HB1J222J	CHIP R	2.2K	J	1/16W	
R424			RK73HB1J182J	CHIP R	1.8K	J	1/16W	
R425			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R426			RK73HB1J100J	CHIP R	10	J	1/16W	
R427			RK73HB1J683J	CHIP R	68K	J	1/16W	
R428			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R429			RK73HB1J101J	CHIP R	100	J	1/16W	
R433			RK73HB1J684J	CHIP R	680K	J	1/16W	
R434			RK73HB1J221J	CHIP R	220	J	1/16W	
R435			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R436			RK73HB1J101J	CHIP R	100	J	1/16W	
R437			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R438			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R439			RK73HB1J391J	CHIP R	390	J	1/16W	
R440			RK73HB1J563J	CHIP R	56K	J	1/16W	
R441			RK73HB1J104J	CHIP R	100K	J	1/16W	
R442			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R443			RK73HB1J563J	CHIP R	56K	J	1/16W	
R444			RK73HB1J104J	CHIP R	100K	J	1/16W	
R445			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R447			RK73HB1J471J	CHIP R	470	J	1/16W	
R448			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R449			RK73HB1J391J	CHIP R	390	J	1/16W	
R450,451			RK73HB1J474J	CHIP R	470K	J	1/16W	
R452			RK73HB1J104J	CHIP R	100K	J	1/16W	
R453			RK73HB1J564J	CHIP R	560K	J	1/16W	
R455			RK73HB1J104J	CHIP R	100K	J	1/16W	
R456			RK73HB1J154J	CHIP R	150K	J	1/16W	
R457,458			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R461,462			RK73HB1J474J	CHIP R	470K	J	1/16W	
R463,464			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R468			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R469,470			RK73HB1J333J	CHIP R	33K	J	1/16W	
R471			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R701-704			RK73HB1J473J	CHIP R	47K	J	1/16W	
R705-712			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R713,714			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R802			RK73GB2A221J	CHIP R	220	J	1/10W	
R803			RK73HB1J473J	CHIP R	47K	J	1/16W	
R804,805			RK73HB1J104J	CHIP R	100K	J	1/16W	
R806,807			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R810			RK73HB1J104J	CHIP R	100K	J	1/16W	
R811			RK73GB2A271J	CHIP R	270	J	1/10W	
R813			RK73HB1J473J	CHIP R	47K	J	1/16W	
R814-816			RK73HB1J104J	CHIP R	100K	J	1/16W	
R817			RK73HB1J223J	CHIP R	22K	J	1/16W	
R818			RK73GB2A331J	CHIP R	330	J	1/10W	
R819,820			RK73HB1J104J	CHIP R	100K	J	1/16W	
R821			RK73HB1J473J	CHIP R	47K	J	1/16W	
R822			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R824			RK73HH1J824D	CHIP R	820K	D	1/16W	
R829			RK73HH1J394D	CHIP R	390K	D	1/16W	
R830			RK73HH1J103D	CHIP R	10K	D	1/16W	
R831,832			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R835,836			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R839			RK73HB1J000J	CHIP R	0.0	J	1/16W	

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

PARTS LIST

TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description	Destination
R842			RK73HB1J223J	CHIP R 22K J 1/16W	
R844			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R845			RK73HB1J103J	CHIP R 10K J 1/16W	
R847			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R848			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R849			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R850			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R851			RK73HB1J223J	CHIP R 22K J 1/16W	
R852			RK73HB1J104J	CHIP R 100K J 1/16W	
R853			RK73HB1J103J	CHIP R 10K J 1/16W	
R854-856			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R857			RK73HB1J680J	CHIP R 68 J 1/16W	
R858			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R860			RK73HB1J104J	CHIP R 100K J 1/16W	
R861			RK73HB1J823J	CHIP R 82K J 1/16W	
R865			RK73HB1J223J	CHIP R 22K J 1/16W	
R867,868			RK73HB1J103J	CHIP R 10K J 1/16W	
R869			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R871			RK73HB1J104J	CHIP R 100K J 1/16W	
R872			RK73HB1J121J	CHIP R 120 J 1/16W	
R874			RK73HB1J150J	CHIP R 15 J 1/16W	
R875			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R876			RK73HB1J564J	CHIP R 560K J 1/16W	
R877			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R878			RK73HB1J103J	CHIP R 10K J 1/16W	
R879-883			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R884			RK73HB1J564J	CHIP R 560K J 1/16W	
R885			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R887			RK73HB1J100J	CHIP R 10 J 1/16W	
R888			RK73HB1J473J	CHIP R 47K J 1/16W	
R890			RK73HB1J153J	CHIP R 15K J 1/16W	
R891			RK73HB1J473J	CHIP R 47K J 1/16W	
R892,893			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R894			RK73HB1J104J	CHIP R 100K J 1/16W	
R895			RK73HB1J394J	CHIP R 390K J 1/16W	
R896			RK73HB1J104J	CHIP R 100K J 1/16W	
R897			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R898			RK73HB1J273J	CHIP R 27K J 1/16W	
R899			RK73HB1J184J	CHIP R 180K J 1/16W	
R900			RK73HB1J104J	CHIP R 100K J 1/16W	
R902			RK73HB1J103J	CHIP R 10K J 1/16W	
R903			RK73HB1J101J	CHIP R 100 J 1/16W	
R904			RK73HB1J474J	CHIP R 470K J 1/16W	
R905			RK73HB1J272J	CHIP R 2.7K J 1/16W	
R906			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R907			RK73HB1J272J	CHIP R 2.7K J 1/16W	
R908			RK73HB1J104J	CHIP R 100K J 1/16W	
R909			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R910,911			RK73HB1J103J	CHIP R 10K J 1/16W	
R912			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R913			RK73HB1J182J	CHIP R 1.8K J 1/16W	
R914			RK73HB1J471J	CHIP R 470 J 1/16W	
R915			RK73HB1J152J	CHIP R 1.5K J 1/16W	
R916			RK73HB1J123J	CHIP R 12K J 1/16W	
R918			RK73HB1J473J	CHIP R 47K J 1/16W	
R919			RK73HB1J682J	CHIP R 6.8K J 1/16W	
R920			RK73HB1J561J	CHIP R 560 J 1/16W	
R921,922			RK73HB1J473J	CHIP R 47K J 1/16W	
R923			RK73HB1J151J	CHIP R 150 J 1/16W	
R924			RK73HB1J474J	CHIP R 470K J 1/16W	
R925			RK73HB1J334J	CHIP R 330K J 1/16W	
R926			RK73HB1J274J	CHIP R 270K J 1/16W	
R927			RK73HB1J473J	CHIP R 47K J 1/16W	
R928			RK73HB1J273J	CHIP R 27K J 1/16W	
R929			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R930			RK73HB1J101J	CHIP R 100 J 1/16W	
R931			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R932			RK73HB1J103J	CHIP R 10K J 1/16W	
R933			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R934			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R935-937			RK73HB1J103J	CHIP R 10K J 1/16W	
R952			RK73HB1J331J	CHIP R 330 J 1/16W	
R953			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R954,955			RK73HB1J121J	CHIP R 120 J 1/16W	
R956			RK73HB1J471J	CHIP R 470 J 1/16W	
R960,961			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R962			RK73HB1J103J	CHIP R 10K J 1/16W	
R963			RK73HB1J184J	CHIP R 180K J 1/16W	
R964			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R965			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R967			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R968			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R978			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R980			RK73HH1J472D	CHIP R 4.7K D 1/16W	
R981			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R982			RK73HB1J121J	CHIP R 120 J 1/16W	
R986			RK73HB1J471J	CHIP R 470 J 1/16W	
R989			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R991			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R992			RK73HB1J824J	CHIP R 820K J 1/16W	
R993			RK73HH1J472D	CHIP R 4.7K D 1/16W	
S1			S70-0414-05	TACT SWITCH (PTT)	
S2,3			S70-0483-05	TACT SWITCH (SIDE1,2)	
D4			1SV323F	VARIABLE CAPACITANCE DIODE	
D6			1SV323F	VARIABLE CAPACITANCE DIODE	
D8,9			1SV323F	VARIABLE CAPACITANCE DIODE	
D10			1SV325F	VARIABLE CAPACITANCE DIODE	
D12			1SV325F	VARIABLE CAPACITANCE DIODE	
D13			HSC119	DIODE	
D14,15			HVC375B-E	VARIABLE CAPACITANCE DIODE	
D16			HVC350B	VARIABLE CAPACITANCE DIODE	
D17,18			HSC277	DIODE	
D201,202			HVC131	DIODE	
D203,204			RN142S	DIODE	
D301			UDZW5.1(B)	ZENER DIODE	
D401,402			KDS121E-P	DIODE	
D404,405			1SV323F	VARIABLE CAPACITANCE DIODE	
D407,408			1SV323F	VARIABLE CAPACITANCE DIODE	
D803			GN1G	DIODE	
D806			RKZ5.1B2KG	ZENER DIODE	
D807-809			KDR731	DIODE	
D810			MC2850	DIODE	
D817			MA2S111-F	DIODE	
D829-832			1SS388F	DIODE	
IC1			AK1541	MOS-IC	
IC2			BD7542FVM	MOS-IC	
IC3			TC75S51FE(F)	MOS-IC	
IC301			NJM2904RB1-ZB	BI-POLAR IC	

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

PARTS LIST

TX-RX UNIT (X57-7880-20)

Ref. No.	Address	New parts	Parts No.	Description	Destination
IC401			NJM2591V	BI-POLAR IC	
IC402		✻	NJU7108	MOS-IC	
IC801			XC6209B502PR	MOS-IC	
IC802			XC6209B502MR	MOS-IC	
IC803			XC6209B502PR	MOS-IC	
IC804			XC6209B332MR	MOS-IC	
IC805			XC61CN4502MR	MOS-IC	
IC806			XC6209B332MR	MOS-IC	
IC807			XC6120N302N1	MOS-IC	
IC808			NJM2904RB1-ZB	BI-POLAR IC	
IC810		✻	EX25512ATA00A	ROM IC	
IC811			HA1630D03MM	MOS-IC	
IC812		✻	CD686AQ3	MOS-IC	
IC815			TA7368FG	MOS-IC	
IC817			TC75S51FE(F)	MOS-IC	
IC820		✻	F363BEDFEKDLB	MICU	
IC821		✻	NJU6434	MOS-IC	
Q2			2SC5636	TRANSISTOR	
Q3			KTC4075E(Y,GR)	TRANSISTOR	
Q4,5			MCH3914(7)-H	FET	
Q6			SSM6L05FU-F	FET	
Q7			SSM3J05FU-F	FET	
Q8,9			2SC5636	TRANSISTOR	
Q11			SSM3J05FU-F	FET	
Q12			2SK1830F	FET	
Q201			2SC5636	TRANSISTOR	
Q203			2SC5455-A	TRANSISTOR	
Q204			RD01MUS1-T113	FET	
Q205			RD07MUS2BT112	FET	
Q301			RT1N140U-T111	TRANSISTOR	
Q303			2SK1830F	FET	
Q304			RT1N141U-T111	TRANSISTOR	
Q305			2SK1824-A	FET	
Q306			RT1P441U-T111	TRANSISTOR	
Q401			RT1N441U-T111	TRANSISTOR	
Q403			KTC4080E-P	TRANSISTOR	
Q404			RT1P441U-T111	TRANSISTOR	
Q405			KTC4080E-P	TRANSISTOR	
Q406			3SK318	FET	
Q407			3SK294-FP	FET	
Q801			UPA672T-A	FET	
Q802,803			SSM6L05FU-F	FET	
Q804			SSM3J05FU-F	FET	
Q805			2SK1830F	FET	
Q806			2SC4919-S	TRANSISTOR	
Q809			KTC4075E(Y,GR)	TRANSISTOR	
Q810			2SC4116(GR)F	TRANSISTOR	
Q811			2SA1586(Y,GR)F	TRANSISTOR	
Q813			RT1N141U-T111	TRANSISTOR	
Q814			2SB1694	TRANSISTOR	
Q815,816			UPA672T-A	FET	
Q817			RT1N441U-T111	TRANSISTOR	
Q818,819			2SK3577-A	FET	
Q820			2SC4617(S)	TRANSISTOR	
Q821			2SB1694	TRANSISTOR	
Q822			RT1N141U-T111	TRANSISTOR	
TH201			ERTJ0EV104J	THERMISTOR	
TH401			NCP18WM224J0S	THERMISTOR	

Ref. No.	Address	New parts	Parts No.	Description	Destination

K1: TK-2312 K M1: TK-2312 M P1: TK-2312 P
M: TK-2317 M

EXPLODED VIEW



Parts with the exploded numbers larger than 700 are not supplied.

PACKING (TK-2312 K, M, P)



Parts with the exploded numbers larger than 700 are not supplied.

PACKING (TK-2317 M)



Parts with the exploded numbers larger than 700 are not supplied.