# 1. CONTRAST OF MISCELLANEOUS PARTS

*NOTES:*
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)*
- *Nos. indicate the pages and Nos. in the service manual for the base model.*
- *When ordering resistors, first convert resistance values into code form as shown in the following examples.*

*Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).*

560Ω → 56 x $10^1$ → 561 ..... RD1/4PU[5][6][1]J
47kΩ → 47 x $10^3$ → 473 ..... RD1/4PU[4][7][3]J
0.5Ω → R50 ..... RN2H[R][5][0]K
1Ω → 1R0 ..... RS1P[1][R][0]K

*Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).*

5.62kΩ → 562 x $10^1$ → 5621 ..... RN1/4PC[5][6][2][1]F

## CONTRAST TABLE

CDJ-2000NXS/UXJCB, CDJ-2000NXS-M/XJCB, CDJ-2000NXS-M/YXJ8, CDJ-2000NXS-M/FLXJ and CDJ-2000NXS-M/AXJ5 are constructed the same except for the following:

| Mark | No. | Symbol and Description | CDJ-2000NXS /UXJCB | CDJ-2000NXS -M/XJCB | CDJ-2000NXS -M/YXJ8 | CDJ-2000NXS -M/FLXJ | CDJ-2000NXS -M/AXJ5 | Remarks |
|---|---|---|---|---|---|---|---|---|
| | | **PCB ASSEMBLIES** | | | | | | |
| NSP | | 1..TFTA ASSY | DWM2458 | DWM2498 | DWM2498 | DWM2498 | DWM2498 | |
| | P75-2 | 2..SDCB ASSY | DWX3333 | DWX3466 | DWX3466 | DWX3466 | DWX3466 | |
| | P81-1 | 2..TFTB ASSY | DWX3331 | DWX3464 | DWX3464 | DWX3464 | DWX3464 | |
| | P81-2 | 2..CDCB ASSY | DWX3332 | DWX3465 | DWX3465 | DWX3465 | DWX3465 | |
| NSP | | 1..JFLA ASSY | DWM2461 | DWM2503 | DWM2503 | DWM2503 | DWM2503 | |
| | P79-2 | 2..JFLB ASSY | DWX3348 | DWX3475 | DWX3475 | DWX3475 | DWX3475 | |
| | | **PACKING SECTION** | | | | | | |
| ⚠ | P73-1 | Power Cable | DDG1108 | DDG1108 | XDG3061 | ADG7076 | ADG7105 | |
| ⚠ | P73-2 | Power Cable | Not used | Not used | Not used | XDG3061 | Not used | |
| | P73-8 | Sub Manual (En) | DRH1207 | DRH1207 | Not used | Not used | Not used | |
| | P73-9 | Sub Manual (En/Fr/De/It/Nl/Es/Pt/Ru) | Not used | Not used | DRH1159 | Not used | Not used | |
| | P73-10 | Sub Manual (En/Es/Zhtw) | Not used | Not used | Not used | DRH1220 | Not used | |
| | P73-11 | Sub Manual (ZHcn, En) | Not used | Not used | Not used | Not used | DRH1208 | |
| NSP | P73-14 | Warranty | Not used | Not used | ARY7158 | Not used | Not used | |
| NSP | P73-15 | Leaflet | DRH1204 | DRH1204 | DRH1204 | DRH1204 | DRH1203 | |
| | P73-17 | Caution Card SB | Not used | Not used | Not used | ARM7064 | Not used | |
| | P73-23 | Packing Case | DHG3154 | DHG3224 | DHG3223 | DHG3226 | DHG3227 | |
| | | Caution Card/M | Not used | DRM1375 | DRM1375 | DRM1375 | DRM1375 | No. 26 |
| | | LABEL (En) | Not used | DRW2575 | DRW2575 | DRW2575 | Not used | No. 27 |
| | | LABEL (Fr) | Not used | DRW2576 | DRW2576 | DRW2575 | Not used | No. 28 |
| | | **EXTERIOR SECTION** | | | | | | |
| ⚠ | P75-8 | AC Inlet/3P | DKP3934 | DKP3934 | Not used | Not used | Not used | |
| ⚠ | P75-8 | AC Inlet/2P | Not used | Not used | DKP3935 | DKP3935 | DKP3935 | |
| | P75-36 | Plate | DNH3026 | DNH3086 | DNH3087 | DNH3086 | DNH3087 | |
| ⚠ | P75-38 | Chassis | DNK6077 | DNK6218 | DNK6217 | DNK6220 | DNK6221 | |
| | P75-39 | Insulator Assy | DXB2057 | DXB2131 | DXB2131 | DXB2131 | DXB2131 | |
| NSP | P75-47 | CCC S&E Label | Not used | Not used | Not used | Not used | DRW2310 | |
| | P75-57 | Screw | PMH40P080FTC | PMH40P080FTC | Not used | Not used | Not used | |
| NSP | | Plate/CDJ | Not used | DAM1090 | DAM1090 | DAM1090 | DAM1090 | No. 58 |
| | | **CONTROL PANEL SECTION** | | | | | | |
| | P77-23 | Button/BSY | DAC2810 | DAC2896 | DAC2896 | DAC2896 | DAC2896 | |
| | P77-25 | Slide Sheet 1C | DAH2404 | DAH2916 | DAH2916 | DAH2916 | DAH2916 | |
| | P77-26 | Panel/TOP | DAH2871 | DAH2919 | DAH2919 | DAH2919 | DAH2919 | |
| | P77-41 | Knob/SLD | DNK5981 | DNK6188 | DNK6188 | DNK6188 | DNK6188 | |

| Mark | No. | Symbol and Description | CDJ-2000NXS /UXJCB | CDJ-2000NXS -M/XJCB | CDJ-2000NXS -M/YXJ8 | CDJ-2000NXS -M/FLXJ | CDJ-2000NXS -M/AXJ5 | Remarks |
|---|---|---|---|---|---|---|---|---|
| | P77-42 | Control Panel | DNK6030 | DNK6189 | DNK6189 | DNK6189 | DNK6189 | |
| | P77-45 | Button Assy/PLY | DXB2126 | DXB2135 | DXB2135 | DXB2135 | DXB2135 | |
| | | **JOG DIAL SECTION** | | | | | | |
| | P79-5 | Plate/JOG | DAH2907 | DAH2915 | DAH2915 | DAH2915 | DAH2915 | |
| | P79-12 | JOG Dial/B | DNK6064 | DNK6135 | DNK6135 | DNK6135 | DNK6135 | |
| | | DS Tape/JOG | Not used | DEH1045 | DEH1045 | DEH1045 | DEH1045 | No. 41 |
| | | **DISPLAY SECTION** | | | | | | |
| | P81-8 | Dial Knob | DAA1246 | DAA1312 | DAA1312 | DAA1312 | DAA1312 | |
| | P81-20 | Control Panel/LCD | DNK6037 | DNK6190 | DNK6190 | DNK6190 | DNK6190 | |

Notes : The numbers in the remarks column correspond to the numbers on the “EXPLODED VIEWS”.
For PCB ASSEMBLIES, Refer to "CONTRAST OF PCB ASSEMBLIES" and "2. PCB CONNECTION DIAGRAM"..

# EXPLODED VIEWS

## PACKING SECTION



## EXTERIOR SECTION




## JOG DIAL SECTION




## CONTRAST OF PCB ASSEMBLIES

### GF SDCB ASSY

Although DWX3333 and DWX3466 are different in part number, there is no difference in the circuit and the component parts.

### IF TFTB ASSY

DWX3331 and DWX3464 are constructed the same except for the following:

| Mark | Symbol and Description | DWX3331 | DWX3464 | Remarks |
|---|---|---|---|---|
| | D4004-D4006, D4024-D4026 LED | SML-512MW(PQ) | NHSW046A-0171 | LED : Green -> White |
| | D4028, D4029, D4034, D4037 LED | SML-512MW(PQ) | NHSW046A-0171 | LED : Green -> White |
| | D4038 LED | SML-512MW(PQ) | NHSW046A-0171 | LED : Green -> White |
| | D4044 LED | NHSW046A-0171 | SML-512MW(PQ) | LED : White -> Green |
| | R4058, R4059, R4093, R4105 | RS1/10SR181J | RS1/10SR222J | |
| | R4107, R4109, R4275, R4276 | RS1/10SR181J | RS1/10SR222J | |
| | R4277, R4288, R4290 | RS1/10SR181J | RS1/10SR222J | |
| | R4412 | RS1/10SR822J | RS1/10SR122J | |
| | R4413 | Not used | RS1/10SR122J | |

The mounting positions of the additional parts are described in the circuit diagram of the parent manual.

### KF JFLB ASSY

DWX3348 and DWX3475 are constructed the same except for the following:

| Mark | Symbol and Description | DWX3348 | DWX3475 | Remarks |
|---|---|---|---|---|
| | Q9203, Q9204 | LTC124EUB | LTC114YUB | |
| | D9203 | RKZ6.8KG(B2) | UDZS6R8(B) | |
| | D9215 | RKZ6.2KG(B2) | UDZS6R2(B) | |
| | D9201, D9202, D9206, D9207 LED | SLI-343U3R(HJKL) | SLR343BC4T(JK) | LED : Red -> Blue |
| | R9216, R9217, R9236, R9237 | RS1/10SR112J | RS1/10SR681J | |

### LF CDCB ASSY

Although DWX3332 and DWX3465 are different in part number, there is no difference in the circuit and the component parts.