EXPLODED VIEW (MECHANISM)

A	M1.7x2.5	: N09-4249-05
B	ϕ2x3.5	: N09-4172-05
C	M1.7x4	: N09-4202-05
D	M2x2	: N38-2020-46
E	ϕ2x6	: N09-4294-05
F	WASHERϕ1.2	: N19-2023-04
G	WASHERϕ1.6	: N19-2058-04
H	WASHERϕ1.6	: N19-2093-04
J	M2x2	: N39-2020-46



KDC-1016/115S

EXPLODED VIEW (UNIT)



Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

*New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KDC-1016/115S					
202	1D	*	A52-0757-02	TOP PLATE	
PA1	3C	*	A64-1938-02	PANEL ASSY	K
PA1	3C	*	A64-1939-02	PANEL ASSY	M1
207	1C		B07-2181-02	ESCUTCHEON	
208	3C	*	B10-3146-03	FRONT GLASS	
-			B46-0100-50	WARRANTY CARD	
-			B58-1344-04	CAUTION CARD	K
-		*	B64-1543-00	INST.MANUAL (ENG,FRE,SPA,POR)	K
-		*	B64-1544-00	INST.MANUAL (ENG,CHI)	M1
-		*	B64-1592-00	INST.MANUAL (ARABIC)	M1
211	1C		D10-3031-04	LEVER	
215	2C	*	E29-1801-03	CONDUCTIVE RUBBER	
⚠ DC1	1C		E30-4783-05	DC CORD	K
⚠ DC2	1C		E30-4784-05	DC CORD	M1
FC1	2C	*	E39-0343-05	FLAT CABLE	
⚠ F1	2D		F52-0006-05	FUSE(MINI BLADE TYPE) (10A)	
⚠ F1	2D		F52-0011-05	FUSE(MINI BLADE TYPE) (10A)	
-		*	H10-4690-12	POLYSTYRENE FOAMED FIXTURE	
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	
-		*	H54-1616-03	ITEM CARTON CASE	K
-		*	H54-1618-03	ITEM CARTON CASE	M1
223	3C	*	J19-4984-02	HOLDER	
224	1C		J21-9491-03	MOUNTING HARDWARE ASSY	
225	1C		J54-0606-04	STAY	
228	3C	*	K24-3548-04	KNOB (SRC)	
229	3C	*	K25-1104-03	KNOB (PRESET1-6)	
230	3C	*	K25-1105-03	KNOB (BAND,UP,CLK,AUTO,RES)	
231	3C	*	K25-1107-03	KNOB (VOL,ATT,DOWN,EJECT)	
234	1C		N99-1632-05	SCREW SET	
A	3D		N30-3004-46	PAN HEAD MACHINE SCREW	
B	3C		N80-2006-46	PAN HEAD TAPTITE SCREW	
C	2C		N82-2006-46	BINDING HEAD TAPTITE SCREW	
D	2C		N83-3005-46	PAN HEAD TAPTITE SCREW	
ME1	1C	*	X92-3690-00	CD MECHANISM ASSY	
SWITCH UNIT (X13-9660-10)					
D1 -12			B30-1565-05	LED(1608,PG)	
CN1			E40-9453-05	SOCKET FOR PIN ASSY (12P)	
R1 -4			RK73EB2B331J	CHIP R 330 J 1/8W	
ELECTRIC UNIT (X25-8420-XX)					
241	2D	*	A33-0621-12	REFLECTOR	
ED1		*	B38-1023-05	LIQUID CRYSTAL	
PL1 ,2			B30-1418-15	LAMP (5.5V 125MA,GR)	
C2			C90-5235-05	ELECTRO 2200UF 16WV	
C3			C90-2926-05	ELECTRO 220UF 16WV	
C4			CK73GB1H103K	CHIP C 0.010UF K	
C5			C90-2594-05	ELECTRO 10UF 10WV	

Ref. No.	Add	New	Parts No.	Description	Destination
C6			CE04CW0J101M	ELECTRO 100UF 6.3WV	
C7			CE04CW1C101M	ELECTRO 100UF 16WV	
C8 ,9			CE04CW1A101M	ELECTRO 100UF 10WV	
C11			CK73FB1H103K	CHIP C 0.010UF K	
C12			CK73GB1H103K	CHIP C 0.010UF K	
C14			C90-2598-05	ELECTRO 3.3UF 25WV	
C15			CK73FB1E683K	CHIP C 0.068UF K	
C16			C90-2602-05	ELECTRO 0.10UF 50WV	
C18			CK73GB1H103K	CHIP C 0.010UF K	
C22			CK73GB1C104K	CHIP C 0.10UF K	
C24			CK73FB1H103K	CHIP C 0.010UF K	
C25			C90-2597-05	ELECTRO 10UF 16WV	
C26			CE04CW1A101M	ELECTRO 100UF 10WV	
C27 -30			C90-5296-05	ELECTRO 0.22UF 50WV	
C31			C90-2935-05	ELECTRO 1.0UF 50WV	
C32			C90-2608-05	ELECTRO 1.0UF 50WV	
C35 ,36			C90-2597-05	ELECTRO 10UF 16WV	
C37 ,38			C90-2610-05	ELECTRO 2.2UF 50WV	
C42			CC73FCH1H151J	CHIP C 150PF J	
C43			CK73FB1E333K	CHIP C 0.033UF K	
C44			CK73FB1H153K	CHIP C 0.015UF K	
C45			CK73FB1C224K	CHIP C 0.22UF K	
C46			CK73FB1C823K	CHIP C 0.082UF K	
C49			C90-2608-05	ELECTRO 1.0UF 50WV	
C50			CE04CW1A470M	ELECTRO 47UF 10WV	
C51			CK73GB1H103K	CHIP C 0.010UF K	
C52			CK73FB1C104K	CHIP C 0.10UF K	
C53			CK73FB1C224K	CHIP C 0.22UF K	
C55			CE04CW1A470M	ELECTRO 47UF 10WV	
C58			CE04CW1A470M	ELECTRO 47UF 10WV	
C59			CK73FB1C104K	CHIP C 0.10UF K	
C60 ,61			CK73FB1H103K	CHIP C 0.010UF K	
C80			CK73FB1H103K	CHIP C 0.010UF K	
C100,101			CC73GCH1H220J	CHIP C 22PF J	
C102,103			CK73FB1H103K	CHIP C 0.010UF K	
CN1			E40-9550-05	FLAT CABLE CONNECTOR (22P)	
⚠ J1	2D		E58-0863-15	RECTANGULAR RECEPTACLE (16P)	
J2	2D		E63-0852-05	PIN JACK (2P)	
J3	2D		E04-0312-05	RF COAXIAL CABLE RECEPTACLE	
J4	2D		E40-9452-05	PIN ASSY (12P)	
L2 ,3			L40-4795-91	SMALL FIXED INDUCTOR(4.7UH,J)	
L7			L40-4795-91	SMALL FIXED INDUCTOR(4.7UH,J)	
L8			L33-1123-05	LINE FILTER COIL	
L9			L40-4795-91	SMALL FIXED INDUCTOR(4.7UH,J)	
⚠ L10	2D	*	L33-1142-05	CHOKE COIL	
X1			L77-2032-05	CRYSTAL RESONATOR (8.0MHZ)	
D	1D		N83-3005-46	PAN HEAD TAPTITE SCREW	
E	1D		N35-3010-46	BINDING HEAD MACHINE SCREW	
F	1D		N80-3008-46	PAN HEAD TAPTITE SCREW	
G	1D		N83-3020-46	PAN HEAD TAPTITE SCREW	
H	2D		N86-2606-46	BINDING HEAD TAPTITE SCREW	
R1			RK73GB1J223J	CHIP R 22K J 1/16W	
R2			RK73GB1J101J	CHIP R 100 J 1/16W	
R3			RK73FB2A103J	CHIP R 10K J 1/10W	

K:KDC-115S M1:KDC-1016

⚠ indicates safety critical components.

PARTS LIST

∗New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-8420-XX)

Ref. No.	Add	New	Parts No.	Description	Destination
R4			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R5			RD14DB2H2R2J	SMALL-RD 2.2 J 1/2W	
R6			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R7			RK73FB2A152J	CHIP R 1.5K J 1/10W	
R8			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R9			RK73FB2A303J	CHIP R 30K J 1/10W	
R11			RK73GB1J103J	CHIP R 10K J 1/16W	
R12			RK73FB2A104J	CHIP R 100K J 1/10W	
R13			RD14DB2H332J	SMALL-RD 3.3K J 1/2W	
R15			RD14BB2C473J	RD 47K J 1/6W	
R16			RK73GB1J473J	CHIP R 47K J 1/16W	
R17			RK73FB2A104J	CHIP R 100K J 1/10W	
R21			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	M1
R22			RK73FB2A473J	CHIP R 47K J 1/10W	
R23			RK73FB2A562J	CHIP R 5.6K J 1/10W	
R24			RK73EB2B472J	CHIP R 4.7K J 1/8W	M1
R25			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	M1
R26			RK73FB2A223J	CHIP R 22K J 1/10W	M1
R27			RK73EB2B472J	CHIP R 4.7K J 1/8W	K
R28			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	
R29			RK73FB2A223J	CHIP R 22K J 1/10W	
R30			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	
R77			RK73GB1J101J	CHIP R 100 J 1/16W	
R79			RK73EB2B472J	CHIP R 4.7K J 1/8W	
R80			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R81			RK73EB2B472J	CHIP R 4.7K J 1/8W	
R82 ,83			RK73GB1J472J	CHIP R 4.7K J 1/16W	
R84			RK73EB2B472J	CHIP R 4.7K J 1/8W	
R85			RK73GB1J431J	CHIP R 430 J 1/16W	
R86			RK73FB2A751J	CHIP R 750 J 1/10W	
R87			RK73EB2B184J	CHIP R 180K J 1/8W	
R89			RK73FB2A303J	CHIP R 30K J 1/10W	
R97 ,98			RK73EB2B101J	CHIP R 100 J 1/8W	
R99 ,100			RK73GB1J303J	CHIP R 30K J 1/16W	
R101,102			RK73FB2A271J	CHIP R 270 J 1/10W	
R103			RK73GB1J272J	CHIP R 2.7K J 1/16W	
R104			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R105			RD14BB2C472J	RD 4.7K J 1/6W	
R106			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R108-110			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R126			RD14BB2C102J	RD 1.0K J 1/6W	
R127			RK73FB2A223J	CHIP R 22K J 1/10W	
R128			RD14BB2C102J	RD 1.0K J 1/6W	
R129			RK73FB2A223J	CHIP R 22K J 1/10W	
R130			RK73GB1J472J	CHIP R 4.7K J 1/16W	
R160			RD14DB2H2R2J	SMALL-RD 2.2 J 1/2W	
R161			RK73EB2B151J	CHIP R 150 J 1/8W	
R170			RD14BB2C222J	RD 2.2K J 1/6W	
R171			RD14BB2E5R6J	RD 5.6 J 1/4W	
R200			RK73FB2A473J	CHIP R 47K J 1/10W	
R201			RK73GB1J473J	CHIP R 47K J 1/16W	K
R202,203			RK73GB1J473J	CHIP R 47K J 1/16W	M1
R203			RK73GB1J473J	CHIP R 47K J 1/16W	K
R205			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R206			RD14BB2C103J	RD 10K J 1/6W	

Ref. No.	Add	New	Parts No.	Description	Destination
R207			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R209			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R210			RK73GB1J103J	CHIP R 10K J 1/16W	
R211			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R212			RK73GB1J472J	CHIP R 4.7K J 1/16W	
R213			RK73GB1J101J	CHIP R 100 J 1/16W	
R214			RK73GB1J222J	CHIP R 2.2K J 1/16W	
R215,216			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R217			RK73GB1J101J	CHIP R 100 J 1/16W	
R218			RK73GB1J222J	CHIP R 2.2K J 1/16W	
R219-221			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R222			RK73GB1J103J	CHIP R 10K J 1/16W	
R223,224			RK73FB2A222J	CHIP R 2.2K J 1/10W	
R227			RK73GB1J222J	CHIP R 2.2K J 1/16W	
R228			RK73GB1J102J	CHIP R 1.0K J 1/16W	
R229			RK73GB1J103J	CHIP R 10K J 1/16W	
R230			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R231			RK73FB2A103J	CHIP R 10K J 1/10W	
R232			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R233-236			RK73GB1J103J	CHIP R 10K J 1/16W	
R238			RK73FB2A333J	CHIP R 33K J 1/10W	
R243			RK73GB1J104J	CHIP R 100K J 1/16W	
R245			RK73GB1J104J	CHIP R 100K J 1/16W	
R246			RK73GB1J473J	CHIP R 47K J 1/16W	
R247			RK73GB1J101J	CHIP R 100 J 1/16W	
W101,102			R92-2052-05	CHIP R 0 J 1/10W	
W103,104			R92-2053-05	CHIP R 0 J 1/8W	
W105			R92-2052-05	CHIP R 0 J 1/10W	
W107-112			R92-2053-05	CHIP R 0 J 1/8W	
W113			R92-2052-05	CHIP R 0 J 1/10W	
W114-118			R92-2053-05	CHIP R 0 J 1/8W	
W121-129			R92-2053-05	CHIP R 0 J 1/8W	
W130			R92-2052-05	CHIP R 0 J 1/10W	
D1			S2V20ÅñA	DIODE	
D2			AM01Z	DIODE	
D2			ERA15-01	DIODE	
D3			MA4056(N)-M	ZENER DIODE	
D4			MA4091(N)-L	ZENER DIODE	
D5			MA4082(N)-L	ZENER DIODE	
D6			MA4110-L	ZENER DIODE	
D7			MA4068(N)-M	ZENER DIODE	
D8			MA4051(N)-M	ZENER DIODE	
D10 ,11			AM01Z	DIODE	M1
D10 ,11			ERA15-01	DIODE	M1
D12 ,13			AM01Z	DIODE	K
D12 ,13			ERA15-01	DIODE	K
D14 ,15			1SS133	DIODE	
D18 ,19			DAP202K	DIODE	
D18 ,19			KDS181	DIODE	
D18 ,19			MA152WA	DIODE	
D20			MA4051(N)-M	ZENER DIODE	
D23			RD6.8MW	ZENER DIODE	
D31			1SR154-400	DIODE	
D32 ,33			AM01Z	DIODE	

K:KDC-115S M1:KDC-1016

⚠ indicates safety critical components.

PARTS LIST

∗New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
D32 ,33			ERA15-01	DIODE	
D34			1SR154-400	DIODE	
D35			AM01Z	DIODE	
D35			ERA15-01	DIODE	
D36			1SR154-400	DIODE	
D37			AM01Z	DIODE	
D37			ERA15-01	DIODE	
D38			1SR154-400	DIODE	
D100-104			1SS133	DIODE	
IC1		∗	M38258MCD067FP	MI-COM IC	
IC2			TDA7400D	ANALOGUE IC	
IC4	1D		TDA7386	ANALOGUE IC	
IC5			PST9135NR	ANALOGUE IC	
IC6			HD74HC27FP	MOS-IC	
Q1	2D		2SB1565(E,F)	TRANSISTOR	
Q1	2D		2SB1655(E,F)	TRANSISTOR	
Q2			2SC2412K	TRANSISTOR	
Q2			2SD601A	TRANSISTOR	
Q3			DTA124EK	DIGITAL TRANSISTOR	
Q3			KRA103S	TRANSISTOR	
Q3			UN2112	DIGITAL TRANSISTOR	
Q4			DTC144EK	DIGITAL TRANSISTOR	
Q4			KRC104S	TRANSISTOR	
Q4			UN2213	DIGITAL TRANSISTOR	
Q6			2SB1184	TRANSISTOR	
Q7			2SC2412K	TRANSISTOR	
Q7			2SD601A	TRANSISTOR	
Q8	2D		2SD2396	TRANSISTOR	
Q9			DTC144EK	DIGITAL TRANSISTOR	
Q9			KRC104S	TRANSISTOR	
Q9			UN2213	DIGITAL TRANSISTOR	
Q10			DTA124EK	DIGITAL TRANSISTOR	
Q10			KRA103S	TRANSISTOR	
Q10			UN2112	DIGITAL TRANSISTOR	
Q11			2SB1184	TRANSISTOR	
Q12 -14			2SC2412K	TRANSISTOR	
Q12 -14			2SD601A	TRANSISTOR	
Q15			2SA1036K	TRANSISTOR	
Q16			2SB1277(Q,R)	TRANSISTOR	M1
Q17			DTC114YK	DIGITAL TRANSISTOR	M1
Q17			UN2214	DIGITAL TRANSISTOR	M1
Q18			2SB1277(Q,R)	TRANSISTOR	
Q19			2SB709A	TRANSISTOR	
Q20			DTA124EK	DIGITAL TRANSISTOR	
Q20			KRA103S	TRANSISTOR	
Q20			UN2112	DIGITAL TRANSISTOR	
Q21			DTC114YK	DIGITAL TRANSISTOR	
Q21			UN2214	DIGITAL TRANSISTOR	
Q23			DTA124EK	DIGITAL TRANSISTOR	
Q23			KRA103S	TRANSISTOR	
Q23			UN2112	DIGITAL TRANSISTOR	
Q24			DTC144EK	DIGITAL TRANSISTOR	
Q24			KRC104S	TRANSISTOR	
Q24			UN2213	DIGITAL TRANSISTOR	
Q25			DTC114YK	DIGITAL TRANSISTOR	

K:KDC-115S M1:KDC-1016

ELECTRIC UNIT (X25-8420-XX)

Ref. No.	Add	New	Parts No.	Description			Destination
Q25			UN2214	DIGITAL TRANSISTOR			
Q28 ,29			DTC143TK	DIGITAL TRANSISTOR			
Q28 ,29			UN2216	DIGITAL TRANSISTOR			
Q30			2SB1277(Q,R)	TRANSISTOR			
Q31			DTC124EK	DIGITAL TRANSISTOR			
Q31			UN2212	DIGITAL TRANSISTOR			
Q32			2SB1277(Q,R)	TRANSISTOR			
Q33			DTC124EK	DIGITAL TRANSISTOR			
Q33			UN2212	DIGITAL TRANSISTOR			
Q40			DTA144EK	DIGITAL TRANSISTOR			
Q40			UN2113	DIGITAL TRANSISTOR			
TH1			PTH9C42BD471Q	POSITIVE RESISTOR			
A1	2D		X86-3160-11	FRONT-END UNIT			
CD PIAYER UNIT (X32-4700-00)							
C1 ,2			CK73FB1A105K	CHIP C	1.0UF	K	
C3			C92-1359-05	CHIP-TAN	10UF	16WV	
C4			C92-0566-05	CHIP-TAN	10UF	6.3WV	
C5			CC73FCH1H330J	CHIP C	33PF	J	
C6			CC73FCH1H030C	CHIP C	3.0PF	C	
C7			CK73FB1C104K	CHIP C	0.10UF	K	
C8			CK73FB1A105K	CHIP C	1.0UF	K	
C9			CC73FCH1H101J	CHIP C	100PF	J	
C10			CK73FB1H472K	CHIP C	4700PF	K	
C11			CK73FB1H682K	CHIP C	6800PF	K	
C12			CK73FB1H222K	CHIP C	2200PF	K	
C13			CK73FB1H273K	CHIP C	0.027UF	K	
C14			CK73FB1H472K	CHIP C	4700PF	K	
C15			CK73FB1E473K	CHIP C	0.047UF	K	
C16			CC73FCH1H101J	CHIP C	100PF	J	
C17			CK73FB1H472K	CHIP C	4700PF	K	
C18			CK73FB1H471K	CHIP C	470PF	K	
C19 ,20			CK73FB1C104K	CHIP C	0.10UF	K	
C21			C92-1359-05	CHIP-TAN	10UF	16WV	
C22			CK73FB1C104K	CHIP C	0.10UF	K	
C23			CK73FB1H102K	CHIP C	1000PF	K	
C24			CK73FB1H223K	CHIP C	0.022UF	K	
C25			CK73FB1H123K	CHIP C	0.012UF	K	
C26			CK73FB1A105K	CHIP C	1.0UF	K	
C28			CK73FB1A105K	CHIP C	1.0UF	K	
C29			CK73FB1C104K	CHIP C	0.10UF	K	
C31 ,32			CK73FB1H103K	CHIP C	0.010UF	K	
C33			CK73FB1C104K	CHIP C	0.10UF	K	
C34			CK73EB1A335K	CHIP C	3.3UF	K	
C35			CK73FB1C104K	CHIP C	0.10UF	K	
C41			CK73EB1C225K	CHIP C	2.2UF	K	
C43			CK73FB1H123K	CHIP C	0.012UF	K	
C44			CK73FB1C104K	CHIP C	0.10UF	K	
C45			CK73FB1H123K	CHIP C	0.012UF	K	
C46			CK73FB1E473K	CHIP C	0.047UF	K	
C51			CK73EB1A335K	CHIP C	3.3UF	K	
C55			CK73FB1C104K	CHIP C	0.10UF	K	
C63			C92-1359-05	CHIP-TAN	10UF	16WV	
C67 ,68			CK73FB1A105K	CHIP C	1.0UF	K	
C71 ,72			CK73FB1H471K	CHIP C	470PF	K	

PARTS LIST

∗New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
C77 ,78			CC73FCH1H680J	CHIP C 68PF J	
C79 ,80			C93-1044-05	CERAMIC 2200PF K	
C85			CK73FB1C104K	CHIP C 0.10U K	
CN1			E40-9536-05	FLAT CABLE CONNECTOR (16P)	
CN2			E40-9339-05	FLAT CABLE CONNECTOR (22P)	
L1			L40-1001-78	SMALL FIXED INDUCTOR(10UH)	
L2			L92-0308-05	FERRITE CORE	
X1			L78-0572-05	RESONATOR (16.93MHZ)	
CP1 -3			R90-1019-05	MULTI-COMP 100 X2	
R1 ,2			RK73FB2A333J	CHIP R 33K J 1/10W	
R3			RK73FB2A823J	CHIP R 82K J 1/10W	
R5			RK73FB2A910J	CHIP R 91 J 1/10W	
R6			RK73FB2A823J	CHIP R 82K J 1/10W	
R8			RK73EB2B4R7J	CHIP R 4.7 J 1/8W	
R9			RK73EB2B100J	CHIP R 10 J 1/8W	
R10 ,11			RK73FB2A682J	CHIP R 6.8K J 1/10W	
R12			RK73FB2A432J	CHIP R 4.3K J 1/10W	
R13			RK73FB2A363J	CHIP R 36K J 1/10W	
R14 ,15			RK73FB2A824J	CHIP R 820K J 1/10W	
R16			RK73FB2A223J	CHIP R 22K J 1/10W	
R17			RK73FB2A363J	CHIP R 36K J 1/10W	
R18			RK73FB2A392J	CHIP R 3.9K J 1/10W	
R19			RK73FB2A273J	CHIP R 27K J 1/10W	
R20			RK73FB2A104J	CHIP R 100K J 1/10W	
R21			RK73FB2A224J	CHIP R 220K J 1/10W	
R22 ,23			RK73FB2A333J	CHIP R 33K J 1/10W	
R31			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R32			RK73FB2A104J	CHIP R 100K J 1/10W	
R34			RK73FB2A683J	CHIP R 68K J 1/10W	
R35			RK73FB2A104J	CHIP R 100K J 1/10W	
R36			RK73FB2A151J	CHIP R 150 J 1/10W	
R37			RK73FB2A471J	CHIP R 470 J 1/10W	
R38			RK73FB2A224J	CHIP R 220K J 1/10W	
R44			RK73FB2A512J	CHIP R 5.1K J 1/10W	
R45			RK73FB2A103J	CHIP R 10K J 1/10W	
R46			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R47			RK73FB2A103J	CHIP R 10K J 1/10W	
R49			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R50			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R52			RK73FB2A104J	CHIP R 100K J 1/10W	
R54			RK73FB2A104J	CHIP R 100K J 1/10W	
R71			RK73FB2A103J	CHIP R 10K J 1/10W	
R72			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R73			RK73FB2A473J	CHIP R 47K J 1/10W	
R74			RK73FB2A103J	CHIP R 10K J 1/10W	
R75			RK73FB2A333J	CHIP R 33K J 1/10W	
R76			RK73FB2A622J	CHIP R 6.2K J 1/10W	
R77			RK73FB2A563J	CHIP R 56K J 1/10W	
R78			RK73FB2A243J	CHIP R 24K J 1/10W	
R79			RK73FB2A242J	CHIP R 2.4K J 1/10W	
R80			RK73FB2A202J	CHIP R 2.0K J 1/10W	
R81			RK73FB2A333J	CHIP R 33K J 1/10W	
R82			RK73FB2A103J	CHIP R 10K J 1/10W	

CD PIAYER UNIT (X32-4700-00)

Ref. No.	Add	New	Parts No.	Description	Destination
R83			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R101,102			RK73FB2A332J	CHIP R 3.3K J 1/10W	
R103,104			RK73FB2A562J	CHIP R 5.6K J 1/10W	
R107,108			RK73FB2A331J	CHIP R 330 J 1/10W	
R117,118			RK73FB2A203J	CHIP R 20K J 1/10W	
R121,122			RK73FB2A203J	CHIP R 20K J 1/10W	
R125,126			RK73FB2A203J	CHIP R 20K J 1/10W	
R202			RK73FB2A102J	CHIP R 1.0K J 1/10W	
R214			RK73FB2A104J	CHIP R 100K J 1/10W	
R216,217			RK73FB2A155J	CHIP R 1.5M J 1/10W	
R218			RK73FB2A473J	CHIP R 47K J 1/10W	
R219			RK73FB2A472J	CHIP R 4.7K J 1/10W	
R220			RK73FB2A103J	CHIP R 10K J 1/10W	
W8			R92-2052-05	CHIP R 0 J 1/10W	
S1 ,2			S68-0838-05	PUSH SWITCH	
S3			S68-0823-05	PUSH SWITCH	
D1 ,2			DAN202U	DIODE	
D3			DA204K	DIODE	
D4			DAN202U	DIODE	
IC1			AN8806SB	ANALOGUE IC	
IC2		∗	MN662774KC3	MOS-IC	
IC4			BA5917AFP	ANALOGUE IC	
IC5			TA78L05F	IC(VOLTAGE REGULATOR/ +5V)	
IC6			NJM4565MD	IC(OP AMP X2)	
Q1			2SB1188	TRANSISTOR	
Q2			DTC124EUA	DIGITAL TRANSISTOR	
Q3 ,4			2SA1362(Y)	TRANSISTOR	
Q5			DTC124EUA	DIGITAL TRANSISTOR	
Q8			DTC124EUA	DIGITAL TRANSISTOR	

CD MECHANISM ASSY (X92-3690-00)

1	2A	∗	A10-4482-01	CHASSIS	
2	1B		A10-4225-33	CHASSIS CALKING ASSY	
3	2B		A11-0915-43	SUB CHASSIS CALKING ASSY	
5	2A		D10-3082-13	ARM	
6	2A		D10-4306-04	ARM ASSY	
7	2A		D10-4305-04	ARM ASSY	
8	3A		D10-3087-44	ARM ASSY	
9	3B		D10-3092-03	SLIDER	
10	3B		D10-3093-04	SLIDER ASSY	
11	2B		D10-3095-04	SLIDER ASSY	
12	2B		D10-3096-04	SLIDER ASSY	
13	1A		D10-3099-24	SLIDER ASSY	
14	1A		D10-3100-04	SLIDER ASSY	
16	1B		D10-4004-04	LEVER ASSY	
17	1B		D10-4006-04	LEVER	
18	1A		D10-4007-04	LEVER	
19	2B		D10-4008-14	LEVER	
20	2A		D10-4009-23	ARM	
21	3A		D10-4010-04	LEVER	
22	3A		D10-4011-34	LEVER ASSY	
23	3A		D10-4013-14	ARM ASSY	
24	3B		D10-4050-04	ARM	
25	3A		D10-4038-23	ARM ASSY	

K:KDC-115S M1:KDC-1016

⚠ indicates safety critical components.

PARTS LIST

∗New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
26	2A		D10-4123-24	LEVER ASSY	
27	3A		D13-1340-13	RACK (GEAR)	
29	3B		D13-1231-04	GEAR	
30	3A		D13-1240-04	GEAR	
31	3B		D13-1233-04	GEAR	
32	3B		D13-1234-14	GEAR ASSY	
33	3A		D13-1238-03	GEAR	
34	3B		D13-1232-04	GEAR	
35	3B		D13-1241-04	GEAR	
36	3A		D13-1242-04	GEAR	
37	1B		D13-1243-04	GEAR	
38	1B		D13-1244-04	GEAR	
39	1B		D13-1245-14	GEAR	
40	2A		D13-1246-04	GEAR	
41	2B		D13-1247-04	GEAR	
43	2B		D13-1249-04	GEAR ASSY	
44	2B		D13-1341-04	GEAR ASSY (LEAD SCREW)	
45	1B		D14-0668-04	ROLLER	
46	2A		D14-0670-04	ROLLER	
47	3B		D14-0674-04	ROLLER	
49	3A		D21-2228-14	SHAFT	
50	1A		D21-2229-04	SHAFT	
51	1A		D23-0925-24	RETAINER	
52	2A		D32-0614-04	STOPPER	
53	1B		D39-0223-05	DAMPER (YELLOW)	
54	2B		D39-0224-05	DAMPER (BLACK)	
55	3B		F09-1246-04	SHEET	
58	3B		F09-1266-14	SHEET	
60	2A		G01-2770-04	EXTENSION SPRING	
61	3A		G01-2771-04	EXTENSION SPRING	
62	3A		G01-2772-24	EXTENSION SPRING	
63	3A		G01-2773-14	EXTENSION SPRING	
64	3A		G01-2774-34	EXTENSION SPRING	
65	1B		G01-2775-04	TORSION COIL SPRING	
66	1B		G01-2776-14	TORSION COIL SPRING	
67	3B		G01-2777-24	TORSION COIL SPRING	
69	2A		G01-2844-04	EXTENSION SPRING	
70	2A		G02-1231-04	FLAT SPRING	
71	2B		G02-1232-24	FLAT SPRING	
72	2A		G02-1241-24	FLAT SPRING	
73	2A		G02-1248-14	FLAT SPRING	
75	2A		J11-0613-13	CLAMPER	
76	3A		J19-4678-13	HOLDER	
77	2B		J19-4679-24	HOLDER	
78	3B		J21-7684-13	MOUNTING HARDWARE	
79	2B		J21-7686-13	MOUNTING HARDWARE	
80	1B		J21-7690-03	MOUNTING HARDWARE	
81	3A		J31-1032-04	COLLAR	
82	3A	∗	J84-0107-05	FLEXIBLE PRINTED WIRING BOARD	
83	1A		J90-0757-22	GUIDE	
A	2A		N09-4249-05	MACHINE SCREW (M1.7X2.5,LOCK)	
B	1B		N09-4172-05	TAPPING SCREW (2X3.5,CTITE)	
C	2B		N09-4202-05	STEPPED SCREW	

CD MECHANISM ASSY (X92-3690-00)

Ref. No.	Add	New	Parts No.	Description	Destination
D	2A		N38-2020-46	PAN HEAD MACHIN SCREW	
E	3A		N09-4294-05	TAPTITE SCREW (BIND P TAPTIT)	
F	3B		N19-2023-04	FLAT WASHER	
G	2A		N19-2058-04	FLAT WASHER	
H	3A		N19-2093-04	FLAT WASHER	
J	2A		N39-2020-46	PAN HEAD MACHIN SCREW	
DM1	3B		T42-0764-04	DC MOTOR ASSY	
DM2	3B		T42-0763-04	DC MOTOR ASSY	
DPU1	2B	∗	T25-0215-05	OPTICAL PICKUP HEAD	

K:KDC-115S M1:KDC-1016