EXPLODED VIEW



Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
XXV-03A					
1	1B	✻	A21-4548-12	DRESSING PANEL	K
1	1B	✻	A21-4549-12	DRESSING PANEL	E1
3	3A	✻	A64-3670-02	PANEL	
4	1A	✻	B07-3153-13	ESCUTCHEON (MAIN FAN)	
5	1B	✻	B07-3154-12	ESCUTCHEON (SIDE FAN L)	
6	1B	✻	B07-3155-12	ESCUTCHEON (SIDE FAN R)	
7	1A	✻	B10-4717-03	FRONT GLASS	
8	1B		B19-2257-03	LIGHTING BOARD	
10	1B	✻	B43-1533-14	BADGE	
-			B46-0100-50	WARRANTY CARD	
-		✻	B46-0672-04	USER CARD (25TH ANNIVERSARY)	K
-		✻	B46-0673-04	USER CARD (25TH ANNIVERSARY)	E1
-		✻	B64-3087-00	INST. MANUAL (ENG,FRE,SPA)	
-		✻	B64-3088-00	INST. MANUAL (GER,DUT,ITA,POR)	E1
-		✻	B64-3088-00	INST. MANUAL (T-CHI)	E1
FC1	3B		E39-0642-05	FLAT CABLE	
13	1B	✻	F01-1795-01	HEAT SINK	
14	1B	✻	F07-1156-02	COVER	K
14	1B	✻	F07-1157-02	COVER	E1
17	1A		F09-1885-15	FAN (60X60X11.5)	
⚠ F1-3	3A		F52-0014-05	FUSE (BLADE TYPE) (25A)	
-			H10-4894-13	POLYSTYRENE FOAMED FIXTURE	
-			H13-2055-04	CARTON BOARD	
-			H25-1199-04	PROTECTION BAG	
-			H25-1200-04	PROTECTION BAG (250X350X0.03)	
-		✻	H54-3497-03	ITEM CARTON CASE	K
-		✻	H54-3498-03	ITEM CARTON CASE	E1
24	1B		K24-4146-03	PUSH KNOB (VR CAP)	
26	1A		N99-1577-15	SCREW SET	
27	1A	✻	N99-1770-15	SCREW & WRENCH KEY SET	
A	2A		N09-6216-05	TAPTITE SCREW (3X12)	
B	3A		N09-6218-05	TAPTITE SCREW (4X8)	
C	1B		N09-6220-05	MACHINE SCREW (2X5)	
D	3A		N15-1040-48	FLAT WASHER	
E	3A		N80-2008-43	PAN HEAD TAPTITE SCREW	
F	3A		N80-3010-43	PAN HEAD TAPTITE SCREW	
G	1A		N82-2006-48	BINDING HEAD TAPTITE SCREW	
H	1A		N84-2606-48	PAN HEAD TAPTITE SCREW	
J	3A		N89-3006-43	BINDING HEAD TAPTITE SCREW	
K	3B		N89-3008-43	BINDING HEAD TAPTITE SCREW	
L	2B		N89-3008-48	BINDING HEAD TAPTITE SCREW	
M	1A		N89-3016-48	BINDING HEAD TAPTITE SCREW	
28	1A		W01-1606-05	ACCESSORY	
PREAMPLIFIER UNIT (X08-4230-10)					
40	2B		B11-1446-04	REFLECTION SHEET	
41	2A		B11-1447-04	OPTICAL DIFFUSER	
42	2B		B19-2258-12	LIGHTING BOARD	
D2			B30-1641-05	LED	
ED1	2B		B38-1150-05	LCD ASSY	

Ref. No.	Add	New	Parts No.	Description	Destination
C1,2			CK73FB1H224K	CHIP C 0.22UF K	
C3			CD04AS1V100M	ELECTRO 10UF 35WV	
C4			CK73GB1H103K	CHIP C 0.010UF K	
C5			CK73GB1H821K	CHIP C 820PF K	
C6,7			CK73GB1H473K	CHIP C 0.047UF K	
C8			CK73FB1H224K	CHIP C 0.22UF K	
C9			CK73GB1H103K	CHIP C 0.010UF K	
C10			CK73FB1H224K	CHIP C 0.22UF K	
C11-13			CK73GB1H103K	CHIP C 0.010UF K	
C14			CD04AS1H010M	ELECTRO 1UF 50WV	
C15			CD04AS1V100M	ELECTRO 10UF 35WV	
C16			CK73GB1H103K	CHIP C 0.010UF K	
C17			CD04AS1V100M	ELECTRO 10UF 35WV	
C18,19			CC73GCH1H221J	CHIP C 220PF J	
C20			CD04AS1V100M	ELECTRO 10UF 35WV	
C21			CC73GCH1H221J	CHIP C 220PF J	
C22,23			CD04AS1V100M	ELECTRO 10UF 35WV	
C24			CK73GB1H103K	CHIP C 0.010UF K	
C25			CD04AS1V100M	ELECTRO 10UF 35WV	
C26			CK73GB1H683K	CHIP C 0.068UF K	
C27			CC73GCH1H220J	CHIP C 22PF J	
C28			CK73FB1E154K	CHIP C 0.15UF K	
C29,30			CK73GB1H103K	CHIP C 0.010UF K	
C31			CK73GB1H223K	CHIP C 0.022UF K	
C32			CD04AS1V100M	ELECTRO 10UF 35WV	
C33			CK73GB1H103K	CHIP C 0.010UF K	
C34			CK73GB1H683K	CHIP C 0.068UF K	
C35			CK73FB1E154K	CHIP C 0.15UF K	
C36			CK73GB1H103K	CHIP C 0.010UF K	
C37			CD04AS1V100M	ELECTRO 10UF 35WV	
C38			CK73GB1H333K	CHIP C 0.033UF K	
C39			CD04AS1C470M	ELECTRO 47UF 16WV	
C40			CD04AS1V100M	ELECTRO 10UF 35WV	
C41-47			CK73GB1H103K	CHIP C 0.010UF K	
C48,49			CD04AS1V100M	ELECTRO 10UF 35WV	
CN1			E41-2178-05	FLAT CABLE CONNECTOR (22P)	
WH1			E39-0655-05	WIRING HARNESS	
R1			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R2			RK73GB2A223J	CHIP R 22K J 1/10W	
R3			RK73GB2A134J	CHIP R 130K J 1/10W	
R4			RK73GB2A623J	CHIP R 62K J 1/10W	
R5-8			RK73GB2A471J	CHIP R 470 J 1/10W	
R10			RK73GB2A683J	CHIP R 68K J 1/10W	
R11,12			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R13,14			RK73GB2A393J	CHIP R 39K J 1/10W	
R16			RK73GB2A563J	CHIP R 56K J 1/10W	
R17			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R18			RD14BB2C391J	RD 390 J 1/6W	
R19			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R20,21			RK73GB2A473J	CHIP R 47K J 1/10W	
R22-24			RK73GB2A101J	CHIP R 100 J 1/10W	
R25			RK73GB2A103J	CHIP R 10K J 1/10W	
R26			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R27			RK73GB2A104J	CHIP R 100K J 1/10W	

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.

PARTS LIST

PREAMPLIFIER UNIT (X08-4230-10)

Ref. No.	Add	New	Parts No.	Description				Destination
R28			RK73GB2A512J	CHIP R	5.1K	J	1/10W	
R29			RK73GB2A471J	CHIP R	470	J	1/10W	
R32			RK73GB2A123J	CHIP R	12K	J	1/10W	
R33			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R34			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R36			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R37			RK73GB2A682J	CHIP R	6.8K	J	1/10W	
R38			RK73GB2A153J	CHIP R	15K	J	1/10W	
R39,40			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R41			RK73GB2A153J	CHIP R	15K	J	1/10W	
R42			RK73GB2A100J	CHIP R	10	J	1/10W	
R43,44			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R45			RK73GB2A103J	CHIP R	10K	J	1/10W	
R46			RK73GB2A473J	CHIP R	47K	J	1/10W	
R47			RK73GB2A153J	CHIP R	15K	J	1/10W	
R48			RK73GB2A123J	CHIP R	12K	J	1/10W	
R49			RK73GB2A153J	CHIP R	15K	J	1/10W	
R50			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R51			RK73GB2A473J	CHIP R	47K	J	1/10W	
R52,53			RK73GB2A103J	CHIP R	10K	J	1/10W	
R54			RK73GB2A473J	CHIP R	47K	J	1/10W	
R55			RK73GB2A103J	CHIP R	10K	J	1/10W	
R56			RK73GB2A431J	CHIP R	430	J	1/10W	
R57			RD14BB2C391J	RD	390	J	1/6W	
R58-60			RK73GB2A103J	CHIP R	10K	J	1/10W	
R61			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R62			RK73GB2A512J	CHIP R	5.1K	J	1/10W	
R63			RK73GB2A562J	CHIP R	5.6K	J	1/10W	
R64			RK73GB2A473J	CHIP R	47K	J	1/10W	
R65			RK73GB2A104J	CHIP R	100K	J	1/10W	
R66			RK73GB2A103J	CHIP R	10K	J	1/10W	
R67			RK73GB2A473J	CHIP R	47K	J	1/10W	
VR1	2A		R31-0241-05	VARIABLE RESISTOR (50K,C)				
VR2	2A		R31-0238-05	VARIABLE RESISTOR (10K,A)				
VR3	2A		R31-0241-05	VARIABLE RESISTOR (50K,C)				
S1	2A		S62-0873-05	SLIDE SWITCH				
S2-4			S70-0922-05	TACT SWITCH				
S5,6	2A		S62-0873-05	SLIDE SWITCH				
S7	2A		S62-0874-05	SLIDE SWITCH				
S8	2A		S62-0873-05	SLIDE SWITCH				
D1			MA3082-M	ZENER DIODE				
IC1			NJM4565MD-ZB	ANALOGUE IC				
IC2			NJM2058M-ZB	ANALOGUE IC				
IC3			NJM4565MD-ZB	ANALOGUE IC				
IC4			E-TDA7409DTR	ANALOGUE IC				
IC5			NJM4565MD-ZB	ANALOGUE IC				
IC6			LC75853NE-E	MOS-IC				

AUDIO UNIT (X09-5930-10)

Ref. No.	Add	New	Parts No.	Description				Destination
D9			B30-1601-05	LED				
C1			C90-5557-05	ELECTRO	10UF		25WV	
C2,3			CK73GB1H103K	CHIP C	0.010UF		K	
C5			CK73GB1H103K	CHIP C	0.010UF		K	
C7			CC73GCH1H100D	CHIP C	10PF		D	
C10			CC73GCH1H330J	CHIP C	33PF		J	
C11			CK73GB1H103K	CHIP C	0.010UF		K	
C12,13			CF92FV1H102J	MF-C	1000PF		J	
C14			CC73GCH1H100D	CHIP C	10PF		D	
C15,16			CD04BJ1H100M	ELECTRO	10UF		50WV	
C17			CK73GB1H103K	CHIP C	0.010UF		K	
C19			CK73GB1H103K	CHIP C	0.010UF		K	
C21			CC73GCH1H470J	CHIP C	47PF		J	
C22			CC73GCH1H330J	CHIP C	33PF		J	
C23			CC73GCH1H101J	CHIP C	100PF		J	
C24			CD04BJ1H100M	ELECTRO	10UF		50WV	
C25,26			CC73GCH1H101J	CHIP C	100PF		J	
C27			CD04BJ1H100M	ELECTRO	10UF		50WV	
C28			CD04BJ1H010M	ELECTRO	1.0UF		50WV	
C30			CK73GB1H103K	CHIP C	0.010UF		K	
C31			CD04BJ1H2R2M	ELECTRO	2.2UF		50WV	
C32			CF92FV1H182J	MF-C	1800PF		J	
C34			CK73GB1H102K	CHIP C	1000PF		K	
C35			CD04BJ1E470M	ELECTRO	47UF		25WV	
C36			CK73GB1H104K	CHIP C	0.10UF		K	
C37			CD04BJ1E470M	ELECTRO	47UF		25WV	
C38			CK73GB1H103K	CHIP C	0.010UF		K	
C39			CC73GCH1H470J	CHIP C	47PF		J	
C40			CF92FV1H392J	MF-C	3900PF		J	
C41			CC45FCH1H390J	CERAMIC	39PF		J	
C42			CK73GB1H103K	CHIP C	0.010UF		K	
C43			CD04BJ1H2R2M	ELECTRO	2.2UF		50WV	
C44			CD04BJ1A101M	ELECTRO	100UF		10WV	
C45			CC45FCH1H390J	CERAMIC	39PF		J	
C46-50			CK73GB1H103K	CHIP C	0.010UF		K	
C52			CK73GB1H104K	CHIP C	0.10UF		K	
C53			CK73GB1H103K	CHIP C	0.010UF		K	
C54			CD04BJ1H100M	ELECTRO	10UF		50WV	
C55,56			CD04BJ1E470M	ELECTRO	47UF		25WV	
C57			CD04BJ1H100M	ELECTRO	10UF		50WV	
C59			CD04BJ1E470M	ELECTRO	47UF		25WV	
C60			CD04BJ1H010M	ELECTRO	1.0UF		50WV	
C61			CK73GB1H103K	CHIP C	0.010UF		K	
C62,63		✻	C90-6752-05	ELECTRO	1500UF		100WV	
C64			CD04BJ1E470M	ELECTRO	47UF		25WV	
C65,66		✻	C90-6752-05	ELECTRO	1500UF		100WV	
C67			CD04BJ1H470M	ELECTRO	47UF		50WV	
C68			CK73GB1H103K	CHIP C	0.010UF		K	
C69-72			CK45FB1H102K	CERAMIC	1000PF		K	
C73,74			CF92FV2A104J	MF-C	0.10UF		J	
C75			CK73GB1H103K	CHIP C	0.010UF		K	
C77			CD04BJ1H100M	ELECTRO	10UF		50WV	
C78,79			CK73GB1H473K	CHIP C	0.047UF		K	
C80,81			CF92FV1H392J	MF-C	3900PF		J	
C82			CD04BJ1E470M	ELECTRO	47UF		25WV	
C83			CK73GB1H682K	CHIP C	6800PF		K	
C84			CK73GB1H103K	CHIP C	0.010UF		K	
C85-87			C91-2267-05	MP-F	10UF		J	
C88			CK73FB1C684K	CHIP C	0.68UF		K	
C89-92			CD04BC1C392M	ELECTRO	3900UF		16WV	
C93			CK73GB1H103K	CHIP C	0.010UF		K	

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.

PARTS LIST

AUDIO UNIT (X09-5930-10)

Ref. No.	Add	New	Parts No.	Description	Destination
C94			CD04BJ1H100M	ELECTRO 10UF 50WV	
C95			CK73GB1H103K	CHIP C 0.010UF K	
C96			CD04BJ1A101M	ELECTRO 100UF 10WV	
C97			CF92FV1H102J	MF-C 1000PF J	
C98			CK73GB1H103K	CHIP C 0.010UF K	
C99			CD04BJ1H100M	ELECTRO 10UF 50WV	
C100			CD04BJ1E470M	ELECTRO 47UF 25WV	
C101			C90-5557-05	ELECTRO 10UF 25WV	
C102			CD04BJ1H100M	ELECTRO 10UF 50WV	
C103			CD04BJ1E470M	ELECTRO 47UF 25WV	
C106			CD04BJ1H100M	ELECTRO 10UF 50WV	
C107			CK73GB1H102K	CHIP C 1000PF K	
C108			CK73GB1H103K	CHIP C 0.010UF K	
C109			CD04BJ1H100M	ELECTRO 10UF 50WV	
C110			CD04BJ1E470M	ELECTRO 47UF 25WV	
C111			CK73GB1H103K	CHIP C 0.010UF K	
C113			CD04BJ1H100M	ELECTRO 10UF 50WV	
C116			CK73GB1H104K	CHIP C 0.10UF K	
C117,118			CC73GCH1H120J	CHIP C 12PF J	
C120			CD04BJ1E221M	ELECTRO 220UF 25WV	
C122			CD04BJ1H100M	ELECTRO 10UF 50WV	
C123			CK73GB1H103K	CHIP C 0.010UF K	
C124			CK73FB1C105K	CHIP C 1.0UF K	
C125,126			CK73FB1H104K	CHIP C 0.10UF K	
C127,128			CC73GCH1H101J	CHIP C 100PF J	
C130			CC73GCH1H101J	CHIP C 100PF J	
C131			CK73FB1H104K	CHIP C 0.10UF K	
C132,133			CK73GB1H103K	CHIP C 0.010UF K	
C134			CK73FB1H104K	CHIP C 0.10UF K	
CN1			E41-0927-05	PIN ASSY (2P)	
CN2			E41-0928-05	PIN ASSY (3P)	
CN3			E41-2202-05	FLAT CABLE CONNECTOR (22P)	
J1	3B		E56-0856-05	CYLINDRICAL RECEPTACLE (13P)	
J2	3B		E56-0853-05	CYLINDRICAL RECEPTACLE (REMOTE)	
J4	3B		E63-0901-05	PIN JACK (4P)	
J5	3A		E70-0838-05	SCREW TERMINAL BOARD (7P)	
53	2B		F20-2205-14	INSULATING SHEET	
⚠ CN4,5	2A		J13-0602-05	FUSE HOLDER	
L1			L41-4795-33	SMALL FIXED INDUCTOR (4.7UH)	
L2			L19-0756-05	TRANSFORMER FOR CONVERTER	
L3			L33-1973-05	CHOKE COIL	
L5			L19-0758-05	TRANSFORMER FOR CONVERTER	
L6			L33-1972-05	CHOKE COIL	
X1			L77-2844-05	CRYSTAL RESONATOR (12.288MHZ)	
F	3A		N80-3010-43	PAN HEAD TAPTITE SCREW	
K	3B		N89-3008-43	BINDING HEAD TAPTITE SCREW	
N	2B		N09-6217-05	TAPTITE SCREW	
R1,2			RK73EB2E271J	CHIP R 270 J 1/4W	
R3			RK73GB2A103J	CHIP R 10K J 1/10W	
R4			RD14BB2C470J	RD 47 J 1/6W	
R5			RK73GB2A101J	CHIP R 100 J 1/10W	
R6			RD14BB2C470J	RD 47 J 1/6W	

Ref. No.	Add	New	Parts No.	Description	Destination
R7			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R10,11			RD14BB2C102J	RD 1.0K J 1/6W	
R13			RK73GB2A103J	CHIP R 10K J 1/10W	
R14			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R15			RN73GH1J103D	CHIP R 10K D 1/16W	
R16,17			RD14BB2C102J	RD 1.0K J 1/6W	
R18			RN73GH1J103D	CHIP R 10K D 1/16W	
R19			RK73GB2A392J	CHIP R 3.9K J 1/10W	
R20			RN73GH1J103D	CHIP R 10K D 1/16W	
R21			RK73GB2A123J	CHIP R 12K J 1/10W	
R22			RK73GB2A203J	CHIP R 20K J 1/10W	
R23			RK73GB2A123J	CHIP R 12K J 1/10W	
R24			RK73GB2A203J	CHIP R 20K J 1/10W	
R25			RN73GH1J103D	CHIP R 10K D 1/16W	
R26			RD14BB2C562J	RD 5.6K J 1/6W	
R27,28			RK73GB2A103J	CHIP R 10K J 1/10W	
R29,30			RK73GB2A273J	CHIP R 27K J 1/10W	
R31-34			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R35			RK73GB2A333J	CHIP R 33K J 1/10W	
R36			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R37			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R38			RK73GB2A103J	CHIP R 10K J 1/10W	
R39			RK73GB2A153J	CHIP R 15K J 1/10W	
R40-43			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R46-48			RK73GB2A101J	CHIP R 100 J 1/10W	
R50			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R51			RD14BB2E151J	RD 150 J 1/4W	
R52			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R59			RD14BB2E151J	RD 150 J 1/4W	
R65			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R66			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R68			RK73GB2A223J	CHIP R 22K J 1/10W	
R70			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R71			RK73GB2A821J	CHIP R 820 J 1/10W	
R72			RK73GB2A103J	CHIP R 10K J 1/10W	
R73			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R76			RD14BB2C751J	RD 750 J 1/6W	
R77			RK73GB2A153J	CHIP R 15K J 1/10W	
R78			RK73GB2A473J	CHIP R 47K J 1/10W	
R79			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R80			RK73GB2A224J	CHIP R 220K J 1/10W	
R82			RK73GB2A103J	CHIP R 10K J 1/10W	
R83			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R84			RK73GB2A511J	CHIP R 510 J 1/10W	
R86			RK73GB2A471J	CHIP R 470 J 1/10W	
R87			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R88			RK73GB2A302J	CHIP R 3.0K J 1/10W	
R89			RK73GB2A684J	CHIP R 680K J 1/10W	
R90			RK73GB2A683J	CHIP R 68K J 1/10W	
R91			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R92,93			RK73GB2A103J	CHIP R 10K J 1/10W	
R94,95			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R96			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R97			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R98			RD14BB2E243J	RD 24K J 1/4W	

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.

PARTS LIST

AUDIO UNIT (X09-5930-10)

Ref. No.	Add	New	Parts No.	Description				Destination
R99			RK73GB2A103J	CHIP R	10K	J	1/10W	
R100			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R102			RK73GB2A473J	CHIP R	47K	J	1/10W	
R103,104			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R105,106			RK73GB2A473J	CHIP R	47K	J	1/10W	
R107			RK73GB2A103J	CHIP R	10K	J	1/10W	
R108			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R109,110			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R111			RK73GB2A111J	CHIP R	110	J	1/10W	
R112			RK73GB2A181J	CHIP R	180	J	1/10W	
R113			RK73GB2A103J	CHIP R	10K	J	1/10W	
R114			RK73GB2A153J	CHIP R	15K	J	1/10W	
R115			RD14NB2E471J	RD	470	J	1/4W	
R116			RD14DB2H751J	SMALL-RD	750	J	1/2W	
R117			RD14NB2E471J	RD	470	J	1/4W	
R118			RD14DB2H751J	SMALL-RD	750	J	1/2W	
R119			RK73GB2A821J	CHIP R	820	J	1/10W	
R120			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R121			RD14NB2E470J	RD	47	J	1/4W	
R122			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R123			RK73GB2A100J	CHIP R	10	J	1/10W	
R124			RD14NB2E271J	RD	270	J	1/4W	
R125			RK73GB2A473J	CHIP R	47K	J	1/10W	
R126,127			RK73EB2E100J	CHIP R	10	J	1/4W	
R128			RK73GB2A103J	CHIP R	10K	J	1/10W	
R129			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R130			RK73GB2A103J	CHIP R	10K	J	1/10W	
R131			RK73EB2E100J	CHIP R	10	J	1/4W	
R132			RD14NB2E331J	RD	330	J	1/4W	
R133			RK73EB2E100J	CHIP R	10	J	1/4W	
R134			RD14NB2E122J	RD	1.2K	J	1/4W	
R135			RK73GB2A103J	CHIP R	10K	J	1/10W	
R136			RD14DB2H152J	SMALL-RD	1.5K	J	1/2W	
R137			RD14DB2H102J	SMALL-RD	1.0K	J	1/2W	
R138,139			RD14NB2E470J	RD	47	J	1/4W	
R142,143			RD14NB2E470J	RD	47	J	1/4W	
R144			RK73GB2A473J	CHIP R	47K	J	1/10W	
R147			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R148-151			RD14NB2E101J	RD	100	J	1/4W	
R152,153			RK73EB2E473J	CHIP R	47K	J	1/4W	
R154,155			RK73GB2A473J	CHIP R	47K	J	1/10W	
R156			RD14BB2C563J	RD	56K	J	1/6W	
R157-160			RK73EB2E100J	CHIP R	10	J	1/4W	
R161,162			R92-0205-05	METAL-PLATE	0.1	K	2W	
R163			RK73GB2A562J	CHIP R	5.6K	J	1/10W	
R164-169			R92-0205-05	METAL-PLATE	0.1	K	2W	
R170,171			RD14DB2H220J	SMALL-RD	22	J	1/2W	
R172,173			R92-0205-05	METAL-PLATE	0.1	K	2W	
R174			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R176,177			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R178			RS14KB3D4R7JP	FL-PROOF RS	4.7	J	2W	
R179			RK73GB2A103J	CHIP R	10K	J	1/10W	
R180			RS14KB3D4R7JP	FL-PROOF RS	4.7	J	2W	
R181			RK73GB2A514J	CHIP R	510K	J	1/10W	
R183			RK73GB2A392J	CHIP R	3.9K	J	1/10W	

Ref. No.	Add	New	Parts No.	Description				Destination
R184			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R185			RK73GB2A302J	CHIP R	3.0K	J	1/10W	
R186,187			RK73GB2A103J	CHIP R	10K	J	1/10W	
R188			RK73GB2A470J	CHIP R	47	J	1/10W	
R189			RK73GB2A103J	CHIP R	10K	J	1/10W	
R190			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R191			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R192			RK73GB2A243J	CHIP R	24K	J	1/10W	
R193			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R194			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R195,196			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R197			RK73GB2A224J	CHIP R	220K	J	1/10W	
R198			RD14BB2C392J	RD	3.9K	J	1/6W	
R199,200			RK73GB2A100J	CHIP R	10	J	1/10W	
R201			RK73GB2A392J	CHIP R	3.9K	J	1/10W	
R202			RK73GB2A103J	CHIP R	10K	J	1/10W	
R203,204			RK73GB2A560J	CHIP R	56	J	1/10W	
R205			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R206			RK73GB2A103J	CHIP R	10K	J	1/10W	
R207,208			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R209			RK73GB2A473J	CHIP R	47K	J	1/10W	
R210			RK73GB2A203J	CHIP R	20K	J	1/10W	
R211			RK73GB2A823J	CHIP R	82K	J	1/10W	
R212			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R213			RK73GB2A123J	CHIP R	12K	J	1/10W	
R214,215			RK73GB2A103J	CHIP R	10K	J	1/10W	
R216			RK73GB2A682J	CHIP R	6.8K	J	1/10W	
R217			RK73GB2A103J	CHIP R	10K	J	1/10W	
R218			RK73GB2A183J	CHIP R	18K	J	1/10W	
R219			RK73GB2A132J	CHIP R	1.3K	J	1/10W	
R220,221			RK73GB2A203J	CHIP R	20K	J	1/10W	
R222			RK73GB2A104J	CHIP R	100K	J	1/10W	
R223			RK73GB2A203J	CHIP R	20K	J	1/10W	
R224			RK73GB2A103J	CHIP R	10K	J	1/10W	
R225			RK73GB2A473J	CHIP R	47K	J	1/10W	
R226,227			RK73GB2A100J	CHIP R	10	J	1/10W	
R228			RK73GB2A153J	CHIP R	15K	J	1/10W	
R229			RK73GB2A271J	CHIP R	270	J	1/10W	
R230			RK73GB2A133J	CHIP R	13K	J	1/10W	
R231			RK73GB2A471J	CHIP R	470	J	1/10W	
R232			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R234,235			RK73GB2A470J	CHIP R	47	J	1/10W	
R236,237			RK73GB2A101J	CHIP R	100	J	1/10W	
R238			RK73GB2A122J	CHIP R	1.2K	J	1/10W	
R240			RK73GB2A104J	CHIP R	100K	J	1/10W	
R241			RK73GB2A512J	CHIP R	5.1K	J	1/10W	
R242			RD14BB2C473J	RD	47K	J	1/6W	
R243			RK73GB2A473J	CHIP R	47K	J	1/10W	
R244			RD14BB2C153J	RD	15K	J	1/6W	
R254,255			RK73GB2A182J	CHIP R	1.8K	J	1/10W	
R256			RK73GB2A103J	CHIP R	10K	J	1/10W	
R257			RD14BB2C104J	RD	100K	J	1/6W	
R258			RD14BB2C153J	RD	15K	J	1/6W	
R260,261			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R262,263			RK73GB2A101J	CHIP R	100	J	1/10W	

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.

PARTS LIST

AUDIO UNIT (X09-5930-10)

Ref. No.	Add	New	Parts No.	Description	Destination
R267,268			RK73GB2A105J	CHIP R 1.0M J 1/10W	
R269			RK73GB2A104J	CHIP R 100K J 1/10W	
R270-272			RK73GB2A103J	CHIP R 10K J 1/10W	
R275,276			RD14BB2C153J	RD 15K J 1/6W	
R282			RK73GB2A163J	CHIP R 16K J 1/10W	
R283-286			RK73GB2A103J	CHIP R 10K J 1/10W	
R287			RK73GB2A182J	CHIP R 1.8K J 1/10W	
R288,289			RK73GB2A104J	CHIP R 100K J 1/10W	
R291			RK73GB2A104J	CHIP R 100K J 1/10W	
R292			RK73GB2A103J	CHIP R 10K J 1/10W	
R293			RK73GB2A333J	CHIP R 33K J 1/10W	
R294			RK73GB2A511J	CHIP R 510 J 1/10W	
R295			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R301			RK73GB2A103J	CHIP R 10K J 1/10W	
R303			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R304			RK73GB2A101J	CHIP R 100 J 1/10W	
R305			RK73GB2A113J	CHIP R 11K J 1/10W	
R306			RK73GB2A103J	CHIP R 10K J 1/10W	
R307			RK73GB2A474J	CHIP R 470K J 1/10W	
R308-311			RK73GB2A103J	CHIP R 10K J 1/10W	
R312,313			RK73GB2A101J	CHIP R 100 J 1/10W	
R319,320			RK73GB2A103J	CHIP R 10K J 1/10W	
R321			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R322			RK73GB2A100J	CHIP R 10 J 1/10W	
W301-310			R92-1252-05	CHIP R 0 OHM J 1/16W	
W311			R92-2053-05	CHIP R 0 OHM J 1/8W	
W312			R92-1252-05	CHIP R 0 OHM J 1/16W	
W313			R92-2053-05	CHIP R 0 OHM J 1/8W	
W314-316			R92-1252-05	CHIP R 0 OHM J 1/16W	
W317-320			R92-2053-05	CHIP R 0 OHM J 1/8W	
W322-328			R92-1252-05	CHIP R 0 OHM J 1/16W	
W329			R92-2053-05	CHIP R 0 OHM J 1/8W	
W330			R92-1252-05	CHIP R 0 OHM J 1/16W	
W331			R92-2053-05	CHIP R 0 OHM J 1/8W	
W332,333			R92-1252-05	CHIP R 0 OHM J 1/16W	
W334			R92-2053-05	CHIP R 0 OHM J 1/8W	
W338,339			R92-2053-05	CHIP R 0 OHM J 1/8W	
W340-342			R92-1252-05	CHIP R 0 OHM J 1/16W	
W343			R92-2053-05	CHIP R 0 OHM J 1/8W	
W344-346			R92-1252-05	CHIP R 0 OHM J 1/16W	
W347,348			R92-2053-05	CHIP R 0 OHM J 1/8W	
W350-352			R92-1252-05	CHIP R 0 OHM J 1/16W	
W353			R92-2053-05	CHIP R 0 OHM J 1/8W	
W354			R92-1252-05	CHIP R 0 OHM J 1/16W	
W356,357			R92-1252-05	CHIP R 0 OHM J 1/16W	
W358			R92-2053-05	CHIP R 0 OHM J 1/8W	
W359			R92-1252-05	CHIP R 0 OHM J 1/16W	
W361			R92-2053-05	CHIP R 0 OHM J 1/8W	
W362-365			R92-1252-05	CHIP R 0 OHM J 1/16W	
W366,367			R92-2053-05	CHIP R 0 OHM J 1/8W	
W368			R92-1252-05	CHIP R 0 OHM J 1/16W	
W369-371			R92-2053-05	CHIP R 0 OHM J 1/8W	
W372-374			R92-1252-05	CHIP R 0 OHM J 1/16W	
W375,376			R92-2053-05	CHIP R 0 OHM J 1/8W	
W377			R92-1252-05	CHIP R 0 OHM J 1/16W	
W378			R92-2053-05	CHIP R 0 OHM J 1/8W	
W379,380			R92-1252-05	CHIP R 0 OHM J 1/16W	
W381,382			R92-2053-05	CHIP R 0 OHM J 1/8W	
W383			R92-1252-05	CHIP R 0 OHM J 1/16W	
W384-386			R92-2053-05	CHIP R 0 OHM J 1/8W	
W387			R92-1252-05	CHIP R 0 OHM J 1/16W	
W388			R92-2053-05	CHIP R 0 OHM J 1/8W	
W389,390			R92-1252-05	CHIP R 0 OHM J 1/16W	
W391			R92-2053-05	CHIP R 0 OHM J 1/8W	
W392-398			R92-1252-05	CHIP R 0 OHM J 1/16W	
W399			R92-2053-05	CHIP R 0 OHM J 1/8W	
W400-402			R92-1252-05	CHIP R 0 OHM J 1/16W	
W403			R92-2053-05	CHIP R 0 OHM J 1/8W	
W404			R92-1252-05	CHIP R 0 OHM J 1/16W	
W405			R92-2053-05	CHIP R 0 OHM J 1/8W	
W407-409			R92-1252-05	CHIP R 0 OHM J 1/16W	
W410,411			R92-2053-05	CHIP R 0 OHM J 1/8W	
W412-415			R92-1252-05	CHIP R 0 OHM J 1/16W	
W416			R92-2053-05	CHIP R 0 OHM J 1/8W	
W417-419			R92-1252-05	CHIP R 0 OHM J 1/16W	
W420			R92-2053-05	CHIP R 0 OHM J 1/8W	
W421-424			R92-1252-05	CHIP R 0 OHM J 1/16W	
W425			R92-2053-05	CHIP R 0 OHM J 1/8W	
W426,427			R92-1252-05	CHIP R 0 OHM J 1/16W	
W428,429			R92-2053-05	CHIP R 0 OHM J 1/8W	
W430-433			R92-1252-05	CHIP R 0 OHM J 1/16W	
W434			R92-2053-05	CHIP R 0 OHM J 1/8W	
W435-439			R92-1252-05	CHIP R 0 OHM J 1/16W	
W440			R92-2053-05	CHIP R 0 OHM J 1/8W	
W441			R92-1252-05	CHIP R 0 OHM J 1/16W	
W442-445			R92-2053-05	CHIP R 0 OHM J 1/8W	
W446			R92-1252-05	CHIP R 0 OHM J 1/16W	
W448			R92-2053-05	CHIP R 0 OHM J 1/8W	
W450			R92-1252-05	CHIP R 0 OHM J 1/16W	
W451			R92-2053-05	CHIP R 0 OHM J 1/8W	
W452,453			R92-1252-05	CHIP R 0 OHM J 1/16W	
W457			R92-1252-05	CHIP R 0 OHM J 1/16W	
W458-463			R92-2053-05	CHIP R 0 OHM J 1/8W	
W464			R92-1252-05	CHIP R 0 OHM J 1/16W	
W468			R92-1252-05	CHIP R 0 OHM J 1/16W	
W469			R92-2053-05	CHIP R 0 OHM J 1/8W	
S1	3B		S68-0806-05	PUSH SWITCH	
S6			S79-0843-05	DIP SWITCHES	
D1			1SS133	DIODE	
D3			UMZ6.8N	ZENER DIODE	
D4		✻	RD6.2JS-AZ(B2)	ZENER DIODE	
D5			UMZ6.8N	ZENER DIODE	
D8		✻	RD6.2JS-AZ(B2)	ZENER DIODE	
D10,11			1SS355	DIODE	
D12-15			1SS133	DIODE	
D17			UDZS10B	ZENER DIODE	
D18,19			1SS355	DIODE	
D20			UDZS10B	ZENER DIODE	

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.

PARTS LIST

AUDIO UNIT (X09-5930-10)

Ref. No.	Add	New	Parts No.	Description	Destination
D21,22			1SS133	DIODE	
D23			RD5.1JS-AZ(B2)	ZENER DIODE	
D24,25			1SS133	DIODE	
D26			UDZS5.1B	ZENER DIODE	
D27,28			1SS133	DIODE	
D30,31			1SS133	DIODE	
D32			UDZS10B	ZENER DIODE	
D33			UDZS2.7B	ZENER DIODE	
D34			UDZS16B	ZENER DIODE	
D37			RD15JS-AZ(B)	ZENER DIODE	
D38			FCH20A20	DIODE	
D39			FRH20A20	DIODE	
D40-43			1SS133	DIODE	
D44			UDZS5.1B	ZENER DIODE	
D46			UDZS5.1B	ZENER DIODE	
D48			1SS355	DIODE	
D49			UDZS5.1B	ZENER DIODE	
D50			UDZS6.8B	ZENER DIODE	
D51			RD15JS-AZ(B)	ZENER DIODE	
D52,53			1SS355	DIODE	
D54			RM4ZLF-J1NF	DIODE	
D55			1SS355	DIODE	
D56,57			RM4ZLF-J1NF	DIODE	
D58			1SS355	DIODE	
D59			DA204U	DIODE	
D60-62			UMZ6.8N	ZENER DIODE	
D64,65			1SS355	DIODE	
D69			UDZS16B	ZENER DIODE	
D70,71			1SS355	DIODE	
D76			LM1MA142WA-G	DIODE	
D77			LM1MA142WK-G	DIODE	
D80			LM1MA142WK-G	DIODE	
D81			1SS355	DIODE	
D82			UDZS5.1B	ZENER DIODE	
D86			UDZS4.7B	ZENER DIODE	
D89			S5566B-Q	DIODE	
D90			1SS355	DIODE	
D91			DA204U	DIODE	
D92,93		*	RD24ES-AZ(B)	ZENER DIODE	
D94			UMZ6.8N	ZENER DIODE	
IC1,2			BA4560F	ANALOGUE IC	
IC3			NJM319D	ANALOGUE IC	
IC4,5			TC74HC00AF	MOS-IC	
IC6			BA10393F	ANALOGUE IC	
IC7			BA4560F	ANALOGUE IC	
IC10			784224YGC117	MICROCONTROLLER IC	
IC11			PST3436UL-E	MOS-IC	
IC13			UPC494GS	ANALOGUE IC	
IC14			BA4560F	ANALOGUE IC	
IC15			P82B96PN	ANALOGUE IC	
IC16			BA10393F	ANALOGUE IC	
Q1			2SC4081	TRANSISTOR	
Q2			2SA1576A	TRANSISTOR	
Q3			2SC4081	TRANSISTOR	
Q4-6			2SA1576A	TRANSISTOR	

Ref. No.	Add	New	Parts No.	Description	Destination
Q7,8			DTC114EUA	DIGITAL TRANSISTOR	
Q9			DTA114EUA	DIGITAL TRANSISTOR	
Q10			2SC4081	TRANSISTOR	
Q15			2SC3478AA(L,K)	TRANSISTOR	
Q16,17			2SA1576A	TRANSISTOR	
Q18			2SC3478AA(L,K)	TRANSISTOR	
Q19			2SA1352E/F-KEN	TRANSISTOR	
Q20			2SA1576A	TRANSISTOR	
Q21,22			2SA1352E/F-KEN	TRANSISTOR	
Q23			2SD1863	TRANSISTOR	
Q24			2SC4081	TRANSISTOR	
Q25			2SC4467NF	TRANSISTOR	
Q26			2SA1859ANF	TRANSISTOR	
Q27,28			2SA1352E/F-KEN	TRANSISTOR	
Q29			2SC1845-A(F,E)	TRANSISTOR	
Q30			2SA992-A(F,E)	TRANSISTOR	
Q31			2SA1376AA(L,K)	TRANSISTOR	
Q33			2SC3478AA(L,K)	TRANSISTOR	
Q35			DTC114EUA	DIGITAL TRANSISTOR	
Q36			DTA114EUA	DIGITAL TRANSISTOR	
Q37			2SC3478AA(L,K)	TRANSISTOR	
Q38			2SA1286-T11	TRANSISTOR	
Q39			2SC3902	TRANSISTOR	
Q40			2SA1286-T11	TRANSISTOR	
Q41			DTC114EUA	DIGITAL TRANSISTOR	
Q42			2SC3478AA(L,K)	TRANSISTOR	
Q43			2SA1286-T11	TRANSISTOR	
Q44			2SC3902	TRANSISTOR	
Q45			2SA1286-T11	TRANSISTOR	
Q46			DTC114EUA	DIGITAL TRANSISTOR	
Q47			2SD1863	TRANSISTOR	
Q48-51			STW34NB20	FET	
Q52			2SC3478AA(L,K)	TRANSISTOR	
Q53,54			2SA1376AA(L,K)	TRANSISTOR	
Q55			2SC3478AA(L,K)	TRANSISTOR	
Q57,58			2SK3662-F	FET	
Q59			DTC114EUA	DIGITAL TRANSISTOR	
Q60,61			2SK3662-F	FET	
Q62			2SC4081	TRANSISTOR	
Q63			DTA114EUA	DIGITAL TRANSISTOR	
Q64,65			2SK3662-F	FET	
Q66			2SC4081	TRANSISTOR	
Q67-70			2SK3662-F	FET	
Q71			2SC4081	TRANSISTOR	
Q72			2SA1576A	TRANSISTOR	
Q73			2SC4081	TRANSISTOR	
Q74			2SC4097	TRANSISTOR	
Q75,76			2SA1577	TRANSISTOR	
Q77			2SC4097	TRANSISTOR	
Q78			2SC4081	TRANSISTOR	
Q79			DTC114EUA	DIGITAL TRANSISTOR	
Q80			2SB1241	TRANSISTOR	
Q81,82			DTA114EUA	DIGITAL TRANSISTOR	
Q83			2SD1863	TRANSISTOR	
Q84			2SK246(BL)-F	FET	

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.

PARTS LIST

AUDIO UNIT (X09-5930-10)

Ref. No.	Add	New	Parts No.	Description	Destination
Q86			DTC114EUA	DIGITAL TRANSISTOR	
Q88,89			2SC4081	TRANSISTOR	
Q95			DTA114EUA	DIGITAL TRANSISTOR	
Q96			DTC114EUA	DIGITAL TRANSISTOR	
Q97-99			2SC4081	TRANSISTOR	
Q102			DTA114EUA	DIGITAL TRANSISTOR	
Q103,104			2SC945AA(Q,P)	TRANSISTOR	
Q106			2SB1238	TRANSISTOR	
Q107,108			2SC4081	TRANSISTOR	
Q109			DTC114EUA	DIGITAL TRANSISTOR	
Q110			2SA992-A(F,E)	TRANSISTOR	
Q111			DTA114EUA	DIGITAL TRANSISTOR	
TH1			NT732ATTD103J	THERMISTOR	

Ref. No.	Add	New	Parts No.	Description	Destination

E : Europe **K** : North America **M** : Other Areas **W** : Without Europe

⚠ Indicates safety critical components.