PARTS LIST

✻ New Parts. ⚠indicates safety critical components.
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia **K** : USA **P** : Canada
Y : PX (Far East, Hawaii) **T** : England **E** : Europe
Y : AAFES (Europe) **X** : Australia **M** : Other Areas

TK-3302/3302(U)/3306 (Y50-635X-XX)
TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination
TK-3302/3302(U)/3306					
1	1A	✻	A02-4040-03	PLASTIC CABINET ASSY	
2	3A	✻	A10-4124-01	CHASSIS	
4	2C,2E	✻	B09-0725-03	CAP ACCESSORY	
7	1C	✻	B62-2109-00	INSTRUCTION MANUAL	AK,AM
7	1C	✻	B62-2111-00	INSTRUCTION MANUAL	BM,BM3
7	1C,1E	✻	B62-2139-00	INSTRUCTION MANUAL	AP,UK
9	1A		D10-0649-03	LEVER	
10	1A		D21-0863-04	SHAFT	
11	1A		D32-0441-13	STOPPER	
13	2B		E04-0477-05	ANTENNA CONNECTOR (SMA)	
14	3A		E23-1253-04	TERMINAL (BATT-)	
15	2A		E23-1254-04	TERMINAL (BATT+)	
16	2B	✻	E37-1175-15	SP WIRE LEAD (BROWN)	
17	2B	✻	E37-1176-15	SP WIRE LEAD (GREEN)	
19	3A		F20-3353-14	INSULATING SHEET (CHASSIS BATT+)	
21	1A		G01-4542-04	COIL SPRING (LEVER)	
22	1A		G01-4543-14	COIL SPRING (STOPPER)	
23	2A		G10-1330-04	FIBROUS SHEET (AUDIO IC)	
24	2A	✻	G11-4465-04	RUBBER SHEET (FINAL FET)	
25	3B		G13-2009-04	CUSHION (CHASSIS)	
26	3A		G13-2033-04	CUSHION (BATT-)	
27	3A		G13-2034-14	CUSHION (CHASSIS-)	
28	3A		G13-2038-24	CUSHION (CHASSIS-CERAMIC FILTER)	
29	2A		G13-2039-14	CUSHION (PCB-CERAMIC FILTER)	
30	3A		G53-1604-03	PACKING (CHASSIS)	
31	2A		G53-1605-03	PACKING (BATT+)	
32	2A		G53-1609-14	PACKING (ECM)	
33	2B	✻	G53-1799-03	PACKING (VOLUME/SELECTOR)	
34	1B	✻	G53-1800-03	PACKING (SP/MIC)	
35	1B	✻	G53-1801-03	PACKING (SPEAKER)	
36	2B	✻	G53-1802-04	PACKING (SMA)	
38	2E	✻	H12-4250-05	PACKING FIXTURE	AP
39	2D	✻	H12-4251-05	PACKING FIXTURE	AK,UK,BM
39	2D	✻	H12-4251-05	PACKING FIXTURE	BM3,AM
40	1F		H13-2109-03	CARTON BOARD	AP
42	3D	✻	H52-2300-03	ITEM CARTON CASE	AK,UK,BM
42	3D	✻	H52-2300-03	ITEM CARTON CASE	BM3,AM
43	3F	✻	H52-2301-13	ITEM CARTON CASE	AP
46	2A		J19-5463-03	HOLDER (BATT+)	
47	2A		J19-5473-03	HOLDER ASSY (BATT+)	
48	2C,2E	✻	J19-5521-03	HOLDER (SP/MIC) ACCESSORY	
49	2B	✻	J19-5522-03	SPEAKER CLASP	
50	2C,1E		J29-0734-05	BELT HOOK ACCESSORY	
51	2A	✻	J82-0121-05	FPC	
52	1A	✻	J99-0737-04	ADHESIVE SHEET (PTT)	
54	1B	✻	K29-9309-13	KNOB (VOLUME)	
55	1A	✻	K29-9425-03	BUTTON KNOB (PTT)	
56	1A	✻	K29-9426-03	BUTTON KNOB (MON/PF)	
57	1B	✻	K29-9427-03	KNOB (SELECTOR)	
A	3B	✻	N14-0848-05	CIRCULAR NUT (SELECTOR)	
B	3B	✻	N14-0849-05	CIRCULAR NUT (VOLUME)	
C	2B		N30-2604-48	PAN HEAD MACHINE SCREW (SMA)	
D	3A		N30-2606-48	PAN HEAD MACHINE SCREW	
E	2A,3A,2B		N83-2005-48	PAN HEAD TAPTITE SCREW	
61	2C,2E		N99-2046-05	SCREW SET ACCESSORY	
63	2A	✻	R31-0670-15	VARIABLE RESISTOR	
65	2A	✻	S60-0440-05	ROTARY SWITCH	
67	1B		T07-0369-15	SPEAKER	
68	2D,2E		T90-1039-25	WHIP ANTENNA	AK,AP,UK
68	2D		T90-1039-25	WHIP ANTENNA	BM,AM
68	2D		T90-1041-25	WHIP ANTENNA	BM3
70	1F		W08-0970-35	AC ADAPTER (TRANSFORMER)	AP
71	1C		W08-0988-05	CHARGER (KSC-35)	AK,UK,AM
72	1D		W08-0989-15	AC ADAPTER (SWITCHING)	AK,UK
73	1D		W08-0992-05	AC ADAPTER (SWITCHING)	AM
74	1C,2F	✻	W08-1067-05	CHARGER (KSC-31)	AP,BM,BM3
75	1D	✻	W08-1075-05	AC ADAPTER (SWITCHING)	BM,BM3

Ref. No.	Address	New parts	Parts No.	Description	Destination
TX-RX UNIT (X57-7580-XX) -20: AK,AP,UK,AM,BM -23: BM3					
D303		✻	B30-2315-05	LED (RED)	
D304		✻	B30-2314-05	LED (GREEN)	
C1			CK73HB1H332K	CHIP C 3300PF K	
C2			CK73HB1C682K	CHIP C 6800PF K	
C3			CK73GB1A105K	CHIP C 1.0UF K	
C4			CK73HB1A104K	CHIP C 0.10UF K	
C5			CK73HB1H471K	CHIP C 470PF K	
C6			CK73HB1E103K	CHIP C 0.010UF K	AK,AP,UK
C6			CK73HB1E103K	CHIP C 0.010UF K	BM,AM
C6			CK73HB1H471K	CHIP C 470PF K	BM3
C7			CC73HCH1H100D	CHIP C 10PF D	
C8-10			CC73HCH1H101J	CHIP C 100PF J	
C11			CK73FB0J106K	CHIP C 10UF K	AK,AP,UK
C11			CK73FB0J106K	CHIP C 10UF K	BM,AM
C11			CK73FB1H471K	CHIP C 470PF K	BM3
C12			CK73HB1H471K	CHIP C 470PF K	
C13			CC73HCH1H100D	CHIP C 10PF D	
C14			CK73HB1E103K	CHIP C 0.010UF K	BM3
C14,15			CK73HB1E103K	CHIP C 0.010UF K	AK,AP,UK
C14,15			CK73HB1E103K	CHIP C 0.010UF K	BM,AM
C15			CK73HB1H471K	CHIP C 470PF K	BM3
C16			CC73HCH1H470J	CHIP C 47PF J	
C17			CK73HB1E103K	CHIP C 0.010UF K	
C18			CC73HCH1H180J	CHIP C 18PF J	
C21			CK73HB1E103K	CHIP C 0.010UF K	
C22			CK73FB0J106K	CHIP C 10UF K	
C23			CK73HB1E103K	CHIP C 0.010UF K	
C25			CC73HCH1H300J	CHIP C 30PF J	
C26			CC73HCH1H020B	CHIP C 2.0PF B	
C27			CS77AA1VR33M	CHIP TNTL 0.33UF 35WV	
C29			CC73HCH1H270J	CHIP C 27PF J	
C30			CK73HB1H471K	CHIP C 470PF K	

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

PARTS LIST

TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description			Destination
C31			CK73HB1E103K	CHIP C	0.010UF	K	
C32			CS77CA1C3R3M	CHIP TNTL	3.3UF	16WV	
C33			CK73HB1H471K	CHIP C	470PF	K	
C35			CS77CA1V0R1M	CHIP TNTL	0.1UF	35WV	AK,AP,UK
C35			CS77CA1V0R1M	CHIP TNTL	0.1UF	35WV	BM,AM
C35			C92-0863-05	CHIP TNTL	0.047UF	35WV	BM3
C36			CK73HB1H332K	CHIP C	3300PF	K	
C38			CK73HB1H471K	CHIP C	470PF	K	BM3
C39			CK73HB1C682K	CHIP C	6800PF	K	
C40			CC73HCH1H050B	CHIP C	5.0PF	B	
C41			CC73HCH1H030B	CHIP C	3.0PF	B	
C42			CC73HCH1H050B	CHIP C	5.0PF	B	
C43			CC73HCH1H101J	CHIP C	100PF	J	BM3
C44,45			CK73GB1A105K	CHIP C	1.0UF	K	
C47			CC73HCH1H100C	CHIP C	10PF	C	
C50			CK73HB1H471K	CHIP C	470PF	K	AK,AP,UK
C50			CK73HB1H471K	CHIP C	470PF	K	BM,AM
C51			CC73HCH1H030B	CHIP C	3.0PF	B	BM3
C51			CC73HCH1H100D	CHIP C	10PF	D	AK,AP,UK
C51			CC73HCH1H100D	CHIP C	10PF	D	BM,AM
C52			CC73HCH1H090B	CHIP C	9.0PF	B	AK,AP,UK
C52			CC73HCH1H090B	CHIP C	9.0PF	B	BM,AM
C52			CC73HCH1H200J	CHIP C	20PF	J	BM3
C53			CC73HCH1H090B	CHIP C	9.0PF	B	BM3
C53			CC73HCH1H110J	CHIP C	11PF	J	AK,AP,UK
C53			CC73HCH1H110J	CHIP C	11PF	J	BM,AM
C56			CC73HCH1H080B	CHIP C	8.0PF	B	BM3
C56			CC73HCH1H120J	CHIP C	12PF	J	AK,AP,UK
C56			CC73HCH1H120J	CHIP C	12PF	J	BM,AM
C57			CC73HCH1H080B	CHIP C	8.0PF	B	AK,AP,UK
C57			CC73HCH1H080B	CHIP C	8.0PF	B	BM,AM
C57			CC73HCH1H120J	CHIP C	12PF	J	BM3
C58,59			CC73HCH1H010B	CHIP C	1.0PF	B	AK,AP,UK
C58,59			CC73HCH1H010B	CHIP C	1.0PF	B	BM,AM
C58,59			CC73HCH1H1R5B	CHIP C	1.5PF	B	BM3
C60			CC73HCH1H020B	CHIP C	2.0PF	B	AK,AP,UK
C60			CC73HCH1H020B	CHIP C	2.0PF	B	BM,AM
C60			CC73HCH1H040B	CHIP C	4.0PF	B	BM3
C61			CC73HCH1H030B	CHIP C	3.0PF	B	AK,AP,UK
C61			CC73HCH1H030B	CHIP C	3.0PF	B	BM,AM
C61			CC73HCH1H070B	CHIP C	7.0PF	B	BM3
C62			CK73HB1H471K	CHIP C	470PF	K	
C63			CC73HCH1H060B	CHIP C	6.0PF	B	
C64			CC73HCH1H050B	CHIP C	5.0PF	B	AK,AP,UK
C64			CC73HCH1H050B	CHIP C	5.0PF	B	BM,AM
C64			CC73HCH1H3R5B	CHIP C	3.5PF	B	BM3
C65			CC73HCH1H040B	CHIP C	4.0PF	B	BM3
C65			CC73HCH1H060B	CHIP C	6.0PF	B	AK,AP,UK
C65			CC73HCH1H060B	CHIP C	6.0PF	B	BM,AM
C66			CK73HB1H471K	CHIP C	470PF	K	
C67			CC73HCH1H040B	CHIP C	4.0PF	B	BM3
C67			CC73HCH1H050B	CHIP C	5.0PF	B	AK,AP,UK
C67			CC73HCH1H050B	CHIP C	5.0PF	B	BM,AM
C68			CK73HB1H471K	CHIP C	470PF	K	
C69			CK73HB1H471K	CHIP C	470PF	K	AK,AP,UK
C69			CK73HB1H471K	CHIP C	470PF	K	BM,AM
C70			CC73HCH1H0R5B	CHIP C	0.5PF	B	BM3
C70,71			CC73HCH1H0R5B	CHIP C	0.5PF	B	AK,AP,UK
C70,71			CC73HCH1H0R5B	CHIP C	0.5PF	B	BM,AM
C71			CC73HCH1H0R3B	CHIP C	0.3PF	B	BM3

Ref. No.	Address	New parts	Parts No.	Description			Destination
C72,73			CK73HB1A104K	CHIP C	0.10UF	K	
C74,75			CK73HB1H471K	CHIP C	470PF	K	
C76			CS77CP0J100M	CHIP TNTL	10UF	6.3WV	
C77			CK73HB1H471K	CHIP C	470PF	K	
C78			CC73HCH1H300J	CHIP C	30PF	J	BM3
C78			CC73HCH1H330J	CHIP C	33PF	J	AK,AP,UK
C78			CC73HCH1H330J	CHIP C	33PF	J	BM,AM
C79,80			CK73HB1H471K	CHIP C	470PF	K	
C81			CC73HCH1H150J	CHIP C	15PF	J	
C83-85			CK73HB1H471K	CHIP C	470PF	K	
C86			CC73HCH1H100B	CHIP C	10PF	B	
C101,102			CK73HB1H471K	CHIP C	470PF	K	
C103			CC73HCH1H120J	CHIP C	12PF	J	BM3
C103			CC73HCH1H300J	CHIP C	30PF	J	AK,AP,UK
C103			CC73HCH1H300J	CHIP C	30PF	J	BM,AM
C104			CC73HCH1H040B	CHIP C	4.0PF	B	AK,AP,UK
C104			CC73HCH1H040B	CHIP C	4.0PF	B	BM,AM
C104			CC73HCH1H160J	CHIP C	16PF	J	BM3
C106			CK73GB1A105K	CHIP C	1.0UF	K	
C107			CK73HB1H471K	CHIP C	470PF	K	
C108			CK73GB1A105K	CHIP C	1.0UF	K	
C109			CC73HCH1H060B	CHIP C	6.0PF	B	AK,AP,UK
C109			CC73HCH1H060B	CHIP C	6.0PF	B	BM,AM
C109			CC73HCH1H150J	CHIP C	15PF	J	BM3
C111			CK73GB1A105K	CHIP C	1.0UF	K	
C112,113			CK73HB1H471K	CHIP C	470PF	K	
C114			CK73HB1A104K	CHIP C	0.10UF	K	
C115			CC73HCH1H050B	CHIP C	5.0PF	B	BM3
C115			CC73HCH1H110J	CHIP C	11PF	J	AK,AP,UK
C115			CC73HCH1H110J	CHIP C	11PF	J	BM,AM
C117			CC73HCH1H110J	CHIP C	11PF	J	AK,AP,UK
C117			CC73HCH1H110J	CHIP C	11PF	J	BM,AM
C118			CC73HCH1H090B	CHIP C	9.0PF	B	BM3
C120			CK73HB1H471K	CHIP C	470PF	K	
C122			CK73HB0J105K	CHIP C	1.0UF	K	BM3
C123			CC73HCH1H0R5B	CHIP C	0.5PF	B	BM3
C124			CK73HB1H471K	CHIP C	470PF	K	
C125			CC73HCH1H100B	CHIP C	10PF	B	AK,AP,UK
C125			CC73HCH1H100B	CHIP C	10PF	B	BM,AM
C125			CC73HCH1H150J	CHIP C	15PF	J	BM3
C126			CC73HCH1H110J	CHIP C	11PF	J	AK,AP,UK
C126			CC73HCH1H110J	CHIP C	11PF	J	BM,AM
C127			CC73HCH1H160J	CHIP C	16PF	J	AK,AP,UK
C127			CC73HCH1H160J	CHIP C	16PF	J	BM,AM
C127			CC73HCH1H470J	CHIP C	47PF	J	BM3
C128,129			CK73HB1H471K	CHIP C	470PF	K	
C130			CK73GB1A105K	CHIP C	1.0UF	K	
C131			CK73HB1E103K	CHIP C	0.010UF	K	
C133			CK73GB1A105K	CHIP C	1.0UF	K	
C135,136			CK73HB1H471K	CHIP C	470PF	K	
C137			CC73HCH1H101J	CHIP C	100PF	J	
C140			CK73HB1H471K	CHIP C	470PF	K	
C141			CK73HB1A104K	CHIP C	0.10UF	K	
C142			CC73GCH1H390J	CHIP C	39PF	J	BM3
C142			CC73GCH1H430J	CHIP C	43PF	J	AK,AP,UK
C142			CC73GCH1H430J	CHIP C	43PF	J	BM,AM
C144			CK73HB1H471K	CHIP C	470PF	K	
C145			CC73GCH1H360J	CHIP C	36PF	J	BM3
C146			CC73GCH1H120J	CHIP C	12PF	J	AK,AP,UK
C146			CC73GCH1H120J	CHIP C	12PF	J	BM,AM

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

PARTS LIST

TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination
C154			CK73HB1H471K	CHIP C 470PF K	
C155			CC73GCH1H0R3B	CHIP C 0.3PF B	BM3
C161			CC73GCH1H010B	CHIP C 1.0PF B	AK,AP,UK
C161			CC73GCH1H010B	CHIP C 1.0PF B	BM,AM
C161			CC73GCH1H1R5B	CHIP C 1.5PF B	BM3
C162			CC73GCH1H020B	CHIP C 2.0PF B	AK,AP,UK
C162			CC73GCH1H020B	CHIP C 2.0PF B	BM,AM
C164			CC73GCH1H030B	CHIP C 3.0PF B	BM3
C166			CC73GCH1H060B	CHIP C 6.0PF B	AK,AP,UK
C166			CC73GCH1H060B	CHIP C 6.0PF B	BM,AM
C166			CC73GCH1H070B	CHIP C 7.0PF B	BM3
C167			CK73HB1H471K	CHIP C 470PF K	
C168			CC73GCH1H040B	CHIP C 4.0PF B	
C169			CC73GCH1H2R5B	CHIP C 2.5PF B	
C170			CC73GCH1H101J	CHIP C 100PF J	
C172			CC73GCH1H010B	CHIP C 1.0PF B	BM3
C172			CC73GCH1H030B	CHIP C 3.0PF B	AK,AP,UK
C172			CC73GCH1H030B	CHIP C 3.0PF B	BM,AM
C173			CC73GCH1H0R5B	CHIP C 0.5PF B	
C174			CC73GCH1H050B	CHIP C 5.0PF B	AK,AP,UK
C174			CC73GCH1H050B	CHIP C 5.0PF B	BM,AM
C174			CC73GCH1H100C	CHIP C 10PF C	BM3
C175			CC73GCH1H020B	CHIP C 2.0PF B	AK,AP,UK
C175			CC73GCH1H020B	CHIP C 2.0PF B	BM,AM
C176			CC73GCH1H050B	CHIP C 5.0PF B	AK,AP,UK
C176			CC73GCH1H050B	CHIP C 5.0PF B	BM,AM
C176			CC73GCH1H100C	CHIP C 10PF C	BM3
C177			CC73GCH1H0R3B	CHIP C 0.3PF B	BM3
C177			CC73GCH1H020B	CHIP C 2.0PF B	AK,AP,UK
C177			CC73GCH1H020B	CHIP C 2.0PF B	BM,AM
C178			CC73GCH1H030B	CHIP C 3.0PF B	AK,AP,UK
C178			CC73GCH1H030B	CHIP C 3.0PF B	BM,AM
C178			CC73GCH1H060B	CHIP C 6.0PF B	BM3
C201			CK73GB1C224K	CHIP C 0.22UF K	
C202			CK73FB0J106K	CHIP C 10UF K	
C203			CK73HB1E103K	CHIP C 0.010UF K	
C204			CK73HB1H102K	CHIP C 1000PF K	
C205			CK73HB1H182K	CHIP C 1800PF K	
C206,207			CK73HB1H561K	CHIP C 560PF K	
C208			CK73HB1A104K	CHIP C 0.10UF K	
C209			CC73HCH1H680J	CHIP C 68PF J	
C210-213			CK73HB1A104K	CHIP C 0.10UF K	
C214			CC73HCH1H020B	CHIP C 2.0PF B	
C215,216			CK73HB1E103K	CHIP C 0.010UF K	
C219			CC73HCH1H010B	CHIP C 1.0PF B	
C220			CC73HCH1H180J	CHIP C 18PF J	
C222			CK73HB1H471K	CHIP C 470PF K	
C223			CK73HB1E103K	CHIP C 0.010UF K	
C224			CK73HB1A104K	CHIP C 0.10UF K	
C225			CK73HB1E103K	CHIP C 0.010UF K	
C226			CK73HB1H471K	CHIP C 470PF K	
C227			CC73HCH1H180J	CHIP C 18PF J	
C228			CK73HB1H471K	CHIP C 470PF K	
C230			CK73HB1E103K	CHIP C 0.010UF K	
C231			CK73HB1H102K	CHIP C 1000PF K	BM3
C231			CK73HB1H471K	CHIP C 470PF K	AK,AP,UK
C231			CK73HB1H471K	CHIP C 470PF K	BM,AM
C232			CC73HCH1H3R5B	CHIP C 3.5PF B	
C233			CC73HCH1H060B	CHIP C 6.0PF B	
C234			CK73HB1H471K	CHIP C 470PF K	

Ref. No.	Address	New parts	Parts No.	Description	Destination
C235			CC73HCH1HR75B	CHIP C 0.75PF B	BM3
C236			CC73GCH1H040B	CHIP C 4.0PF B	AK,AP,UK
C236			CC73GCH1H040B	CHIP C 4.0PF B	BM,AM
C236			CC73GCH1H070B	CHIP C 7.0PF B	BM3
C237			CC73HCH1H220J	CHIP C 22PF J	AK,AP,UK
C237			CC73HCH1H220J	CHIP C 22PF J	BM,AM
C237			CC73HCH1H270J	CHIP C 27PF J	BM3
C238			CC73HCH1H010B	CHIP C 1.0PF B	
C239			CK73HB1H471K	CHIP C 470PF K	
C240			CC73HCH1H020B	CHIP C 2.0PF B	AK,AP,UK
C240			CC73HCH1H020B	CHIP C 2.0PF B	BM,AM
C240			CC73HCH1H040B	CHIP C 4.0PF B	BM3
C241			CK73FB0J106K	CHIP C 10UF K	
C242			CC73HCH1H060B	CHIP C 6.0PF B	AK,AP,UK
C242			CC73HCH1H060B	CHIP C 6.0PF B	BM,AM
C242			CC73HCH1H080B	CHIP C 8.0PF B	BM3
C243			CK73HB1H471K	CHIP C 470PF K	
C244			CC73HCH1H220J	CHIP C 22PF J	AK,AP,UK
C244			CC73HCH1H220J	CHIP C 22PF J	BM,AM
C244			CC73HCH1H270J	CHIP C 27PF J	BM3
C245			CC73HCH1H010B	CHIP C 1.0PF B	
C246			CK73HB1H471K	CHIP C 470PF K	
C247			CC73HCH1H020B	CHIP C 2.0PF B	AK,AP,UK
C247			CC73HCH1H020B	CHIP C 2.0PF B	BM,AM
C247			CC73HCH1H040B	CHIP C 4.0PF B	BM3
C248			CC73HCH1H220J	CHIP C 22PF J	AK,AP,UK
C248			CC73HCH1H220J	CHIP C 22PF J	BM,AM
C248			CC73HCH1H270J	CHIP C 27PF J	BM3
C249			CC73GCH1H040B	CHIP C 4.0PF B	AK,AP,UK
C249			CC73GCH1H040B	CHIP C 4.0PF B	BM,AM
C249			CC73GCH1H080B	CHIP C 8.0PF B	BM3
C250			CK73HB1H471K	CHIP C 470PF K	
C252-254			CK73HB1H471K	CHIP C 470PF K	
C256			CK73HB1H471K	CHIP C 470PF K	
C257			CC73HCH1H080B	CHIP C 8.0PF B	BM3
C257			CC73HCH1H3R5B	CHIP C 3.5PF B	AK,AP,UK
C257			CC73HCH1H3R5B	CHIP C 3.5PF B	BM,AM
C258			CC73HCH1H220J	CHIP C 22PF J	
C259			CC73HCH1H020B	CHIP C 2.0PF B	AK,AP,UK
C259			CC73HCH1H020B	CHIP C 2.0PF B	BM,AM
C259			CC73HCH1H1R5B	CHIP C 1.5PF B	BM3
C260			CK73HB1H471K	CHIP C 470PF K	
C261			CC73HCH1H020B	CHIP C 2.0PF B	BM3
C261			CC73HCH1H030B	CHIP C 3.0PF B	AK,AP,UK
C261			CC73HCH1H030B	CHIP C 3.0PF B	BM,AM
C262			CC73HCH1H220J	CHIP C 22PF J	
C263			CC73HCH1H010B	CHIP C 1.0PF B	AK,AP,UK
C263			CC73HCH1H010B	CHIP C 1.0PF B	BM,AM
C263			CC73HCH1H060B	CHIP C 6.0PF B	BM3
C264			CC73HCH1H020B	CHIP C 2.0PF B	BM3
C264			CC73HCH1H3R5B	CHIP C 3.5PF B	AK,AP,UK
C264			CC73HCH1H3R5B	CHIP C 3.5PF B	BM,AM
C265			CC73HCH1H030B	CHIP C 3.0PF B	AK,AP,UK
C265			CC73HCH1H030B	CHIP C 3.0PF B	BM,AM
C265			CC73HCH1H050B	CHIP C 5.0PF B	BM3
C266			CC73HCH1H050B	CHIP C 5.0PF B	AK,AP,UK
C266			CC73HCH1H050B	CHIP C 5.0PF B	BM,AM
C266			CC73HCH1H070B	CHIP C 7.0PF B	BM3
C290			CC73HCH1H020B	CHIP C 2.0PF B	
C291			CC73HCH1H060B	CHIP C 6.0PF B	

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

PARTS LIST

TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination
C303			CC73HCH1H101J	CHIP C 100PF J	
C304			CK73HB1A104K	CHIP C 0.10UF K	
C305			CC73HCH1H101J	CHIP C 100PF J	
C306			CK73GB1A105K	CHIP C 1.0UF K	
C307			CC73HCH1H101J	CHIP C 100PF J	
C310			CK73GB1A105K	CHIP C 1.0UF K	
C311			CC73HCH1H101J	CHIP C 100PF J	
C312			CK73HB1H471K	CHIP C 470PF K	
C313			CC73HCH1H101J	CHIP C 100PF J	
C315			CC73HCH1H101J	CHIP C 100PF J	
C316			CK73HB1H471K	CHIP C 470PF K	
C318			CK73HB1E103K	CHIP C 0.010UF K	
C319			CK73HB1H102K	CHIP C 1000PF K	
C320			CC73HCH1H101J	CHIP C 100PF J	
C321			CK73GB1A105K	CHIP C 1.0UF K	
C322			CC73HCH1H101J	CHIP C 100PF J	
C323			CK73GB1A105K	CHIP C 1.0UF K	
C325			CC73HCH1H101J	CHIP C 100PF J	
C327			CK73HB1H471K	CHIP C 470PF K	
C331			CK73HB1A104K	CHIP C 0.10UF K	
C332			CC73HCH1H050B	CHIP C 5.0PF B	
C334			CK73HB1E103K	CHIP C 0.010UF K	
C335			CK73FB0J106K	CHIP C 10UF K	
C337			CC73HCH1H050B	CHIP C 5.0PF B	
C339			CK73GB1A105K	CHIP C 1.0UF K	
C341			CK73HB1H471K	CHIP C 470PF K	
C353,354			CK73HB1E103K	CHIP C 0.010UF K	
C355			CK73HB1E103K	CHIP C 0.010UF K	
C356			CK73HB1H102K	CHIP C 1000PF K	
C358			CK73GB1C224K	CHIP C 0.22UF K	
C359			CK73FB0J106K	CHIP C 10UF K	
C360			CK73HB1A104K	CHIP C 0.10UF K	
C361			CK73GB1A105K	CHIP C 1.0UF K	
C362			CK73HB1H471K	CHIP C 470PF K	
C363			CC73HCH1H820J	CHIP C 82PF J	
C364			CC73HCH1H120J	CHIP C 12PF J	
C365			CC73HCH1H820J	CHIP C 82PF J	
C366			CK73HB1A104K	CHIP C 0.10UF K	
C367			CK73GB1A105K	CHIP C 1.0UF K	
C368			CK73HB1H271K	CHIP C 270PF K	
C369,370			CK73HB1A104K	CHIP C 0.10UF K	
C371			CK73FB0J106K	CHIP C 10UF K	
C372			CK73HB1H471K	CHIP C 470PF K	
C373			CC73HCH1H121J	CHIP C 120PF J	
C374			CK73HB1H102K	CHIP C 1000PF K	
C375,376			CK73HB1H471K	CHIP C 470PF K	
C377			CK73HB1A683K	CHIP C 0.068UF K	
C378			CC73HCH1H820J	CHIP C 82PF J	
C379,380			CK73GB1A105K	CHIP C 1.0UF K	
C381			CK73HB1H391K	CHIP C 390PF K	
C382			CK73HB1C153K	CHIP C 0.015UF K	
C383-385			CK73HB1A104K	CHIP C 0.10UF K	
C386			CK73HB1E103K	CHIP C 0.010UF K	
C388,389			CK73HB1H471K	CHIP C 470PF K	
C390,391			CK73GB1A105K	CHIP C 1.0UF K	
C392			CK73HB1A473K	CHIP C 0.047UF K	
C393			CK73FB0J106K	CHIP C 10UF K	
C395			CC73HCH1H221J	CHIP C 220PF J	
C396			CK73HB1A104K	CHIP C 0.10UF K	
C397			CK73GB1C474K	CHIP C 0.47UF K	

Ref. No.	Address	New parts	Parts No.	Description	Destination
C399			CC73HCH1H101J	CHIP C 100PF J	
C400			CK73FB0J106K	CHIP C 10UF K	
C402			CK73HB1A104K	CHIP C 0.10UF K	
C403			CK73HB1A473J	CHIP C 0.047UF J	
C404			CS77CC0J101M	CHIP TNTL 100UF 6.3WV	
C405			CC73HCH1H221J	CHIP C 220PF J	
C408,409			CK73HB1H471K	CHIP C 470PF K	
C411			CK73HB1H471K	CHIP C 470PF K	AK,AP,UK
C411			CK73HB1H471K	CHIP C 470PF K	BM,AM
C413-415			CK73HB1H471K	CHIP C 470PF K	
TC1,2			C05-0384-05	CERAMIC TRIMMER CAP (10PF)	
CN301			E40-6573-05	FLAT CABLE CONNECTOR	
J301			E11-0703-05	PHONE JACK (2.5/3.5)	
F301			F53-0324-05	FUSE (2.5A)	
101	2A		J30-1282-14	SPACER	
CD201			L79-1866-05	TUNING COIL	
CF201	2A		L72-0973-05	CERAMIC FILTER	
L1			L92-0138-05	CHIP FERRITE	
L2			L40-4791-86	SMALL FIXED INDUCTOR (4.7UH)	
L4			L40-5681-86	SMALL FIXED INDUCTOR (0.56UH)	
L6			L40-5681-86	SMALL FIXED INDUCTOR (0.56UH)	
L7			L92-0138-05	CHIP FERRITE	
L8			L40-1875-71	SMALL FIXED INDUCTOR (18NH)	
L9			L92-0470-05	CHIP FERRITE	
L10,11			L40-1885-92	SMALL FIXED INDUCTOR (180NH)	
L12			L40-1875-71	SMALL FIXED INDUCTOR (18NH)	
L13,14			L40-1885-92	SMALL FIXED INDUCTOR (180NH)	
L15			L40-2778-67	SMALL FIXED INDUCTOR (27NH)	
L16			L40-1878-67	SMALL FIXED INDUCTOR (18NH)	AK,AP,UK
L16			L40-1878-67	SMALL FIXED INDUCTOR (18NH)	BM,AM
L16			L40-2278-67	SMALL FIXED INDUCTOR (22NH)	BM3
L17,18			L41-2785-45	SMALL FIXED INDUCTOR (270NH)	
L19,20			L40-1885-92	SMALL FIXED INDUCTOR (180NH)	
L21			L92-0138-05	CHIP FERRITE	
L22,23			L40-2275-71	SMALL FIXED INDUCTOR (22NH)	
L101			L40-1875-71	SMALL FIXED INDUCTOR (18NH)	
L102			L40-2775-71	SMALL FIXED INDUCTOR (27NH)	BM3
L102			L40-3975-71	SMALL FIXED INDUCTOR (39NH)	AK,AP,UK
L102			L40-3975-71	SMALL FIXED INDUCTOR (39NH)	BM,AM
L103			L40-1575-71	SMALL FIXED INDUCTOR (15NH)	AK,AP,UK
L103			L40-1575-71	SMALL FIXED INDUCTOR (15NH)	BM,AM
L103			L40-1875-71	SMALL FIXED INDUCTOR (18NH)	BM3
L104			L40-8265-71	SMALL FIXED INDUCTOR (8.2NH)	
L105		✻	L41-2278-45	SMALL FIXED INDUCTOR (22NH)	AK,AP,UK
L105		✻	L41-2278-45	SMALL FIXED INDUCTOR (22NH)	BM,AM
L105		✻	L41-4765-45	SMALL FIXED INDUCTOR (4.7NH)	BM3
L106		✻	L92-0472-05	CHIP FERRITE	
L107			L40-2263-92	SMALL FIXED INDUCTOR (2.2NH)	BM3
L107			L40-2763-92	SMALL FIXED INDUCTOR (2.7NH)	AK,AP,UK
L107			L40-2763-92	SMALL FIXED INDUCTOR (2.7NH)	BM,AM
L108			L34-4603-15	AIR-CORE COIL	
L109		✻	L92-0472-05	CHIP FERRITE	
L111			L41-2785-45	SMALL FIXED INDUCTOR (270NH)	
L112			L34-4572-05	AIR-CORE COIL	
L113-115			L34-4564-05	AIR-CORE COIL	
L116			L41-1092-44	SMALL FIXED INDUCTOR (1UH)	
L201			L40-1091-86	SMALL FIXED INDUCTOR (1.0UH)	

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

If a part reference number is listed in a shaded box, that part does not come with the PCB.

PARTS LIST

TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination
L202			L92-0138-05	CHIP FERRITE	
L203			L41-5685-39	SMALL FIXED INDUCTOR (0.56UH)	
L204			L40-1885-92	SMALL FIXED INDUCTOR (180NH)	
L205			L40-2775-71	SMALL FIXED INDUCTOR (27NH)	AK,AP,UK
L205			L40-2775-71	SMALL FIXED INDUCTOR (27NH)	BM,AM
L205			L40-3375-71	SMALL FIXED INDUCTOR (33NH)	BM3
L206,207			L41-8268-14	SMALL FIXED INDUCTOR (8.2NH)	
L208			L92-0138-05	CHIP FERRITE	
L209			L41-8268-14	SMALL FIXED INDUCTOR (8.2NH)	
L210			L41-2785-45	SMALL FIXED INDUCTOR (270NH)	
L212,213			L41-8268-14	SMALL FIXED INDUCTOR (8.2NH)	
L214			L41-4775-45	SMALL FIXED INDUCTOR (47NH)	
L250			L40-1875-71	SMALL FIXED INDUCTOR (18NH)	
L301		✻	L92-0472-05	CHIP FERRITE	
L302-304			L92-0138-05	CHIP FERRITE	
L305			L92-0140-05	CHIP FERRITE	
X1		✻	L77-3042-05	TCXO (12.8MHZ)	
X301		✻	L78-1433-05	RESONATOR (14.746MHZ)	
XF201			L71-0619-05	MCF (38.85MHZ/6.5KH)	
CP1			RK75HA1J101J	CHIP-COM 100 J 1/16W	
CP201			RK75HA1J104J	CHIP-COM 100K J 1/16W	
CP202			RK75HA1J474J	CHIP-COM 470K J 1/16W	
CP203			RK75HA1J104J	CHIP-COM 100K J 1/16W	
CP204			RK75HA1J474J	CHIP-COM 470K J 1/16W	
CP301,302			RK75HA1J473J	CHIP-COM 47K J 1/16W	
CP303,304			RK75HA1J102J	CHIP-COM 1.0K J 1/16W	
R1			RK73HB1J223J	CHIP R 22K J 1/16W	
R2			RK73HB1J103J	CHIP R 10K J 1/16W	
R3			RK73HB1J154J	CHIP R 150K J 1/16W	BM3
R3			RK73HB1J184J	CHIP R 180K J 1/16W	AK,AP,UK
R3			RK73HB1J184J	CHIP R 180K J 1/16W	BM,AM
R4			RK73HB1J563J	CHIP R 56K J 1/16W	
R5			RK73HB1J104J	CHIP R 100K J 1/16W	
R7			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R8			RK73HB1J101J	CHIP R 100 J 1/16W	
R9			RK73HB1J821J	CHIP R 820 J 1/16W	
R10			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R11			RK73HB1J274J	CHIP R 270K J 1/16W	
R12			RK73HB1J221J	CHIP R 220 J 1/16W	
R13			RK73HB1J101J	CHIP R 100 J 1/16W	
R14			RK73HB1J100J	CHIP R 10 J 1/16W	
R15			RK73HB1J561J	CHIP R 560 J 1/16W	
R16			RK73HB1J000J	CHIP R 0.0 J 1/16W	AK,AP,UK
R16			RK73HB1J000J	CHIP R 0.0 J 1/16W	BM,AM
R16			RK73HB1J181J	CHIP R 180 J 1/16W	BM3
R17			RK73HB1J122J	CHIP R 1.2K J 1/16W	BM3
R17			RK73HB1J182J	CHIP R 1.8K J 1/16W	AK,AP,UK
R17			RK73HB1J182J	CHIP R 1.8K J 1/16W	BM,AM
R18			RK73HB1J681J	CHIP R 680 J 1/16W	
R19			RK73HB1J223J	CHIP R 22K J 1/16W	
R20			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R21,22			RK73HB1J103J	CHIP R 10K J 1/16W	
R23			RK73HB1J470J	CHIP R 47 J 1/16W	BM3
R26			RK73HB1J333J	CHIP R 33K J 1/16W	
R27			RK73HB1J684J	CHIP R 680K J 1/16W	
R28			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R29			RK73HB1J154J	CHIP R 150K J 1/16W	
R30			RK73HB1J273J	CHIP R 27K J 1/16W	
R31			RK73HB1J274J	CHIP R 270K J 1/16W	

Ref. No.	Address	New parts	Parts No.	Description	Destination
R32			RK73HB1J394J	CHIP R 390K J 1/16W	BM3
R32			RK73HB1J474J	CHIP R 470K J 1/16W	AK,AP,UK
R32			RK73HB1J474J	CHIP R 470K J 1/16W	BM,AM
R33			RK73HB1J100J	CHIP R 10 J 1/16W	BM3
R33			RK73HB1J101J	CHIP R 100 J 1/16W	AK,AP,UK
R33			RK73HB1J101J	CHIP R 100 J 1/16W	BM,AM
R34			RK73HB1J181J	CHIP R 180 J 1/16W	
R35,36			RK73HB1J101J	CHIP R 100 J 1/16W	
R37			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R38			RK73HB1J154J	CHIP R 150K J 1/16W	
R39			RK73HB1J101J	CHIP R 100 J 1/16W	
R40			RK73HB1J472J	CHIP R 4.7K J 1/16W	AK,AP,UK
R40			RK73HB1J472J	CHIP R 4.7K J 1/16W	BM,AM
R41			RK73HB1J562J	CHIP R 5.6K J 1/16W	
R42			RK73HB1J220J	CHIP R 22 J 1/16W	
R43			RK73HB1J471J	CHIP R 470 J 1/16W	
R45			RK73HB1J562J	CHIP R 5.6K J 1/16W	
R101			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R102			RK73HB1J273J	CHIP R 27K J 1/16W	
R103			RK73HB1J331J	CHIP R 330 J 1/16W	
R104			RK73HB1J390J	CHIP R 39 J 1/16W	BM3
R104			RK73HB1J470J	CHIP R 47 J 1/16W	AK,AP,UK
R104			RK73HB1J470J	CHIP R 47 J 1/16W	BM,AM
R105			RK73HB1J183J	CHIP R 18K J 1/16W	BM3
R105			RK73HB1J273J	CHIP R 27K J 1/16W	BM,AM
R105			RK73HB1J333J	CHIP R 33K J 1/16W	AK,AP,UK
R106			RK73HB1J331J	CHIP R 330 J 1/16W	
R107			RK73HB1J390J	CHIP R 39 J 1/16W	BM3
R107			RK73HB1J560J	CHIP R 56 J 1/16W	AK,AP,UK
R107			RK73HB1J560J	CHIP R 56 J 1/16W	BM,AM
R109			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R111			RK73HB1J393J	CHIP R 39K J 1/16W	AK,AP,UK
R111			RK73HB1J393J	CHIP R 39K J 1/16W	BM,AM
R111			RK73HB1J473J	CHIP R 47K J 1/16W	BM3
R112			RK73HB1J220J	CHIP R 22 J 1/16W	
R113			RK73HB1J104J	CHIP R 100K J 1/16W	
R114			RK73HB1J822J	CHIP R 8.2K J 1/16W	
R116			RK73HB1J331J	CHIP R 330 J 1/16W	AK,AP,UK
R116			RK73HB1J331J	CHIP R 330 J 1/16W	BM,AM
R118			RK73HB1J331J	CHIP R 330 J 1/16W	BM3
R119			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R120			RK73EB2ER39K	CHIP R 0.39 K 1/4W	
R121			RK73HB1J103J	CHIP R 10K J 1/16W	AK,AP,UK
R121			RK73HB1J103J	CHIP R 10K J 1/16W	BM,AM
R121			RK73HB1J153J	CHIP R 15K J 1/16W	BM3
R122			RK73HB1J273J	CHIP R 27K J 1/16W	AK,AP,UK
R122			RK73HB1J273J	CHIP R 27K J 1/16W	BM,AM
R122			RK73HB1J683J	CHIP R 68K J 1/16W	BM3
R123			RK73EB2ER39K	CHIP R 0.39 K 1/4W	
R124			RK73HB1J101J	CHIP R 100 J 1/16W	BM3
R124			RK73HB1J220J	CHIP R 22 J 1/16W	AK,AP,UK
R124			RK73HB1J220J	CHIP R 22 J 1/16W	BM,AM
R125			RK73HB1J683J	CHIP R 68K J 1/16W	
R126			RK73EB2ER39K	CHIP R 0.39 K 1/4W	
R127,128			RK73GH2A154D	CHIP R 150K D 1/10W	
R129,130			RK73GH2A334D	CHIP R 330K D 1/10W	
R131			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R132			RK73HB1J473J	CHIP R 47K J 1/16W	
R133			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R134			RK73HB1J563J	CHIP R 56K J 1/16W	

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

PARTS LIST

TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description				Destination
R135			RK73HB1J104J	CHIP R	100K	J	1/16W	BM3
R135			RK73HB1J184J	CHIP R	180K	J	1/16W	AK,AP,UK
R135			RK73HB1J184J	CHIP R	180K	J	1/16W	BM,AM
R136			RK73HB1J474J	CHIP R	470K	J	1/16W	
R137			RK73FB2B000J	CHIP R	0.0	J	1/8W	
R138			RK73GB2A151J	CHIP R	150	J	1/10W	
R140			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R141			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R201			RK73HB1J184J	CHIP R	180K	J	1/16W	BM3
R201			RK73HB1J823J	CHIP R	82K	J	1/16W	AK,AP,UK
R201			RK73HB1J823J	CHIP R	82K	J	1/16W	BM,AM
R203			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R204			RK73HB1J100J	CHIP R	10	J	1/16W	
R205			RK73HB1J823J	CHIP R	82K	J	1/16W	
R206			RK73HB1J272J	CHIP R	2.7K	J	1/16W	
R207			RK73HB1J332J	CHIP R	3.3K	J	1/16W	
R208			RK73HB1J823J	CHIP R	82K	J	1/16W	
R209			RK73HB1J332J	CHIP R	3.3K	J	1/16W	
R210			RK73HB1J392J	CHIP R	3.9K	J	1/16W	AK,AP,UK
R210			RK73HB1J392J	CHIP R	3.9K	J	1/16W	BM,AM
R210			RK73HB1J472J	CHIP R	4.7K	J	1/16W	BM3
R211			RK73HB1J101J	CHIP R	100	J	1/16W	
R212			RK73HB1J224J	CHIP R	220K	J	1/16W	
R213			RK73HB1J391J	CHIP R	390	J	1/16W	
R214			RK73HB1J331J	CHIP R	330	J	1/16W	
R215			RK73HB1J222J	CHIP R	2.2K	J	1/16W	
R216			RK73HB1J151J	CHIP R	150	J	1/16W	
R217			RK73HB1J332J	CHIP R	3.3K	J	1/16W	
R218			RK73HB1J823J	CHIP R	82K	J	1/16W	BM3
R218,219			RK73HB1J563J	CHIP R	56K	J	1/16W	AK,AP,UK
R218,219			RK73HB1J563J	CHIP R	56K	J	1/16W	BM,AM
R219			RK73HB1J563J	CHIP R	56K	J	1/16W	BM3
R220			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R221			RK73HB1J105J	CHIP R	1.0M	J	1/16W	
R222			RK73HB1J150J	CHIP R	15	J	1/16W	BM3
R222			RK73HB1J220J	CHIP R	22	J	1/16W	AK,AP,UK
R222			RK73HB1J220J	CHIP R	22	J	1/16W	BM,AM
R223			RK73HB1J121J	CHIP R	120	J	1/16W	BM3
R223			RK73HB1J221J	CHIP R	220	J	1/16W	AK,AP,UK
R223			RK73HB1J221J	CHIP R	220	J	1/16W	BM,AM
R225			RK73HB1J683J	CHIP R	68K	J	1/16W	
R226			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R227			RK73FB2B000J	CHIP R	0.0	J	1/8W	
R228			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R301			RK73HH1J474D	CHIP R	470K	D	1/16W	
R302			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R303			RK73HB1J101J	CHIP R	100	J	1/16W	
R304			RK73HB1J334J	CHIP R	330K	J	1/16W	
R305			RK73HH1J474D	CHIP R	470K	D	1/16W	
R306			RK73HB1J184J	CHIP R	180K	J	1/16W	
R307			RK73GB2A271J	CHIP R	270	J	1/10W	
R308			RK73GB2A221J	CHIP R	220	J	1/10W	
R309,310			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R313			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R314,315			RK73HB1J103J	CHIP R	10K	J	1/16W	
R316			RK73HB1J222J	CHIP R	2.2K	J	1/16W	
R317			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R318			RK73HB1J182J	CHIP R	1.8K	J	1/16W	
R319			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R320			RK73HB1J123J	CHIP R	12K	J	1/16W	

Ref. No.	Address	New parts	Parts No.	Description				Destination
R321			RK73HB1J103J	CHIP R	10K	J	1/16W	
R322,323			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R324,325			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R340-342			RK73HB1J103J	CHIP R	10K	J	1/16W	
R344			RK73HB1J474J	CHIP R	470K	J	1/16W	
R345			RK73HB1J273J	CHIP R	27K	J	1/16W	
R347			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R348			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R349			RK73HB1J105J	CHIP R	1.0M	J	1/16W	
R350			RK73HB1J124J	CHIP R	120K	J	1/16W	
R351			RK73HB1J334J	CHIP R	330K	J	1/16W	
R352			RK73HB1J154J	CHIP R	150K	J	1/16W	
R353			RK73HB1J123J	CHIP R	12K	J	1/16W	
R354			RK73HB1J334J	CHIP R	330K	J	1/16W	
R355			RK73HB1J124J	CHIP R	120K	J	1/16W	
R356			RK73HB1J472J	CHIP R	4.7K	J	1/16W	
R357			RK73HB1J563J	CHIP R	56K	J	1/16W	
R358			RK73HB1J474J	CHIP R	470K	J	1/16W	
R359			RK73HB1J473J	CHIP R	47K	J	1/16W	
R360			RK73HB1J562J	CHIP R	5.6K	J	1/16W	
R361			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R362			RK73HB1J184J	CHIP R	180K	J	1/16W	
R363,364			RK73HB1J104J	CHIP R	100K	J	1/16W	
R365			RK73HB1J332J	CHIP R	3.3K	J	1/16W	
R366			RK73HB1J154J	CHIP R	150K	J	1/16W	
R367			RK73HB1J393J	CHIP R	39K	J	1/16W	
R368			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R369			RK73HB1J823J	CHIP R	82K	J	1/16W	
R370			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R371			RK73HB1J272J	CHIP R	2.7K	J	1/16W	
R372			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R373			RK73HB1J224J	CHIP R	220K	J	1/16W	
R374			RK73HB1J153J	CHIP R	15K	J	1/16W	
R375			RK73HB1J182J	CHIP R	1.8K	J	1/16W	
R376			RK73HB1J471J	CHIP R	470	J	1/16W	
R377			RK73HB1J473J	CHIP R	47K	J	1/16W	
R378			RK73HB1J561J	CHIP R	560	J	1/16W	
R379			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R380			RK73HB1J474J	CHIP R	470K	J	1/16W	
R381			RK73HB1J151J	CHIP R	150	J	1/16W	
R383			RK73HB1J563J	CHIP R	56K	J	1/16W	
R384			RK73HB1J333J	CHIP R	33K	J	1/16W	
R385			RK73GB2A101J	CHIP R	100	J	1/10W	
R387			RK73HB1J104J	CHIP R	100K	J	1/16W	
R388			RK73HB1J101J	CHIP R	100	J	1/16W	
R389			RK73HB1J000J	CHIP R	0.0	J	1/16W	
R390			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R391			RK73HB1J102J	CHIP R	1.0K	J	1/16W	
R393			RK73GB2A000J	CHIP R	0.0	J	1/10W	
R394			RK73HB1J473J	CHIP R	47K	J	1/16W	
R398			RK73HB1J000J	CHIP R	0.0	J	1/16W	
VR1			R32-0736-05	SEMI FIXED VARIABLE RESISTOR				
S1-S3			S70-0414-05	TACT SWITCH				
MIC301	2A		T91-0651-15	MIC ELEMENT (ECM)				
D3,4			1SV325F	VARIABLE CAPACITANCE DIODE				
D6			1SV325F	VARIABLE CAPACITANCE DIODE				
D8			1SV325F	VARIABLE CAPACITANCE DIODE				
D9			KDV214E-P	DIODE				

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

PARTS LIST

TX-RX UNIT (X57-7580-XX)

Ref. No.	Address	New parts	Parts No.	Description	Destination
D10			MC2858	DIODE	
D101			UDZW5.1(B)	ZENER DIODE	
D103			HSC277	DIODE	
D104,105			HVC131	DIODE	
D201-205			HVC355B	VARIABLE CAPACITANCE DIODE	
D301			GN1G	DIODE	
D302		✻	HRC0203C	DIODE	
D306		✻	KDR731	DIODE	
D307			MC2850	DIODE	
D308,309		✻	KDR731	DIODE	
IC1			MB15A02PFV2E1	MOS-IC	
IC101		✻	BA2904FVM	MOS-IC	
IC201			TA31136FNG	MOS-IC	
IC301			BD4840FVE	MOS-IC	
IC303			XC6209B502PR	MOS-IC	
IC304		✻	XC6209B502MR	MOS-IC	
IC305			BR24L16F-W	ROM IC	
IC306		✻	R5F212CCKCMB	MICRO CONTROL UNIT	
IC308			AQUA-L	MOS-IC	
IC309			TA7368FG	MOS-IC	
Q1		✻	KTC4075E(Y,GR)	TRANSISTOR	
Q2		✻	2SC4774	TRANSISTOR	
Q3			2SC5636	TRANSISTOR	
Q4,5			2SK1875-F(V)	FET	
Q6		✻	KTC4075E(Y,GR)	TRANSISTOR	
Q7,8			RT1P430U	TRANSISTOR	
Q9			2SC5636	TRANSISTOR	
Q10		✻	KTC4075E(Y,GR)	TRANSISTOR	
Q11			2SC5636	TRANSISTOR	
Q101			2SC5636	TRANSISTOR	
Q102			2SC4926YD	TRANSISTOR	
Q103			RQA0004PXDQS	FET	
Q104			RT1N441U	TRANSISTOR	BM3
Q106			RD07MVS1BT122	FET	
Q107			RT1N441U	TRANSISTOR	
Q108			2SK1824-A	FET	
Q109			RT1P441U	TRANSISTOR	
Q201			RT1P441U	TRANSISTOR	
Q202		✻	2SC4774	TRANSISTOR	
Q203,204			3SK318	FET	
Q301,302			RT1N441U	TRANSISTOR	
Q303			RT1P141U	TRANSISTOR	
Q304		✻	DTB723YE	DIGITAL TRANSISTOR	
Q305,306			2SC4919	TRANSISTOR	
Q307			RT1N441U	TRANSISTOR	
Q308		✻	KTC4075E(Y,GR)	TRANSISTOR	
Q310			2SC4116(GR)F	TRANSISTOR	
Q311			2SA1586(Y,GR)F	TRANSISTOR	
Q312			RT1N441U	TRANSISTOR	
Q313		✻	2SB1694	TRANSISTOR	
Q314			RT1N441U	TRANSISTOR	
Q315,316			2SK3577-A	FET	
TH101			B57331V2104J	THERMISTOR	
TH201			B57331V2104J	THERMISTOR	

Ref. No.	Address	New parts	Parts No.	Description	Destination

AK: TK-3302 K AP: TK-3302 P UK: TK-3302(U) K
AM: TK-3302 M BM: TK-3306 M BM3: TK-3306 M3

EXPLODED VIEW



A		: N14-0848-05
B		: N14-0849-05
C	M2.6 x 4	: N30-2604-48
D	M2.6 x 6	: N30-2606-48
E	M2 x 5	: N83-2005-48

Parts with the exploded numbers larger than 700 are not supplied.
If a part reference number is listed in a box on the exploded view of the PCB, that part does not come with the PCB.
These parts must be ordered separately.

PACKING (K,M TYPE)



Parts with the exploded numbers larger than 700 are not supplied.

PACKING (P TYPE)



Parts with the exploded numbers larger than 700 are not supplied.